


Honeywell



ENRG. SAV. SYSTEM

Chronotherm III

EM. HT. HEAT OFF COOL

ON AUTO

EM. HT. AUX. HEAT

How to operate your new Honeywell *Chronotherm III*

This Owner's Guide will show you how to get the most benefit from your new thermostat.

Your **Chronotherm III** comes to you preprogrammed (see preprogrammed schedule, page 24). If this program does not meet your specific needs, it's an easy matter to "custom" program the thermostat to individual requirements. Turn this page for instructions.



Features

Monitor thermostat operation, read current time and room temperature at a glance.

Check status lights to see if the thermostat is on and saving energy, even in the dark.

Set different schedules for weekdays, Saturday, and Sunday if desired.


Choose manual or automatic thermostat operation.

Program up to four different time periods in each schedule.

Set the temperature warmer or cooler at the touch of a key.

Bypass the stored program for a single period.

Choose system and fan operating modes with the thermostat switches (on subbase).



Check AUX, HT., EM. HT., (on some models). See Glossary page 24.

Simple Four-Step Programming

Of course, you can use the schedule preprogrammed into your new thermostat (see Glossary, page 24). But it's an easy manner to program the thermostat to fit your lifestyle.

1 Set the current time and day. See page 2.

3 Set the cooling temperatures. See page 9.

2 Set the program schedule and heating temperatures. See page 3.

4 Set the system and fan switches. See page 14.

TABLE OF CONTENTS

Programming Your Thermostat	1, 15	Checking the current temperature setting	21
Set the current day and time	2	Maintaining Your Thermostat	22, 23
Set the program schedule and heating temperatures	3	Removing the thermostat	22
Set the cooling temperatures	9	Replacing the thermostat	22
Set the system and fan switches on the subbase	14	Replacing the batteries	23
Operating Your Thermostat	16, 21	Power outages	23
Temporarily changing the program	16	Glossary	24, 25
Permanently changing the program	18	Your Personal Program	26, 27
Operating the thermostat manually	19	Troubleshooting Guide	28, 29
Cancelling program settings	20	Quick Reference to the Keys	30, 31
Checking the program times and temperatures	20	Index	33
		Warranty	

PROGRAMMING YOUR THERMOSTAT

STEP 1 SET THE CURRENT DAY AND TIME

You can program this thermostat either on the wall or in your hand. SEE PAGE 22 TO FIND OUT HOW TO REMOVE THE THERMOSTAT FROM THE WALL.

Always press the keys with your fingertip or similar blunt tool. Sharp instruments like a pen or pencil point can damage the keyboard.

NOTE: Check the glossary, page 24 for definitions of unfamiliar words.




Press and release. The display shows 1:00 PM Mon.



Press and hold until the current day appears in the display.



Press and hold until the current time appears in the display. Be sure AM or PM appears as desired.



You have programmed the current day and time. Go on to Step 2.

2

STEP 2 SET THE PROGRAM SCHEDULE AND HEATING TEMPERATURES

Before You Begin . . .
The schedule form on page 26 provides an opportunity to plan your schedule.

Now . . .
Start by programming the WAKE time and temperature for weekdays.

The thermostat requires a program for WAKE. You can program LEAVE, RETURN, and SLEEP or not, as you please.



Press and release. Note that the displays shows WAKE and the preprogrammed time and temperature.



If you have air conditioning and the display reads COOL, press and release to switch to HEAT.



If display reads SAT or SUN, press and hold until MON TUE WED THU FRI appears.



Press and hold until the display shows the desired starting time.



3

PROGRAMMING YOUR THERMOSTAT

Program the LEAVE time and temperature, if desired.

NOTE: You can cancel the LEAVE, RETURN, or SLEEP program by holding down the period key until the time and temperature disappear from the display.



Press and hold until the display shows the desired temperature.

If the display starts to blink while you are holding down TEMPERATURE WARMER or COOLER, you have reached the setting limit. If your thermostat can switch automatically between heating and cooling, the heating



Press and release. The display shows LEAVE, but no time or temperature.



Press and hold until the display shows the desired starting time.



Press and hold until the display shows the desired temperature.



temperature must be at least 2°C below the air conditioning temperature. For example, if the cooling setting is 24°C, the maximum heating setting is 22°C.



4

Program the RETURN time and temperature, if desired.



Press and release. The display shows RETURN, but no time or temperature.



Press and hold until the display shows the desired starting time.



Press and hold until the display shows the desired temperature.



5

PROGRAMMING YOUR THERMOSTAT

Program the SLEEP time and temperature, if desired.



Press and release. The display shows SLEEP and the preprogrammed time and temperature.



Press and hold until the display shows the desired starting time.



Press and hold until the display shows the desired temperature.



6

Set the SATURDAY schedule. Use the same procedure as for weekdays.



Press and hold until SAT appears on the display.



Press WAKE, LEAVE, RETURN, or SLEEP to select the time period.



Use the AHEAD/BACK keys to set the time and the WARMER/COOLER keys to set the temperature.



7

PROGRAMMING YOUR THERMOSTAT

Set the SUNDAY schedule. Use the same procedure as for weekdays.



Press and hold until SUN appears on the display.



Press WAKE, LEAVE, RETURN, or SLEEP to select the time period.




Use the AHEAD/BACK keys to set the time and the WARMER/COOLER keys to set the temperature.




You have completed setting the program schedule and heating temperatures. To set air conditioning, go to Step 3 (page 9).



NOTE: Some models will show 0°C instead of the current temperature until mounted on the wallplate.



If you do not want to program, cool temperature skip Step 3 and press RUN PROGRAM Key.




STEP 3 SET THE COOLING TEMPERATURES

The program times are the same for both heating and cooling. Only the cooling temperatures need to be programmed if you have already programmed for heating. To set times as you program the cooling temperatures, use the TIME AHEAD and BACK keys as described in Step 2 (page 3). But if you change times for cooling, you are also changing them for heating.

First program the WAKE temperature for weekdays.



Press and release. The display shows WAKE and the time and temperature you programmed for heating.



Press and release so COOL shows on the display, along with the preprogrammed cooling temperature.



If display reads SAT or SUN, press and hold until MON TUE WED THU FRI appears.



PROGRAMMING YOUR THERMOSTAT



Press and hold until the display shows the desired temperature.



If the display blinks while you hold down TEMPERATURE WARMER or COOLER, you have reached the setting limit. If your thermostat can switch automatically between heating and cooling, the cooling temperature must be at least 2°C higher than the corresponding heating temperature. For example, if the heating setting is 21°C, the minimum cooling setting is 23°C.



Program the LEAVE temperature, if desired.



Press and release. The display shows LEAVE, the time programmed for heating, and 26°C.



Press and hold until the display shows the desired temperature.



Program the RETURN temperature, if desired.



Press and release. The display shows RETURN, the time programmed for heating, and 26°C.



Press and hold until the display shows the desired temperature.



PROGRAMMING YOUR THERMOSTAT

Program the SLEEP temperature, if desired.

SLEEP

Press and release.



WARMER

Press and hold until the display shows the desired temperature.

COOLER



Set the cooling temperatures for the SATURDAY schedule. Use the same procedure as for weekdays.

DAY

Press and hold until SAT appears on the display.



WAKE

Press WAKE, LEAVE, RETURN, or SLEEP to select the time period.

LEAVE

SLEEP

RETURN

12

WARMER

Use the WARMER/COOLER keys to set the temperature.

COOLER

Set the cooling temperatures for the SUNDAY schedule. Use the same procedure as for weekdays.

DAY

Press and hold until SUN appears on the display.



WAKE

Press WAKE, LEAVE, RETURN, or SLEEP to select the time period.

LEAVE

SLEEP

RETURN

WARMER

Use the WARMER/COOLER keys to set the temperature.

COOLER

You have completed programming the cooling temperatures.

NOTE: Some models will show 0°C instead of the current temperature until mounted on the wallplate.

RUN PROGRAM

Press and release to start the program.



Go to Step 4, (page 14).

13

PROGRAMMING YOUR THERMOSTAT

STEP 4 SET THE SYSTEM AND FAN SWITCHES ON THE SUBBASE.

Depending on thermostat model, some or all of the switch positions shown may not be available to you. Note the positions provided on your subbase, then set the switch(es) as desired.




First set the fan switch.

Then set the system switch.

FAN ON: The fan runs continuously. Use for improved air circulation during special occasions or for more efficient electronic air cleaning.

FAN AUTO: Normal setting for most homes and businesses. The fan starts and stops with the compressor in heat pump systems when the system switch is set to HEAT, AUTO or COOL. When system switch is set to EM. HT., the fan operates with the auxiliary heat (on some models).

EM. HT: The thermostat controls only backup heat. The heat pump is off.




HEAT: The thermostat controls your heating system

OFF: Both the heating and cooling systems are off.

COOL: The thermostat controls your cooling system.

AUTO (select models only): The thermostat controls either your heating or cooling system, depending on room temperature. You have finished programming your thermostat.



Now, while you enjoy precision temperature control, read on to learn about the operating flexibility that makes this thermostat THE SMART CHOICE.

If you removed it from the wall to program, replace it following the procedure on page 22.

OPERATING YOUR THERMOSTAT

TEMPORARILY CHANGING THE PROGRAM

These features let you custom-tailor the program for those times when someone comes home early, or you're staying up late, or you plan to be out for the evening.

To keep the current temperature through the next program period:

SKIP
NEXT
PERIOD

Press and release. The name of the period to be skipped will flash in the display until the next regularly scheduled period starts.



To go back to the temperature of the previous program period:

CHANGE
TO LAST
PERIOD

Press and release. The display will show the name of the previous period and flash "temporary" until the next regularly scheduled period starts.



16

To temporarily raise or lower the temperature for the current period only:




Press and hold until the desired temperature is reached. The display will flash "temporary" until the next programmed time period starts.



If you change your mind:

RUN
PROGRAM

Press and release to cancel any of the temporary settings.



17

OPERATING YOUR THERMOSTAT

PERMANENTLY CHANGING THE PROGRAM

If your schedule changes or you want a different temperature, you can update any setting without affecting the rest of the program.




Press and release the desired period key.



Press and hold until the desired schedule day shows on the display.



Press and hold the Time or Temperature keys until the display shows the desired new program.



Press and release to return to normal operation.




OPERATING THE THERMOSTAT MANUALLY


This feature is particularly useful when you go on vacation or other extended absence. It does not cancel your program.



Press and release.



Press and hold to change the temperature setting. After a few seconds the display will show the current temperature.



Press and release to check the temperature setting.



Press and release to cancel manual control.



OPERATING YOUR THERMOSTAT

CANCELLING PROGRAM SETTINGS

The thermostat requires time and temperature settings in the WAKE* period, but any of the others (SLEEP, LEAVE, RETURN) can be cancelled. Weekday, Saturday, and Sunday settings are cancelled separately.

WAKE timing can be **changed** but not cancelled.

CHECKING THE PROGRAM TIMES AND TEMPERATURES

You can check all the stored settings without affecting the permanent program.



Press and hold the desired period key until the time and temperature clear from the display (about 3 seconds).



Press and release to return to normal operation.



Press and release the desired period key. The start time and temperature setting will appear on the display.



Press and release to display the next daily time and temperature for that period.



Press and release to return to normal operation.



CHECKING THE CURRENT TEMPERATURE SETTING

Press a single key to compare current room temperature to the settings at any time.



Press and release. The display will show the current temperature setting for several seconds, then revert to the room temperature.






During recovery from winter energy savings, the setting displayed will not match the programmed setting. This is because the thermostat gradually raises the temperature setting during recovery to provide most efficient use of the heating equipment. The same is true during recovery from summer energy savings, except the temperature is gradually lowered during recovery.

MAINTAINING YOUR THERMOSTAT



REMOVING THE THERMOSTAT FOR BATTERY REPLACEMENT

- 1 Loosen the two captive screws at the bottom corners of the case.
- 2 Pull the thermostat out from the bottom.
- 3 Lift the thermostat up and off the base.



REPLACING THE THERMOSTAT

- 1 Hang the thermostat on the tabs at the top of the base.
- 2 Swing down and press on lower edge until thermostat snaps in place.
- 3 Tighten the captive screws.




22

REPLACING THE BATTERIES

Your thermostat uses three AA or AAA alkaline batteries, depending on model. See the instructions inside the thermostat door to determine the size. The display will flash "REPL BAT" when the batteries get low. Unless the display is blank (indicating the batteries are dead) when you start, you won't have to reprogram the thermostat if you can insert the new batteries within 20-30 seconds of taking out the old ones.

To replace:

- If your thermostat has a system switch, set it to OFF.
- Remove the thermostat from the wall.
- Lift the batteries out of the holder.



- Insert the new batteries, making sure the positive (+) terminals all face toward the right.
- Replace the thermostat on the wall.
- Reprogram, if necessary.

POWER OUTAGES

Reasonably fresh backup batteries will hold the programming and keep the display on during most power outages. Once the power is restored, the system will resume normal operation.

If the display goes off when power is lost, either the backup batteries need to be replaced or are not installed. When power is restored, the display will flash 1:00 PM to remind you to reprogram.

23

GLOSSARY

Comfort temperature

The temperature you want in the morning and evening when you're home.

Energy-saving temperature

The lower (heating) or higher (cooling) temperature that lets you save on heating and cooling costs when you're asleep or away. Also called the setback (heating) or setup (cooling) temperature.

Period key

One of the four keys—WAKE, LEAVE, RETURN or SLEEP—that you press to check or program the start time and temperature for a time period.

Preprogrammed schedule

This is the schedule programmed into your thermostat at the factory. It sets a night program that provides energy savings if you don't set your own program, or if your personal program is lost for any reason. The program, which is the same for all days of the

week, is:

Period	Start Time	Temperature	
		Heating	Cooling
WAKE	6:00 AM	21°C	26°C
LEAVE	---- No	program -----	-----
RETURN	---- No	program -----	-----
SLEEP	10:00 PM	16°C	26°C

Program

The times and temperatures you set to define the comfort and energy savings periods for each schedule (weekdays, Saturday, Sunday).

Recovery

The time when the thermostat operates the heating or cooling equipment to return the house from the energy savings to the comfort temperature. The thermostat starts the recovery period early so the house will be at the comfort setting by the time you've chosen.

Saturday program schedule

The schedule of WAKE, LEAVE, RETURN and SLEEP period start times and temperatures that you program to

Setback

Reducing the temperature in the house for a set period every day in winter for energy savings. The lower temperature is the energy savings temperature.

Setup

Raising the temperature in the house for a set period every day in summer for energy savings. The higher temperature is the energy savings temperature.

Set point

The temperature you set on the thermostat. The thermostat turns the heating or cooling equipment on and off to maintain this temperature at the thermostat location until another temperature setting goes into effect.

Status Lights—Lights that show system operating mode.

ENRG SAV light (green)—This light glows during the LEAVE and SLEEP periods (located on thermostat).

SYSTEM light (yellow)—This light glows whenever the thermostat is calling for heating or cooling (located on thermostat).

AUX HT light (green)—This light glows whenever the thermostat is calling for operation of the backup heater. Backup (auxiliary) heat is more expensive to operate than the heat pump and typically is used only when the heat pump is unable to handle the load (located on subbase).

CHECK light (yellow)—Consult your heat pump equipment literature to determine whether this light is used and its meaning (located on subbase).

EM HT light (red)—This light glows whenever the thermostat

system switch is in the EM HT position (located on subbase). On some systems it may also indicate the need to switch to EM. HEAT because of a problem with the heat pump.

Sunday program schedule

The schedule of WAKE, LEAVE, RETURN and SLEEP period start times and temperatures that you program to run on Sundays.

Time period

One of four program periods: WAKE, LEAVE, return and SLEEP available with the Chronotherm III thermostat. One period begins when the previous period ends.

WAKE—The time period when you want the house at a comfortable temperature while the family gets up and gets ready to leave for work or school. This is the only period that must contain a time and temperature.

LEAVE—The time period when you can set back (winter) or up

(summer) the temperature for energy savings because the family is usually away from home.

RETURN—The time period when you want the house at a comfortable temperature for family activities in the evening before bedtime.

SLEEP—The time period when you can set back (winter) or up (summer) the temperature for energy savings because the family is sleeping. Set it to start at your family's normal bedtime. Often the SLEEP program is set only for the heating season so family members can sleep cool in summer.

Weekday program schedule

The schedule of WAKE, LEAVE, RETURN and SLEEP period start times and temperatures that you program to run Monday through Friday.

YOUR PERSONAL PROGRAM

You can use the tables below to plan your schedule before you begin programming. If you choose not to program a daytime energy savings period, leave the LEAVE and RETURN periods blank.

Weekday Program

PERIOD	START TIME	HEATING TEMPERATURE	COOLING TEMPERATURE
WAKE	_____	_____	_____
LEAVE	_____	_____	_____
RETURN	_____	_____	_____
SLEEP	_____	_____	_____

Saturday Program

PERIOD	START TIME	HEATING TEMPERATURE	COOLING TEMPERATURE
WAKE	_____	_____	_____
LEAVE	_____	_____	_____
RETURN	_____	_____	_____
SLEEP	_____	_____	_____

26

Sunday Program

PERIOD	START TIME	HEATING TEMPERATURE	COOLING TEMPERATURE
WAKE	_____	_____	_____
LEAVE	_____	_____	_____
RETURN	_____	_____	_____
SLEEP	_____	_____	_____

27

TROUBLESHOOTING GUIDE

IF...

Display will not come on.

Display flashes during programming.

Display flashes during operation.

Program is lost due to power outage.

Temperature change occurs at the wrong times.

Heating will not come on.

THEN...

- Check that heat or cool system power is on. If you use batteries, replace with fresh ones.
- Makes sure thermostat is correctly mounted on subbase.
- You have reached the temperature setting limit. The setting range is 7°C to 31°C. In models with automatic heat-cool changeover, the COOL temperature setting must be at least 2°C above the HEAT temperature setting.
- Programming has been lost because of a power outage. You must reprogram.
- Check that backup batteries are installed correctly. Replace if necessary. Reprogram the thermostat.
- Check the program times for the period in question. Be sure that AM and PM indications are correct. Make sure the current day and time are correct. Reprogram if necessary.
- Remember that the heating system or cooling system comes on *before* the WAKE and RETURN start times so the house will be at the desired temperature when the period starts.
- Check the fuse or circuit breaker and replace or reset if necessary.
- Check that switch on thermostat is set to HEAT or AUTO.

28

Heating will not come on. (con't)

Cooling will not come on.

The building is too warm or too cool.

Display says HEAT ON or system light is on, but no heat is coming from the registers.

Display flashes REPL BAT or goes blank when power is turned off.

- Heat pump thermostats have a built-in time delay which may add to time delays in the heating equipment. Allow up to 10 minutes after changing the setting before the compressor starts.
- If temperature setting is higher than current temperature, and display says HEAT ON or SYSTEM light is on, contact your heating and air conditioning contractor.
- Check the fuse or circuitbreaker and replace or reset if necessary.
- Check that switch on thermostat is set to COOL or AUTO.
- The thermostat has a built-in time delay, which may add to time delays in the cooling equipment. Allow up to 10 minutes after changing the setting before the compressor starts.
- If temperature setting is lower than current temperature, and display says COOL ON or SYSTEM light is on, contact your heating and air conditioning contractor.
- Press PRESENT SETTING to check the current temperature setting.
- If desired, change the time or temperature setting. See page 20.
- Allow time for the heating equipment to heat up before checking for heat at the register.
- Install fresh AAA alkaline batteries (See page 23).

29

QUICK REFERENCE TO THE KEYS

**Press these
keys to:**



Begin the current day or time programming.



Set the day of the week and select the program day during programming.



Select the time period to program or review.



Switch between heat and cool modes during programming or when reviewing the program.



Set the time ahead and back. Hold either key down to change the setting faster.



30



Set the temperature while programming and temporarily change the temperature during operation.



Hold either key down to change the setting faster.



Hold any temperature you desire for an extended period.




Change the temperature to the set point of the previous period.



Maintain the current temperature through the next program period.



Start your programmed schedule, cancel temporary program changes.



See the current temperature setting. Setting may not match programmed setting during recovery from energy savings.

31

BATTERIES , replacement	23
Blinking display	28
Cancelling programs	20
Change temperature	18
Checking present setting	21
Checking programs	20
Clock display	1*
Cooling temperatures	9
Day	2
Display	2*
Energy-saving temperature	24
Enrg Sav light	25
Fan Switch	14
FEATURES	*
Flashing display	28
Glossary	24
Heating temperatures	3
Hold tempaure	19
KEYS reference	30

LEAVE	24, 30
Lights	24*
Maintenance	22
Manual operation	19
Operation	16
Period keys	24
Personal program	26
Power outage	23
Preprogrammed schedule	24
Present setting	21
Program schedule	3
Programming overview	
Programming steps	2
Quick reference to the keys	30
RETURN	25, 30
Removing thermostat	22
Replacing batteries	23
SLEEP	25, 30
Saturday program	7
Set cooling temperatures	9
Set current day	2

Set current time	2
Set fan switch	14
Set heating temperatures	3
Set program schedule	3
Set system switch	15
Setback	24
Setting limits	4, 10
Setup	25
Skip	16
Sunday program	8, 13, 25
Switch, fan	14
Switch, system	15

System light	25
System switch	15
Table of Contents	1
Temporary program changes	16
Time	2
Time period	25
TROUBLESHOOTING	28
WAKE	25, 30
Warranty	back cover
Weekday program	3, 9, 25

* See the product features inside the front cover.

LIMITED WARRANTY

Honeywell warrants all Residential products to be free of defects due to workmanship or materials, under normal use and service, for one year from date of installation. If defective due to workmanship or materials, and certified by the installer that the product was removed, due to failure within 12 months after date of installation the product will be repaired or replaced at Honeywell's option. This warranty applies to all parts or components of such products and where possible Honeywell shall only be required to repair or replace such part or component.

Honeywell assumes no liability for consequential damages of any kind and the purchaser by acceptance of this equipment

will assume all liability for the consequences of its use or misuse by the purchaser, his employees or others.

This warranty is expressly in lieu of all other warranties, guarantees, obligations or liabilities, expressed or implied.

All statutory or implied warranties, other than title, are hereby expressly negated and excluded.

Honeywell Limited
740 Ellesmere Road
Scarborough, Ontario M1P 2V9

Honeywell

HELPING YOU CONTROL YOUR WORLD

69-0501/2-89

A 1254 12/88 PRINTED IN TAIWAN

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>