



Lenovo Storage N3310
User Guide and Hardware Maintenance
Manual

Machine Types: 70FX and 70FY

Note: Before using the information and the product it supports, be sure to read and understand the following:

- The *Read Me First* that comes with your product
- “Safety information” on page iii
- Appendix A “Notices” on page 125

First Edition (March 2015)

© Copyright Lenovo 2015.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant a General Services Administration “GSA” contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Contents

Safety information	iii
Products that are not assessed	x
Safety inspection guide	x
Grounding requirements	xi

Chapter 1. General information	1
Introduction	1
Documentation	2

Chapter 2. Storage product setup road map	5
--	----------

Chapter 3. Product overview	7
Storage product package	7
Features	7
Specifications	11
Software	12
BIOS and TSM update utilities.	12
Lenovo ThinkServer Deployment Manager	12
Lenovo ThinkServer System Manager	13
Lenovo ThinkServer System Manager Premium	13
Locations	13
Machine type, model, and serial number label	13
Front view of the storage product	14
Front panel	15
Rear view of the storage product.	17
Storage product components	19
ThinkServer RAID 710 Adapter	21
Hot-swap-drive backplane	22
System board components	23
System board jumpers.	25
Hot-swap-drive status LEDs	27
Power supply status LEDs	28
Connecting the cables.	28

Chapter 4. Turning on and turning off the storage product.	29
Turning on the storage product	29
Turning off the storage product	29

Chapter 5. Configuring the storage product	31
Using the Setup Utility program	31
Starting the Setup Utility program	31
Viewing information in the Setup Utility program	31

Setup Utility program interface	31
Setting the system date and time	34
Using passwords	34
Selecting a startup device	35
Setting an Ethernet connector for system management	36
Exiting the Setup Utility program	36
Updating or recovering the BIOS.	36
Configuring RAID.	38
About RAID	38
Configuring RAID using the Lenovo ThinkServer Deployment Manager program	39
Configuring the advanced SATA or SAS hardware RAID	40
Updating the firmware.	40
Chapter 6. Replacing hardware	41
Guidelines	41
Precautions	41
Handling static-sensitive devices	42
System reliability guidelines.	42
Working inside the storage product with the power on	43
Removing or extending the storage product from the rack cabinet	43
Removing the cover	43
Installing, removing, or replacing hardware	44
Removing and reinstalling the rack handles	45
Removing and reinstalling the cooling shroud	46
Installing or removing a memory module.	48
Installing or removing the ThinkServer System Manager Premium module	55
Installing or removing the RAID 110i upgrade key	57
Installing or removing the ThinkServer RAID Super Capacitor Module	59
Installing or removing a PCIe card	62
Installing or removing the optical module	67
Installing or removing the intrusion switch	70
Installing or replacing a heat sink.	72
Installing or replacing the microprocessor	74
Installing or replacing a hot-swap redundant power supply	83
Installing or replacing a hot-swap hard disk drive	86
Installing or replacing a 2.5-inch solid-state drive into a 3.5-inch-drive bay	89
Installing or replacing the optical drive	95

Replacing the hot-swap hard-disk-drive backplane.	98
Replacing a system fan	99
Replacing the front panel board	101
Replacing the riser card assembly	103
Replacing the coin-cell battery	105
For service technician only: replacing the system board	107
Completing the parts replacement	112
Reinstalling the storage product cover and reconnecting cables.	112
Updating the storage product configuration.	113

Chapter 7. Troubleshooting and diagnostics 115

Troubleshooting procedure	115
Viewing the status and diagnostic LEDs.	115
Viewing the system event log	115
Basic troubleshooting tables	116
Lenovo ThinkServer Deployment Manager program problems	116
Optical drive problems.	116
Storage drive problems	117
Memory module problems	118
Keyboard, mouse, and USB device problems	119

Chapter 8. Getting information, help, and service 121

Information resources	121
Using the documentation.	121

Lenovo Storage Web site.	121
Lenovo Support Web site.	121
Help and service	122
Before you call	122
Calling for service.	122
Using other services	123
Purchasing additional services	123

Appendix A. Notices 125

Trademarks	126
Important notes	126
Polyvinyl Chloride (PVC) cable and cord notice	126
Recycling information	126
Battery return program.	127
Requirement for batteries containing perchlorate	127
Particulate contamination	128
Important WEEE information	128
European Union RoHS	129
German Ordinance for Work gloss statement.	129
Export classification notice	129
Electronic emission notices.	129
Federal Communications Commission (FCC) Statement.	129
Eurasian compliance mark	131
Brazil regulatory notice	131
Recycling information for Brazil	131
ENERGY STAR model information	132

Index. 133

Safety information

Note: Before using the product, be sure to read and understand the multilingual safety instructions on the documentation DVD that comes with the product.

قبل استخدام المنتج، تأكد من قراءة إرشادات الأمان متعددة اللغات وفهمها، وتوجد هذه الإرشادات في قرص DVD الوثائقي الذي يأتي مع المنتج.

Antes de usar o produto, leia e entenda as instruções de segurança multilíngues no DVD de documentação que o acompanha.

Преди да използвате този продукт, задължително прочетете и вникнете в многоезичните инструкции за безопасност в DVD диска с документация, който се предоставя с продукта.

Prije upotrebe ovog proizvoda obavezno pročitajte višejezične sigurnosne upute koje se nalaze na DVD-u s dokumentacijom koji dobivate uz proizvod.

Před použitím produktu je třeba si přečíst a porozumět bezpečnostním pokynům uvedeným na disku DVD s dokumentací, který je dodáván s produktem.

Før du bruger produktet, skal du sørge for at læse og forstå de sikkerhedsforskrifter, der findes på flere sprog, på den dokumentations-dvd, der følger med produktet.

Lue tuotteen mukana toimitetulla DVD-tietolevyllä olevat monikieliset turvaohjeet ennen tämän tuotteen käyttöä.

Avant d'utiliser le produit, veuillez à bien lire et comprendre les instructions de sécurité multilingues figurant sur le DVD de documentation fourni avec le produit.

Πριν χρησιμοποιήσετε το προϊόν, βεβαιωθείτε ότι έχετε διαβάσει και κατανοήσει τις οδηγίες ασφάλειας, οι οποίες είναι διαθέσιμες σε διάφορες γλώσσες στο DVD τεκμηρίωσης που συνοδεύει το προϊόν.

Vor Verwendung des Produkts sollten Sie unbedingt die mehrsprachigen Sicherheitsanweisungen auf der Dokumentations-DVD lesen, die im Lieferumfang des Produkts enthalten ist.

לפני השימוש במוצר, הקפידו לקרוא ולהבין את הוראות הבטיחות, המופיעות בשפות שונות ב-DVD התיעוד המצורף למוצר.

A termék használata előtt mindenképpen olvassa el és értelmezze a termékhez kapott dokumentációs DVD lemezen található, több nyelven elolvasható biztonsági előírásokat.

Prima di utilizzare il prodotto, accertarsi di leggere e comprendere le informazioni sulla sicurezza multilingue disponibili sul DVD di documentazione fornito con il prodotto.

製品をご使用になる前に、製品に付属の Documentation DVD に収録されているマルチリンガルの「安全に正しくご使用いただくために」を読んで理解してください。

제품을 사용하기 전에 제품과 함께 제공되는 문서 DVD의 다국어 안전 지침을 주의 깊게 읽어보십시오.

Voordat u het product gebruikt, moet u ervoor zorgen dat u de meertalige veiligheidsinstructies op de documentatie-dvd van het product hebt gelezen en begrijpt.

Przed skorzystaniem z produktu należy zapoznać się z wielojęzycznymi instrukcjami bezpieczeństwa znajdującymi się na płycie DVD z dokumentacją dostarczoną wraz z produktem.

Antes de utilizar o produto, leia atentamente as instruções de segurança multilíngues que constam no DVD de documentação fornecido com o produto.

Înainte de a utiliza produsul, asigurați-vă că ați citit și înțeles instrucțiunile de siguranță în mai multe limbi de pe DVD-ul cu documentație care însoțește produsul.

Før du bruker produktet, må du lese og forstå den flerspråklige sikkerhetsinformasjonen på DVDen med dokumentasjon som følger med produktet.

Прежде чем использовать этот продукт, внимательно ознакомьтесь с инструкциями по технике безопасности на разных языках, которые можно найти на DVD-диске с документацией в комплекте с продуктом.

在使用本产品之前，请务必先阅读和了解产品附带的文档 DVD 中的多语言安全说明。

Pre nego to upotrebite proizvod obavezno paljivo pročitajte i prouite viejziko uputstvo za bezbednost na dokumentacionom DVD-u koji ste dobili uz proizvod.

Pred pouvanm produktu si pretajte viacjazyn bezpenostn pokyny na disku DVD s dokumentciou dodanom s produktom.

Preden začnete uporabljati izdelek, je pomembno, da preberete in razumete večjezična varnostna navodila na DVD-ju z dokumentacijo, ki ste ga prejeli skupaj z izdelkom.

Antes de utilizar el producto, asegúrese de leer y comprender las instrucciones de seguridad multilingües del DVD de documentación que se proporciona con el producto.

Var noga med att läsa säkerhetsinstruktionerna på dokumentations-DVD-skivan som följer med produkten innan du börjar använda produkten.

使用本產品之前，請務必閱讀並瞭解產品隨附的文件 DVD 上的多國語言版本安全資訊。

Bu ürünü kullanmadan önce, ürünle birlikte gönderilen belge DVD'si üzerindeki çok dil içeren güvenlik yönergelerini okuyup anladığınızdan emin olun.

Перед використанням цього продукту уважно ознайомтеся з інструкціями з техніки безпеки на різних мовах, що можна знайти на DVD-диску з документацією в комплекті з продуктом.

Important: For translated versions of the caution or danger statement, refer to the *Safety, Warranty, and Support Information* document.

Ensure that you read and understand all caution and danger statements in this document before you perform the procedures. Read and understand any additional safety information that is included with the storage product or optional device before you install, remove, or replace the device.

Statement 1



DANGER

Electrical current from power, telephone, and communication cables is hazardous.

To avoid a shock hazard:

- Do not connect or disconnect any cables or perform installation, maintenance, or reconfiguration of this product during an electrical storm.
- Connect all power cords to a properly wired and grounded electrical outlet.
- Ensure that all power cord connectors are securely and completely plugged into receptacles.
- Connect to properly wired outlets any equipment that will be attached to this product.
- When possible, use one hand only to connect or disconnect signal cables.
- Never turn on any equipment when there is evidence of fire, water, or structural damage.
- Disconnect the attached power cords, telecommunications systems, networks, and modems before you open the device covers, unless instructed otherwise in the installation and configuration procedures.
- Connect and disconnect cables as described in the following table when installing, moving, or opening covers on this product or attached devices.

To connect:

1. Turn everything OFF.
2. First, attach all cables to devices.
3. Attach signal cables to connectors.
4. Attach power cords to outlets.
5. Turn devices ON.

To disconnect:

1. Turn everything OFF.
2. First, remove power cords from outlets.
3. Remove signal cables from connectors.
4. Remove all cables from devices.

Statement 2



DANGER

Danger of explosion if battery is incorrectly replaced.

When replacing the lithium coin cell battery, use only the same or an equivalent type that is recommended by the manufacturer. The battery contains lithium and can explode if not properly used, handled, or disposed of.

Do not:

- Throw or immerse into water
- Heat to more than 100°C (212°F)
- Repair or disassemble

Dispose of the battery as required by local ordinances or regulations.

Statement 3



CAUTION:

When laser products (such as CD-ROMs, DVD drives, fiber optic devices, or transmitters) are installed, note the following:

- Do not remove the covers. Removing the covers of the laser product could result in exposure to hazardous laser radiation. There are no serviceable parts inside the device.
- Use of controls or adjustments or performance of procedures other than those specified herein might result in hazardous radiation exposure.




DANGER


Some laser products contain an embedded Class 3A or Class 3B laser diode. Note the following:

Laser radiation when open. Do not stare into the beam, do not view directly with optical instruments, and avoid direct exposure to the beam.


Statement 4



≥ 18 kg (39.7 lb)
< 32 kg (70.5 lb)



≥ 32 kg (70.5 lb)
< 55 kg (121.2 lb)



≥ 55 kg (121.2 lb)
< 100 kg (220.5 lb)

CAUTION:


Use safe practices when lifting.

Statement 5



CAUTION:

The power control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.



Statement 6



CAUTION:

If you install a strain-relief bracket option over the end of the power cord that is connected to the device, you must connect the other end of the power cord to a power source that is easily accessible in case it needs to be disconnected.

Statement 7



CAUTION:

If the device has doors, ensure that you remove or secure the doors before moving or lifting the device to protect against personal injury. The doors will not support the weight of the device.

Statement 8



CAUTION:

Never remove the cover on a power supply or any part that has the following label attached.



Hazardous voltage, current, and energy levels are present inside any component that has this label attached. There are no serviceable parts inside these components. If you suspect a problem with one of these parts, contact a service technician.

Statement 9



CAUTION:

Disconnect the hot-swap fan cables before removing the fan from the device to protect against personal injury.

Statement 10



CAUTION:

The following label indicates a sharp-edge hazard.



Statement 11



CAUTION:

The following label indicates a potential heat hazard.



Statement 12



DANGER

Overloading a branch circuit is a potential fire hazard and a shock hazard under certain conditions. To avoid these hazards, ensure that your system electrical requirements do not exceed branch current ratings at the installation site.

Statement 13



CAUTION:

Ensure that the rack is secured properly to avoid tipping when the storage unit is extended on the rails.

Statement 14



CAUTION:


Some accessory or option board outputs exceed Class 2 or limited power source limits. You must install the appropriate interconnecting cabling in accordance with your local electrical code requirements.

Statement 15



CAUTION:

The power-control button on the device may put the device in standby mode instead of turning off the device. In addition, the device might have multiple connections to dc power. To remove all electrical current from the device, ensure that all connections to dc power are disconnected at the dc power input terminals.



Statement 16



CAUTION:

To reduce the risk of electric shock or energy hazards:

- This equipment must be installed by trained service personnel in a restricted-access location, as defined by your local electrical code and the latest edition of IEC 60950.
- The branch circuit overcurrent protection must be rated in accordance with local electrical code requirements.
- Use 1.3 mm² or 16 American Wire Gauge (AWG) copper conductor only, not exceeding 3 meters in length.
- Torque the wiring-terminal screws to 1.4 newton-meters or 12 inch-pounds.
- Provide a readily available, approved and rated disconnect device in the field wiring.

Statement 17



CAUTION:

This product contains a Class 1M laser. Do not view directly with optical instruments.

Statement 18



CAUTION:

Do not place any object on top of rack-mounted products.



Statement 19



CAUTION:

Hazardous moving parts. Keep fingers and other body parts away.



Statement 20



CAUTION:

A lithium ion battery is provided. To avoid possible explosion, do not burn the battery. Replace the battery only with the Lenovo-approved part. Recycle or discard the battery as instructed by local regulations.

Products that are not assessed

Typical products that are **not assessed** include but not limited to the following:

- Storage and IT-rack components (for example, uninterruptible power supplies and current distribution systems)
- Devices in IT rooms (for example, bulk storage units and network products)
- Industrial low-voltage switchgear

Safety inspection guide

The purpose of this inspection guide is to assist you in identifying potentially unsafe conditions. As each machine was designed and built, required safety items were installed to protect users and service technicians from injury. This guide addresses only those items. You should use good judgment to identify potential safety hazards due to attachment of non-Lenovo Storage features or options not covered by this inspection guide.

If any unsafe conditions are present, you must determine how serious the apparent hazard could be and whether you can continue without first correcting the problem.

Consider these conditions and the safety hazards they present:

- Electrical hazards, especially primary power (primary voltage on the frame can cause serious or fatal electrical shock)
- Explosive hazards, such as a damaged Cathode Ray Tube (CRT) monitor or a bulging capacitor
- Mechanical hazards, such as loose or missing hardware

To determine whether there are any potentially unsafe conditions, use the following checklist at the beginning of every service task. Begin the checks with the power off, and the power cords disconnected.

Checklist:

1. Check exterior covers for damage (loose, broken, or sharp edges).
2. Power off the storage. Disconnect the power cords.
3. Check the power cord for:
 - a. A third-wire ground connector in good condition. Use a meter to measure third-wire ground continuity for 0.1 ohm or less between the external ground pin and the frame ground.
 - b. The power cord should be the authorized type specified for your storage. Go to: <http://www.lenovo.com/serviceparts-lookup>
 - c. Insulation must not be frayed or worn.
4. Check for cracked or bulging batteries.
5. Remove the cover.
6. Check for any obvious non-Lenovo Storage alterations. Use good judgment as to the safety of any non-Lenovo Storage alterations.

7. Check inside the unit for any obvious unsafe conditions, such as metal filings, contamination, water or other liquids, or signs of fire or smoke damage.
8. Check for worn, frayed, or pinched cables.
9. Check that the power-supply cover fasteners (screws or rivets) have not been removed or tampered with.

Grounding requirements

Electrical grounding of the storage is required for operator safety and correct system function. Proper grounding of the electrical outlet can be verified by a certified electrician.

Chapter 1. General information

This chapter provides some general information about your product.

This chapter contains the following items:

- “Introduction” on page 1
- “Documentation” on page 2

Introduction

This document for your Lenovo® network-attached storage (NAS) product contains information about the storage product features, specifications, component locations, configuration instructions, hardware replacement procedures, and basic troubleshooting and diagnostics.

Your storage product comes with a documentation DVD that contains various storage product documents to help you use and maintain the storage product.

The Lenovo Limited Warranty (LLW) contains the warranty terms that apply to the product you purchased from Lenovo. Read the LLW on the documentation DVD that comes with your storage product. A printable generic version of the latest LLW also is available in more than 30 languages at http://www.lenovo.com/warranty/llw_02. If you cannot obtain the LLW through the documentation DVD or Lenovo Web site, contact your local Lenovo office or reseller to obtain a printed version of the LLW, free of charge.

For warranty service, consult the worldwide Lenovo Support telephone list. Telephone numbers are subject to change without notice. The most up-to-date telephone list for Lenovo Support is always available on the Web site at <http://www.lenovo.com/support/phone>. If the telephone number for your country or region is not listed, contact your Lenovo reseller or Lenovo marketing representative.

To obtain the most up-to-date information about the storage product, go to:
<http://shop.lenovo.com/us/en/servers/network-storage/>

Lenovo maintains pages on the World Wide Web, where you can get the latest technical information and download documentation or device drivers and updates. To access the Lenovo Support Web site, go to:
<http://www.lenovo.com/support>

Record information about your storage product in the following table. You will need the information if you ever need to have your storage product serviced.

For where to find the product information label on the chassis, see “Machine type, model, and serial number label” on page 13.

Product name	_____
Machine type and model (MT-M)	_____
Serial number (S/N)	_____
Date of purchase	_____

You can register your storage product with Lenovo by following the instructions at:
<http://www.lenovo.com/register>

When you register your storage product, information is entered into a database, which enables Lenovo to contact you in case of a recall or other severe problem. After you register your storage product with Lenovo, you will receive quicker service when you call Lenovo for help. In addition, some locations offer extended privileges and services to registered users.

Documentation

This topic provides a general description of each document for your storage product and instructions on how to obtain all the documents.

Printed documents

The following documents are printed out and included in your storage product package.

- *Getting Started Guide*

This document provides general information to help you get familiar with your storage product.

- *Rack Installation Instructions* (available on some models)

This document provides instructions on how to install your storage product into a standard rack cabinet by using the rail kit shipped with the storage product.

Note: Depending on the model, a printed English version of this document might be included in your storage product package. PDF versions of other languages are provided on the documentation DVD that comes with your storage product.

Documentation DVD

The documentation DVD, which comes with your storage product, contains various documents for your storage product in Portable Document Format (PDF) and HyperText Markup Language (HTML). The documentation DVD is not bootable. To view the documents on the DVD, you will need a computer with a Web browser and the Adobe Reader program, which is available for download at: <http://www.adobe.com>

To start the documentation DVD, insert the DVD into the optical drive. The DVD is AutoPlay enabled and starts automatically in most Microsoft® Windows® environments. If the DVD fails to start or if you are using a Linux® operating system, open the launch.htm file located in the root directory of the DVD.

Note: Lenovo maintains pages on the World Wide Web, where you can get the latest technical information and download documentation or device drivers and updates. Some information in the documents on the documentation DVD might change without notice after the first release of the DVD. You can always obtain all the most up-to-date documentation for your storage product from the Lenovo Web site at: <http://www.lenovo.com/support>

The following documents are on the documentation DVD that comes with your storage product:

- *Safety, Warranty, and Support Information*

This is a multilingual document that includes all the safety statements for your product in more than 30 languages. Be sure to read and understand all the safety statements before using the product. This document also includes the Lenovo warranty statement, Customer Replaceable Units (CRUs) information, and information about how to contact the Lenovo Customer Support Center.

- *Lenovo License Agreement*

This document includes the terms and conditions of the Lenovo License Agreement.

- *User Guide and Hardware Maintenance Manual*

This document provides detailed information to help you get familiar with your storage product and help you use, configure, and maintain your storage product.

- *Rack Installation Instructions*

This document provides instructions on how to install your storage product into a standard rack cabinet by using the rail kit shipped with the storage product.

- *NAS Administrator Guide*

This document provides instructions on how to manage your storage product using the programs and utilities that come with the Microsoft Windows Storage Server 2012 R2 operating system.

Chapter 2. Storage product setup road map

This chapter provides a general road map to guide you through setting up your storage product.

The storage product setup procedure varies depending on the configuration of the storage product when it was delivered. In some cases, the storage product is fully configured and you just need to connect the storage product to the network and an ac power source, and then you can turn on the storage product. In other cases, the storage product needs to have hardware features installed, requires hardware and firmware configuration, and requires an operating system to be installed.

The general procedure for setting up your storage product is:

1. Unpack the storage product package. See “Storage product package” on page 7.
2. Install any required hardware or storage product option. See the related topics in Chapter 6 “Replacing hardware” on page 41.
3. If necessary, install the storage product into a standard rack cabinet by using the rail kit shipped with the storage product. See the *Rack Installation Instructions* that comes with the storage product.
4. Connect the Ethernet cable and power cords to the storage product. See “Rear view of the storage product” on page 17 to locate the connectors.
5. Turn on the storage product to verify operation. See “Turning on the storage product” on page 29.
6. Review the Unified Extensible Firmware Interface (UEFI) settings and customize as needed. See “Using the Setup Utility program” on page 31.
7. Configure RAID and install the operating system and basic drivers. See “Lenovo ThinkServer Deployment Manager” on page 12 and “Configuring RAID” on page 38.
8. Install any additional drivers needed for added features. Refer to the instructions that come with the hardware option.
9. Configure Ethernet settings in the operating system by referring to the operating system help. This step is not required if the operating system was installed using the Lenovo ThinkServer Deployment Manager program.
10. Check for firmware updates. See “Updating the firmware” on page 40.
11. Install management applications and any other applications. Refer to the documentation that comes with the applications that you want to install.

Chapter 3. Product overview

This chapter provides information about the storage product package, features, specifications, software programs, and component locations.

This chapter contains the following items:

- “Storage product package” on page 7
- “Features” on page 7
- “Specifications” on page 11
- “Software” on page 12
- “Locations” on page 13

Storage product package

The storage product package includes the following items:

- Storage product
- Rail kit (available on some models)
- Cable management arm or cable management bar (available on some models)
- Slim optical drive (available on some models)
- Material box, including items such as power cords, printed documentation, and a documentation DVD

Features

This topic provides general information about the storage product features for various models. Depending on your specific model, some features might vary or not apply. For information about your specific model, use the Setup Utility program. See “Viewing information in the Setup Utility program” on page 31. You also can refer to the *Product Specifications Reference* document for Lenovo Storage products at: <http://www.lenovo.com/psref/>

Microprocessor

One or two Intel® Xeon® microprocessors (internal cache size varies by model)

Memory

Your storage product has 16 memory slots. For more information, see “Memory module installation rules” on page 48.

Power supply

Your storage product comes with one or two power supplies. When two power supplies are both installed, they provide redundant and hot-swap features. Depending on the storage product model, the power supplies for your storage product can be any of the following types:

- 450-watt, 90–264 V ac, universal input and compliant with 80 PLUS Gold
- 550-watt, 90–264 V ac, universal input and compliant with 80 PLUS Platinum
- 750-watt, 90–264 V ac, universal input and compliant with 80 PLUS Platinum
- 750-watt, 180–264 V ac, universal input and compliant with 80 PLUS Titanium

System fans

Your storage product supports up to six system fans. This design helps you avoid significant cooling problems when a system fan fails.

Internal drives

Internal drives are devices that your storage product uses to read and store data. The internal drives supported by your storage product vary by model.

- Internal storage drive

Your storage product supports up to four 3.5-inch hot-swap Serial Advanced Technology Attachment (SATA) hard disk drives, Serial Attached SCSI (SAS) hard disk drives (SCSI is the acronym for Small Computer System Interface), or solid-state drives.

Note: You can install a 2.5-inch solid-state drive into a 3.5-inch-drive bay. For more information, see “Installing a 2.5-inch solid-state drive into a 3.5-inch hard-disk-drive bay” on page 90.

- Optical drive
 - One slim SATA optical drive in some models

To locate the internal drives or drive bays, see “Storage product components” on page 19.

Expansion slots

- One PCI Express (PCIe) slot on the system board
- One PCIe slot on each riser card
- Two riser card assembly slots on the system board

For detailed information, see “Rear view of the storage product” on page 17.

Input/Output (I/O) features

- On the rear panel:
 - One video graphics array (VGA) DB-15 connector
 - One serial connector
 - Three RJ-45 Ethernet connectors (Ethernet connector 0 is for system management)
 - Two USB 3.0 connectors
- On the front panel:
 - One DisplayPort connector
 - Two USB 2.0 connectors

To locate the connectors, refer to the related topics in “Locations” on page 13.

Video subsystem

An integrated graphics controller is available in your storage product to support DisplayPort connectors for connecting video devices. The integrated graphics controller is located in the Baseboard Management Controller (BMC) chip on the system board.

- Integrated graphics controller: on-board ASPEED AST2400
- 16 MB of video memory cache

Ethernet connectivity

There are three RJ-45 Ethernet connectors on the rear panel with 10 megabits per second (Mbps), 100 Mbps, or 1000 Mbps network connectivity. Ethernet connector 0 is for system management by default. However, you also can set Ethernet connector 1 or 2 for system management use in the Setup Utility program.

For more information, see “Rear view of the storage product” on page 17.

Reliability, availability, and serviceability

Reliability, availability, and serviceability (hereinafter referred to as RAS) are three important storage product design features. The RAS features help you ensure the integrity of the data stored on the storage product, the availability of the storage product when you need it, and the ease with which you can diagnose and correct problems.

Your storage product has the following RAS features:

- **Security features**
 - Administrator password and user password to help protect unauthorized access to the storage product (see “Using passwords” on page 34)
 - Remote monitoring or control by an administrator to provide protection or help
 - Hot-swap redundant power supplies to help avoid significant interruption to the operation of the system when a power supply fails
 - An intrusion switch that informs you that the storage product cover is not properly installed or closed by creating an event in the system event log (SEL)
- **Basic system management features**
 - Ability to store the power-on self-test (POST) hardware test results
 - BIOS Setup Utility program

The BIOS Setup Utility program helps you view the storage product information and configure the storage product in the pre-operating system environment. See “Using the Setup Utility program” on page 31.

- TSM (also known as BMC) and Intelligent Platform Management Interface (IPMI) 2.0

The system board platform management subsystem is based on the integrated TSM features. The TSM is a management chip that is integrated on the system board of your storage product. With the TSM, no matter what condition the storage product operating system is in and no matter if the storage product is on or off, as long as the storage product is connected to network and an ac power source, the interaction with the TSM-controlled storage products can be achieved through system network. The user can obtain the storage product hardware health information and system event log (SEL), and is able to conduct the operations including turning on or off the storage product, restarting the storage product, and so on. This part of storage product management is independent of the operating system and is called out-of-band management.

The system board platform management subsystem consists of the integrated TSM, communication buses, sensors, the BIOS, and storage product management firmware. It is responsible for error reporting, system power control, thermal monitoring, system fan control, and other management features. The TSM provides system management and monitoring features based on the IPMI 2.0 specification. IPMI helps lower the overall costs of storage product management. You can find more information about IPMI 2.0 from the Web site of Intel. The TSM also supports some non-IPMI features, such as the Dynamic Host Configuration Protocol (DHCP) and the Platform Environment Control Interface (PECI), to provide more system management functions.

You can find the default user name, password, and other information for the TSM in the *ThinkServer System Manager User Guide*, which is available for download at:
<http://www.lenovo.com/support>

- Hot-swap feature

Your storage product supports hot-swap storage drives (including hard disk drives and solid-state drives), and hot-swap redundant power supplies. With the hot-swap feature, you can install, remove, or replace a hot-swap device without turning off the storage product.

- Preboot Execution Environment (PXE)

The Intel PXE technology enables you to boot your computers, load an operating system, or deploy executable images from a remote storage product by using a network interface. The operation can be done independently of local data storage devices (such as hard disk drives) or operating systems.

- Redundant Array of Independent Disks (RAID)

Your storage product supports onboard SATA software RAID. If a required RAID card is installed, your storage product also supports advanced SATA/SAS hardware RAID configurations. For detailed information, see “Configuring RAID” on page 38.

- Status light-emitting diodes (LEDs) and diagnostic LEDs

For more information about the LEDs for your storage product, refer to the related topics in “Locations” on page 13.

- Software programs

For more information about the software programs, see “Software” on page 12.

- Wake on LAN

Wake on LAN is an Ethernet computer networking standard that allows a computer or a storage product to be turned on or woken up by a network message. The message is usually sent by a program running on another computer on the same local area network.

- **Advanced system management features**

The advanced system management features are only available when the TSM detects the presence of a TSM Premium module. The TSM Premium module is a remote management module. You can purchase a

TSM Premium module from Lenovo and install it on the system board to activate the advanced system management features.

For more information about advanced system management, refer to the *ThinkServer System Manager User Guide*, which is available for download at:

<http://www.lenovo.com/support>

Specifications

This topic lists the physical specifications for your storage product.

Dimensions

Width without rack handles: 447 mm (17.59 inches)

Width with rack handles: 482 mm (18.98 inches)

Depth without rack handles: 781.6 mm (30.77 inches)

Depth with rack handles: 802.5 mm (31.59 inches)

Height: 43 mm (1.69 inches)

Weight

The product weight varies depending on different system configurations.

Range of product weight without package: 13.6 kg (29.98 lb) to 18 kg (39.68 lb)

Range of product weight with package: 19.9 kg (43.87 lb) to 24.3 kg (53.57 lb)

Environment

- Air temperature:

Operating: 10°C to 35°C (50°F to 95°F)

Storage: -40°C to 70°C (-40°F to 158°F) in original shipping package

- Altitude: 0 to 3048 m (0 to 10 000 ft) in an unpressurized environment

Note: When the altitude exceeds 950 m (3117 ft), the defined maximum dry-bulb temperature for operation becomes a dependent variable. This temperature value decreases by 1°C (33.8°F) with every 300 m (984 ft) of altitude increase.

- Humidity:

Operating: 20% to 80% (non-condensing)

Storage without package: 8% to 90% (non-condensing)

Storage with package: 8% to 90% (non-condensing)

Electrical input

- Universal input:

- Low range:

Minimum: 100 V ac

Maximum: 127 V ac

Input frequency range: 50 to 60 Hz

- High range:

Minimum: 200 V ac

Maximum: 240 V ac

Input frequency range: 50 to 60 Hz

Software

This topic provides information about the software programs that you can use to set up, use, and maintain the storage product.

To download the software programs, go to the Lenovo Support Web site at <http://www.lenovo.com/support> and follow the instructions on the Web page.

BIOS and TSM update utilities

The BIOS and TSM (also known as BMC) firmware keeps updating after the shipment of the storage product. Lenovo maintains pages on the Support Web site and provides the BIOS and TSM update utilities with instructions for download to help you update the BIOS and TSM firmware if needed. For more information, see “Updating or recovering the BIOS” on page 36 and “Updating the firmware” on page 40.

Lenovo ThinkServer Deployment Manager

The Lenovo ThinkServer Deployment Manager program (hereinafter referred to as Deployment Manager) simplifies the process of configuring RAID, configuring BIOS settings, and updating the firmware. The program works in conjunction with your Windows or Linux operating system installation disc to automate the process of installing the operating system and associated device drivers. The program is part of the server firmware. The help system for the program can be accessed directly from the program interface.

Deployment Manager has the following features:

- Easy-to-use, language-selectable interface
- Integrated help system
- Automatic hardware detection
- Selectable partition size and file system type
- Ability to install the operating system and device drivers in an unattended mode to save time
- Ability to create a reusable response file that can be used with similarly configured Lenovo storage products to make future installations even faster
- Contains RAID configuration utility
- Provides device drivers based on the storage product model and detected devices
- Supports BIOS settings configuration
- Supports firmware and applications update

To use Deployment Manager, do the following:

1. Launch the program through one of the following methods:
 - Turn on the storage product. Press F10 as soon as you see the logo screen. Then, wait for several seconds. Deployment Manager opens.
 - Start the Setup Utility program. Select **Boot Manager** → **Launch TDM**. Deployment Manager opens.
2. Read and accept the license agreement.
3. Select the language in which you want to view the program. Then, follow the instructions on the screen to use the program.

Before installing a Windows or a Linux operating system using Deployment Manager, it is recommended that you do the following:

1. Download the latest device driver bundle file for your storage product. To find and download the bundle file, go to <http://www.lenovo.com/drivers> and follow the instructions on the Web page.
2. Launch Deployment Manager and click **Platform Update** on the left pane.
3. Select **Application** and then click **Next**.
4. Click **Browse** to select the corresponding bundle file and then click **OK**. The version information is displayed.
5. Click **Flash** to apply the bundle file and update the current device drivers.

Note: If you want to install a VMware hypervisor using Deployment Manager, the device driver bundle file is not needed.

To download the latest Deployment Manager, go to <http://www.lenovo.com/drivers> and follow the instructions on the Web page.

Lenovo ThinkServer System Manager

The Lenovo ThinkServer System Manager (TSM) is a management solution that provides comprehensive and secure management features. These features enable you to manage your storage products remotely using a one-to-one or one-to-many method.

The TSM provides a one-to-one web-based console. The web-based console is developed in HTML 5 and structured in the way that makes platform management intuitive and efficient. The TSM also provides a secure command-line interface to manage your storage products using a one-to-many method for improved efficiency and functionality.

For detailed information about using the Lenovo ThinkServer System Manager, refer to the integrated help screens and user guides.

Lenovo ThinkServer System Manager Premium

Lenovo ThinkServer System Manager Premium provides you a solution that enables you to receive all the benefits and features provided by both the Lenovo ThinkServer System Manager program and the Lenovo ThinkServer Energy Manager program. It also enables you to control the storage product remotely using Lenovo virtual keyboard, video, and mouse.

For detailed information about using the Lenovo ThinkServer System Manager Premium features and tools, refer to the integrated help screens and user guides.

Locations

This topic provides information to help you locate your storage product components.

Machine type, model, and serial number label

When you contact Lenovo for help, the machine type, model, and serial number information helps support technicians to identify your storage product and provide faster service.

The machine type, model, and serial number label is attached on the pull-out information card, which is a small plastic tab and can be slid out of the front of the chassis. The following illustrations are samples of the machine type, model, and serial number labels on storage product models with different hard disk drive configurations.

Note: Depending on the model, your storage product might look slightly different from the illustrations in this topic.




Figure 1. Label on storage product models with 3.5-inch-drive bays

Front view of the storage product




Figure 2. Front view of the storage product

1 Front panel	2 Slim optical drive (available on some models)
3 Pull-out information card	4 Rack handle (right)
5 3.5-inch-drive bays (0-3)	6 Rack handle (left)

1 Front panel

For detailed information about the controls, connectors, and status LEDs on the front panel, see “Front panel” on page 15.

2 Slim optical drive

Some storage product models come with a slim SATA optical drive.

3 Pull-out information card

The machine type, model, and serial number label of the storage product is attached on the pull-out information card. See “Machine type, model, and serial number label” on page 13.

4 Rack handle (right)

6 Rack handle (left)

If your storage product is installed in a rack cabinet, you can use the rack handles to help you slide the storage product out of the rack cabinet. You also can use the rack handles and screws to secure the storage product in the rack cabinet so that the storage product cannot slide out, especially in vibration-prone areas. For more information, refer to the *Rack Installation Instructions* that comes with your storage product.

5 3.5-inch-drive bays (0-3)

The EMI integrity and cooling of the storage product are protected by having all drive bays covered or occupied. The number of the installed hard disk drives in your storage product varies by model. The vacant hard-disk-drive bays are occupied by dummy hard-disk-drive trays.

When you install drives, follow the order of the drive bay numbers.

Front panel

The following illustration shows the controls, connectors, and LEDs on the front panel of the storage product. The front panel varies by model.




Figure 3. Front panel

1 Network status LED	2 System health LED
3 Power button with power status LED	4 System ID button with ID LED
5 DisplayPort connector	6 USB 2.0 connectors (2)

1 Network status LED

The network status LED on the front panel helps you identify the network connectivity and activity.

Network status LED	Color	Description
On	Green	The storage product is connected to a LAN.
Off	None	The storage product is disconnected from a LAN.
Blinking	Green	The LAN is connected and active.

2 System health LED

The system health LED helps you to determine if there are any system errors.

- **Off:** The storage product is off or the storage product is on and working correctly.
- **Amber:** The storage product has potential system errors. Check the information in the following table for potential system errors and corresponding solutions.
- **Blinking:** TSM initialization is in progress.

Potential system error (system health LED: amber)	Solution
The temperature of the storage product reached the non-critical temperature threshold.	Check the BMC for errors and check the system fans.
The voltage of the storage product reached the non-critical voltage threshold.	Replace the system board. Note: This action must be performed only by Lenovo service personnel. See Chapter 8 “Getting information, help, and service” on page 121.
A fan is running at low speed.	Check the system fans.
A system fan has been removed.	<ol style="list-style-type: none">1. Ensure that the system fans are connected securely to the system board.2. Reinstall the removed fan or install a new fan to replace the removed fan.
The power supply has a critical error.	Check the BMC for detailed information.
A power cord has been disconnected or a redundant power supply has been removed.	<ol style="list-style-type: none">1. Ensure that the power supplies are installed securely.2. Ensure that the power cords are connected securely to the power supplies.3. Install a new power supply to replace the removed one.
The system is overheated.	Check the BMC for errors and then check the system fans.

3 Power button with power status LED

You can press the power switch to turn on the storage product when you finish setting up the storage product. You also can hold the power switch for several seconds to turn off the storage product if you cannot turn it off from the operating system. See Chapter 4 “Turning on and turning off the storage product” on page 29. The power status LED helps you to determine the current power status.

Status	Color	Description
On	Green	The storage product is on.
Off	None	The storage product is off.

4 System ID button with ID LED

When you press the system ID button, the ID LEDs on both the front and rear of the storage product are lit to help you locate the storage product among other storage products. You also can turn on the ID LEDs using a remote management program for storage product presence detection.

Status	Color	Description
On	Blue	The system is identified.
Off	None	The ID LED is not in use or the system is not identified.

5 DisplayPort connector

Used to attach a high-performance monitor, a direct-drive monitor, or other devices that use a DisplayPort connector.

6 USB 2.0 connectors (2)

Used to attach a USB-compatible device, such as a USB keyboard, mouse, scanner, or printer. If you have more than four USB devices, you can purchase a USB hub, which you can use to connect additional USB devices.

Rear view of the storage product

This topic provides information to help you locate the connectors and components on the rear of your storage product.

The following illustration shows the connectors and components on the rear of your storage product. The rear view of the storage product varies by model.




Figure 4. Rear view of the storage product

1 Power supply 1	2 Power supply 2 (available on some models)
3 PCIe slot 2	4 PCIe slot 1
5 System ID LED	6 USB 3.0 connectors (2)
7 Ethernet connector 2 (RJ-45)	8 Ethernet connector 1 (RJ-45)
9 Serial connector	10 Ethernet connector for system management (RJ-45)
11 VGA connector (DB-15)	

1 Power supply 1

2 Power supply 2 (available on some models)

The hot-swap redundant power supplies help you avoid significant interruption to the operation of the system when a power supply fails. You can purchase a power supply option from Lenovo and install the power supply to provide power redundancy without turning off the storage product.

On each power supply, there are three status LEDs near the power cord connector. For information about the status LEDs, see “Power supply status LEDs” on page 28.

3 PCIe slot 2

It is recommended that you attach a RAID card to the low-profile PCIe slot.

Physical link width	Negotiable link width	Supported card length and height
x16	x16, x8, x4, x2, x1	Low-profile card

4 PCIe slot 1

Used to attach an Ethernet card or any other supported PCIe card.

Physical link width	Negotiable link width	Supported card length and height
x16	x16, x8, x4, x2, x1	Half-length, full-height card

5 System ID LED

When you press the ID button on the front panel, the ID LEDs on both the front and rear of the storage product are lit to help you locate the storage product among other storage products. You also can turn on the ID LEDs using a remote management program for storage product presence detection.

Status	Color	Description
On	Blue	The system is identified.
Off	None	The ID LED is not in use or the system is not identified.


6 USB 3.0 connectors (2)

Used to attach a USB-compatible device, such as a USB keyboard, mouse, scanner, or printer. If you have more than four USB devices, you can purchase a USB hub, which you can use to connect additional USB devices.

7 8 10 Ethernet connectors (RJ-45)

Used to attach an Ethernet cable for a LAN. Each Ethernet connector has two status LEDs to help you identify the Ethernet connectivity, activity, and connection speed.

Note: Ethernet connector 0 (callout **10**) marked with “MGMT” is for system management by default.



Ethernet status LED	Color	Status	Description
1 Left	Amber	On	The connection speed is 1000 Mbps.
	Green	On	The connection speed is 100 Mbps.
	None	Off	The connection speed is 10 Mbps.
2 Right	Green	On	The storage product is connected to a LAN.
	None	Off	The storage product is disconnected from a LAN.
	Green	Blinking	The LAN is connected and active.

9 Serial connector

Used to attach a device that uses a 9-pin serial connector.

11 VGA connector (DB-15)

Used to attach a VGA-compatible video device, such as a VGA monitor.

Storage product components

This topic provides information to help you locate the components of your storage product. For more information about major components, see the related topics in “Locations” on page 13.

To remove the storage product cover and the cooling shroud and gain access to the inside of the storage product, see “Removing the cover” on page 43 and “Removing and reinstalling the cooling shroud” on page 46.

The chassis configuration varies by model.

Note: Depending on the model, your storage product might look slightly different from the illustrations in this topic.




Figure 5. Storage product components

1 One or two hot-swap redundant power supplies	2 DIMMs (vary by model)
3 System board	4 Cooling shroud
5 Backplane for 3.5-inch drives	6 ThinkServer RAID Super Capacitor Module (available on some models)
7 Rack handle (right)	8 3.5-inch-drive area
9 Rack handle (left)	10 Slim optical drive (available on some models)
11 System fans	12 Heat sink(s) with microprocessor(s) underneath
13 Riser card assembly 1	14 Riser card assembly 2

CRUs are parts that can be upgraded or replaced by the customer. If a CRU is determined to be defective during the warranty period, a replacement CRU will be provided to the customer. Customers are responsible for installing the self-service CRUs for this product. Customers also can install optional-service CRUs, which might require some technical skills or tools, or request that a technician install the optional-service CRU under the terms of the applicable warranty service type for your country or region.

Non-CRUs must be replaced only by trained service technicians.

The following table lists the major FRUs in your storage product and the CRU identification information. For a complete listing of FRU information, such as FRU part numbers and supported storage product models, go to:

<http://www.lenovo.com/serviceparts-lookup>

Notes:

- Before servicing a Lenovo product, ensure that you read and understand “Safety information” on page iii.
- Use only parts provided by Lenovo.

* Available on some models

FRU description	Self-service CRU	Optional-service CRU
Coin-cell battery	Yes	No
Cooling shroud	Yes	No
Front backplane	No	Yes
Front panel board	Yes	No
Heat sink	Yes	No
Hot-swap storage drive*	Yes	No
Hot-swap redundant power supply	Yes	No
Intrusion switch*	Yes	No
Memory module	Yes	No
Microprocessor	No	Yes
PCIe card	Yes	No
Power cord	Yes	No
Rack handles	Yes	No
Riser card	Yes	No
Slim optical drive*	Yes	No
System board	No	No
System fan	Yes	No
ThinkServer optical module*	Yes	No
ThinkServer RAID 110i upgrade key*	Yes	No
ThinkServer RAID Super Capacitor Module*	Yes	No
ThinkServer RAID Super Capacitor Module holder*	Yes	No
ThinkServer System Manager Premium module*	Yes	No

ThinkServer RAID 710 Adapter

Some storage product models come with a RAID card to provide advanced SATA/SAS hardware RAID functions to the storage product. This topic provides information to help you locate the connectors on a RAID card. If your storage product has a RAID card installed, the RAID card is seated on the riser card assembly 2.

Note: The option kit for the RAID card is designed for different types of storage products and might contain additional cables that are not required for your storage product.

The following illustration shows the connectors on the ThinkServer RAID 710 Adapter.




Figure 6. ThinkServer RAID 710 Adapter

1 Port 1

Used to connect a mini-SAS signal cable to the mini-SAS ports 0-3 on the backplane.

2 ThinkServer RAID Super Capacitor Module connector

Used to connect the cable of a ThinkServer RAID Super Capacitor Module.

To install or remove the RAID card, refer to “Installing or removing a PCIe card” on page 62.

Hot-swap-drive backplane

The following illustrations show the slots and connectors on the backplane for 3.5-inch drives.




Figure 7. Front view of the backplane for 3.5-inch drives




Figure 8. Rear view of the backplane for 3.5-inch drives

0 - 3 Slot 0-slot 3

Used to connect 3.5-inch drives.

4 10-pin power connector

Used to connect to the backplane power connector on the system board to provide power to the backplane.

5 Optical drive power connector

Used to connect the power cable for the slim optical drive.

6 Mini-SAS ports 0-3

Used to connect the mini-SAS connector on one end of a mini-SAS to mini-SAS signal cable to support the hard disk drive 0 to hard disk drive 3.

System board components

The following illustration shows the component locations on the system board.




Figure 9. System board components

1 SATA connector (optical drive)	2 Coin-cell battery
3 SATA connector 0 (ports 0–3)	4 Front panel connector 1
5 Front panel connector 2	6 Riser card assembly 1 slot
7 TSM Premium module connector	8 PCIe slot
9 Riser card assembly 2 slot	10 RAID upgrade key connector
11 Power supply connector 2	12 Power supply connector 1
13 Intrusion switch connector	14 Backplane power connector 2
15 Backplane power connector 1	16 System fan 6 connector
17 Microprocessor 2 memory slots (4)	18 System fan 5 connector
19 Microprocessor 2 socket	20 System fan 4 connector
21 Microprocessor 2 memory slots (4)	22 Microprocessor 1 memory slots (4)
23 System fan 3 connector	24 System fan 2 connector

25 Microprocessor 1 socket	26 System fan 1 connector
27 Microprocessor 1 memory slots (4)	

1 SATA connector (optical drive)

Used to connect the signal cable of the slim optical drive.

2 Coin-cell battery

Your storage product has a special type of memory that maintains the date, time, and configuration information for built-in features. The coin-cell battery keeps the information active when you turn off the storage product.

3 SATA connector 0 (ports 0–3)

Used to connect to the Mini-SAS ports 0-3 on the backplane.

4 5 Front panel connector

Used to connect to the front panel board.

6 Riser card assembly 1 slot

Used to install the riser card assembly 1.

7 TSM Premium module connector

Used to connect a TSM Premium module to enable advanced remote management functions on your storage product.

8 PCIe slot

Used to install a supported PCIe card. For information about supported PCIe cards, see “Rear view of the storage product” on page 17.

9 Riser card assembly 2 slot

Used to install the riser card assembly 2.

10 RAID upgrade key connector

Used to connect a ThinkServer RAID 110i upgrade key.

11 Power supply connector 2

Used to connect the power supply 2.

12 Power supply connector 1

Used to connect the power supply 1.

13 Intrusion switch connector

Used to connect to an intrusion switch.

14 15 Backplane power connector

Used to connect to the 10-pin power connector on the backplane.

16 18 20 23 24 26 System fan connector

Used to connect a system fan.

17 21 22 27 Memory slots

There are 16 memory slots on the system board. For detailed information, see “Memory module installation rules” on page 48.

19 Microprocessor 2 socket

25 Microprocessor 1 socket

If the storage product has two microprocessors, each of the microprocessor is secured in the microprocessor socket on the system board and a heat sink is installed above the microprocessor to provide cooling. If the storage product has only one microprocessor, the microprocessor socket 2 is protected by a microprocessor socket cover.

System board jumpers

The following illustration shows the jumpers on the system board of your storage product.




Figure 10. System board jumpers

1 Jumper cap storage	2 BIOS recovery jumper
3 BIOS default settings jumper	4 Clear password jumper

Attention: To set the jumpers, remove the storage product cover and gain access to the system board first. Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

1 Jumper cap storage

Used to store the jumper cap. A jumper cap is encased on the pins by default.

2 BIOS recovery jumper

Used to recover the BIOS if the power to your storage product is interrupted while the BIOS is being updated and your storage product cannot start correctly.

To recover the BIOS, see “Recovering from a BIOS update failure” on page 37.

3 BIOS default settings jumper

Used to turn the BIOS settings into the factory-default settings.

To turn the BIOS settings into the factory-default settings, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Locate the BIOS default settings jumper **3** on the system board. Then, remove any parts and disconnect any cables that might impede your access to the jumper.

Note: Do not remove the memory modules or microprocessors.

5. Remove the jumper cap from the jumper cap storage **1**.
6. Note the orientation of the jumper cap and then install the jumper cap on the BIOS default settings jumper.
7. Reinstall any parts and reconnect any cables. Then, reinstall the storage product cover. See “Completing the parts replacement” on page 112.
8. Connect the storage product to an ac power source and wait for several minutes. Then, turn on the storage product. The BIOS settings turn into the factory-default settings.
9. Repeat step 1 through step 3.
10. Move the jumper cap back to the jumper cap storage **1**.
11. Reinstall any parts and reconnect any cables. Then, reinstall the storage product cover. See “Completing the parts replacement” on page 112.
12. Connect the storage product to an ac power source and turn on the storage product.

4 Clear password jumper

Used to erase forgotten passwords, such as the BIOS passwords.

To clear passwords, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.

4. Locate the clear password jumper **4** on the system board. Then, remove any parts and disconnect any cables that might impede your access to the jumper.

Note: Do not remove the memory modules or microprocessors.

5. Remove the jumper cap from the jumper cap storage **1**.
6. Note the orientation of the jumper cap and then install the jumper cap on the clear password jumper.
7. Reinstall any parts and reconnect any cables. Then, reinstall the storage product cover. See “Completing the parts replacement” on page 112.
8. Connect the storage product to an ac power source and wait for several minutes. Then, turn on the storage product. The BIOS passwords are erased, including the administrator password and user password.
9. Repeat step 1 through step 3.
10. Move the jumper cap back to the jumper cap storage **1**.
11. Reinstall any parts and reconnect any cables. Then, reinstall the storage product cover. See “Completing the parts replacement” on page 112.
12. Connect the storage product to an ac power source and turn on the storage product.
13. To set new passwords, see “Using passwords” on page 34.

Hot-swap-drive status LEDs

Each hot-swap drive has two status LEDs on the front.




Figure 11. Hot-swap-drive status LEDs

1 Drive activity LED	2 Drive status LED	Description
Off	Off	The drive has failed or is not present.
On, green	Off	The drive is present but not in use.
Blinking, green	Off	The drive is active and data is being transferred.
On, green	Blinking rapidly (about four flashes per second), amber	The RAID controller is identifying the drive.
On, green	On, amber	The RAID array has failed and cannot be recovered. You need to recreate a new array.
Blinking, green	Blinking slowly (about one flash per second), amber	The drive is being rebuilt.

Power supply status LEDs

Each hot-swap power supply has three status LEDs.




Figure 12. Power supply status LEDs

LED	Status	Description	Action
1 Input status LED	Off	The power supply is disconnected from the ac power source.	No action is needed.
	On, green	The power supply is connected to the ac power source.	No action is needed.
2 Output status LED	Off	The storage product is off or the power supply is not working normally.	Replace the power supply. See “Installing or replacing a hot-swap redundant power supply” on page 83.
	Blinking, green (about one flash every two seconds)	The power supply is in cold redundancy active mode.	No action is needed.
	Blinking, green (about two flashes each second)	The power supply is in cold redundancy sleep mode.	No action is needed.
	On, green	The storage product is on and the power supply is working normally.	No action is needed.
3 Fault LED	Off	The power supply is working normally.	No action is needed.
	On, amber	The power supply has failed.	Replace the power supply. See “Installing or replacing a hot-swap redundant power supply” on page 83.

Connecting the cables

To connect the signal cables from the installed hardware components, refer to the related information in the following topics:

- “Hot-swap-drive backplane” on page 22
- “ThinkServer RAID 710 Adapter” on page 21
- “System board components” on page 23

Chapter 4. Turning on and turning off the storage product

This chapter provides information about turning on and turning off the storage product.

Turning on the storage product


The storage product can be turned on in one of the following ways:

- After you finish unpacking and setting up the storage product, connect it to an ac power source. Press the power button on the front panel to turn on the storage product. See “Front panel” on page 15. The storage product needs about 30 seconds for the ThinkServer System Manager (TSM, also known as BMC) to initialize whenever you connect the storage product to an ac power source. If you press the power button on the front panel during this period, the storage product will not start immediately; it will start after the TSM initialization finishes.
 - When the Wake on LAN feature is enabled on the storage product that is connected to an ac power source and a LAN, a network administrator can remotely turn on or wake up the storage product from a management console using remote network management software.
 - You also can use the related TSM feature to remotely turn on the storage product through the management LAN.
-

Turning off the storage product

CAUTION:

The power control button on the device and the power switch on the power supply do not turn off the electrical current supplied to the device. The device also might have more than one power cord. To remove all electrical current from the device, ensure that all power cords are disconnected from the power source.



The storage product can be turned off in one of the following ways:

- Turn off the storage product from the operating system if your operating system supports this feature. After an orderly shutdown of the operating system, the storage product will turn off automatically. For instructions on how to shut down your specific operating system, refer to the related documentation or help system for the operating system.
- Press the power switch on the front panel to start an orderly shutdown of the operating system and turn off the storage product, if your operating system supports this feature.
- If your storage product stops responding and you cannot turn it off, press and hold the power switch on the front panel for four seconds or more. If you still cannot turn off the storage product, disconnect all power cords from the storage product.
- If the storage product is connected to a LAN, a network administrator can remotely turn off the storage product from a management console using remote network management software.
- You also can use the related TSM feature to remotely turn off the storage product through the management LAN.
- The storage product might be turned off as an automatic response to a critical system failure.

Notes:

- When you turn off the storage product and leave it connected to an ac power source, the storage product also can respond to a remote request to turn on the storage product. To remove all power from the storage product, you must disconnect the storage product from the ac power source.
- For information about your specific operating system, refer to the related documentation or help system for the operating system.

Chapter 5. Configuring the storage product

This chapter provides the following information to help you configure the storage product:

- “Using the Setup Utility program” on page 31
- “Configuring RAID” on page 38
- “Updating the firmware” on page 40

Using the Setup Utility program

This topic provides information about using the Setup Utility program.

The Setup Utility program is part of the storage product firmware. You can use the Setup Utility program to view and change the configuration settings of your storage product, regardless of which operating system you are using. However, the operating system settings might override any similar settings in the Setup Utility program.

Starting the Setup Utility program

This topic provides instructions on how to start the Setup Utility program.

To start the Setup Utility program, do the following:

1. Connect the storage product to an ac power source and press the power switch on the front panel to turn on the storage product. See “Turning on the storage product” on page 29.
2. Press the F1 key as soon as you see the screen. Then, wait for several seconds, and the Setup Utility program opens. If you have set a password, type the correct password to enter the Setup Utility program. For password information, see “Using passwords” on page 34.

Viewing information in the Setup Utility program

The Setup Utility program menu lists various items about the system configuration. Select a desired item to view information or change settings.

When working with the Setup Utility program, you must use the keyboard. The keys used to perform various tasks are displayed on the right bottom pane of each screen. You also can press the F1 key for general help about the keys. For most items, the corresponding help message is displayed on the right top pane of the screen when the item is selected. If the item has submenus, you can display the submenus by pressing Enter.

Setup Utility program interface

Depending on the BIOS version of your storage product, some menu or item information might differ slightly from the information in this topic.

Notes:

- The default settings already are optimized for you. Use the default value for any item you are not familiar with. Do not change the value of unfamiliar items to avoid unexpected problems. If you consider changing the storage product configuration, proceed with extreme caution. Setting the configuration incorrectly might cause unexpected results. If you cannot turn on the storage product because of incorrect BIOS settings, use the BIOS default settings jumper to restore the BIOS settings to the factory default settings. See “System board jumpers” on page 25.

- If you have changed any hardware in the storage product, you might need to upgrade the BIOS and the TSM firmware.

The Setup Utility program main interface consists of the following menus:

- “System Information menu” on page 32
- “Advanced Settings menu” on page 32
- “System Security menu” on page 33
- “TSM Settings menu” on page 33
- “Boot Manager menu” on page 33
- “Save & Exit menu” on page 33

Lenovo provides the BIOS update utility on the Lenovo Support Web site. You can download the BIOS update utility to update the BIOS. See “Updating or recovering the BIOS” on page 36.

If the power to your storage product is interrupted while the BIOS is being updated and your storage product cannot start correctly, the BIOS will recover to the previous version automatically. The recovery process lasts about 20 minutes. You also can use the BIOS recovery jumper to recover from a BIOS update failure. See “System board jumpers” on page 25.

System Information menu

After entering the Setup Utility program, you can see the **System Information** menu, which lists basic information about the BIOS, microprocessor type, memory, system date and time, and so on.

To set the system date and time on the **System Information** menu, see “Setting the system date and time” on page 34.

Advanced Settings menu

You can view or change various storage product component settings on the **Advanced Settings** menu in the Setup Utility program. The **Advanced Settings** menu contains various configuration submenus and items. On each submenu, press Enter to show selectable options and select a desired option by using the up and down arrow keys or type desired values from the keyboard. Some items are displayed on the menu only if the storage product supports the corresponding features.

Notes:

- **Enabled** means that the function is configured.
- **Disabled** means that the function is not configured.

The **Advanced Settings** menu contains the following submenus. For more information, enter the corresponding submenu and refer to the instructions on the screen.

- **Processor Settings:** View information about the installed microprocessors and set microprocessor configuration parameters.
- **Memory Settings:** View information about the installed memory modules and set memory configuration parameters.
- **Advanced Power Settings:** View and set power and performance parameters.
- **PCI/PCIE Settings:** View and set PCI or PCIe configuration parameters.
- **SATA Settings:** Set onboard SATA parameters.
- **USB Settings:** View and set USB configuration parameters, such as enabling or disabling USB devices.
- **Serial Settings:** View and set configuration parameters for the serial connector.

- **Wakeup Settings:** View and configure the wakeup timing and set the power state after a power failure.
- **Miscellaneous Settings:** View and configure some miscellaneous items, such as the NumLock key on the keyboard and the boot status code.

System Security menu

You can set passwords and configure the TPM function on the **System Security** menu in the Setup Utility program. For each menu item, press Enter to show selectable options and select a desired option by using the up and down arrow keys or type desired values from the keyboard. Some items are displayed on the menu only if the storage product supports the corresponding features.

Notes:

- **Enabled** means that the function is configured.
- **Disabled** means that the function is not configured.

The **System Security** menu contains the following items:

- **Administrator Password:** Set an administrator password to protect against unauthorized access to your storage product. See “Using passwords” on page 34.
- **User Password:** Set a user password to protect against unauthorized access to your storage product. See “Using passwords” on page 34.
- **Secure Boot:** Set secure boot parameters.

TSM Settings menu

You can view or change event log and BMC settings on the **TSM Settings** menu in the Setup Utility program. On each submenu, press Enter to view the information or show selectable options and select a desired option by using the up and down arrow keys. Some items are displayed on the menu only if the storage product supports the corresponding features.

The **TSM Settings** menu contains the following submenus. For more information, enter the corresponding submenu and refer to the instructions on the screen.

- **TSM Network Settings:** Set BMC management network configuration parameters.
- **User Account Settings:** Set BMC user account parameters.

Boot Manager menu

The **Boot Manager** menu in the Setup Utility program lists all the bootable devices installed in your storage product and the listed items vary depending on your storage product configuration.

The **Boot Sequence** submenu in the **Boot Manager** menu provides an interface to help you view or change the storage product startup options, including the startup sequence and boot priority for various devices. Changes in the startup options take effect when the storage product restarts. The startup sequence specifies the order in which the storage product checks devices to find a boot record. The storage product starts from the first boot record that it finds. For example, you can define a startup sequence that checks a disc in the optical drive, then checks the internal storage drive, and then checks a network device. For information about setting the startup sequence or selecting a startup device, see “Selecting a startup device” on page 35.

Save & Exit menu

After you finish viewing or changing settings in the Setup Utility program, you can choose a desired action from the **Save & Exit** menu to save changes, discard changes, or load default values, and exit the program. Press Enter to select the item on the **Save & Exit** menu, and then select **Yes** when prompted to confirm the action. For information about exiting the Setup Utility program, see “Exiting the Setup Utility program” on page 36.

The **Save & Exit** menu contains the following items:

- **Save Changes and Reset:** Save changes and then continue with further configuration in the Setup Utility program.
- **Discard Changes and Exit:** Discard changes, load previous values, and then exit the Setup Utility program.
- **Load Optimized Defaults:** Return to the optimized default settings.
- **Save as User Defaults:** Save the current settings as user default values.
- **Restore User Defaults:** Restore the user default values for all the items.
- **Pure UEFI OS Optimized Defaults:** Enable or disable optimized default settings for the pure UEFI operating system.

Setting the system date and time

To set the system date and time in the Setup Utility program, do the following:

1. Start the Setup Utility program. See “Starting the Setup Utility program” on page 31.
2. On the **System Information** menu, select **System Date** or **System Time**.
3. Use the Tab key to switch between data elements and type the numbers from the keyboard to set the system date and time.
4. Press F10 to save settings and exit the Setup Utility program.

Using passwords

By using the Setup Utility program, you can set a password to prevent unauthorized access to your storage product.

You do not have to set a password to use your storage product. However, using a password improves computing security. If you decide to set a password, read the following topics.

Setup Utility program password types

The following types of passwords are available in the Setup Utility program:

- **Administrator password**

Setting an administrator password deters unauthorized users from changing configuration settings. If you are responsible for maintaining the configuration settings of several computers, you might want to set an administrator password. When an administrator password is set, you are prompted to type a valid password each time you try to access the Setup Utility program. The Setup Utility program cannot be accessed until a valid password is typed in.

- **User password**

When a user password is set, you are prompted to type a valid password each time the storage product turns on. You cannot log in to any operating system until a valid password is typed in.

Note: If both the administrator password and user password are set, you can type either password to use the storage product. However, you must use your administrator password to change any configuration settings.

Password considerations

For security reasons, it is recommended to use a strong password that cannot be easily compromised.

Notes:

- The Setup Utility program passwords are not case sensitive.
- The storage product supports Setup Utility program passwords that consist of three to 32 characters.

To set a strong password, use the following guidelines:

- Have at least eight characters in length
- Contain at least one alphabetic character and one numeric character
- Not be your name or your user name
- Not be a common word or a common name
- Be significantly different from your previous passwords

Besides the alphabetic characters (a-z) and numeric characters (0-9), the storage product also supports characters typed using special keys on the keyboard for a password. Refer to the help message on the screen when setting a password to determine the valid special characters.

Setting, changing, or deleting a password

To set, change, or delete a password in the Setup Utility program, do the following:

1. Start the Setup Utility program. See “Starting the Setup Utility program” on page 31.
2. On the **System Security** menu, select **Administrator Password** to set an administrator password or select **User Password** to set a user password.
3. See “Password considerations” on page 34. Then, follow the instructions on the screen to set or change a password.
4. If you want to delete a password, type your current password. Press Enter when you are prompted to type a new password. Then, press Enter to confirm the new password. The previous password will be cleared.

Note: For security reasons, it is recommended that you always set a password for your storage product.

5. Press F10 to save settings and exit the Setup Utility program.

If you have forgotten the password, you can use the clear password jumper on the system board to erase the password. See “System board jumpers” on page 25. Then, set a new password for the storage product.

Selecting a startup device

If your storage product does not start up from a desired device such as the disc or storage drive as expected, do one of the following to select the startup device you want.

Note: Not all discs, storage drives, or other removable devices are bootable.

- To select a temporary startup device, do the following:

Note: Selecting a startup device using the following method does not permanently change the startup sequence.

1. Turn on or restart your storage product.
 2. When you see the logo screen, press F11 if your storage product is connected to a network and you want to start up the storage product from the network. Otherwise, press F12 to display the boot menu. The boot device selection window opens.
 3. In the boot device selection window, use the up and down arrow keys on the keyboard to switch between the selections. Press Enter to select the device of your choice. Then, the storage product will start up from the selected device.
- To view or permanently change the configured startup device sequence, do the following:
 1. Start the Setup Utility program. See “Starting the Setup Utility program” on page 31.

2. On the **Boot Sequence** submenu under the **Boot Manager** menu, follow the instructions on the screen to set the startup device for **Boot Option #1** to **Boot Option #5** depending on your needs. You also can set the boot priority for various devices. See “Boot Manager menu” on page 33.
3. Press F10 to save settings and exit the Setup Utility program. The storage product will follow the startup device sequence you have set each time you turn on the storage product.

Setting an Ethernet connector for system management

There are three RJ-45 Ethernet connectors on the rear of the storage product. The Ethernet connector 0 is for system management by default. However, you also can set the Ethernet connector 1 for system management use. To locate the three Ethernet connectors, see “Rear view of the storage product” on page 17.

To set the Ethernet connector for system management, do the following:

1. Start the Setup Utility program. See “Starting the Setup Utility program” on page 31.
2. On the **TSM Settings** menu, select **TSM Network Settings → TSM NIC Selection**.
3. Do one of the following:
 - To set the Ethernet connector 0 for system management, select **Dedicated Port**.
 - To set the Ethernet connector 1 for system management, select **Shared NIC Port**.
4. Press F10 to save settings and exit the Setup Utility program.

Exiting the Setup Utility program

After you finish viewing or changing settings, press Esc to return to the Setup Utility program main interface. If you are on a nested submenu, press Esc repeatedly until you reach the main interface. Then, you can do one of the following to exit the Setup Utility program:

- If you want to save the new settings and exit the Setup Utility program, press F10 or select **Save & Exit → Save Changes and Reset**. Otherwise, your changes will not be saved.
- If you do not want to save the new settings, select **Save & Exit → Discard Changes and Exit**.
- If you want to return to the default settings, press F9 or select **Save & Exit → Load Optimized Defaults**.

For more information about the **Save & Exit** menu in the Setup Utility program, see “Save & Exit menu” on page 33.

Updating or recovering the BIOS

This topic provides instructions on how to update the BIOS and how to recover from a POST and BIOS update failure.

Lenovo might make changes and enhancements to the BIOS and TSM firmware. When updates are released, they are available for download on the Lenovo Web site at <http://www.lenovo.com/drivers>. You can update the storage product firmware by downloading an update package and following the instructions on the Web page.

Updating (flashing) the BIOS

This topic provides instructions on how to update (flash) the BIOS.

Notes:

- Update the BIOS on your storage product only if the newer BIOS version specifically solves a problem you have. We do not recommend BIOS updates for storage products that do not need them. You can view the updated information for the new BIOS version in the installation instructions for the BIOS update utility program.

- Downgrading the BIOS to an earlier version is not recommended and might not be supported. An earlier BIOS version might not support the latest system configurations.
- If the power to your storage product is interrupted while the POST and BIOS are being updated, your storage product might not restart correctly. Ensure that you perform the BIOS update procedure in an environment with a steady power supply. Besides, ensure that your storage product can restart successfully without encountering hardware problems.
- After updating the BIOS firmware, all of your previous BIOS settings will be automatically restored. Check and reconfigure the BIOS settings for your specific needs.

To update (flash) the BIOS, do the following:

1. Go to <http://www.lenovo.com/drivers> and follow the instructions on the Web page to locate the BIOS update package.
2. Download the BIOS update package and the TXT file that contains installation instructions.
3. Print the TXT file and follow the instructions to update (flash) the BIOS.
4. Check and reconfigure the BIOS settings for your specific needs based on your note or refer to “Using the Setup Utility program” on page 31 after the BIOS update process is completed.

Recovering from a BIOS update failure

If the power to your storage product is interrupted while the BIOS is being updated, your storage product might not restart correctly. If this happens, perform the following procedures to recover from the BIOS update failure.

Note: If the operating system of your storage product is installed under EFI mode, you must reinstall the operating system after recovering the BIOS.

To recover from a BIOS update failure, do one of the following:

- **Using the automatic recovery feature**

1. Reconnect the storage product to an ac power source.
2. After the system health LED turns off, press the power button to turn on the storage product. The storage product will be turned on and then turned off automatically. Then, the recovery process starts. The recovery process lasts about 20 minutes. After the recovery process is completed, the storage product starts automatically.
3. Check and configure the BIOS settings for your specific needs. See “Using the Setup Utility program” on page 31.

- **Using the BIOS recovery jumper**

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Locate the BIOS recovery jumper on the system board. See “System board jumpers” on page 25. Then, remove any parts and disconnect any cables that might impede your access to the jumper.

Note: Do not remove the memory modules or microprocessors.

5. Remove the jumper cap from the jumper cap storage. See “System board jumpers” on page 25.
6. Note the orientation of the jumper cap and then install the jumper cap on the BIOS recovery jumper.

7. Connect the storage product to an ac power source. The storage product turns on and then turns off automatically.
8. Move the jumper cap back to the jumper cap storage. See “System board jumpers” on page 25.
9. Wait for several minutes. When the BIOS recovery process is completed, the storage product turns on automatically.
10. Ensure that the Setup Utility program starts normally. See “Starting the Setup Utility program” on page 31. Then, disconnect the storage product from the ac power source.
11. Reinstall any parts and reconnect any cables. Then, reinstall the storage product cover. See “Completing the parts replacement” on page 112.
12. Connect the storage product to an ac power source and turn on the storage product. Check and configure the BIOS settings for your specific needs. See “Using the Setup Utility program” on page 31.

Note: If you cannot recover the BIOS after using the instructions in this topic, the BIOS read-only memory (ROM) might be damaged. You must replace the system board. Contact the Lenovo Customer Support Center.

Configuring RAID

This topic provides information about RAID and the utility programs that are available for you to configure RAID.

This topic contains the following information:

- “About RAID” on page 38
- “Configuring RAID using the Lenovo ThinkServer Deployment Manager program” on page 39
- “Configuring the advanced SATA or SAS hardware RAID” on page 40

About RAID

RAID, an acronym for Redundant Array of Independent Disks, is a technology that provides increased storage functions and reliability through redundancy. This is achieved by combining multiple hard disk drives into a logical unit, where data is distributed across the drives in one of several ways called RAID levels.

When a group of independent physical hard disk drives are set up to use RAID technology, they are in a RAID array. This array distributes data across multiple hard disk drives, but the array appears to the host storage product as one single storage unit. Creating and using RAID arrays provides high performance, such as the expedited I/O performance, because several drives can be accessed simultaneously.

RAID drive groups also improve data storage reliability and fault tolerance compared with single-drive storage systems. Data loss resulting from a drive failure can be prevented by reconstructing missing data from the remaining drives.

The following list describes some of the most commonly used RAID levels:

- **RAID 0:** block-level striping without parity or mirroring
Simple stripe sets are normally referred to as RAID 0. RAID 0 uses striping to provide high data throughput, especially for large files in an environment that does not require fault tolerance. RAID 0 has no redundancy and it provides improved performance and additional storage without fault tolerance. Any drive failure destroys the array and the likelihood of failure increases with more drives in the array. RAID 0 does not implement error checking, so any error is uncorrectable. More drives in the array means higher bandwidth, but greater risk of data loss.
RAID 0 requires a minimum number of two hard disk drives.

- **RAID 1:** mirroring without parity or striping

RAID 1 uses mirroring so that data written to one drive is simultaneously written to another drive. This is good for small databases or other applications that require small capacity but complete data redundancy. RAID 1 provides fault tolerance from disk errors or failures and continues to operate as long as at least one drive in the mirrored set is functioning. With appropriate operating system support, there can be increased read performance and only a minimal write performance reduction.

RAID 1 requires a minimum number of two hard disk drives.

- **RAID 5:** block-level striping with distributed parity

RAID 5 uses disk striping and parity data across all drives (distributed parity) to provide high data throughput, especially for small random access. RAID 5 distributes parity along with the data and requires all drives but one to be present to operate; drive failure requires replacement, but the array is not destroyed by a single drive failure. Upon drive failure, any subsequent read operations can be calculated from the distributed parity so that the drive failure is masked from the end user. The array will have data loss in the event of a second drive failure and is vulnerable until the data that was on the failing drive is rebuilt onto a replacement drive. A single drive failure in the set will result in reduced performance of the entire set until the failing drive has been replaced and rebuilt.

RAID 5 requires a minimum number of three hard disk drives.

- **RAID 6:** block-level striping with distributed parity

RAID 6 uses distributed parity, with two independent parity blocks per stripe, and disk striping. A RAID 6 virtual drive can survive the loss of any two drives without losing data. A RAID 6 drive group is similar to a RAID 5 drive group. Blocks of data and parity information are written across all drives. The parity information is used to recover the data if one or two drives fail in the drive group.

RAID 6 requires a minimum number of three hard disk drives.

- **RAID 10:** a combination of RAID 0 and RAID 1

RAID 10 consists of striped data across mirrored spans. A RAID 10 drive group is a spanned drive group that creates a striped set from a series of mirrored drives. RAID 10 allows a maximum of eight spans. You must use an even number of drives in each RAID virtual drive in the span. The RAID 1 virtual drives must have the same stripe size. RAID 10 provides high data throughput and complete data redundancy but uses a larger number of spans.

RAID 10 requires a minimum number of four hard disk drives and also requires an even number of drives, for example, six hard disk drives or eight hard disk drives.

For detailed information about RAID, refer to “Introduction to RAID” in the *MegaRAID SAS Software User Guide* on the documentation DVD that comes with your storage product.

Configuring RAID using the Lenovo ThinkServer Deployment Manager program

Deployment Manager simplifies the process of configuring supported RAID. The help system for the program can be accessed directly from the program interface.

Deployment Manager has the following features for RAID configuration:

- For use with all supported RAID controllers
- Automatically detects hardware and lists all supported RAID configurations
- Configures one or more disk arrays per controller depending on the number of drives attached to the controller and the RAID level selected
- Supports hot-spare drives
- Creates a RAID response file that can be used to configure RAID controllers on similarly configured Lenovo storage products

See “Lenovo ThinkServer Deployment Manager” on page 12 and view the help system from the main interface of the program.

Configuring the advanced SATA or SAS hardware RAID

Your storage product comes with a RAID adapter to provide advanced SATA or SAS hardware RAID functions.

Note: Depending on the operating system, the total drive capacity of the primary RAID might be limited to 2 TB.

You can use the following programs or tools to configure the advanced SATA or SAS hardware RAID.

- MegaRAID Human Interface Infrastructure (HII) configuration utility
This utility enables you to configure RAID independently of the operating system. To display the HII configuration utility interface, start the storage product and press the F1 key as soon as you see the logo screen to enter the Setup Utility program. Then, select **Boot Manager → Adapters and UEFI Drivers**.
- MegaRAID Storage Manager program
This program provides graphical user interface (GUI) for you to create and manage storage configurations in an operating system environment.
- Storage Command Line Tool (StorCLI)
This is a command-line management tool that is used to configure RAID in an operating system environment.

To download the MegaRAID Storage Manager program and StorCLI, go to <http://www.lenovo.com/drivers> and follow the instructions on the Web page.

For more information about how to configure and manage the advanced SATA or SAS hardware RAID, refer to the *MegaRAID SAS Software User Guide* on the documentation DVD that comes with your storage product. This document also is available on the Lenovo Web site at: <http://www.lenovo.com/support>

Updating the firmware

When you replace a device in the storage product, you might have to either update the storage product with the latest version of the firmware that is stored in memory on the device or reflash the BIOS, the TSM firmware, and the FRU/SDR.

To update the firmware, do one of the following:

- Go to <http://www.lenovo.com/drivers> and follow the instructions on the Web page to check for the latest level of firmware, such as the BIOS updates and device drivers.
- Use the Lenovo ThinkServer Deployment Manager program. See “Lenovo ThinkServer Deployment Manager” on page 12.

Chapter 6. Replacing hardware

This chapter provides instructions on how to replace hardware for your storage product.

This chapter contains the following items:

- “Guidelines” on page 41
- “Removing the cover” on page 43
- “Installing, removing, or replacing hardware” on page 44
- “Completing the parts replacement” on page 112

For a list of Lenovo storage product options, go to:
<http://shop.lenovo.com/us/en/servers/network-storage/>

Guidelines

This topic provides some guidelines that you should read and understand before using your storage product.

Precautions

Before using the storage product, ensure that you read and understand the following precautions:

- Before using the product, ensure that you read and understand the multilingual safety instructions and the Lenovo Limited Warranty (LLW) on the documentation DVD that comes with the product. Reading and understanding the safety instructions reduces the risk of personal injury and damage to your product.
- When you install your new storage product, take the opportunity to download and apply the most recent firmware updates. This step will help to ensure that any known issues are addressed and that your storage product is ready to function at maximum levels of performance. To download firmware updates for your storage product, go to <http://www.lenovo.com/drivers> and follow the instructions on the Web page. See “Updating the firmware” on page 40 for more information.
- Before you install optional hardware devices, ensure that the storage product is working correctly. If the storage product is not working correctly, see Chapter 7 “Troubleshooting and diagnostics” on page 115 to do basic troubleshooting. If the problem cannot be solved, see Chapter 8 “Getting information, help, and service” on page 121.
- Observe good housekeeping in the area where you are working. Put removed covers and other parts in a safe place.
- If you must turn on the storage product while the storage product cover is removed, ensure that no one is near the storage product and that no tools or other objects have been left inside the storage product.
- Do not attempt to lift an object that you think is too heavy for you. If you have to lift a heavy object, observe the following precautions:
 - Ensure that you can stand safely without slipping.
 - Distribute the weight of the object equally between your feet.
 - Use a slow lifting force. Never move suddenly or twist when you lift a heavy object.
 - To avoid straining the muscles in your back, lift by standing or by pushing up with your leg muscles.
- Ensure that you have an adequate number of properly grounded electrical outlets for the storage product, monitor, and other devices.
- Back up all important data before you make changes to drives.
- Have a small flat-blade screwdriver available.

- You do not have to turn off the storage product to install or replace a hot-swap redundant power supply, hot-swap hard disk drives, hot-swap solid-state drives, or hot-plug USB devices. However, you must turn off the storage product before performing any steps that involve installing, removing, or replacing adapter cables or non-hot-swap devices or components.
- To view the LEDs on the system board and internal components, leave the storage product connected to power.
- When you are finished working on the storage product, reinstall all safety shields, guards, labels, and ground wires.

Handling static-sensitive devices

Attention: Do not open the static-protective package that contains the new part until the defective part has been removed from the storage product and you are ready to install the new part. Static electricity, although harmless to you, can seriously damage storage product components and parts.

When you handle storage product parts and components, take these precautions to avoid static-electricity damage:

- Limit your movement. Movement can cause static electricity to build up around you.
- The use of a grounding system is recommended. For example, it is recommended to wear an electrostatic discharge (ESD) wrist strap, if one is available. Ensure that you work in an ESD-safe area.
- Always carefully handle the parts and other components (such as PCI cards, memory modules, system boards, and microprocessors) by edges or frame. Do not touch solder joints, pins, or exposed circuitry.
- Do not leave the device where others can handle and possibly damage the device.
- Before you replace a new part, touch the static-protective package containing the new part to an unpainted metal part of the storage product for at least two seconds. This reduces static electricity from the package and your body.
- Remove the new part from the static-protective package and directly install it in the storage product without placing it on any other surface. If it is hard for you to do this in your specific situation, place the static-protective package of the new part on a smooth, level surface, and then place the new part on the static-protective package.
- Do not place the part on the storage product cover or other metal surface.
- Take additional care when handling devices during cold weather. Heating reduces indoor humidity and increases static electricity.

System reliability guidelines

To help ensure proper cooling and system reliability, strictly follow these guidelines:

- Each of the drive bays has a drive or a dummy tray installed; or there is an electromagnetic interface (EMI) protective panel or EMI shield installed to protect the drive cage.
- If the storage product supports hot-swap redundant power supplies, each of the power supply bay has a redundant power supply installed, or one bay has a redundant power supply installed while the other bay is covered by a shield.
- Leave adequate space around the storage product to ensure that the storage product cooling system works well. Leave approximately 50 mm (2 inches) of open space around the front and rear of the storage product. Do not place objects in front of the fans. For proper cooling and airflow, install the storage product cover before you turn on the storage product. Operating the storage product with the storage product cover removed might damage storage product components.
- Properly route the cables. For some options, such as PCI cards, follow the cabling instructions that come with the options in addition to the instructions in this manual.

- When replacing a hot-swap drive, install the new hot-swap drive as soon as possible.
- If your storage product has air ducts or air baffles, do not remove them while the storage product is running. Operating the storage product without the air ducts or air baffles might cause the microprocessor(s) to overheat.
- For storage products that support up to two microprocessors, ensure that the second microprocessor socket always contains a microprocessor or is protected by a microprocessor socket cover.

Working inside the storage product with the power on

Attention: Static electricity that is released to internal storage product components when the storage product is turned on might cause the storage product to halt, which might result in the loss of data. To avoid this potential problem, always use an ESD wrist strap or other grounding system when you work inside the storage product with the power on.

The storage product supports hot-swap devices and is designed to operate safely while it is turned on and the cover is removed. Follow these guidelines when you work inside the storage product with the power on:

- Avoid wearing loose-fitting clothing on your forearms. Button long-sleeved shirts before working inside the storage product; do not wear cuff links while you are working inside the storage product.
- Do not allow your necktie or scarf to hang inside the storage product.
- Remove jewelry, such as bracelets, necklaces, rings, and loose-fitting wrist watches.
- Remove items from your shirt pocket, such as pens and pencils. These items might fall into the storage product as you lean over it.
- Avoid dropping any metallic objects into the storage product, such as paper clips, hairpins, and screws.

Removing or extending the storage product from the rack cabinet

If the storage product is installed in a rack cabinet, remove or extend the storage product from the rack cabinet before installing or replacing hardware. Depending on the rail type, do one of the following:

- If the storage product is installed in a rack cabinet using static rails, remove the storage product from the rack cabinet and place it on a flat, clean, and static-protective surface. See the *Rack Installation Instructions* that comes with the storage product.
- If the storage product is installed in a rack cabinet using slide rails, press the rack handles to extend the storage product from the rack cabinet. However, if the working environment, cabling configuration, or the storage product location in the rack cabinet creates awkward conditions, remove the storage product from the rack cabinet. See the *Rack Installation Instructions* that comes with the storage product.

Removing the cover

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Depending on the model, your storage product might look slightly different from the illustrations in this topic.

To remove the cover, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets.

2. Disconnect all power cords from electrical outlets.
3. Disconnect the power cords, Input/Output (I/O) cables, and all other cables that are connected to the storage product.
4. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
5. Do the following to remove the storage product cover:
 - a. Use a screw driver to unscrew the cover lock to the open position as shown.
 - b. Fully open the cover latch.
 - c. Slide the storage product cover to the rear until it is disengaged from the chassis. Then, lift the storage product cover off the chassis and set it aside.

Note: It is recommended that you wait several minutes to let the storage product cool before removing the storage product cover.




Figure 13. Removing the storage product cover

Attention: For proper cooling and airflow, install the storage product cover before turning on the storage product. Operating the storage product for more than 30 minutes with the storage product cover removed might damage storage product components.

To reinstall the storage product cover, see “Reinstalling the storage product cover and reconnecting cables” on page 112.

Installing, removing, or replacing hardware

This topic provides instructions on how to install, remove, or replace hardware for your storage product. You can expand the capabilities of your storage product by adding new hardware devices, such as memory modules or other storage product options, and maintain your storage product by replacing the failing hardware devices.

If you are handling a storage product option, refer to the appropriate installation or removal instructions in this topic along with the instructions that come with the option.

Notes:

- Use only parts provided by Lenovo.
- Depending on the model, your storage product might look slightly different from the illustrations in this topic.

The EMI integrity and cooling of the storage product are protected by having all drive bays and PCIe card slots covered or occupied. When you install an internal drive or a PCIe card, save the EMI shield or dummy tray from the drive bay or save the PCIe card slot bracket in case that you later remove the device.

Attention: An unoccupied drive bay or PCIe card slot without a cover, shield, dummy tray, filler, or any other protection might impact the EMI integrity and cooling of the storage product, which might result in overheating or component damage.

Removing and reinstalling the rack handles

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

To remove and reinstall the rack handles, do the following:

1. On each side of the storage product, remove the five screws that secure the rack handle and then remove the rack handle from the chassis.




Figure 14. Removing the rack handles

2. To reinstall the rack handles, align the five screw holes in the rack handle with the corresponding holes in the chassis. Install the five screws to secure the rack handle on each side of the storage product.




Figure 15. Installing the rack handles

Removing and reinstalling the cooling shroud

To access some storage product components on the system board, remove the cooling shroud. To ensure proper cooling and airflow, reinstall the cooling shroud before turning on the storage product.

Removing the cooling shroud

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Depending on the model, your storage product might look slightly different from the illustrations in this topic.

To remove the cooling shroud, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.

4. Insert a finger into each of the two holes **1** in the cooling shroud and then lift the cooling shroud out of the storage product.

Attention: For proper cooling and airflow, reinstall the cooling shroud before turning on the storage product. Operating the storage product for more than 30 minutes with the cooling shroud removed might damage storage product components.




Figure 16. Removing the cooling shroud

Reinstalling the cooling shroud

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Depending on the model, your storage product might look slightly different from the illustrations in this topic.

To reinstall the cooling shroud, do the following:

1. Ensure that all components have been reassembled correctly and that no tools or loose screws are left inside your storage product.
2. Ensure that all internal cables are routed correctly and secured by any cable clips or ties in the storage product. Keep cables clear of the hinges and sides of the storage product chassis to avoid interference with reinstalling the cooling shroud.

- Note the orientation of the cooling shroud and then place it above the storage product so that the tabs on both sides of the cooling shroud are aligned with the corresponding holes or gaps in both sides of the chassis. Then, lower the cooling shroud into the chassis until it snaps into position.

Note: If necessary, gently press the cooling shroud on both sides so that the tabs on the cooling shroud completely engage with both sides of the chassis.




Figure 17. Reinstalling the cooling shroud

- Reinstall the storage product cover and reconnect cables to the storage product. For more information, refer to “Reinstalling the storage product cover and reconnecting cables” on page 112.

Installing or removing a memory module

Note: The memory modules are extremely sensitive to ESD. Ensure that you read and understand “Handling static-sensitive devices” on page 42 first and carefully perform the operation.

Memory module installation rules

Your storage product has 16 memory slots. The following list describes the memory module installation rules.

- Each slot supports 4 GB, 8 GB, and 16 GB double data rate 4 registered dual inline memory modules (DDR4 RDIMMs) with Error Checking and Correcting (ECC) technology.
- Each slot supports 32 GB double data rate 4 load reduction dual inline memory modules (DDR4 LRDIMMs) with ECC technology.
- Your storage product supports up to eight memory modules when one microprocessor is installed. Your storage product supports up to 16 memory modules when two microprocessors are installed.
- The minimum system memory is 4 GB (only one microprocessor installed and only one 4 GB RDIMM installed in the CPU1 DIMMA1 slot).
- The maximum system memory is 512 GB (two microprocessors installed and one 32 GB LRDIMM installed in each of the 16 memory slots).

For more information about the memory modules in your specific storage product model, use the Setup Utility program. See “Viewing information in the Setup Utility program” on page 31.

For a list of storage product options, go to:
<http://shop.lenovo.com/us/en/servers/network-storage/>

Before installing a memory module, ensure that you observe the following guidelines:

- All memory modules to be installed must be the same type. Your storage product supports the following types of memory modules:
 - DDR4 RDIMM with ECC technology
 - DDR4 LRDIMM with ECC technology
- When you install memory modules with different ranks in one channel, start from the farthest memory slot in the channel. Install the memory module that has the most ranks first.
- When you install memory modules with different frequencies into the memory slots for the same microprocessor, all the memory modules run at the lowest frequency.
- It is recommended that you install the high-frequency memory modules into the memory slots for the same microprocessor to ensure high performance.

The following illustration helps you to locate the memory slots on the system board. The following illustration shows the system board with two installed microprocessors (also known as CPU).




Figure 18. Memory slots on the system board

The following table provides information about the memory module installation rules for storage products that have only one microprocessor (CPU1) installed. The “X” mark indicates the memory slots into which the memory modules should be installed in different situations.

Table 1. Memory module installation rules for storage products with one microprocessor

CPU1 DIMM	A1	A2	B1	B2	C1	C2	D1	D2
1 DIMM	X							
2 DIMMs	X		X					
4 DIMMs	X		X		X		X	
8 DIMMs	X	X	X	X	X	X	X	X

The following table provides information about the memory module installation rules for storage products that have two microprocessors (CPU1 and CPU2) installed. The “X” mark indicates the memory slots into which the memory modules should be installed in different situations.

Table 2. Memory module installation rules for storage products with two microprocessors

	CPU1 DIMM								CPU2 DIMM							
	A1	A2	B1	B2	C1	C2	D1	D2	A1	A2	B1	B2	C1	C2	D1	D2
2 DIMMs	X								X							
4 DIMMs	X		X						X		X					
8 DIMMs	X		X		X		X		X		X		X		X	
16 DIMMs	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X

The following section explains the memory module installation rules in independent mode, mirroring mode, sparing mode, and lockstep mode.

Memory module installation order in independent mode

In independent mode, the RAS features are not available. For more information about the RAS features, refer to the related section in “Features” on page 7.

Notes:

- All memory modules to be installed must be the same type.
- When you install memory modules with different capacity, install the memory module that has the highest capacity first.

The following table explains the memory module installation order for storage products that have only one microprocessor (CPU1) installed.

Table 3. Memory module installation order in independent mode for storage products with one microprocessor

CPU1 DIMM	A1	A2	B1	B2	C1	C2	D1	D2
DIMM installation order	1	5	2	6	3	7	4	8

The following table explains the memory module installation order for storage products that have two microprocessors (CPU1 and CPU2) installed.

Table 4. Memory module installation order in independent mode for storage products with two microprocessors

	CPU1 DIMM								CPU2 DIMM							
	A1	A2	B1	B2	C1	C2	D1	D2	A1	A2	B1	B2	C1	C2	D1	D2
DIMM installation order	1	9	3	11	5	13	7	15	2	10	4	12	6	14	8	16

Memory module installation order in mirroring mode

In mirroring mode, the storage product maintains two identical copies of all data in memory and the RAS features are available. For more information about the RAS features, refer to the related section in “Features” on page 7.

Notes:

- All memory modules to be installed must be the same type with the same capacity, frequency, voltage, and number of ranks.
- All memory modules must be installed in pairs.

The following table explains the memory module installation order for storage products that have only one microprocessor (CPU1) installed.

Table 5. Memory module installation order in mirroring mode for storage products with one microprocessor

CPU1 DIMM	A1	A2	B1	B2	C1	C2	D1	D2
DIMM installation order	1	3	1	3	2	4	2	4

The following table explains the memory module installation order for storage products that have two microprocessors (CPU1 and CPU2) installed.

Table 6. Memory module installation order in mirroring mode for storage products with two microprocessors

	CPU1 DIMM								CPU2 DIMM							
	A1	A2	B1	B2	C1	C2	D1	D2	A1	A2	B1	B2	C1	C2	D1	D2
DIMM installation order	1	5	1	5	3	7	3	7	2	6	2	6	4	8	4	8

Memory module installation order in sparing mode

The sparing mode provides memory redundancy. In this mode, the RAS features are available. For more information about the RAS features, refer to the related section in “Features” on page 7.

Note: All memory modules to be installed must be the same type with the same capacity, frequency, voltage, and number of ranks.

Your storage product supports rank sparing mode. In rank sparing mode, one rank of a memory module works as the spare rank for the other ranks on the same channel. The spare rank is not available as system memory. To enable rank sparing mode, ensure that:

- At least three ranks are available in one channel.
- At least two memory modules are installed in one channel.

The following table explains the memory module installation order for storage products that have only one microprocessor (CPU1) installed.

Table 7. Memory module installation order in sparing mode for storage products with one microprocessor

CPU1 DIMM	A1	A2	B1	B2	C1	C2	D1	D2
DIMM installation order	1	1	2	2	3	3	4	4

The following table explains the memory module installation order for storage products that have two microprocessors (CPU1 and CPU2) installed.

Table 8. Memory module installation order in sparing mode for storage products with two microprocessors

	CPU1 DIMM								CPU2 DIMM							
	A1	A2	B1	B2	C1	C2	D1	D2	A1	A2	B1	B2	C1	C2	D1	D2
DIMM installation order	1	1	3	3	5	5	7	7	2	2	4	4	6	6	8	8

Memory module installation order in lockstep mode

In lockstep mode, the RAS features are available. For more information about the RAS features, refer to the related section in “Features” on page 7.

Notes:

- All memory modules to be installed must be the same type with the same capacity, frequency, voltage, and number of ranks.
- All memory modules must be installed in pairs.

The following table explains the memory module installation order for storage products that have only one microprocessor (CPU1) installed.

Table 9. Memory module installation order in lockstep mode for storage products with one microprocessor

CPU1 DIMM	A1	A2	B1	B2	C1	C2	D1	D2
DIMM installation order	1	3	1	3	2	4	2	4

The following table explains the memory module installation order for storage products that have two microprocessors (CPU1 and CPU2) installed.

Table 10. Memory module installation order in lockstep mode for storage products with two microprocessors

	CPU1 DIMM								CPU2 DIMM							
	A1	A2	B1	B2	C1	C2	D1	D2	A1	A2	B1	B2	C1	C2	D1	D2
DIMM installation order	1	5	1	5	3	7	3	7	2	6	2	6	4	8	4	8

Installing a memory module

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- To optimize system performance, ensure that you consider and follow the memory module installation rules when performing the operation. See “Memory module installation rules” on page 48.
- Use any documentation that comes with the memory module and follow those instructions in addition to the instructions in this topic.

To install a memory module, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the cooling shroud. See “Removing and reinstalling the cooling shroud” on page 46.
5. Locate the memory slots on the system board and read the memory module installation rules. See “Memory module installation rules” on page 48.
6. Remove any parts or disconnect any cables that might prevent your access to the memory slots.
7. Open the retaining clips of the appropriate memory slot.




Figure 19. Opening the retaining clips of the memory slots

8. Touch the static-protective package that contains the new memory module to any unpainted surface on the outside of the storage product. Then, take the new memory module out of the package.

Note: Carefully handle the memory module by its edges.

9. Position the new memory module over the memory slot. Ensure that the notch **1** on the new memory module is aligned with the key **2** in the memory slot. Then, press the new memory module straight down into the memory slot until the retaining clips close and the new memory module snaps into position.

Note: If there is a gap between the memory module and the retaining clips, the memory module has not been installed correctly. Open the retaining clips, remove the memory module, and then reinstall it into the memory slot until the retaining clips are completely closed.




Figure 20. Installing a memory module

10. Reinstall any parts or reconnect any cables that you have removed.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the installation, go to “Completing the parts replacement” on page 112.

Removing a memory module

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: To optimize system performance, ensure that you consider and follow the memory module installation rules when performing the operation. See “Memory module installation rules” on page 48.

To remove a memory module, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the cooling shroud. See “Removing and reinstalling the cooling shroud” on page 46.
5. Locate the memory slots on the system board and read the memory module installation rules. See “Memory module installation rules” on page 48.
6. Remove any parts or disconnect any cables that might prevent your access to the memory slots.

7. Locate the memory module that you want to remove and open the retaining clips on both ends of the memory slot. Then, grasp the memory module by its edges and carefully pull it straight up to remove it from the memory slot.




Figure 21. Removing a memory module

8. Reinstall any parts or reconnect any cables that you have removed.
9. If you are instructed to return the old memory module, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the removal procedure, go to “Completing the parts replacement” on page 112.

Installing or removing the ThinkServer System Manager Premium module

The ThinkServer System Manager Premium (TSM Premium) offers convenient, remote KVM access and control through the LAN or Internet. You can use the TSM Premium to gain location-independent remote access to respond to critical incidents and to undertake necessary maintenance. Therefore, working as an integrated solution in your storage product, the TSM Premium provides an increased level of manageability over the basic storage product management available. You can purchase a TSM Premium module from Lenovo.

For a list of storage product options, go to:
<http://shop.lenovo.com/us/en/servers/network-storage/>

Installing the TSM Premium module

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- Use any documentation that comes with the TSM Premium module and follow those instructions in addition to the instructions in this topic.
- Depending on the model, your storage product might look slightly different from the illustration in this topic.

To install the TSM Premium module, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the riser card assembly 2. See “Replacing the riser card assembly” on page 103.
5. Touch the static-protective package that contains the TSM Premium module to any unpainted surface on the outside of the storage product. Then, take the TSM Premium module out of the package.
6. Locate the TSM Premium module connector on the system board and then insert the TSM Premium module into the TSM Premium module connector.

Note: Ensure that the TSM Premium module is securely seated on the system board.




Figure 22. Installing the TSM Premium module

7. Reinstall the riser card assembly 2. See “Replacing the riser card assembly” on page 103.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the installation, go to “Completing the parts replacement” on page 112. For information about storage product remote management, download and read the *ThinkServer System Manager User Guide* at:
<http://www.lenovo.com/support>

Removing the TSM Premium module

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- Use any documentation that comes with the TSM Premium module and follow those instructions in addition to the instructions in this topic.
- If you remove the TSM Premium module, the iKVM function for storage product remote management will be unavailable.
- Depending on the model, your storage product might look slightly different from the illustration in this topic.

To remove the TSM Premium module, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the riser card assembly 2. See “Replacing the riser card assembly” on page 103.
5. Locate the TSM Premium module on the system board and then lift the TSM Premium module straight up to remove it from the TSM Premium module connector.




Figure 23. Removing the TSM Premium module

6. Reinstall the riser card assembly 2. See “Replacing the riser card assembly” on page 103.
7. If you are instructed to return the old TSM Premium module, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the removal procedure, go to “Completing the parts replacement” on page 112.

Installing or removing the RAID 110i upgrade key

The Lenovo ThinkServer RAID 110i upgrade key (hereinafter referred to as RAID 110i key) activates RAID 5 for the onboard SATA software RAID. As a result, the capability of the system board is expanded. You can purchase a RAID 110i key from Lenovo and install it to the RAID upgrade key connector on the system board.

For a list of storage product options, go to:

<http://shop.lenovo.com/us/en/servers/network-storage/>

Installing the RAID 110i key

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Use any documentation that comes with the RAID 110i key and follow those instructions in addition to the instructions in this topic.

To install the RAID 110i key, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Touch the static-protective package that contains the RAID 110i key to any unpainted surface on the outside of the storage product. Then, take the RAID 110i key out of the package.

Note: Carefully handle the RAID 110i key by its edges.

5. Locate the RAID upgrade key connector on the system board and then insert the RAID 110i key into the RAID upgrade key connector on the system board.




Figure 24. Installing the RAID 110i key

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the installation, go to “Completing the parts replacement” on page 112.

Removing the RAID 110i key

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- If you remove the RAID 110i key, the onboard SATA software RAID function will be unavailable.
- Use any documentation that comes with the RAID 110i key and follow those instructions in addition to the instructions in this topic.

To remove the RAID 110i key, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Locate the RAID upgrade key connector on the system board. Then, remove the installed RAID 110i key by lifting it straight up.

Note: Carefully handle the RAID 110i key by its edges.




Figure 25. Removing the RAID 110i key

5. If you are instructed to return the old RAID 110i key, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the removal procedure, go to “Completing the parts replacement” on page 112.

Installing or removing the ThinkServer RAID Super Capacitor Module

The ThinkServer RAID Super Capacitor Module protects the cache memory on the installed ThinkServer RAID Adapter. You can purchase a ThinkServer RAID Super Capacitor Module from Lenovo.

For a list of storage product options, go to:
<http://shop.lenovo.com/us/en/servers/network-storage/>

Installing the ThinkServer RAID Super Capacitor Module

Attention: Do not open your server or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- You can install two ThinkServer RAID Super Capacitor Modules in your storage product.
- Use any documentation that comes with the ThinkServer RAID Super Capacitor Module and follow those instructions in addition to the instructions in this topic.

To install the ThinkServer RAID Super Capacitor Module, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Touch the static-protective package that contains the ThinkServer RAID Super Capacitor Module to any unpainted surface on the outside of the storage product. Then, take the ThinkServer RAID Super Capacitor Module out of the package.
5. Locate the place for installing the Super Capacitor Module in the storage product. See “Storage product components” on page 19.
6. Install the Super Capacitor Module into the holder.




Figure 26. Installing the Super Capacitor Module into the holder

7. Note the orientation of the ThinkServer RAID Super Capacitor Module. Then, lower the Super Capacitor Module and gently slide it until it is secured by the mounting studs on the chassis.

Note: Depending on your storage product model, refer to one of the following illustrations below.




Figure 27. Installing the ThinkServer RAID Super Capacitor Module

8. Connect the ThinkServer RAID Super Capacitor Module to a RAID card.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the installation, go to “Completing the parts replacement” on page 112.

Removing the ThinkServer RAID Super Capacitor Module

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Use any documentation that comes with the ThinkServer RAID Super Capacitor Module and follow those instructions in addition to the instructions in this topic.

To remove the ThinkServer RAID Super Capacitor Module, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Disconnect the cable of the ThinkServer RAID Super Capacitor Module from the RAID card.

5. Gently lift the plastic tab **1** that secures the ThinkServer RAID Super Capacitor Module. Then, slide the ThinkServer RAID Super Capacitor Module as shown to completely remove it from the chassis.




Figure 28. Removing the ThinkServer RAID Super Capacitor Module

6. Remove the Super Capacitor Module from the holder.




Figure 29. Removing the Super Capacitor Module from the holder

7. If you are instructed to return the old ThinkServer RAID Super Capacitor Module, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the removal procedure, go to “Completing the parts replacement” on page 112.

Installing or removing a PCIe card

This topic provides instructions on how to install or remove a PCIe card, such as an Ethernet card, a RAID card, or any other supported PCIe cards.

Note: The PCIe card is extremely sensitive to ESD. Ensure that you read and understand “Handling static-sensitive devices” on page 42 first and carefully perform the operation.

Installing a PCIe card

<p>Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.</p>
--

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

To install a PCIe card on the riser card assembly, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the riser card assembly on which you want to install the PCIe card. See “Replacing the riser card assembly” on page 103.

5. Pivot the card latch to the open position.




Figure 30. Opening the PCIe card latch

6. Remove the PCIe slot bracket from the riser card assembly. Store the bracket in case that you later remove the PCIe card and need the bracket to cover the place.




Figure 31. Removing a PCIe slot bracket

7. Touch the static-protective package that contains the PCIe card to any unpainted surface on the outside of the storage product. Then, take the PCIe card out of the package.

Note: Carefully handle the PCIe card by its edges.

8. Carefully press the PCIe card straight into the PCIe slot until it is securely seated.




Figure 32. Installing a PCIe card

9. Pivot the card latch to the closed position to secure the PCIe card in position.




Figure 33. Pivoting the card latch to the closed position

10. Depending on the type of the PCIe card, you might need to connect any required cables. Refer to the documentation that comes with the PCIe card for specific information.

11. Reinstall the riser card assembly with the PCIe card to the system board. See “Replacing the riser card assembly” on page 103.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the installation, go to “Completing the parts replacement” on page 112. Then, continue with the following procedure to install the PCIe card driver if required.

Removing a PCIe card

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

To remove a PCIe card from the riser card assembly, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the riser card assembly and lay it upside down on a flat, clean, and static-protective surface. See “Replacing the riser card assembly” on page 103.
5. Pivot the card latch to the open position.




Figure 34. Pivoting the card latch to the open position

6. Grasp the PCIe card by its edges and carefully pull it out of the PCIe slot on the riser card assembly.

Note: The PCIe card might fit tightly into the PCIe slot. If necessary, alternate moving each side of the PCIe card a small and equal amount until it is completely removed from the slot.




Figure 35. Removing the PCIe card

7. Install a new PCIe card to replace the old one or install a PCIe card slot bracket to cover the place. See “Installing a PCIe card” on page 63.
8. Reinstall the riser card assembly. See “Replacing the riser card assembly” on page 103.
9. If you are instructed to return the old PCIe card, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the removal procedure, go to “Completing the parts replacement” on page 112.

Installing or removing the optical module

The optical module enables you to connect two network devices with optical fiber cables. The optical module is needed only on some PCIe cards.

Note: The optical module is extremely sensitive to ESD. Ensure that you read and understand “Handling static-sensitive devices” on page 42 first and carefully perform the operation.

Installing the optical module

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- The optical module and the PCIe card might look different from the illustration in this topic.
- Before you install the optical module, ensure that the PCIe card that requires the optical module is installed in the storage product. See “Installing a PCIe card” on page 63.

To install the optical module, do the following:

1. Locate the two holes at the rear of the PCIe card for installing the optical module.
2. Touch the static-protective package that contains the optical module to any unpainted surface on the outside of the storage product. Then, take the optical module out of the package.
3. With the optical module handle in the open position, insert the optical module into one of the two holes in the PCIe card.




Figure 36. Installing the optical module

4. Pivot the optical module handle to the closed position to secure the optical module in place.




Figure 37. Pivoting the optical module handle to the closed position

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the installation, go to “Completing the parts replacement” on page 112.

Removing the optical module

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: The optical module and the PCIe card might look different from the illustration in this topic.

To remove the optical module, do the following:

1. Locate the optical module at the rear of your storage product.

2. Pivot the optical module handle to the open position.




Figure 38. Pivoting the optical module handle

3. Gently pull the optical module out from the PCIe card.




Figure 39. Removing the optical module

4. If you are instructed to return the old optical module, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the removal procedure, go to “Completing the parts replacement” on page 112.

Installing or removing the intrusion switch

The intrusion switch prevents your storage product from logging in to the operating system when the storage product cover is not properly installed or closed. You can purchase an intrusion switch from Lenovo.

Installing the intrusion switch

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Use any documentation that comes with the intrusion switch and follow those instructions in addition to the instructions in this topic.

To install the intrusion switch, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Touch the static-protective package that contains the intrusion switch to any unpainted surface on the outside of the storage product. Then, take the intrusion switch out of the package.
5. Press the tab **1** outward as shown and then lower the intrusion switch until it is secured in the socket.




Figure 40. Installing the intrusion switch

6. Connect the intrusion switch cable to the intrusion switch connector on the system board. See “System board components” on page 23.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the installation, go to “Completing the parts replacement” on page 112.

Removing the intrusion switch

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- If you remove the intrusion switch, you will not get the warning message when logging in to your storage product with the cover removed.
- Use any documentation that comes with the intrusion switch and follow those instructions in addition to the instructions in this topic.

To remove the intrusion switch, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Locate the intrusion switch and disconnect the cable from the system board.
5. Press the tab **1** outward and lift the intrusion switch out of the socket.




Figure 41. Removing the intrusion switch

6. If you are instructed to return the old intrusion switch, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the removal procedure, go to “Completing the parts replacement” on page 112.

Installing or replacing a heat sink

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

CAUTION:

The heat sink might be very hot. Turn off the storage product and wait several minutes to let the storage product cool before removing the storage product cover.

Note: Use any documentation that comes with the heat sink and follow those instructions in addition to the instructions in this topic.

To install or replace a heat sink, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the cooling shroud. See “Removing and reinstalling the cooling shroud” on page 46.
5. Locate the heat sink you want to replace or the place for installing the second heat sink. See “Storage product components” on page 19.

6. If you are replacing a heat sink, remove the four screws that secure the heat sink to the system board. It is recommended that you carefully remove the four screws from the system board using the following method to avoid any possible damage to the system board.
 - a. Partially remove screw **1**, then completely remove screw **3**, and then return to screw **1** and completely remove it.
 - b. Partially remove screw **2**, then completely remove screw **4**, and then return to screw **2** and completely remove it.

Note: The four screws are integrated parts of the heat sink. Do not try to remove the four screws from the heat sink.




Figure 42. Removing the heat sink

7. Gently twist the heat sink to free it from the microprocessor and then lift the heat sink off the system board.
8. Lay aside the old heat sink. Touch the static-protective package that contains the new heat sink to any unpainted surface on the outside of the storage product. Then, take the new heat sink out of the package.

Notes:

- If you are replacing a heat sink, use a cleaning pad that might come with the new heat sink to wipe the thermal grease from the top of the microprocessor before installing the new heat sink. Dispose of the cleaning pad after all of the thermal grease is removed from the microprocessor.
 - When handling the new heat sink, do not touch the thermal grease on the bottom of it.
9. Remove any protective cover that protects the thermal grease on the bottom of the new heat sink. Then, place the new heat sink on the system board so that the four screws on the new heat sink are aligned with the corresponding mounting studs on the system board.

10. Install the four screws to secure the new heat sink on the system board. It is recommended that you carefully install the four screws using the following method to avoid any possible damage to the system board.
 - a. Partially tighten screw **1**, then firmly tighten screw **3**, and then return to screw **1** and firmly tighten it. Do not over-tighten the screws.
 - b. Partially tighten screw **2**, then firmly tighten screw **4**, and then return to screw **2** and firmly tighten it. Do not over-tighten the screws.




Figure 43. Installing the screws to secure the heat sink

11. If you are instructed to return the old heat sink, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the installation or replacement, go to “Completing the parts replacement” on page 112.

Installing or replacing the microprocessor

This topic provides instructions on how to install or replace the microprocessor.

Installing the second microprocessor

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Depending on the model, your storage product might come with one or two microprocessors. For storage product models with one microprocessor, the microprocessor is installed in the microprocessor socket 1 and the microprocessor socket 2 is protected by a plastic socket cover. You can purchase a microprocessor option kit from Lenovo and install the second microprocessor to expand system capabilities.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

CAUTION:





The heat sinks and microprocessors might be very hot. Turn off the storage product and wait several minutes to let the storage product cool before removing the storage product cover.

Notes:

- Ensure that you install the correct type of microprocessor option your storage product supports. See “Features” on page 7. When two microprocessors are installed, both must have the same core voltage and core speed.
- Use any documentation that comes with the microprocessor option kit and follow those instructions in addition to the instructions in this topic.
- Your microprocessor, socket, and socket cover might look slightly different from the illustrations in this topic.

To install the second microprocessor, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the cooling shroud. See “Removing and reinstalling the cooling shroud” on page 46.
5. Locate the microprocessor socket 2 on the system board. See “System board components” on page 23.
6. Open the small handle **1** first by gently pressing down the handle a little bit and then pushing the handle inward to release it from the secured position. Then, open the other small handle **2** in the same way.

Note: There are two marks on the microprocessor retainer. Open the small handle marked with  first and then open the other small handle marked with . Always follow the correct sequence when you open the small handles.




Figure 44. Opening the handles

7. Gently press the microprocessor retainer to open it. Ensure that the small handles and the microprocessor retainer are in the fully open position.

Note: Do not drop anything onto the microprocessor socket while it is exposed. The socket pins must be kept as clean as possible.




Figure 45. Opening the microprocessor retainer

8. Touch the static-protective package that contains the new microprocessor to any unpainted surface on the outside of the storage product. Then, remove the new microprocessor from the package.
9. Remove the new microprocessor from the protective cover that protects the gold contacts on the bottom of the new microprocessor. Do not touch the pins on the microprocessor socket and the gold contacts on the bottom of the new microprocessor.




Figure 46. Do not touch the pins

10. Note the orientation of the new microprocessor. Hold the new microprocessor by its edges and align the notches **1** on it with the tabs **2** in the microprocessor socket. Then, carefully lower the new microprocessor straight down into the microprocessor socket.

Note: The small triangle **3** on one corner of the new microprocessor is the microprocessor orientation indicator. The new microprocessor is in the correct orientation when this indicator faces the beveled corner **4** of the microprocessor socket.




Figure 47. Installing the microprocessor

11. Remove the plastic microprocessor socket cover. Store the microprocessor socket cover in case that you later remove the microprocessor and need the socket cover to protect the pins on the socket.

Note: Do not remove the socket cover until you install a microprocessor into the socket. If you remove the microprocessor, install the socket cover or a new microprocessor immediately.






Figure 48. Removing the microprocessor socket cover

12. Close the microprocessor retainer. Then, close the small handle **1** first and then close the small handle **2** to lock the retainer into position and secure the new microprocessor in the socket.

Note: There are two marks on the microprocessor retainer. Open the small handle marked with  first and then open the other small handle marked with . Always follow the correct sequence when you open the small handles.




Figure 49. Securing the microprocessor in the socket

13. Install the new heat sink that comes with the microprocessor option kit. See “Installing or replacing a heat sink” on page 72.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the installation, go to “Completing the parts replacement” on page 112.

Replacing the microprocessor

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

CAUTION:



The heat sink and microprocessor might be very hot. Turn off the storage product and wait several minutes to let the storage product cool before removing the storage product cover.



Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- Ensure that the new microprocessor is the correct type your storage product supports. See “Memory module installation rules” on page 48. When two microprocessors are installed, both must have the same core voltage and core speed.
- Use any documentation that comes with the microprocessor option kit and follow those instructions in addition to the instructions in this topic.
- Your microprocessor, socket, and socket cover might look slightly different from the illustrations in this topic.

To replace the microprocessor, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the cooling shroud. See “Removing and reinstalling the cooling shroud” on page 46.
5. Remove the heat sink. See “Installing or replacing a heat sink” on page 72.
6. Locate the microprocessor socket. Open the small handle **1** first by gently pressing down the handle a little bit and then pushing the handle inward to release it from the secured position. Then, open the other small handle **2** in the same way.

Note: There are two marks on the microprocessor retainer. Open the small handle marked with  first and then open the other small handle marked with . Always follow the correct sequence when you open the small handles.




Figure 50. Opening the handles

7. Gently press the microprocessor retainer as shown to open it. Ensure that the small handles and the microprocessor retainer are in the fully open position.




Figure 51. Opening the microprocessor retainer

8. Touch only the edges of the microprocessor and carefully lift it straight up and out of the microprocessor socket. Place the old microprocessor on a static-protective surface.

Notes:

- a. Do not touch the gold contacts on the bottom of the microprocessor.
- b. Do not drop anything onto the microprocessor socket while it is exposed. The socket pins must be kept as clean as possible.




Figure 52. Removing the microprocessor

9. Touch the static-protective package that contains the new microprocessor to any unpainted surface on the outside of the storage product. Then, remove the new microprocessor from the package.

10. Remove the new microprocessor from the protective cover that protects the gold contacts on the bottom of the new microprocessor. Do not touch the pins on the microprocessor socket and the gold contacts on the bottom of the new microprocessor.




Figure 53. Do not touch the pins

11. Note the orientation of the new microprocessor. Hold the new microprocessor by its edges and align the notches **1** on it with the tabs **2** in the microprocessor socket. Then, carefully lower the new microprocessor straight down into the microprocessor socket.

Note: The small triangle **3** on one corner of the new microprocessor is the microprocessor orientation indicator. The new microprocessor is in the correct orientation when this indicator faces the beveled corner **4** of the microprocessor socket.






Figure 54. Installing the microprocessor

12. Close the microprocessor retainer. Close the small handle **1** first. Then, close the small handle **2** to lock the retainer into position and secure the new microprocessor in the socket.

Note: There are two marks on the microprocessor retainer. Ensure that you close the small handle marked with  first and then close the small handle marked with . Always follow the correct sequence when you close the small handles.




Figure 55. Securing the microprocessor in the socket

13. Use a cleaning pad to wipe the thermal grease from the removed heat sink. Dispose of the cleaning pad after all of the thermal grease is removed.
14. Use one of the following methods to apply appropriate amount of thermal grease to the top of the newly installed microprocessor in the shape of a cross or a circle as shown. Either too much or too less application of thermal grease can cause a thermal problem due to imperfect contact with the components.

Notes:

- Do not touch the thermal grease.
- Keep the thermal grease off the system board.



Figure 56. Applying the thermal grease to the top of the microprocessor

15. Reinstall the heat sink. See “Installing or replacing a heat sink” on page 72.
16. If you are instructed to return the old microprocessor, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.


- To complete the replacement, go to “Completing the parts replacement” on page 112.

Installing or replacing a hot-swap redundant power supply

Depending on the model, your storage product might come with one or two hot-swap redundant power supplies. When the storage product is populated with two hot-swap redundant power supplies, the storage product can withstand a power loss from either power supply. This helps you avoid significant interruption to the operation of the storage product when a power supply fails. You can replace the failing hot-swap redundant power supply without turning off the storage product.

CAUTION:

Hazardous moving parts. Keep fingers and other body parts away.



CAUTION:

Never remove the cover on a power supply or any part that has the following label attached.



Hazardous voltage, current, and energy levels are present inside any component that has this label attached. There are no serviceable parts inside these components. If you suspect a problem with one of these parts, contact a service technician.

Notes:

- To maintain the EMI integrity and cooling of the storage product, install a new power supply as soon as you remove the failing one. Cover the other bay with a shield if you just use one power supply to provide power.
- Use any documentation that comes with the new power supply and follow those instructions in addition to the instructions in this topic.

Installing a hot-swap redundant power supply

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

To install a hot-swap redundant power supply, do the following:

1. Touch the static-protective package that contains the new hot-swap redundant power supply to any unpainted surface on the outside of the storage product. Then, take the new hot-swap redundant power supply out of the package.

2. If you are installing a power supply, locate the bay for the power supply in the rear of your storage product. Insert your index finger and thumb into the holes in the metal shield that protects the bay and pull the shield out of the chassis. Store the shield in case that you later remove the power supply and need the shield to cover the bay.




Figure 57. Removing the protective shield for the power supply bay

3. Note the orientation of the new hot-swap redundant power supply and then slide the new hot-swap redundant power supply into the chassis until it snaps into position.




Figure 58. Installing a hot-swap redundant power supply

4. Connect the power cord to the power connector on the new hot-swap redundant power supply. Then, check the status LED near the power connector. When the LED is lit in green, it indicates that the hot-swap redundant power supply is working correctly. When the LED is lit in amber, it indicates that the hot-swap redundant power supply is likely to fail or has failed. You need to reinstall or replace it.

Replacing a hot-swap redundant power supply

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Use any documentation that comes with the hot-swap redundant power supply and follow those instructions in addition to the instructions in this topic.

To replace a hot-swap redundant power supply, do the following:

1. Locate the failing hot-swap redundant power supply in the rear of your storage product. Then, disconnect the power cord from the failing hot-swap redundant power supply.

2. Press the tab **1** inward and carefully pull the handle **2** to slide the hot-swap redundant power supply out of the chassis.

Note: Do not use too much force. You can first carefully slide the hot-swap redundant power supply a little bit out to release it from the secured position. Then, completely slide it out of the chassis.




Figure 59. Removing a hot-swap redundant power supply

3. Install a new hot-swap redundant power supply. See “Installing a hot-swap redundant power supply” on page 83.
4. If you are instructed to return the old hot-swap redundant power supply, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

Installing or replacing a hot-swap hard disk drive

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

You can install or replace a hot-swap hard disk drive without turning off the storage product, which helps you avoid significant interruption to the operation of the system.

For a list of storage product options, go to:
<http://shop.lenovo.com/us/en/servers/network-storage/>

The EMI integrity and cooling of the storage product are protected by having all drive bays covered or occupied. The number of the installed hard disk drives in your storage product varies depending on the storage product model. The vacant bays are occupied by dummy hard-disk-drive trays. When you install a hot-swap hard disk drive, save the removed dummy hard-disk-drive tray from the drive bay in case that you later remove the hot-swap hard disk drive and need the dummy tray to cover the place.

Attention: An unoccupied drive bay without any other protection might impact the EMI integrity and cooling of the storage product, which might result in overheating or component damage. To maintain the EMI

integrity and cooling of the storage product, install a new hot-swap hard disk drive as soon as you remove the failing one or the dummy tray.

Before you begin, review the following hard disk drive installation rules:

- Follow the order of the hard-disk-drive bays when installing a hard disk drive. See “Front view of the storage product” on page 14 to locate the hard-disk-drive bays in your storage product.
- For RAID configuration, the hard disk drives must be the same type with the same capacity if they are within a single RAID array. For more information, see “Configuring RAID” on page 38.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- Depending on the model, your storage product might come with 3.5-inch hot-swap hard disk drives or 2.5-inch hot-swap hard disk drives. The illustrations in this topic are based on storage product models with 3.5-inch hot-swap hard disk drives. For other models, the replacement procedure is similar.
- Use any documentation that comes with the hot-swap hard disk drive and follow those instructions in addition to the instructions in this topic.

To install or replace a hot-swap hard disk drive, do the following:

1. Locate the appropriate hard-disk-drive bay. See “Front view of the storage product” on page 14.
2. Press the release button **1** to open the handle of the hot-swap hard disk drive or the dummy tray.




Figure 60. Opening the handle of a hard disk drive




Figure 61. Opening the handle of a dummy hard-disk-drive tray

3. Pull the handle and carefully slide the hot-swap hard disk drive or the dummy tray out of the front of the chassis.




Figure 62. Removing the hot-swap hard disk drive or the dummy tray

4. Touch the static-protective package that contains the new hot-swap hard disk drive to any unpainted surface on the outside of the storage product. Then, take the new hot-swap hard disk drive out of the package.

Note: Do not touch the circuit board on the hard disk drive.

5. Slide the new hot-swap hard disk drive into the drive bay from the front until it snaps into position and then completely close the handle.




Figure 63. Installing the hot-swap hard disk drive

6. Check the hot-swap hard-disk-drive status LEDs to ensure that the hard disk drive is operating correctly. You might have to restart the storage product for the newly installed hard disk drive to be recognized. See “Hot-swap-drive status LEDs” on page 27. If the hard disk drive is faulty, you need to reinstall or replace it until it is operating correctly.

7. Do one of the following:

- If you are installing a hot-swap hard disk drive, save the removed dummy hard-disk-drive tray in case that you later remove the hot-swap hard disk drive and need a dummy tray to cover the drive bay.
- If you are replacing a hot-swap hard disk drive and are instructed to return the old hot-swap hard disk drive, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To configure RAID, go to “Configuring RAID” on page 38.

Installing or replacing a 2.5-inch solid-state drive into a 3.5-inch-drive bay

You can install or replace a hot-swap solid-state drive without turning off the storage product, which helps you avoid significant interruption to the operation of the system.

For a list of storage product options, go to:

<http://shop.lenovo.com/us/en/servers/network-storage/>

The EMI integrity and cooling of the storage product are protected by having all drive bays covered or occupied. The number of the installed hard disk drives or solid-state drives in your storage product varies depending on the storage product model. The vacant bays are occupied by dummy hard-disk-drive trays. When you install a hot-swap hard disk drive or solid-state drive, save the removed dummy hard-disk-drive tray from the drive bay in case that you later remove the hot-swap hard disk drive or solid-state drive and need the dummy tray to cover the place.

Attention: An unoccupied drive bay without any other protection might impact the EMI integrity and cooling of the storage product, which might result in overheating or component damage. To maintain the EMI integrity and cooling of the storage product, install a new hot-swap hard disk drive or solid-state drive as soon as you remove the failing one or the dummy tray.

Before you begin, review the following solid-state drive installation rules:

- Follow the order of the hard-disk-drive bays when installing a solid-state drive. See “Storage product components” on page 19 to locate the hard-disk-drive bays in your storage product.
- For RAID configuration, the solid-state drives must be the same type with the same capacity if they are within a single RAID array. For more information, see “Configuring RAID” on page 38.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- Depending on the model, your storage product might come with 3.5-inch hot-swap hard disk drives or 2.5-inch hot-swap hard disk drives. The illustrations in this topic are based on storage product models with 3.5-inch hot-swap hard disk drives. For other models, the replacement procedure is similar.
- Depending on the model, your storage product might look slightly different from the illustrations in this topic.
- Use any documentation that comes with the solid-state drive and follow those instructions in addition to the instructions in this topic.

Installing a 2.5-inch solid-state drive into a 3.5-inch hard-disk-drive bay

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Ensure that you have a 3.5-inch to 2.5-inch drive adapter and a 3.5-inch drive bracket available before the installation.

To install a 2.5-inch solid-state drive into a 3.5-inch hard-disk-drive bay, do the following:

1. Locate the appropriate hard-disk-drive bay. See “Front view of the storage product” on page 14.
2. Press the release button **1** to open the handle of the dummy hard-disk-drive tray.




Figure 64. Opening the handle of the dummy hard-disk-drive tray

3. Pull the handle and carefully slide the dummy hard-disk-drive tray out of the front of the chassis.




Figure 65. Removing the dummy hard-disk-drive tray

4. Touch the static-protective package that contains the 2.5-inch solid-state drive to any unpainted surface on the outside of the storage product. Then, take the solid-state drive out of the package.

Note: Do not touch the circuit board on the solid-state drive.

5. Position the 2.5-inch solid-state drive into the 3.5-inch to 2.5-inch drive adapter as shown in the following illustration.




Figure 66. Positioning the 2.5-inch solid-state drive into the drive adapter

6. Align the two screw holes in the solid-state drive with the corresponding holes in the drive adapter. Then, install the two screws to secure the solid-state drive to the drive adapter.




Figure 67. Installing the screws to secure the solid-state drive to the drive adapter

7. Position the drive adapter with the solid-state drive into the 3.5-inch drive bracket.

- Align the screw holes in the drive adapter and the solid-state drive with the corresponding holes in the drive bracket. Then, install the five screws to secure the drive adapter and the solid-state drive to the bracket.




Figure 68. Installing the screws to secure the drive adapter and the solid-state drive to the bracket

- Slide the bracket with the solid-state drive into the drive bay from the front until it snaps into position and then completely close the handle.




Figure 69. Installing the bracket with the solid-state drive

- Check the drive status LEDs to ensure that the solid-state drive is operating correctly. You might have to restart the storage product for the newly installed solid-state drive to be recognized. See “Hot-swap-drive status LEDs” on page 27. If the solid-state drive is faulty, reinstall or replace it until it is operating correctly.
- Save the removed dummy hard-disk-drive tray in case that you later remove the solid-state drive and need a dummy tray to cover the drive bay.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To configure RAID, go to “Configuring RAID” on page 38.

- To complete the installation, go to “Completing the parts replacement” on page 112.

Replacing a 2.5-inch solid-state drive from a 3.5-inch hard-disk-drive bay

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

To replace a 2.5-inch solid-state drive from a 3.5-inch hard-disk-drive bay, do the following:

1. Locate the appropriate hard-disk-drive bay. See “Front view of the storage product” on page 14.
2. Press the release button **1** to open the handle of the 3.5-inch drive bracket.




Figure 70. Opening the handle of the 3.5-inch drive bracket

3. Pull the handle and carefully slide the bracket with the solid-state drive out of the front of the chassis.




Figure 71. Removing the bracket with the solid-state drive

4. Remove the five screws that secure the solid-state drive and the 3.5-inch to 2.5-inch drive adapter. Then, remove the drive adapter with the solid-state drive from the bracket.




Figure 72. Removing the screws that secure the solid-state drive and the drive adapter

5. Remove the two screws that secure the solid-state drive.




Figure 73. Removing the screws that secure the solid-state drive

6. Lift the solid-state drive up to remove it from the drive adapter.




Figure 74. Removing the solid-state drive from the drive adapter

7. Install a new solid-state drive. See “Installing a 2.5-inch solid-state drive into a 3.5-inch hard-disk-drive bay” on page 90.
8. If you are instructed to return the old solid-state drive, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To configure RAID, go to “Configuring RAID” on page 38.
- To complete the replacement, go to “Completing the parts replacement” on page 112.

Installing or replacing the optical drive

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

CAUTION:

When laser products (such as CD-ROMs, DVD drives, fiber optic devices, or transmitters) are installed, note the following:

- **Do not remove the covers.** Removing the covers of the laser product could result in exposure to hazardous laser radiation. There are no serviceable parts inside the device.
- **Use of controls or adjustments or performance of procedures other than those specified herein might result in hazardous radiation exposure.**



Some laser products contain an embedded Class 3A or Class 3B laser diode. Note the following:

Laser radiation when open. Do not stare into the beam, do not view directly with optical instruments, and avoid direct exposure to the beam.

Notes:

- Depending on the model, your storage product might look slightly different from the illustrations in this topic.
- Use any documentation that comes with the new optical drive and follow those instructions in addition to the instructions in this topic.

To install or replace the optical drive, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Locate the optical drive or dummy optical drive. See “Storage product components” on page 19.
5. If you are replacing the optical drive, disconnect the signal cable and the power cable from the rear of the optical drive. Press the release button inward and then slide the optical drive out from the front of the storage product.




Figure 75. Removing the optical drive

6. Touch the static-protective package that contains the new optical drive to any unpainted surface on the outside of the storage product. Then, take the new optical drive out of the package.
7. Slide the new optical drive into the drive bay from the front until it is secured by the release button **1**.




Figure 76. Installing the optical drive

8. Connect the connector **1** to the rear of the optical drive.




Figure 77. Connecting the connector **1** to the rear of the optical drive

9. If necessary, connect the other end of the signal cable to the SATA connector for the optical drive on the system board. See “System board components” on page 23.
10. If you are instructed to return the old optical drive, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the installation or replacement, go to “Completing the parts replacement” on page 112.

Replacing the hot-swap hard-disk-drive backplane

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- The hot-swap hard-disk-drive backplane is sensitive to ESD. Ensure that you read and understand “Handling static-sensitive devices” on page 42 first and carefully perform the operation.
- Depending on the model, your storage product might look slightly different from the illustrations in this topic.
- The illustrations in the following procedure show the backplane for 3.5-inch hard disk drives.

To replace the hot-swap hard-disk-drive backplane, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the cooling shroud. See “Removing and reinstalling the cooling shroud” on page 46.
5. Locate the hot-swap hard-disk-drive backplane. See “Storage product components” on page 19.
6. Remove all the installed hot-swap hard disk drives and dummy trays (if any) from the hard-disk-drive bays. See “Installing or replacing a hot-swap hard disk drive” on page 86.
7. Record the cable connections on the backplane and then disconnect all the cables from the backplane.
8. Press the two latches **1** in the direction as shown until the latches are disengaged from the chassis. Carefully lift the backplane straight up a little bit so that the small hooks on the chassis are aligned with the corresponding holes in the backplane. Then, move the backplane to the rear of the chassis to release the backplane from the hooks.




Figure 78. Removing the hot-swap hard-disk-drive backplane

9. Touch the static-protective package that contains the new hot-swap hard-disk-drive backplane to any unpainted surface on the outside of the storage product. Then, remove the new backplane from the package.

Note: Carefully handle the backplane by its edges.

10. Note the orientation of the new backplane. Ensure that the small hooks **1** on the chassis pass through the corresponding holes in the new backplane. Then, carefully press the new backplane straight down so that it is secured by the latches **2** on the backplane.




Figure 79. Installing the hot-swap hard-disk-drive backplane

11. Reinstall all the hot-swap hard disk drives and dummy trays (if any) on the backplane. See “Installing or replacing a hot-swap hard disk drive” on page 86.
12. Refer to your note to reconnect the cables to the backplane.
13. If you are instructed to return the old hot-swap hard-disk-drive backplane, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the replacement, go to “Completing the parts replacement” on page 112.


Replacing a system fan

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Your storage product supports up to six system fans. This design helps you to avoid significant cooling problems when a system fan fails.

CAUTION:

Hazardous moving parts. Keep fingers and other body parts away.



Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Depending on the model, your storage product might look slightly different from the illustrations in this topic.

To replace a system fan, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the cooling shroud. See “Removing and reinstalling the cooling shroud” on page 46.
5. Locate the system fans. See “Storage product components” on page 19.
6. Disconnect the cable of the system fan from the system fan connector on the system board. Grasp the top of the system fan with your index finger and thumb and then lift the system fan out of the storage product.




Figure 80. Removing the system fan

7. Touch the static-protective package that contains the new system fan to any unpainted surface on the outside of the storage product. Then, remove the new system fan from the package.

- Note the orientation of the new system fan and then insert the new system fan into the chassis until it is secured into place. Connect the cable of the new system fan to the system fan connector on the system board.




Figure 81. Installing the system fan

- If you are instructed to return the old system fan, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the replacement, go to “Completing the parts replacement” on page 112.

Replacing the front panel board

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Notes:

- Depending on the model, your storage product might look slightly different from the illustrations in this topic.
- The illustrations in the following procedure show the front panel board for 3.5-inch hard disk drives.
- The front panel board is extremely sensitive to ESD. Ensure that you read and understand “Handling static-sensitive devices” on page 42 first and carefully perform the operation.

To replace the front panel board, do the following:

- Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
- Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
- Remove the storage product cover. See “Removing the cover” on page 43.
- Locate the front panel board.

5. Disconnect the front-panel-board cables from the system board. See “System board components” on page 23.
6. Remove the two screws that secure the front panel board and then carefully remove the front panel board from the chassis.




Figure 82. Removing the front panel board

7. Touch the static-protective package that contains the new front panel board to any unpainted surface on the outside of the storage product. Then, take the new front panel board out of the package.

Note: Carefully handle the front panel board by its edges.

- Carefully position the new front panel board so that the two screw holes in the new front panel board are aligned with the corresponding mounting studs on the chassis. Then, install the screws to secure the front panel board in place.




Figure 83. Installing the front panel board

- Connect the front-panel-board cables to the system board. See “System board components” on page 23.
- If you are instructed to return the old front panel board, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the replacement, go to “Completing the parts replacement” on page 112.

Replacing the riser card assembly

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Use any documentation that comes with the new riser card assembly and follow those instructions in addition to the instructions in this topic.

To replace the riser card assembly, do the following:

- Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.

2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Locate the riser card assembly that you want to remove. See “Storage product components” on page 19.
5. Grasp the riser card assembly that you want to replace by its edges and carefully lift it straight up and off the chassis.




Figure 84. Removing the riser card assembly

6. If there is any PCIe card (such as an Ethernet card) installed on the riser card assembly, record the cable connections, and then disconnect all cables from the card to completely remove the riser card assembly out of the chassis. Then, remove the PCIe card from the riser card assembly. See “Removing a PCIe card” on page 65.
7. Remove the two screws that secure the failing riser card. Then, remove the failing riser card from the bracket.




Figure 85. Removing the riser card

8. Touch the static-protective package that contains the new riser card to any unpainted surface on the outside of the storage product. Then, remove the new riser card from the package.

9. Align the screw holes in the new riser card with the corresponding ones in the bracket. Then, install the two screws to secure the riser card to the bracket.




Figure 86. Installing the riser card

10. Reinstall the PCIe card on the new riser card assembly.
11. Position the new riser card assembly on the chassis and align it with the riser card slot on the system board. Align the mounting studs on the system board with the corresponding holes in the riser card assembly. Then, carefully press the riser card assembly straight down into the chassis until it is fully seated.




Figure 87. Installing the riser card assembly

12. Reinstall any parts or reconnect any cables that you have removed.
13. If you are instructed to return the old riser card assembly, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the replacement, go to “Completing the parts replacement” on page 112.

Replacing the coin-cell battery

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

Your storage product has a special type of memory that maintains the date, time, and configuration information for built-in features. The coin-cell battery keeps the information active when you turn off the storage product. The coin-cell battery normally requires no charging or maintenance throughout its life; however, no battery lasts forever. If the coin-cell battery fails, the date, time, and configuration information, including passwords, are lost and an error message is displayed when you turn on the storage product.



DANGER

Danger of explosion if battery is incorrectly replaced.

When replacing the lithium coin cell battery, use only the same or an equivalent type that is recommended by the manufacturer. The battery contains lithium and can explode if not properly used, handled, or disposed of.

Do not:

- **Throw or immerse into water**
- **Heat to more than 100°C (212°F)**
- **Repair or disassemble**

Dispose of the battery as required by local ordinances or regulations.

The following statement applies to users in the state of California, U.S.A.

California Perchlorate Information:

Products containing manganese dioxide lithium coin cell batteries may contain perchlorate.

Perchlorate Material - special handling may apply, See <http://www.dtsc.ca.gov/hazardouswaste/perchlorate>

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

To replace the coin-cell battery, do the following:

Note: After you replace the coin-cell battery, you must reset passwords, reset system date and time, and reconfigure the storage product.

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Locate the coin-cell battery. See “System board components” on page 23.

Note: If there is any PCIe card installed on the riser card assembly, it might block your access to the coin-cell battery. In this case, you need to carefully lift the riser card assembly up so that you can access the coin-cell battery. You do not need to disconnect any cables from the riser card assembly or completely remove the riser card assembly.

5. Remove the old coin-cell battery.




Figure 88. Removing the coin-cell battery

6. Install a new coin-cell battery.




Figure 89. Installing the coin-cell battery

7. If you have lifted up the riser card assembly, reinstall it into the chassis. See “Replacing the riser card assembly” on page 103.

8. Dispose of the old coin-cell battery as required by local ordinances or regulations.

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the replacement, go to “Completing the parts replacement” on page 112.


Note: After you replace the system board battery, you must reset passwords, reset system date and time, and reconfigure the storage product. See Chapter 5 “Configuring the storage product” on page 31.

For service technician only: replacing the system board

Attention: This procedure must be performed only by trained service personnel of Lenovo. Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

CAUTION:

Hazardous moving parts. Keep fingers and other body parts away.



CAUTION:



The heat sinks and microprocessors might be very hot. Turn off the storage product and wait several minutes to let the storage product cool before removing the storage product cover.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Depending on the model, your storage product might look slightly different from the illustrations in this topic.

To replace the system board, do the following:

1. Remove all external media from the drives and turn off all attached devices and the storage product. Then, disconnect all power cords from electrical outlets and disconnect all cables that are connected to the storage product.
2. Prepare your storage product. See “Removing or extending the storage product from the rack cabinet” on page 43.
3. Remove the storage product cover. See “Removing the cover” on page 43.
4. Remove the cooling shroud. See “Removing the cooling shroud” on page 46.
5. Remove the system fans. See “Replacing a system fan” on page 99.
6. Record the component locations, cable connections, and cable routing in the storage product.
7. Remove the two riser card assemblies. See “Replacing the riser card assembly” on page 103.
8. Remove all memory modules. See “Removing a memory module” on page 54.
9. Remove the TSM Premium module if one is installed. See “Removing the TSM Premium module” on page 56.
10. Remove the coin-cell battery. See “Replacing the coin-cell battery” on page 105.
11. Remove the heat sinks. See “Installing or replacing a heat sink” on page 72.

12. Disconnect all cables from the system board.
13. Lift the release pin **1** and the lifting handle **2** to disengage the system board from the chassis. Then, move the system board to the front of the storage product and carefully pivot the system board upward to remove it out of the chassis.

Note: Carefully handle the system board by the release pin **1** and the lifting handle **2**.




Figure 90. Removing the system board

14. Place the old system board on a clean, flat, and static-protective surface. Touch the static-protective package that contains the new system board to any unpainted surface on the outside of the storage product. Then, take the new system board out of the package.

15. Install the new system board into the chassis and press the system board to the rear of the storage product. Ensure that:
 - The new system board is engaged by the mounting stud on the chassis.
 - The rear connectors on the new system board are inserted into the corresponding holes in the rear panel.




Figure 91. Installing the system board

16. Remove the microprocessors from the old system board and install them on the new system board. See “Installing or replacing the microprocessor” on page 74.

Note: Do not drop anything onto the microprocessor socket on the old system board while it is exposed. The socket pins must be kept as clean as possible.

17. Use a cleaning pad to wipe the thermal grease from the heat sinks and the top of the microprocessors. Dispose of the cleaning pad after all of the thermal grease is removed.
18. Use one of the following methods to apply appropriate amount of thermal grease to the top of the microprocessors in the shape of a cross or a circle as shown. Either too much or too less application of thermal grease can cause a thermal problem due to imperfect contact with the components.

Notes:

- Do not touch the thermal grease.
- Keep the thermal grease off the system board.



Figure 92. Applying the thermal grease to the top of the microprocessor



19. Install the heat sinks on the new system board. See “Installing or replacing a heat sink” on page 72.

20. Reinstall all parts that you have removed one by one in the reversed sequence as you remove them. Connect all cables to the new system board. Refer to the information that you have noted down and the related topics in “Installing, removing, or replacing hardware” on page 44.
21. If you are instructed to return the old system board, follow all packaging instructions and use any packaging materials that are supplied to you for shipping.

The old system board must be returned with two microprocessor socket covers to protect the pins on the microprocessor sockets during shipping and handling. Use the microprocessor socket covers removed from the new system board.

To install a microprocessor socket cover on the old system board, do the following:

1. Close the microprocessor retainer. Close the small handle **1** first and then close the small handle **2**. Ensure that the retainer is locked into position and the new microprocessor is securely seated in the socket.

Note: There are two marks on the microprocessor retainer. Ensure that you close the small handle marked with  first and then close the small handle marked with . Always follow the correct sequence when you close the small handles.




Figure 93. Securing the microprocessor retainer

2. Position the microprocessor socket cover above the microprocessor socket so that the small triangle **1** on the socket cover faces the small triangle **2** on the microprocessor retainer. Then, carefully press the socket cover straight down into the socket until it snaps into position.




Figure 94. Installing the microprocessor socket cover

What to do next:

- To work with another piece of hardware, go to the appropriate section.
- To complete the replacement, go to “Completing the parts replacement” on page 112.
- After a system board is replaced, do the following:
 1. Start the Setup Utility program by pressing the F1 key, and then check the BIOS and BMC version.
 2. Go to <http://www.lenovo.com/drivers> and follow the instructions on the Web page to download the latest version of firmware. Then, install the firmware to your storage product.
 3. Update the machine type, model number, and serial number of the system board. Either you will be prompted to do this while upgrading the BIOS, or you can locate the files for updating the VPD within the DOS BIOS package. For some storage products, the VPD utility is available for download at: <http://www.lenovo.com/drivers>.

Completing the parts replacement

This topic provides instructions to help you complete the parts replacement and turn on your storage product.

To complete the parts replacement, you must properly route the cables inside the storage product, reinstall the storage product cover, reconnect all the external cables and, for some devices, update the firmware and run the Setup Utility program to do further setup.

Reinstalling the storage product cover and reconnecting cables

Attention: Do not open your storage product or attempt any repair before reading and understanding “Safety information” on page iii and “Guidelines” on page 41.

This topic provides instructions on how to reinstall the storage product cover and reconnect cables to your storage product.

Attention: For proper cooling and airflow, reinstall the storage product cover before turning on the storage product. Operating the storage product for extended periods of time (more than 30 minutes) with the storage product cover removed might damage storage product components.

Before you begin, print all the related instructions or ensure that you can view the PDF version on another computer for reference.

Note: Depending on the model, your storage product might look slightly different from the illustrations in this topic.

To reinstall the storage product cover and reconnect cables to your storage product, do the following:

1. Ensure that all components have been reassembled correctly and that no tools or loose screws are left inside your storage product.
2. Ensure that all internal cables are routed correctly and secured by any cable clips or ties in the storage product. Keep cables clear of the hinges and sides of the storage product chassis to avoid interference with reinstalling the cooling shroud and the storage product cover.
3. If you have removed the cooling shroud, reinstall it. See “Removing and reinstalling the cooling shroud” on page 46.

4. Ensure that the cover latch is in the open position. Lower the storage product cover onto the chassis until both sides of the storage product cover engage the guides on both sides of the chassis. Then, pivot the cover latch and slide the cover to the front of the chassis at the same time until the storage product cover snaps into position. Ensure that the cover latch is completely closed. Use a screwdriver to turn the cover lock to the closed position.




Figure 95. Installing the storage product cover

5. If the storage product is installed in a rack cabinet, reinstall the storage product into the rack cabinet. See the *Rack Installation Instructions* that comes with the storage product.
6. Reconnect external cables and power cords to the storage product. See “Rear view of the storage product” on page 17 to identify the connectors on the rear panel of the storage product.

Attention: To avoid component damage, connect the power cords last.

Note: In most areas of the world, Lenovo requires the return of the defective CRU. Information about this will come with the CRU or will come a few days after the CRU arrives.

Updating the storage product configuration

When you turn on the storage product for the first time after you install, remove, or replace a device, you might need to update the storage product configuration.

Some optional devices have device drivers that you must install. For information about installing device drivers, use the documentation that comes with each optional device. To obtain the supported device drivers for your storage product from the Lenovo Support Web site, go to <http://www.lenovo.com/drivers> and follow the instructions on the Web page to find and download the device drivers you need.

Refer to the following information resources to update the storage product configuration:

- To update the BIOS configuration, see “Using the Setup Utility program” on page 31.
- To update the RAID configuration, see “Configuring RAID” on page 38.

- To use the Lenovo ThinkServer Deployment Manager program, see “Lenovo ThinkServer Deployment Manager” on page 12.
- To update your system firmware, see “Updating the firmware” on page 40.

Chapter 7. Troubleshooting and diagnostics

This chapter provides information about basic troubleshooting and diagnostic methods to help you solve problems that might occur in the storage product.

If you cannot diagnose and correct a problem by using the information in this chapter, see Chapter 8 “Getting information, help, and service” on page 121 for additional troubleshooting resources.

Troubleshooting procedure

Use the following information as a general procedure for diagnosing and troubleshooting problems you experience with your storage product:

1. Verify that the power cords and the cables for all attached devices are connected correctly and securely.
2. Verify that the storage product and all attached devices that require ac power are connected to properly grounded, functioning electrical outlets.
3. Verify that all installed hardware and attached devices are enabled in the BIOS settings of your storage product. For more information about accessing and changing the BIOS settings, see “Using the Setup Utility program” on page 31.
4. View the status and diagnostic LEDs to identify the system and device status and diagnose problems. See “Viewing the status and diagnostic LEDs” on page 115.
5. If the storage product is not working after you have added new software, installed a new optional device, or replaced a piece of hardware, remove or reinstall the software, device, or hardware to see if the problem could be solved.
6. View the system event log to diagnose problems. See “Viewing the system event log” on page 115.
7. Turn on the storage product and press Esc as soon as you see the logo screen to view any diagnostic messages.
8. Refer to “Basic troubleshooting tables” on page 116 and follow the instructions for the type of problem you are experiencing. If the basic troubleshooting information does not help you resolve a problem, continue with the next step.
9. Try using a previous storage product configuration to see if a recent change to hardware or software settings has caused a problem. Before restoring your previous configuration, capture your current configuration in case the older configuration settings do not solve the problem or have adverse effect.
10. Use an antivirus program to see if your storage product has been infected by a virus. If the program detects a virus, remove the virus.
11. If none of these actions solve the problem, seek technical assistance. See Chapter 8 “Getting information, help, and service” on page 121.

Viewing the status and diagnostic LEDs

Your storage product has status and diagnostic LEDs on the front panel, the rear panel, the system board, the hot-swap storage drives, and the optical drive (if supported). The various LEDs help you easily identify the system and device status and diagnose problems. For information about the LEDs, refer to the related topics in “Locations” on page 13.

Viewing the system event log

The system event log (SEL) contains information about all the POST and system management interrupt (SMI) events. You can view the SEL to diagnose system problems.

The TSM implements the SEL as specified in the IPMI 2.0 specification. The SEL is accessible regardless of the system power state through the TSM in-band and out-of-band interfaces.

For more information about viewing the SEL, refer to the *ThinkServer System Manager User Guide*, which is available for download at <http://www.lenovo.com/support>.

Basic troubleshooting tables

Use the basic troubleshooting information to find solutions to problems that have definite symptoms.

Lenovo ThinkServer Deployment Manager program problems

Follow the suggested actions for the corresponding symptom in the order in which they are listed until the problem is solved. If none of these actions solve the problem, see “Troubleshooting procedure” on page 115 for the subsequent steps you should check after using the information in this topic. If the problem still cannot be solved, seek technical assistance. See Chapter 8 “Getting information, help, and service” on page 121.

Note: If you are instructed to remove, install, or replace any CRUs, refer to the related procedure in Chapter 6 “Replacing hardware” on page 41.

Symptom	Action
The operating system installation program continuously loops.	Make more space available on the hard disk drive.
The Lenovo ThinkServer Deployment Manager program cannot start the operating system medium.	Ensure that the operating system medium is supported by the Lenovo ThinkServer Deployment Manager program version you are using. For a list of supported operating systems, refer to the user guide and compatibility notes for the Lenovo ThinkServer Deployment Manager program through the program main interface. See “Lenovo ThinkServer Deployment Manager” on page 12.

Optical drive problems

Follow the suggested actions for the corresponding symptom in the order in which they are listed until the problem is solved. If none of these actions solve the problem, see “Troubleshooting procedure” on page 115 for the subsequent steps you should check after using the information in this topic. If the problem still cannot be solved, seek technical assistance. See Chapter 8 “Getting information, help, and service” on page 121.

Notes:

- If you are instructed to remove, install, or replace any CRUs, refer to the related procedure in Chapter 6 “Replacing hardware” on page 41.
- If an action step is preceded by “(Trained service technician only),” this action step is reserved for a trained service technician and must be performed only by a trained service technician.

Symptom	Action
The optical drive is not recognized.	<ol style="list-style-type: none"> 1. Ensure that: <ul style="list-style-type: none"> • The related cables and connectors are not damaged and the connector pins are not bent. • The optical drive is securely connected to the correct SATA connector on the system board and the SATA connector is enabled in the Setup Utility program. See “Using the Setup Utility program” on page 31. • All cables and jumpers (if any) are installed correctly. • The correct device driver is installed for the optical drive. 2. Run any optical drive diagnostic programs if you have. 3. Reinstall the optical drive and reconnect cables. 4. Replace the signal cable for the optical drive. 5. Replace the power cable for the optical drive. 6. Replace the power cable for the backplane. 7. Replace the optical drive. 8. Replace the backplane. 9. (Trained service technician only) Replace the system board.
A disc is not working correctly.	<ol style="list-style-type: none"> 1. Ensure that the disc is in the optical drive with the shiny side facing down. 2. Ensure that the disc surface is clean and not scratched. 3. Check the disc or package for regional coding. You might need to purchase a disc with coding for the region where you are using the product. 4. Restart the disc player program. 5. Restart the storage product. 6. Run any optical drive diagnostic programs if you have. 7. Reinstall the optical drive and reconnect cables. 8. Replace the signal cable for the optical drive. 9. Replace the optical drive.

Storage drive problems

Follow the suggested actions for the corresponding symptom in the order in which they are listed until the problem is solved. If none of these actions solve the problem, see “Troubleshooting procedure” on page 115 for the subsequent steps you should check after using the information in this topic. If the problem still cannot be solved, seek technical assistance. See Chapter 8 “Getting information, help, and service” on page 121.

Notes:

- If you are instructed to remove, install, or replace any CRUs, refer to the related procedure in Chapter 6 “Replacing hardware” on page 41.

- The status LEDs on each hot-swap hard disk drive help you easily identify a problem. See “Hot-swap-drive status LEDs” on page 27.

Symptom	Action
A newly installed hot-swap hard disk drive is not recognized.	<ol style="list-style-type: none"> 1. Ensure that the drive is installed into the correct drive bay. 2. Restart the storage product. 3. Remove the drive from the bay, wait 45 seconds, and reinsert the drive into the bay, making sure that the drive connects to the hot-swap hard-disk-drive backplane. 4. Run any diagnostic programs to test the hard disk drive if you have. 5. Ensure that the hot-swap hard-disk-drive backplane is correctly seated. When it is correctly seated, the drive assemblies correctly connect to the backplane without bowing or causing movement of the backplane. 6. Ensure that the cable connection is correct. See “Connecting the cables” on page 28. 7. Reconnect the backplane power cable and repeat step 1 through step 4. 8. Reconnect the backplane signal cable and repeat step 1 through step 4. 9. If you suspect a problem with the backplane signal cable or the backplane: <ol style="list-style-type: none"> a. Replace the affected backplane signal cable. b. Replace the affected backplane.
Multiple hard disk drives fail.	<ol style="list-style-type: none"> 1. Ensure that the cable connection is correct. See “Connecting the cables” on page 28. 2. Reconnect the power cables. 3. Reconnect the signal cables. 4. Replace the affected signal cables. 5. If you suspect a problem with the backplane, replace the affected backplane.

Memory module problems

Follow the suggested actions for the corresponding symptom in the order in which they are listed until the problem is solved. If none of these actions solve the problem, see “Troubleshooting procedure” on page 115 for the subsequent steps you should check after using the information in this topic. If the problem still cannot be solved, seek technical assistance. See Chapter 8 “Getting information, help, and service” on page 121.

Notes:

- If you are instructed to remove, install, or replace any CRUs, refer to the related procedure in Chapter 6 “Replacing hardware” on page 41.
- If an action step is preceded by “(Trained service technician only),” this action step is reserved for a trained service technician and must be performed only by a trained service technician.

Symptom	Action
The amount of system memory that is displayed is less than the total capacity of the installed physical memory modules and you suspect a memory module problem.	<ol style="list-style-type: none"> 1. Ensure that: <ul style="list-style-type: none"> • All memory modules are the correct type supported by the storage product. See “Memory module installation rules” on page 48. • You followed the memory module installation rules. See “Memory module installation rules” on page 48. • All memory modules are seated correctly and securely. • The system firmware is up-to-date. 2. Reinstall the memory modules. 3. Replace the suspect memory modules. 4. (Trained service technician only) Replace the system board.

Keyboard, mouse, and USB device problems

Follow the suggested actions for the corresponding symptom in the order in which they are listed until the problem is solved. If none of these actions solve the problem, see “Troubleshooting procedure” on page 115 for the subsequent steps you should check after using the information in this topic.

Symptom	Action
All or some keys on the keyboard do not work.	<ol style="list-style-type: none"> 1. Ensure that: <ul style="list-style-type: none"> • The USB keyboard cable is securely connected to a USB connector on the storage product. If the USB keyboard is connected to a USB hub, disconnect the keyboard from the hub and connect it directly to the storage product. • No keys are stuck. • The USB controller is enabled in the Setup Utility program. See “Using the Setup Utility program” on page 31. 2. Restart the storage product. 3. Replace the keyboard.
The mouse or pointing device does not work.	<ol style="list-style-type: none"> 1. Ensure that: <ul style="list-style-type: none"> • The mouse or pointing device cable is securely connected to the storage product. If the USB mouse or pointing device is connected to a USB hub, disconnect the mouse or pointing device from the hub and connect it directly to the storage product. • The mouse or pointing device is clean and no dust accumulates. • The device drivers are installed correctly. • The USB controller is enabled in the Setup Utility program. See “Using the Setup Utility program” on page 31. 2. Restart the storage product.

Symptom	Action
	3. Replace the mouse or pointing device.
A USB device does not work.	1. Ensure that: <ul style="list-style-type: none"> • The USB cable is securely connected to the storage product. If the USB device is connected to a USB hub, disconnect the device from the hub and connect it directly to the storage product. • The device drivers are installed correctly. • The USB controller is enabled in the Setup Utility program. See “Using the Setup Utility program” on page 31. 2. Restart the storage product. 3. Replace the USB device.

Chapter 8. Getting information, help, and service

This chapter contains information about help, service, and technical assistance for products manufactured by Lenovo and where to go for additional information about Lenovo and Lenovo products.

Information resources

You can use the information in this topic to access useful resources relating to your needs when using the product.

Using the documentation

Information about your Lenovo system and installed software, if any, or optional devices is available in the documentation that comes with the product. The documentation can include printed documents, online documents, readme files, and help files. Most of the documentation for your storage product is on the documentation DVD provided with your storage product. Refer to the troubleshooting information for instructions on how to diagnose problems and do basic troubleshooting. The troubleshooting and diagnostics information might tell you that you need additional or updated device drivers or other software. Lenovo maintains pages on the World Wide Web where you can get the latest technical information and download documentation or device drivers and updates. To access the Lenovo Support Web site, go to: <http://www.lenovo.com/support>

For more information about your storage product documentation, see “Documentation” on page 2.

If you suspect a software problem, refer to the documentation, including readme files and online help, that comes with the operating system or software program.

Lenovo Storage Web site

The Lenovo Storage Web site provides up-to-date information and services to help you buy, use, upgrade, and maintain your storage product. You also can do the following by visiting the Lenovo Storage Web site at: <http://shop.lenovo.com/us/en/servers/network-storage/>

- Shop for storage products as well as upgrades and accessories for your storage product.
- Purchase additional services and software.
- Purchase upgrades and extended hardware repair services.
- Access the Lenovo Limited Warranty (LLW).
- Access the online manuals for your products.
- Access troubleshooting and support information for your storage product model and other supported products.
- Download the latest device drivers and software updates for your storage product model.
- Find the service and support phone numbers for your country or region.
- Find a Service Provider located near you.

Lenovo Support Web site

Technical support information is available on the Lenovo Support Web site at: <http://www.lenovo.com/support>

This Web site is updated with the latest support information such as the following:

- Drivers and software
 - Diagnostic solutions
 - Product and service warranty
 - Product and parts details
 - User guides and manuals
 - Knowledge base and frequently asked questions
-

Help and service

This topic contains information about obtaining help and service.

Before you call

Before you call, do the following to try to solve the problem by yourself:

- Check all cables to ensure that they are connected.
- Check the power switches to ensure that the system and optional devices are turned on.
- Use the troubleshooting information in your system documentation on the documentation DVD that comes with your product.
- Check for the updated information, new device drivers, and hints and tips on the Lenovo Support Web site at:
<http://www.lenovo.com/support>

If possible, be at your product when you call. Have the following information available:

- Machine type and model
- Serial numbers of your Lenovo hardware products
- Description of the problem
- Exact wording of any error messages
- Hardware and software configuration information

Calling for service

During the warranty period, you can get help and information by telephone through the Customer Support Center.

The following services are available during the warranty period:

- **Problem determination** - Trained service personnel are available to assist you with determining a hardware problem and deciding what action is necessary to fix the problem.
- **Hardware repair** - If the problem is caused by hardware under warranty, trained service personnel are available to provide the applicable level of service.
- **Engineering Change management** - There might be changes that are required after a product has been sold. Lenovo or your reseller will make selected Engineering Changes (ECs) that apply to your hardware available.

The warranty does not cover the following:

- Replacement or use of parts not manufactured for or by Lenovo or non-warranted Lenovo parts
- Identification of software problem sources
- Configuration of the Unified Extensible Firmware Interface (UEFI) BIOS as part of an installation or upgrade
- Changes, modifications, or upgrades to device drivers
- Installation and maintenance of network operating systems (NOS)
- Installation and maintenance of application programs

For the warranty type and duration for your product, refer to the *Safety, Warranty, and Support Information* on the documentation DVD that comes with your storage product. You must retain your proof of purchase to obtain warranty service.

For warranty service, consult the worldwide Lenovo Support telephone list. Telephone numbers are subject to change without notice. The most up-to-date telephone list for Lenovo Support is always available on the Web site at <http://www.lenovo.com/support/phone>. If the telephone number for your country or region is not listed, contact your Lenovo reseller or Lenovo marketing representative.

Using other services

If you travel with a Lenovo notebook computer or relocate your computer to a country where your desktop, notebook, or storage product machine type is sold, your computer might be eligible for International Warranty Service, which automatically entitles you to obtain warranty service throughout the warranty period. Service will be performed by service providers authorized to perform warranty service.

Service methods and procedures vary by country, and some services might not be available in all countries. International Warranty Service is delivered through the method of service (such as depot, carry-in, or on-site service) that is provided in the servicing country. Service centers in certain countries might not be able to service all models of a particular machine type. In some countries, fees and restrictions might apply at the time of service.

To determine whether your computer is eligible for International Warranty Service and to view a list of the countries where service is available, go to <http://www.lenovo.com/support>, click **Warranty**, and follow the instructions on the screen.

For technical assistance with the installation of or questions related to Service Packs for your installed Windows product, refer to the Microsoft Product Support Services Web site at <http://support.microsoft.com/directory> or you can contact the Customer Support Center. Some fees might apply.

Purchasing additional services

During and after the warranty period, you can purchase additional services, such as support for hardware, operating systems, and application programs; network setup and configuration services; upgraded or extended hardware repair services; and custom installation services. Service availability and service names might vary by country or region. For more information about these services, go to the Lenovo Web site at: <http://www.lenovo.com>

Appendix A. Notices

Lenovo may not offer the products, services, or features discussed in this document in all countries. Consult your local Lenovo representative for information on the products and services currently available in your area. Any reference to a Lenovo product, program, or service is not intended to state or imply that only that Lenovo product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any Lenovo intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any other product, program, or service.

Lenovo may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

*Lenovo (United States), Inc.
1009 Think Place - Building One
Morrisville, NC 27560
U.S.A.
Attention: Lenovo Director of Licensing*

LENOVO PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. Lenovo may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

The products described in this document are not intended for use in implantation or other life support applications where malfunction may result in injury or death to persons. The information contained in this document does not affect or change Lenovo product specifications or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Lenovo or third parties. All information contained in this document was obtained in specific environments and is presented as an illustration. The result obtained in other operating environments may vary.

Lenovo may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Any references in this publication to non-Lenovo Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this Lenovo product, and use of those Web sites is at your own risk.

Any performance data contained herein was determined in a controlled environment. Therefore, the result obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Trademarks

Lenovo, the Lenovo logo, and ThinkServer are trademarks of Lenovo in the United States, other countries, or both.

Intel and Intel Xeon are trademarks of Intel Corporation in the United States, other countries, or both.

Internet Explorer, Microsoft, and Windows are trademarks of the Microsoft group of companies.

Linux is a registered trademark of Linus Torvalds.

Other company, product, or service names may be trademarks or service marks of others.

Important notes

Processor speed indicates the internal clock speed of the microprocessor; other factors also affect application performance.

CD or DVD drive speed is the variable read rate. Actual speeds vary and are often less than the possible maximum.

When referring to processor storage, real and virtual storage, or channel volume, KB stands for 1 024 bytes, MB stands for 1 048 576 bytes, and GB stands for 1 073 741 824 bytes.

When referring to hard disk drive capacity or communications volume, MB stands for 1 000 000 bytes, and GB stands for 1 000 000 000 bytes. Total user-accessible capacity can vary depending on operating environments.

Maximum internal hard disk drive capacities assume the replacement of any standard hard disk drives and population of all hard-disk-drive bays with the largest currently supported drives that are available from Lenovo.

Maximum memory might require replacement of the standard memory with an optional memory module.

Lenovo makes no representations or warranties with respect to non-Lenovo products. Support (if any) for the non-Lenovo products is provided by the third party, not Lenovo.

Some software might differ from its retail version (if available) and might not include user manuals or all program functionality.

Polyvinyl Chloride (PVC) cable and cord notice

WARNING: Handling the cord on this product or cords associated with accessories sold with this product will expose you to lead, a chemical known to the State of California to cause cancer, and birth defects or other reproductive harm. ***Wash hands after handling.***

Recycling information

Lenovo encourages owners of information technology (IT) equipment to responsibly recycle their equipment when it is no longer needed. Lenovo offers a variety of programs and services to assist equipment owners in recycling their IT products. For information on recycling Lenovo products, go to:
<http://www.lenovo.com/recycling>

Battery return program

This product may contain a lithium or lithium ion battery. Consult your user manual or service manual for specific battery information. The battery must be recycled or disposed of properly. Recycling facilities may not be available in your area. For information on disposal or batteries outside the United States, go to <http://www.lenovo.com/recycling> or contact your local waste disposal facility.


Battery recycling information for the United States and Canada



US & Canada Only

Battery recycling information for the European Union

EU



Notice: This mark applies only to countries within the European Union (EU).

Batteries or packaging for batteries are labeled in accordance with European Directive 2006/66/EC concerning batteries and accumulators and waste batteries and accumulators. The Directive determines the framework for the return and recycling of used batteries and accumulators as applicable throughout the European Union. This label is applied to various batteries to indicate that the battery is not to be thrown away, but rather reclaimed upon end of life per this Directive.

In accordance with the European Directive 2006/66/EC, batteries and accumulators are labeled to indicate that they are to be collected separately and recycled at end of life. The label on the battery may also include a chemical symbol for the metal concerned in the battery (Pb for lead, Hg for mercury, and Cd for cadmium). Users of batteries and accumulators must not dispose of batteries and accumulators as unsorted municipal waste, but use the collection framework available to customers for the return, recycling, and treatment of batteries and accumulators. Customer participation is important to minimize any potential effects of batteries and accumulators on the environment and human health due to the potential presence of hazardous substances. For proper collection and treatment, go to: <http://www.lenovo.com/lenovo/environment>

Requirement for batteries containing perchlorate

The following statement applies to users in the state of California, U.S.A.

California Perchlorate Information:

Products containing CR (manganese dioxide) lithium coin cell batteries may contain perchlorate.

Perchlorate Material - special handling may apply, See <http://www.dtsc.ca.gov/hazardouswaste/perchlorate>


Particulate contamination

Attention: Airborne particulates (including metal flakes or particles) and reactive gases acting alone or in combination with other environmental factors such as humidity or temperature might pose a risk to the storage product that is described in this document. Risks that are posed by the presence of excessive particulate levels or concentrations of harmful gases include damage that might cause the storage product to malfunction or cease functioning altogether. This specification sets forth limits for particulates and gases that are intended to avoid such damage. The limits must not be viewed or used as definitive limits, because numerous other factors, such as temperature or moisture content of the air, can influence the impact of particulates or environmental corrosives and gaseous contaminant transfer. In the absence of specific limits that are set forth in this document, you must implement practices that maintain particulate and gas levels that are consistent with the protection of human health and safety. If Lenovo determines that the levels of particulates or gases in your environment have caused damage to the storage product, Lenovo may condition provision of repair or replacement of storage products or parts on implementation of appropriate remedial measures to mitigate such environmental contamination. Implementation of such remedial measures is a customer responsibility.

Table 11. Limits for particulates and gases

Contaminant	Limits
Particulate	<ul style="list-style-type: none"> The room air must be continuously filtered with 40% atmospheric dust spot efficiency (MERV 9) according to ASHRAE Standard 52.2¹. Air that enters a data center must be filtered to 99.97% efficiency or greater, using high-efficiency particulate air (HEPA) filters that meet MIL-STD-282. The deliquescent relative humidity of the particulate contamination must be more than 60%². The room must be free of conductive contamination such as zinc whiskers.
Gaseous	<ul style="list-style-type: none"> Copper: Class G1 as per ANSI/ISA 71.04-1985³ Silver: Corrosion rate of less than 300 Å in 30 days
<p>¹ ASHRAE 52.2-2008 - <i>Method of Testing General Ventilation Air-Cleaning Devices for Removal Efficiency by Particle Size</i>. Atlanta: American Society of Heating, Refrigerating and Air-Conditioning Engineers, Inc.</p> <p>² The deliquescent relative humidity of particulate contamination is the relative humidity at which the dust absorbs enough water to become wet and promote ionic conduction.</p> <p>³ ANSI/ISA-71.04-1985. <i>Environmental conditions for process measurement and control systems: Airborne contaminants</i>. Instrument Society of America, Research Triangle Park, North Carolina, U.S.A.</p>	

Important WEEE information



The WEEE marking on Lenovo products applies to countries with WEEE and e-waste regulations (for example, the European WEEE Directive, India E-Waste Management & Handling Rules, 2011). Appliances are labeled in accordance with local regulations concerning waste electrical and electronic equipment (WEEE).

These regulations determine the framework for the return and recycling of used appliances as applicable within each geography. This label is applied to various products to indicate that the product is not to be thrown away, but rather put in the established collective systems for reclaiming these end of life products.

Users of electrical and electronic equipment (EEE) with the WEEE marking must not dispose of end of life EEE as unsorted municipal waste, but use the collection framework available to them for the return, recycle, and recovery of WEEE and to minimize any potential effects of EEE on the environment and human health due to the presence of hazardous substances. For additional WEEE information go to: <http://www.lenovo.com/recycling>

European Union RoHS

Lenovo products sold in the European Union, on or after 3 January 2013 meet the requirements of Directive 2011/65/EU on the restriction of the use of certain hazardous substances in electrical and electronic equipment (“RoHS recast” or “RoHS 2”).

For more information about Lenovo progress on RoHS, go to: http://www.lenovo.com/social_responsibility/us/en/RoHS_Communication.pdf

German Ordinance for Work gloss statement

The product is not suitable for use with visual display work place devices according to clause 2 of the German Ordinance for Work with Visual Display Units.

Das Produkt ist nicht für den Einsatz an Bildschirmarbeitsplätzen im Sinne § 2 der Bildschirmarbeitsverordnung geeignet.

Export classification notice

This product is subject to the United States Export Administration Regulations (EAR) and has an Export Classification Control Number (ECCN) of 4A994.b. It can be re-exported except to any of the embargoed countries in the EAR E1 country list.

Electronic emission notices

The following information refers to the Lenovo Storage product machine types 70FX and 70FY.

Federal Communications Commission (FCC) Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. Lenovo is not responsible for any radio or television interference caused by using other than specified or recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Industry Canada Compliance Statement

CAN ICES-3(A)/NMB-3(A)

United Kingdom telecommunications safety requirement

Notice to Customers

This apparatus is approved under approval number NS/G/1234/J/100003 for indirect connection to public telecommunication systems in the United Kingdom.

European Union - Compliance to the Electromagnetic Compatibility Directive

This product is in conformity with the protection requirements of EU Council Directive 2004/108/EC on the approximation of the laws of the Member States relating to electromagnetic compatibility. Lenovo cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the installation of option cards from other manufacturers.

This product has been tested and found to comply with the limits for Class A Information Technology Equipment according to European Standard EN 55022. The limits for Class A equipment were derived for commercial and industrial environments to provide reasonable protection against interference with licensed communication equipment.

Lenovo, Einsteinova 21, 851 01 Bratislava, Slovakia



Warning: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

German Class A compliance statement

Deutschsprachiger EU Hinweis:

Hinweis für Geräte der Klasse A EU-Richtlinie zur Elektromagnetischen Verträglichkeit

Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2004/108/EG (früher 89/336/EWG) zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55022 Klasse A ein.

Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der Lenovo empfohlene Kabel angeschlossen werden. Lenovo übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung der Lenovo verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung der Lenovo gesteckt/eingebaut werden.

Deutschland:

Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Betriebsmitteln

Dieses Produkt entspricht dem „Gesetz über die elektromagnetische Verträglichkeit von Betriebsmitteln“

EMVG (früher „Gesetz über die elektromagnetische Verträglichkeit von Geräten“). Dies ist die Umsetzung der EU-Richtlinie 2004/108/EG (früher 89/336/EWG) in der Bundesrepublik Deutschland.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Betriebsmitteln, EMVG vom 20. Juli 2007 (früher Gesetz über die elektromagnetische Verträglichkeit von Geräten), bzw. der EMV EG Richtlinie 2004/108/EC (früher 89/336/EWG), für Geräte der Klasse A.

Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen. Verantwortlich für die Konformitätserklärung nach Paragraf 5 des EMVG ist die Lenovo (Deutschland) GmbH, Gropiusplatz 10, D-70563 Stuttgart.

Informationen in Hinsicht EMVG Paragraf 4 Abs. (1) 4:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55022 Klasse A.

Nach der EN 55022: „Dies ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funkstörungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen durchzuführen und dafür aufzukommen.“

Nach dem EMVG: „Geräte dürfen an Orten, für die sie nicht ausreichend entstört sind, nur mit besonderer Genehmigung des Bundesministers für Post und Telekommunikation oder des Bundesamtes für Post und Telekommunikation betrieben werden. Die Genehmigung wird erteilt, wenn keine elektromagnetischen Störungen zu erwarten sind.“ (Auszug aus dem EMVG, Paragraph 3, Abs. 4). Dieses Genehmigungsverfahren ist nach Paragraph 9 EMVG in Verbindung mit der entsprechenden Kostenverordnung (Amtsblatt 14/93) kostenpflichtig.

Anmerkung: Um die Einhaltung des EMVG sicherzustellen sind die Geräte, wie in den Handbüchern angegeben, zu installieren und zu betreiben.

Eurasian compliance mark



Brazil regulatory notice

Ouvir sons com mais de 85 decibéis por longos períodos pode provocar danos ao sistema auditivo.

Recycling information for Brazil

Declarações de Reciclagem no Brasil

Descarte de um Produto Lenovo Fora de Uso

Equipamentos elétricos e eletrônicos não devem ser descartados em lixo comum, mas enviados à pontos de coleta, autorizados pelo fabricante do produto para que sejam encaminhados e processados por empresas especializadas no manuseio de resíduos industriais, devidamente certificadas pelos órgãos ambientais, de acordo com a legislação local.

A Lenovo possui um canal específico para auxiliá-lo no descarte desses produtos. Caso você possua um produto Lenovo em situação de descarte, ligue para o nosso SAC ou encaminhe um e-mail para: reciclar@lenovo.com, informando o modelo, número de série e cidade, a fim de enviarmos as instruções para o correto descarte do seu produto Lenovo.

ENERGY STAR model information



ENERGY STAR® is a joint program of the U.S. Environmental Protection Agency and the U.S. Department of Energy aimed at saving money and protecting the environment through energy efficient products and practices.

Lenovo is proud to offer our customers products with an ENERGY STAR compliant designation. Some models of the following machine types have been designed and tested to conform to the ENERGY STAR Program Requirements Product Specification for Data Center Storage at the time of manufacture: 70FX and 70FY.

For more information about ENERGY STAR ratings for Lenovo storage products, go to <http://www.lenovo.com>.

By using ENERGY STAR compliant products and taking advantage of the power-management features of your storage product, you reduce the consumption of electricity. Reduced electrical consumption contributes to potential financial savings, a cleaner environment, and the reduction of greenhouse gas emissions.

For more information about ENERGY STAR, go to: <http://www.energystar.gov>

Lenovo encourages you to make efficient use of energy an integral part of your day-to-day operations. To help in this endeavor, set the following power-management features to take effect when your storage products have been used:

- Processor- or core-reduced power states
- Variable speed fan control based on power or thermal readings
- Low power memory states

Index

3.5-inch drive backplane
locations 22

A

about RAID 38
advanced SATA or SAS hardware RAID
configuring 40
Advanced Settings menu
Setup Utility program 32

B

BIOS and TSM update utilities
software 12
Boot Manager menu
Setup Utility program 33

C

cable connection 28
coin-cell battery
replacing 105
configuring
storage product 31
configuring RAID
advanced SATA or SAS hardware RAID 40
using the Lenovo ThinkServer Deployment Manager
program 39
configuring the storage product 31
considerations, password 34
contamination, particulate and gaseous 128
cooling shroud
reinstalling 47
removing 46
cover
removing 43
CRU
completing the replacement 112

D

devices, handling static-sensitive 42
DIMM
installation rules 48
installing 52
removing 54
documentation 2
using 121

E

Ethernet connectivity
features 9
Ethernet connector

Setup Utility program 36
Ethernet status
LED 18
exiting
Setup Utility program 36
expansion slots
features 8
export classification notice 129

F

features 7
Lenovo ThinkServer Deployment Manager program 12
firmware
updating 40
flashing
the BIOS 36
front panel
LED 15
locations 15
front panel board
replacing 101

G

gaseous contamination 128
German gloss statement 129
getting help 121
getting information 121
getting service 121
guidelines 41

H

hardware
replacing 41
heat sink
installing or replacing 72
help, getting 121
hot-swap hard disk drive
installing 86
replacing 86
hot-swap hard-disk-drive backplane
replacing 98
hot-swap redundant power supply
installing 83
replacing 85
hot-swap-drive status
LED 27
hot-swap-drive status LEDs
locations 27

I

ID

- LED 17
- information, getting 121
- Input/Output (I/O)
 - features 9
- installation rules
 - DIMM 48
 - memory module 48
- installing
 - DIMM 52
 - hot-swap hard disk drive 86
 - hot-swap redundant power supply 83
 - intrusion switch 70
 - memory module 52
 - microprocessor 74
 - optical module 67
 - RAID 110i key 58
 - solid-state drive 89–90
 - storage product cover 112
 - ThinkServer RAID Super Capacitor Module 59–60
 - TSM Premium module 55
- installing or replacing
 - heat sink 72
 - optical drive 95
- interface
 - Setup Utility program 31
- internal drives
 - features 8
- intrusion switch
 - installing 70
 - removing 71

L

- LED
 - Ethernet status 18
 - front panel 15
 - hot-swap-drive status 27
 - ID 17
 - Network status 15
 - power status 16
 - power supply status 28
 - system health 16
- Lenovo ThinkServer Deployment Manager
 - software 12
- Lenovo ThinkServer Deployment Manager program
 - features 12
- Lenovo ThinkServer System Manager
 - software 13
- Lenovo ThinkServer System Manager Premium
 - software 13
- locations 13

M

- machine type and model label
 - locations 13
- memory
 - features 7
- memory module
 - installation rules 48

- installing 52
- removing 54
- memory module installation
 - guidelines 48
- microprocessor
 - features 7
 - installing 74
 - replacing 78

N

- Network status
 - LED 15

O

- optical drive
 - installing or replacing 95
- optical module
 - installing 67
 - removing 68
- option
 - completing the replacement 112

P

- particulate contamination 128
- parts replacement, completing 112
- password
 - considerations 34
 - setting, changing, deleting 35
 - Setup Utility program 34
- power status
 - LED 16
- power supply
 - features 8
- power supply status
 - LED 28
- power supply status LEDs
 - locations 28
- precautions
 - guidelines 41

R

- RAID
 - configuring 38
 - introduction 38
- RAID 110i key
 - installing 58
 - removing 58
- RAID card
 - locations 21
- rear view of the storage product
 - locations 17
- recovering
 - the BIOS 37
- reinstalling
 - cooling shroud 47

- reliability, availability, and serviceability
 - features 9
- removing
 - cooling shroud 46
 - cover 43
 - DIMM 54
 - intrusion switch 70–71
 - memory module 54
 - optical module 68
 - RAID 110i key 58
 - ThinkServer RAID Super Capacitor Module 59, 61
 - TSM Premium module 56
- replacing
 - coin-cell battery 105
 - front panel board 101
 - hardware 41
 - hot-swap hard disk drive 86
 - hot-swap hard-disk-drive backplane 98
 - hot-swap redundant power supply 85
 - microprocessor 78
 - riser card assembly 103
 - solid-state drive 89, 93
 - system board 107
 - system fan 99
- riser card assembly
 - replacing 103
- road map
 - storage product setup 5

S

- Save & Exit menu
 - Setup Utility program 33
- serial number label
 - locations 13
- service, getting 121
- setting, changing, deleting
 - password 35
- Setup Utility program
 - Ethernet connector 36
 - exiting 36
 - interface 31
 - password 34
 - starting 31
 - using 31
- slim optical drive
 - locations 15
- software 12
 - Lenovo ThinkServer Deployment Manager 12
- solid-state drive
 - installing 89–90
 - replacing 89, 93
- specifications 11
- starting
 - Setup Utility program 31
- startup device
 - selecting 35
 - Setup Utility program 35
- static-sensitive devices
 - guidelines 42

- static-sensitive devices, handling 42
- Storage product components
 - locations 19
- storage product configuration
 - updating 113
- storage product cover
 - installing 112
- storage product package 7
- storage product setup
 - road map 5
- system board 23
 - replacing 107
- system board components
 - locations 23
- system board jumpers
 - locations 25
- system date
 - setting 34
- system event log
 - troubleshooting and diagnostics 115
- system fan
 - replacing 99
- system fans
 - features 8
- system health
 - LED 16
- System Information menu
 - Setup Utility program 32
- system reliability
 - guidelines 42
- System Security menu
 - Setup Utility program 33
- system time
 - setting 34

T

- the BIOS
 - flashing 36
 - recovering 37
 - updating 36
 - updating or recovering 36
- ThinkServer RAID Super Capacitor Module
 - installing 59–60
 - removing 59, 61
- troubleshooting and diagnostics
 - hard disk drive problems 117
 - keyboard, mouse, and USB device problems 119
 - Lenovo ThinkServer Deployment Manager program
 - problems 116
 - memory module problems 118
 - optical drive problems 116
 - status and diagnostic LEDs 115
 - system event log 115
 - troubleshooting procedure 115
- TSM Premium module
 - installing 55
 - removing 56
- TSM Settings menu
 - Setup Utility program 33

turning off the storage product 29
turning on the storage product 29
TÜV gloss statement 129

U

updating
 firmware 40
 storage product configuration 113
 the BIOS 36
updating or recovering
 the BIOS 36
using
 documentation 121
 passwords 34
 Setup Utility program 31

V

video subsystem
 features 9
viewing information
 Setup Utility program 31

W

Web address 1
Web site
 compatible options 49
working inside the storage product with the power on
 guidelines 43

lenovo®

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>