

Instruction Manual

Model 1856D 3.7GHz Frequency Counter

WARRANTY

Warranty service covers a period of one year from the date of original purchase.

In case of technical failure within one year, repair service will be provided by our service center or sales outlet free of charge.

We charge customers for repairs after the one-year warranty period has expired. We charge for repairs regardless of the warranty period if failure resulted from the user's negligence, natural disaster or accident.

For more professional repair service, be sure to contact our service center or sales outlet.

Introduction

Thank you for purchasing our product. Electronic measuring instruments produced by us are high technology products made under strict quality control. We guarantee their exceptional precision and utmost reliability. For proper use of the product, please read this operation manual carefully.

Note







- To maintain the full precision and reliability of this product, use it within the temperature range of 10 °C to 35 °C (50 °F to 95 °F), and within a humidity of 45% to 85%.
- After turning on the power, allow a warm up period of about 30 minutes before use.
- This equipment should be used with a triple line power cord for safety.
- Due to ongoing product development and improvement, things such as exterior design and technical specifications can change without prior notice.
- If you have further questions concerning use of this product, visit www.bkprecision.com.

Safety Summary

Please take a moment to read these operating instructions thoroughly and completely before operating this instrument. Pay particular attention to WARNINGS concerning conditions and actions that pose a hazard to the user and CAUTIONS describing conditions and actions that may damage the instrument.

- Before every use, inspect the instrument and other accessories for signs of damage or abnormality.
- Keep your body isolated from ground.
- Never touch exposed wiring, connections or any live circuit conductors.
- Do not install substitute parts or perform any unauthorized modifications on the instrument.
- Use caution when working above 60V DC or 30V AC rms. Such voltages pose a shock hazard.
- Remember that line voltage is present on circuit points such as on-off switches, fuse, power transformers, etc., even when the equipment is turned off.
- Remember that high voltage may appear at unexpected points in defective equipment.

Safety Symbols

	DANGEROUS VOLTAGE		SEE EXPLANATION IN MANUAL
	AC-ALTERNATING CURRENT		GROUND
	DC-DIRECT CURRENT		FUSE

CONTENTS

1. PRODUCT DESCRIPTION

1-1. Introduction -----	(5)
1-2. Technical Specifications -----	(6)
1-3. Equipment Ratings -----	(9)
1-4. Supplied Accessories -----	(10)

2. INSTALLATION

2-1. Initial Inspection -----	(10)
2-2. Connecting AC Power -----	(10)
2-3. Cooling and Ventilation -----	(10)
2-4. Position -----	(10)
2-5. Warming-Up -----	(11)

3. OPERATION

3-1. Controls, Indicators and Connectors -----	(11)
3-2. Operating Instructions-----	(14)
3-3. Frequency Measurements -----	(14)
3-4. Period Measurements -----	(16)
3-5. Total Measurements -----	(16)
3-6. RPM Measurements -----	(16)
3-7. Use of RS-232C Serial Interfacing -----	(17)

4. MAINTENANCE

4-1. Fuse Replacement -----	(18)
4-2. Adjustment and Calibration -----	(18)
4-3. Cleaning and Decontamination -----	(18)

5. OTHER

5-1. BNC Cable Considerations -----	(19)
5-2. Attenuator Probes -----	(20)
5-3. Line Frequency Measurements-----	(20)

1. PRODUCT DESCRIPTION

1-1. Introduction

This reciprocal FREQUENCY COUNTER is a microprocessor-controlled instrument for frequency measurement. Due to uniquely developed LSI circuitry in an expanding/reciprocal system, high accuracy with 9-digit resolution is achieved with a one second gate time. It covers a frequency range of from 0.1 Hz to 3.5 GHz based on a 10 MHz TCO (Temperature Controlled Oscillator). Other features include:

- RPM (Revolutions Per Minute) Measuring Function
- External Frequency Standard Input with 9 Digit LED Display
- Attenuator
- Period
- Total
- Low Pass Filter
- Line Filter

Also provided is a self-test function for a quick check of several operating modes. Each mode can be selected by a front panel push button switch with automatic decimal points and indicators. The high accuracy, sensitivity and versatility of this counter make it an extremely valuable instrument to the scientist, engineer, experimenter and communications technician. Lightweight and compact size make it practical for use by the hobbyist or field technician.

1-2. Technical Specifications

■ INPUT A CHARACTERISTICS

- FREQUENCY RANGE: 0.1 Hz to 100 MHz (DC coupled)
30 Hz to 100 MHz (AC coupled)
- SENSITIVITY: 30 mV rms
- COUPLING: AC or DC selectable.
- IMPEDANCE: 1 MΩ resistance shunted by < 40 pF
- ATTENUATOR: x1 or x10 switch selectable
- LOW PASS FILTER: -3 dB point at approx. 100 KHz, switch selectable
- ACCURACY: 0.1Hz to 999Hz \pm Time base stability \pm 1 count \pm 1Hz
1KHz to 99KHz \pm Time base stability \pm 1 count \pm 0.1Hz
100KHz to 100MHz \pm Time base stability \pm res. (Table 1 x 10)

- Resolution and Number of Displayed Digits

Time Base Selector	INT	EXT	INT	EXT	INT	EXT	INT	EXT
Gate Time	0.01S		0.1S		1S		10S	
Number of Display Digits	5	6	6	7	7	8	8	9
Frequency (Input A)	RESOLUTION							
0.1 Hz-0.99 Hz	10 uHz	1 uHz	1 uHz	0.1 uHz	0.1 uHz	10nHz	10nHz	1nHz
1 Hz-9.9 Hz	0.1mHz	10 uHz	10 uHz	1 uHz	1 uHz	0.1 uHz	0.1 uHz	10nHz
10 Hz-99 Hz	1 mHz	0.1mHz	0.1mHz	10 uHz	10 uHz	1 uHz	1 uHz	0.1 uHz
100 Hz-999 Hz	10mHz	1 mHz	1 mHz	0.1mHz	0.1mHz	10 uHz	10 uHz	1 uHz
1 KHz-9.9 KHz	0.1 Hz	10 mHz	10 mHz	1 mHz	1 mHz	0.1 Hz	0.1 mHz	10 uHz
10 KHz-99 KHz	1 Hz	0.1 Hz	0.1 Hz	10 mHz	10 mHz	1 mHz	1 mHz	0.1mHz
100 KHz-999 KHz	10 Hz	1 Hz	1 Hz	0.1 Hz	0.1 Hz	10 mHz	10 mHz	1 mHz
1 MHz-9.9 MHz	100 Hz	10 Hz	10 Hz	1 Hz	Hz	0.1 Hz	0.1 Hz	10 mHz
10 MHz-99 MHz	1 KHz	100 Hz	100 Hz	10 Hz	10 Hz	1 Hz	1 Hz	0.1 Hz
100MHz	10 KHz	1 KHz	1 KHz	100 Hz	100 Hz	10 Hz	10 Hz	1 Hz

(Table 1)

- Max. Input Voltage Level




FIG. 1 MAX. Input Level. (Input A)

- PERIOD RANGE: 10 nS to 10 S
DISPLAY: n/u/m (nano/micro/milli) Sec. with dec point
Accuracy: \pm Time base stability \pm 0.3% \pm 1 count
- TOTAL RANGE: 10 Hz to 30 MHz
CAPACITY: 0 to 999 999 999, OVER FLOW : "OF"
- RPM RANGE: 600 to 600×10^6 RPM, OVER FLOW : "OF"

■ INPUT C. CHARACTERISTICS

- FREQUENCY RANGE: 80 MHz to 3.5 GHz
- SENSITIVITY: 15mV from 80 MHz to 2000 MHz
20mV from 2000 MHz to 3.0 GHz
30mV from 3.0GHz to 3.2GHz
50mV from 3.2GHz to 3.5GHz
- COUPLING: AC only
- IMPEDANCE: $50 \Omega \pm 5\%$
- MAX. INPUT LEVEL: 3 V rms sine wave
- Accuracy: \pm Time base stability \pm resolution (table 2) \pm 1 count

- Resolution and Number of Displayed Digits

Time Base Selector	INT	EXT	INT	EXT	INT	EXT	INT	EXT
Gate Time	0.01S		0.1S		1S		10S	
Number Of Displayed Digits	5	6	6	7	7	8	8	9
Frequency (Input C)	RESOLUTION							
80 MHz-999 MHz	10 KHz	1 KHz	1 KHz	100 Hz	100 Hz	10 Hz	10 Hz	1 Hz
1 GHz-3.7 GHz	100 KHz	10 KHz	10 KHz	1 KHz	1 KHz	100 Hz	100 Hz	10 Hz

(Table 2)

■ TIME BASE CHARACTERISTICS

- TYPE: TCO (Temperature Controlled Oscillator)
- FREQUENCY: 10.000000 MHz
- STABILITY: ± 1 PPM (± 1 count)
- LINE VOLTAGE STABILITY: Less than ± 1 PPM with $\pm 10\%$ line voltage variation
- TEMPERATURE STABILITY: ± 5 PPM from 0°C to 50°C
- MAX. AGING RATE: ± 5 PPM/year
- INT. STD. OUT: 10 MHz (Internal Standard Frequency Output)
 - LEVEL: 1 V p-p or more. TTL (10TTL)
 - CAPACITANCE: 15pF
- EXT. STD. IN: 10 MHz (External Standard Frequency Input)
 - LEVEL: 1.5Vrms to 5Vrms
 - IMPEDANCE: Approx. 600Ω

■ DISPLAY CHARACTERISTICS

- DISPLAY: Nine Digit 0.56" LED with M (Mega) or K (Kilo) Hz; nano, micro, or milli (n/u/m) Sec.; GT (GATE TIME); H (HOLD); and OF (OVERFLOW) indicators. FUNCTION and GATE TIME are

user selected. OF display is shown when the count exceeds 999 999 999.

- **HOLD:** In the FREQUENCY, PERIOD, TOTAL, RPM modes, measurement in progress is stopped; and the last complete measurement is displayed. When HOLD is released, a new measurement begins.
- **GATE TIME:** Depending on input frequency
 - < 10 mS----- Somewhere between 0.9 and 9mS
 - < 0.1 S----- Somewhere between 9 and 90mS
 - < 1 S-----Somewhere between 90 and 900mS
 - < 10 S-----Somewhere between 0.9 and 9S

NOTE:

LAST MEASUREMENT DISPLAY WILL REMAIN FOR 10 SECONDS AFTER SIGNAL OFF.

■ **DIMENSIONS AND WEIGHT**

- Dimensions (WxHxD): 9.4 x 3.5 x 10.6" (240 x 90 x 270mm)
- Weigh (Approx)t: 5.5lbs. (2.5 kg.)

1-3. Equipment Ratings

- AC Input and Fuse Ratings:

AC Input	Fuse	Power Max.
103 ~ 126V AC (50/60Hz)	F 0.5A / 250 V	9 W
206 ~ 252V AC (50/60Hz)	F 0.2A / 250 V	

- Plug and Socket: 3 wire ac power plug and 3 wire outlet
- Operating Environment:
 - TEMPERATURE: 0 °C to + 40 °C (Accuracy Specified at 23 °C ± 5 °C)
 - HUMIDITY: up to 85% RH (Relative Humidity) to 40°C without

temperature extremes causing condensation within the instrument.

- Storage Environment:
 TEMPERATURE: -20 °C to +70 °C
 HUMIDITY: below 85% RH
- Insulation Category II: Portable equipment of local level.
- Pollution Degree: 2
- Protection to IEC 529: Ordinary

Information and specifications are subject to change without notice. Please visit www.bkprecision.com for the most current product information.

1-4. Supplied Accessories

- User's Manual -----1
- BNC cable -----1
- Power cord-----1
- Spare Fuse-----1

2. INSTALLATION

2-1. Initial Inspection

This instrument was carefully inspected both mechanically and electrically before shipment. It should be physically free of damage. To confirm this, the instrument should be inspected for physical damage which may have occurred in transit. Also, verify that all supplied accessories have been included.

2-2. Connecting AC Power

This instrument requires 115V AC or 230V AC (50-60 Hz) power through a 3-conductor AC power cable to be plugged into a three-contact electrical outlet to secure grounding. If adapted into a 2-conductor cable, use the ground terminal on the rear panel for grounding the instrument.

<p>CAUTION AC POWER OF THIS INSTRUMENT IS PRESET TO 115 V IN FACTORY. BEFORE POWERING ON THIS INSTRUMENT, CHECK AND MAKE SURE THE VOLTAGE OF THE POWER SOURCE IS SAME WITH THE MARKING OF UNIT.</p>
--

IN CASE OF 230 V AC, VOLTAGE SELECTOR (on rear panel) SHOULD BE SELECTED TO 230 V POSITION AND THE FUSE SHOULD BE CHANGED ACCORDING TO THE FUSE RATINGS IN THE SPECIFICATIONS.

2-3. Cooling and Ventilation

No special cooling and ventilation is required. However, the instrument should be operated where the ambient temperature is maintained.

2-4. Position

This instrument is built as a bench-type instrument with rubber feet and tilt stand in place. The stand-up angle can be adjusted by changing the angle of the carrying handle.

2-5. Warming-Up

Allow at least 30 minutes for the unit to warm up so that it can stabilize.

3. OPERATION

3-1. Controls, Indicators and Connectors




FIG.2 FRONT PANEL

- ① GATE INDICATOR: The gate light, when lit, indicates the main gate is open and measurement is in progress.
- ② RS-232C INDICATOR: TX (transmitting), RX (receiving) blinking
- ③ OVER FLOW INDICATOR: OF is displayed when there is an overflow.
- ④ DISPLAY: 9 digit (0.56") green LED display used for all readings.

NOTE: LAST MEASUREMENT DISPLAY WILL REMAIN FOR 10 SECONDS AFTER SIGNAL OFF.

- ⑤ UNIT INDICATOR: When lit, indicates that the frequency displayed is in MHz, KHz, Hz and period is in nano, micro, or milli (n/u/m) Sec.
- ⑥ HOLD INDICATOR: The HOLD function is engaged the when lit.
- ⑧ INPUT C: Use this input for all frequency measurements above 80 MHz. Female N type connector terminated in 50Ω.
- ⑨ LOW PASS FILTER: With this switch pushed in, the A input is routed through a low-pass filter with a -3 dB point at approximately 100 KHz. When it is released, the A input is applied directly to the counter.
- ⑩ ATT. SWITCH: When this switch is set to x10 (pushed in) the A input is attenuated 10:1 before application to the counter. With the switch set to x1 (pushed out), the A input signal is applied unattenuated. The attenuator has no effect on the C input.
- ⑫ COUPLE. SWITCH: This switch is used to select the input coupling mode, AC or DC.
- ⑭ INPUT A: Use this input for frequency measurements below 100 MHz and all period measurements. Female BNC connector. Input impedance is 1 MΩ shunted by < 40

pF.

- ⑮ GATE TIME SWITCH: This switch selects the degree of resolution on the display in all modes except TOTAL.
- ⑯ HOLD SWITCH: In the HOLD function, the display is held but the counter continues to increment. When HOLD is released, the display is updated and resumes counting.
- ⑰ FUNCTION SWITCH: This selects the desired operating mode.
 - a. FREQ. A: When this mode is selected, the counter reads the frequency of the input at A. Resolution is selected using the GATE TIME.
 - b. FREQ. C: When this mode is selected, the counter reads the frequency of the input at C. All readings are in MHz.
 - c. PERIOD A: When this mode is selected, the counter reads the period of the input at A. Resolution is selected using the GATE TIME.
 - d. TOTAL A: When this mode is selected, the unit counts the cycles of the signal at input A and continuously displays that count.
 - e. RPM A: When this mode is selected, the unit displays the RPM (Revolutions Per Minute) of the signal at input A.
- ⑱ POWER SWITCH: This push type switch, turns on the power when pressed.
- ⑳ TILT STAND: Pull out to adjust tilt.




FIG.3 REAR PANEL

- ① AC INLET: AC power input connector
- ② INT/EXT TIME BASE SELECTOR:

Selects the source of the time base. EXT.STD. IN sets up BNC ⑤ as a nominal 600Ω input impedance path for an external 10 MHz time base signal. INT. STD. OUT sets up BNC ⑤ to monitor the internal time base signal.
- ③ GROUND TERMINAL
- ④ FUSE HOLDER: Replace fuse by unscrewing
- ⑤ INT/EXT TIME BASE BNC:

Provides a connector through which the internal time base signal can be monitored or through which an external time base signal can be applied (see item ② above). The external signal should have a voltage range of 1.5 V~5 V rms.
- ⑥ RS-232C CONNECTOR: Connector for serial interfacing with a computer.

3-2. Operating Instructions

- a. Connect the unit up to the AC power.
- b. Turn on the unit by pushing in the POWER on-off switch.
- c. Set the FUNCTION indicator position to FREQ A and the gate TIME indicator to the 1 Sec, position.

CAUTION

1. APPLICATION OF INPUT VOLTAGES HIGHER THAN THE LIMITS LISTED IN THE SPECIFICATIONS SECTION MAY DAMAGE THE COUNTER. BEFORE APPLYING ANY SIGNAL TO THE INPUTS, MAKE CERTAIN THAT IT DOES NOT EXCEED THESE SPECIFIED MAXIMUMS.

2. FREQUENCY COUNTER GROUND POINTS ARE CONNECTED DIRECTLY TO EARTH GROUND. CONNECT GROUND OF THE CIRCUIT UNDER TEST TO THE FREQUENCY COUNTER GROUND ONLY

3-3. Frequency Measurements

A. INPUT A (0.1 Hz to 100 MHz):

- a. Apply the signal to be measured at input A.
- b. Set the FUNCTION indicator to FREQ. A
- c. Select the resolution using the GATE TIME selector switch.
- d. The frequency is indicated on the display. The gate indicator is lit while the measurement is in progress, and the display is updated at the end of each measurement interval.
- e. Engaging the HOLD switch “freezes” the display at the existing reading. When HOLD is released, the display is updated and resumes counting.
- f. Engage the ATTENUATOR if necessary. When set to x10 (pushed in), the signal at input A is attenuated by a factor of approximately 10 before it is applied to the counter. This helps prevent miscounting caused by noisy or improperly terminated high amplitude signals.
- g. Engage the LOW PASS FILTER (LPF) if necessary. When this switch is

pushed in, the signal at input A is routed through a low pass filter (-3 dB point at approximately 100 KHz) before it is applied to the counter. This helps eliminate counting errors in low frequency measurements by minimizing effects of high frequency noise that may accompany the signal.

- h. When making measurements near the lower cut-off frequency of input A (10 Hz or less), use DC coupling (Push in the DC COUPLING switch).

B. INPUT C (80 MHz to 3.5 GHz)

CAUTION

THE MAXIMUM INPUT TO THIS INPUT IS 3 Vrms OVER THE INPUT FREQUENCY RANGE. THE "X 10 ATTENUATOR" DOES NOT APPLY.

- a. Apply the signal to be measured at input C.
- b. Set the FUNCTION indicator to FREQ. C
- c. Select the resolution using the GATE TIME selector switch.
- d. The frequency is indicated on the display. The gate indicator is lit while the measurement is in progress, and the display is updated at the end of each measurement interval.
- e. Engaging the HOLD switch "freezes" the display at the existing reading, When HOLD is released, the display is updated and resumes counting.
- f. The ATTENUATOR, LPF, and COUPLING switches have no effect with input C.

3-4. Period Measurements

- a. Apply the signal to be measured at input A.
- b. Select the resolution using the GATE TIME selector switch.
- c. The period is indicated on the display. The gate indicator is lit while the measurement is in progress.
- d. The ATTENUATOR, LPF, and COUPLING switches operate the same as they do in the frequency measurements modes.

3-5. Total Measurements

The totalize mode is used to count the total number of events occurring during a specific time period. The maximum frequency is 30 MHz.

- a. With the FUNCTION switch, select the TOTAL A mode. Gate and unit settings are ignored.
- b. Apply the signal to be measured at input A. The accumulated counts will be displayed continuously to a maximum count of 999999999. If this is exceeded, the overflow message, OF, will be displayed.
- c. The ATTENUATOR, LPF, and COUPLING switches operate the same as they do in the frequency measurements modes.

NOTE

THE HOLD SWITCH MAY BE USED TO LATCH THE DISPLAY. THE COUNTER, HOWEVER, WILL CONTINUE TO INCREMENT. WHEN THE HOLD SWITCH IS RELEASED, THE UPDATED COUNT WILL BE DISPLAYED.

3-6. RPM (Revolutions Per Minute) Measurement

- a. Apply the signal to be measured at input A. The count will be displayed as revolutions per minute (RPM). Maximum count is 999999999. If this is exceeded, the overflow message, OF, will be displayed.
- b. The ATTENUATOR, LPF, and COUPLING switches operate the same as they do in the frequency measurements modes.

3-7. Use of RS-232C Serial Interfacing

1) Hardware/Software Requirements

IBM PC/XT/AT or compatible computer

Microsoft Windows

Serial port for connection with counter

2) Output Data Formats

(1) Baud rate : 9600BPS

1 start bit (0)

8 data bit

1 stop bit (1)

NONE PARITY

(2) To Frequency counter

Command	Parameter	Terminate Code
'H' : HOLD	'0' : OFF '1' : ON '2' : TOGGLE	CR (0DH)
'G' : GATE	'0' : 0.01 SEC '1' : 0.1 SEC '2' : 1 SEC '3' : 10 SEC	CR (0DH)
'D' : DATA REQUEST	DON'T CARE	CR(0DH)
'F' : FUNCTION SET	N*	CR(0DH)
'R' : REMOTE	'0' : OFF '1' : ON	CR(0DH)

N*=	0	1	2	3	4	5	6	7
3.5GHz,F/C	FA	NC	FC	PERIOD	TOTAL	RPM	NC	NC

(3) From Frequency counter

DATA

UNIT

10BYTES include dp

4bytes CR

4. MAINTENANCE

CAUTION

FOR SAFETY, IT IS ESSENTIAL TO PROPERLY MAINTAIN AND SERVICE THIS INSTRUMENT

WARNING

VOLTAGES WITHIN THIS INSTRUMENT ARE SUFFICIENTLY HIGH TO BE LETHAL. COVERS MUST NOT BE REMOVED EXCEPT BY PERSONS QUALIFIED AND AUTHORIZED TO DO SO, AND THESE PERSONS SHOULD ALWAYS USE EXTREME CARE ONCE THE COVERS HAVE BEEN REMOVED.

4-1. Fuse Replacement

- a. Disconnect and remove all connections from any live power source.
- b. Unscrew the fuse holder with a screwdriver.
- c. Remove the defective fuse.
- d. Install a new fuse of the SAME SIZE AND RATING.
- e. Screw the fuse holder back in.

CAUTION

REPLACEMENT FUSES MUST HAVE THE SAME SIZE AND RATING AS THOSE BEING REPLACED.

4-2. Adjustment and Calibration

Regular adjustment and calibration of this instrument is recommended. The procedures involved should be executed by qualified and authorized personnel only.

4-3. Cleaning and decontamination

The instrument can be cleaned with a soft clean cloth to remove any oil, grease or grime. Never use liquid solvents or detergents. If the instrument gets wet for any reason, dry it using low-pressure clean air at less than 25 PSI. Use care and caution around the window cover areas where water could leak into the instrument while drying.

5. OTHER

5-1. BNC Cable Considerations

The accuracy of radio frequency measurements can be affected by the connections between the signal source and counter. The main issues involved are

standing waves and cable shunt capacitance.

Waves propagating along a transmission line will be reflected at its ends if the line is not terminated in its characteristic impedance. These reflections will set up standing waves in the line, which may cause damage to the signal source or produce inaccurate measurements. This effect increases as the cable length reaches one-fourth of the wavelength for the frequency being measured. Standing waves can be minimized by keeping cable lengths short, or eliminated by providing a proper termination. RG58 cable, for example, has a characteristic impedance of 50Ω . The proper termination for this cable would, therefore, be a 50Ω resistor between the center conductor and the shield. A standard BNC, 50Ω cable termination is most often used for this.

Input A has an input impedance of $1\text{ M}\Omega$ shunted by $< 40\text{ pF}$. Radio frequency measurements made at this input will experience standing waves and attenuation due to the shunt capacitance of the cable which adds to the shunt capacitance at the input. For RF measurements at input A, it is recommended that a 50Ω termination be used, or that the cable be no longer than three feet (91 cm).

Input C has a built in impedance of 50Ω , thus the need for an external termination is eliminated.

In situations where a 50Ω termination could affect bias voltages or other DC voltages in the circuit under test, a blocking capacitor should be used.

5-2. Attenuator Probes

When measuring signals at input A that will exceed its maximum input voltage level (See FIG. 1), a 10:1 attenuating probe such as an oscilloscope probe should be used.

NOTE

DO NOT USE A 10:1 PROBE WITH THE INPUT C. THESE PROBES ARE DESIGNED WITH A 10:1 ATTENUATION FOR AN INSTRUMENT WITH AN INPUT RESISTANCE OF 1 M Ω . THE 50 Ω TERMINATION OF INPUT C WOULD RESULT IN UNACCEPTABLY HIGH ATTENUATION.

5-3. Line Frequency Measurements

When making line frequency measurements, use of the LOW PASS FILTER, the ATTENUATOR, and/or the 10:1 probe is recommended.

WARNING

USE CAUTION WHEN MEASURING THE LINE FREQUENCY OF AN AC OUTLET. USE THE PROBE TIP ONLY, AND MEASURE BOTH SIDES OF THE LINE. THE NEUTRAL SIDE WILL GIVE A ZERO READING AND THE HOT SIDE WILL PROVIDE THE DESIRED MEASUREMENT. DO NOT USE THE "GROUND" LEAD OF THE PROBE. REMEMBER THAT THE CHASSIS OF THE COUNTER AND THE "GROUND" LEAD OF THE PROBE ARE ALREADY AT EARTH GROUND (VIA THE 3-WIRE POWER CORD OF THE INSTRUMENT). TOUCHING THE "GROUND" LEAD TO THE "HOT" SIDE OF THE LINE WOULD PLACE A DIRECT SHORT ON THE POWER LINE THROUGH THE PROBE CABLE, RESULTING IN A BIG SPARK, DAMAGE TO THE PROBE CABLE, AND POSSIBLE INJURY TO THE USER.



Limited One-Year Warranty

B&K Precision Corp. warrants to the original purchaser that its product and the component parts thereof, will be free from defects in workmanship and materials for a period of one year from the date of purchase.

B&K Precision Corp. will, without charge, repair or replace, at its' option, defective product or component parts. Returned product must be accompanied by proof of the purchase date in the form a sales receipt.

To obtain warranty coverage in the U.S.A., this product must be registered by completing and mailing the enclosed warranty card to B&K Precision Corp., 22820 Savi Ranch Parkway, Yorba Linda, CA 92887 within fifteen (15) days from proof of purchase.

Exclusions: This warranty does not apply in the event of misuse or abuse of the product or as a result of unauthorized alternations or repairs. It is void if the serial number is alternated, defaced or removed.

B&K Precision Corp. shall not be liable for any consequential damages, including without limitation damages resulting from loss of use. Some states do not allow limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific rights and you may have other rights, which vary



from state-to-state.

Model Number: _____

Date Purchased: _____

Service Information

Warranty Service: Please return the product in the original packaging with proof of purchase to the below address. Clearly state in writing the performance problem and return any leads, connectors and accessories that you are using with the device.

Non-Warranty Service: Return the product in the original packaging to the below address. Clearly state in writing the performance problem and return any leads, connectors and accessories that you are using with the device. Customers not on open account must include payment in the form of a money order or credit card. For the most current repair charges contact the factory before shipping the product.

Return all merchandise to B&K Precision Corp. with pre-paid shipping. The flat-

rate repair charge includes return shipping to locations in North America. For overnight shipments and non-North America shipping fees contact B&K Precision Corp..

B&K Precision Corp.
22820 Savi Ranch Parkway
Yorba Linda, CA 92887
Phone: 714- 921-9095
Facsimile: 714-921-6422
Email: service@bkprecision.com

Include with the instrument your complete return shipping address, contact name, phone number and description of problem.

v4.8.2014

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>