

# MatchPort<sup>®</sup>







# EDS1100/2100



# Linux Software Developers Kit (SDK) Quick Start Guide

Part Number 900-549 Revision C June 2010

Download from Www.Somanuals.com. All Manuals Search And Download.

### **Copyright and Trademark**

© 2010 Lantronix. All rights reserved. No part of the contents of this book may be transmitted or reproduced in any form or by any means without the written permission of Lantronix.

MatchPort and XPort are registered trademarks of Lantronix.

Linux is a registered trademark of Linus Torvalds. µClinux is a registered trademark of Arcturus Networks Inc. Ubuntu is a registered trademark of Canonical Ltd. The Fedora trademark is a trademark of Red Hat, Inc.

### Contacts

### Lantronix Corporate Headquarters

167 Technology Irvine, CA 92618, USA

Phone: 949-453-3995 Fax: 949-450-7249

### **Technical Support**

Online: www.lantronix.com/support

### Sales Offices

For a current list of our domestic and international sales offices, go to the Lantronix Web site at <u>www.lantronix.com/about/contact</u>

### **Disclaimer**

The information in this guide may change without notice. The manufacturer assumes no responsibility for any errors that may appear in this guide.

### **Revision History**

Date	Rev.	Comments
	А	Initial document
9/09	В	Updated
6/10	С	Updated to include EDS11/2100

For supporting product documentation, or the most current version of this document, please visit the Lantronix Web site at www.lantronix.com/support/documentation.

## Contents

	Copyright and Trademark	2
	Contacts	2
	Disclaimer	2
	Revision History	2
1.	Introduction	5
	Overview	5
2.	What's in the Box	6
	MatchPort	6
	XPort Pro	6
	EDS1100	6
	EDS2100	6
3.	Target Setup	7
	Connecting the Lantronix Evaluation Board	7
	Connecting an Evaluation Board – Power	7
	Connecting an Evaluation Board – Serial Port	7
	Connecting an Evaluation Board – Ethernet	8
	Connecting the EDS1100/2100	8
	Booting the Target Device	8
	Configuring an IP Address	9
4.	SDK Installation Overview	10
	Host requirements	10
	Linux Distributions	10
	Redhat-based distributions	10
	Debian-based distributions	10
	Other Distributions	11
	Installation Procedure	12
<b>5</b> .	Building Images with the SDK	13
<b>6</b> .	SDK Forum Information	15

## **List of Figures**

Figure 3-1. Connecting an Evaluation Board via Serial Port	7
Figure 3-2. Connecting an Evaluation Board via Ethernet	8
Figure 4-1. Message Prompts	12
Figure 5-1. Configuration Profile Menu	13
Figure 5-2. Configuration Prompts	14
Figure 5-3. Installed Images	14

# 1. Introduction

This Quick Start Guide explains the basics: how to connect and set up your target on the network; how to install the SDK; and how to build the firmware images. For more detailed information, refer to the User Guide supplied with this product or our Lantronix Web site <u>www.lantronix.com/support/downloads</u>.

### **Overview**

The Lantronix Linux Software Developer's Kit (SDK) is an embedded hardware and software suite that enables Linux developers to create applications on Lantronix' embedded networking modules.

The MatchPort AR module can be used to add networking capabilities to your device. The development board includes two RS-232 serial ports and a 10/100Base-TX network connection (RJ45).

The XPort Pro module can be used to add networking capabilities to your device. The development board includes an RS-232 serial port and a 10/100Base-TX network connection (RJ45).

The EDS1100 & EDS2100 are external device servers that can be used to add networking capabilities to your device. The EDS1100 has one RS-232 serial port and a 10/ 100Base-TX network connection (RJ45). The EDS2100 has two RS-232 serial ports and a 10/100 Base-TX network connection (RJ45).

Based on the 2.6 Linux kernel, and leveraging existing open source software, the SDK simplifies the process of adding custom applications. Device drivers, GNU toolchain, pre-defined configuration profiles, and sample applications are all included.

# 2. What's in the Box

Items included depend on which model you have.

### **MatchPort**

The box contains the following items:

- Ethernet cable 10 ft
- MatchPort AR Evaluation Board
- MatchPort AR Module (may have optional BDM connector)
- Antenna 2.4GHz 2.15 dbi reverse polarity SMA
- 3.3V wall-mount power supply AC/DC, 1A
- RS-232, DB9F/F, 10ft, null modem cable
- SMA to UFL adapter cable

### EDS1100

The box contains the following items:

- EDS1100
- Cat5e UTP RJ45M/M Ethernet cable
- DB25M to DB9F serial cable
- Power Cube, 100-240VAC, with international adapters and Power Cord Restraint

### **XPort Pro**

The box contains the following items:

- Cat5e UTP RJ45M/M Ethernet cable
- XPort Universal Demo Board
- XPort Pro Development Board with BDM Connector
- 3.3V wall-mount power supply AC/DC, 1.2A
- RS-232 cable, DB9F/F, null modem

### **EDS2100**

The box contains the following items:

- EDS2100
- Cat5e UTP RJ45M/M Ethernet Cable
- DB9F to DB9F serial cable
- Power Cube, 100-240VAC, with international adapters and Power Cord Restraint

# 3. Target Setup

### **Connecting the Lantronix Evaluation Board**

This section describes how to connect the MatchPort AR evaluation board or XPort Pro demo board to your host computer and network.

### **Connecting an Evaluation Board – Power**

- 1. Make sure that the power switch on the evaluation or demo board is set to off.
- 2. Select the appropriate power plug adaptor for your geographical location. Insert it into the slot on the Universal Power Supply; then plug the power supply into an outlet.
- 3. Connect the output plug of the power supply to the evaluation or demo board.

### **Connecting an Evaluation Board – Serial Port**

- 1. Connect one end of the supplied DB9F/F (DB25F on EDS1100) serial cable to the serial port on the laptop or desktop.
- Connect the other end of the supplied DB9F/F serial cable to the serial port on the evaluation board (CON1 on MatchPort AR and EDS2100).



#### Figure 3-1. Connecting an Evaluation Board via Serial Port

### **Connecting an Evaluation Board – Ethernet**

Connect the PC to the evaluation or demo board with a cross-over cable, or a hub/switch and two regular RJ45 cables.

#### Figure 3-2. Connecting an Evaluation Board via Ethernet



### Connecting the EDS1100/2100

- 1. Select the appropriate power plug adaptor for your geographical location. Insert it into the slot on the Universal Power Supply; then plug the power supply into an outlet.
- 2. Connect the output plug of the power supply to the EDS1100/EDS2100.
- 3. Connect one end of the supplied DB9F/F (DB25F on EDS1100) serial cable to the serial port on the laptop or desktop.
- 4. Connect the other end of the supplied serial cable to the serial port on the EDS1100 (CON1 on EDS2100).
- 5. Connect the PC to the evaluation or demo board with a cross-over cable, or a hub/switch and two regular RJ45 cables.

### **Booting the Target Device**

### To boot your target device (MatchPort AR, XPort Pro, or EDS1100 / 2100):

- 1. From the host computer, open a terminal emulation program for the serial port.
- 2. Configure the following serial port settings:
  - baud rate: 115200
  - data length: 8
  - parity: None
  - stop bit: 1
  - flow control: None
- 3. Turn the power on.

A series of boot messages displays before the Linux shell prompt of '#' appears.

### **Configuring an IP Address**

By default, the target device (MatchPort AR, XPort Pro, or EDS1100 / 2100) will attempt to obtain an IP address via the DHCP protocol. Type the following command at the Linux shell prompt to determine the IP address:

```
$ ifconfig eth0
```

The ifconfig command can also be used to set an address, but it will not persist across a reboot.

To set a temporary static address, issue the following command (replace angle bracketed items with actual values):

```
$ ifconfig eth0 <target_ip_address> <target_subnet_mask>
```

### To set a static address that persists across reboots:

- 1. Use the vi text editor to edit /usr/local/etc/netcfg. (Consult a vi manual for details on using this text editor).
- 2. Add the following lines to the netcfg file (replace angle bracketed items with actual values)

```
IPADDR=<target_ip_address>
NETMASK=<target_subnet_mask>
GATEWAY=<target_gateway_address>
```

- 3. Write the changes to the file and exit the from the vi editor.
- 4. Issue the 'reboot' command to reset the target for changes to take effect.

# 4. SDK Installation Overview

### **Host requirements**

Please make sure that at least 2.5 GB of disk space is available before installation.

Some operations may require root privileges. Consult the User Guide for instructions on setting up sudo access.

### **Linux Distributions**

The SDK was validated on the following Linux distributions:

### **Redhat-based distributions**

- Fedora 9, 10, 11, 12, Fedora Core 5 & 6
- CentOS 5.2, 5.3, 5.4
- groupinstall 'Development Tools' (installs additional development tools not necessary for the SDK) or gcc, make, glibc-devel
- python
- sudo
- libacl-devel
- tftp-server or tftpd-hpa
- libtasn1-devel
- zlib-devel
- rsync
  - Optional but recommended packages
- openssh, openssh-clients, openssh-server
- nfs-utils
- ncurses-devel (for the ncurses-based configuration utility)
- libglade2-devel (for the GTK-based graphical configuration utility)
- qt-devel (for the Qt3-based graphical configuration utility)

### **Debian-based distributions**

- Debian Lenny 5.0.2 & 5.0.4
- Ubuntu 8.04, 8.10, 9.04, 9.10, 10.04
- build-essential

- python
- sudo
- libacl1-dev
- tftpd or tftpd-hpa
- libtasn1-3-dev
- zlib1g-dev
- rsync
  - Optional but recommended packages
- ssh
- nfs-kernel-server
- libncurses5-dev (for the ncurses-based configuration utility)
- libglade2-dev (for the GTK-based graphical configuration utility)
- libqt3-mt-dev (for the Qt3-based graphical configuration utility)

### **Other Distributions**

- OpenSUSE 11.2
- pattern install devel\_C\_C++
- pattern install devel\_kernel
- python
- sudo
- libacl-devel
- tftp or tftpd-hpa
- libtasn1-devel
- zlib-devel
- rsync
  - Optional but recommended packages
- openssh, openssh-clients, openssh-server
- nfs-utils
- ncurses-devel (for the ncurses-based configuration utility)
- libglade2-devel (for the GTK-based graphical configuration utility)
- qt-devel (for the Qt3-based graphical configuration utility)

### NOTE

If you are able to compile the Linux kernel on your host machine, you will also be able to build the SDK images.

### **Installation Procedure**

#### To install the SDK software on your host machine:

- 1. Mount the SDK CD image on your host system. The User Guide provides additional information about image mounting procedures.
- 2. Select and create an installation directory (replace angle bracketed items with actual values). You must have write privileges to this directory.

```
$ mkdir -p <install_directory>
```

3. Switch into the installation directory.

```
$ cd <install directory>
```

4. Run the installation script. Use the full path to <cdrom directory>

```
$ <cdrom directory>/install.sh
```

- 5. When prompted, type Y to accept the installation directory.
- 6. Install the directory.

```
[<install directory>] ? (Y/n) : Y
```

7. Type Y to continue the installation process, if the following message prompts appear.

#### Figure 4-1. Message Prompts

```
You are using /bin/sh -> dash.
To use Linux SDK, you cannot use /bin/sh -> dash.
Attempt to automatically relink /bin/sh -> bash?
(y/N): y
Missing needed host development packages.
Note that sudo privileges are required for
installation.
Attempt to automatically install missing packages?
(y/N): y
```

The SDK begins the installation process on your host system.

#### NOTE

The installation process may take several minutes to complete.

## 5. Building Images with the SDK

To build an image with the SDK:

- 1. From the development host, switch into the installation directory.
  - \$ cd <install directory>
- 2. Source the environment file.
  - \$ . env\_m68k-µClinux
- 3. Issue the make command.

\$ make

4. Select a configuration profile when prompted.

### NOTE

If you are unsure of which configuration profile to use, begin with the DEFAULT profile.

Figure 5-1. Configuration Profile Menu

Configuration Profile
<pre>&gt; 1. DEFAULT (LTRX_PROFILE_DEFAULT) (NEW)</pre>
2. DEVELOPMENT (LTRX_PROFILE_DEVELOP) (NEW)
<pre>3. NO_IPV6 (LTRX_PROFILE_NO_IPV6) (NEW)</pre>
<pre>4. COMPACT (LTRX_PROFILE_COMPACT) (NEW)</pre>
<pre>5. AUFS (LTRX_PROFILE_AUFS) (NEW)</pre>
<pre>6. SHARED (LTRX_PROFILE_SHARED) (NEW)</pre>
choice[1-6?]: 1
*
* Kernel/Library/Defaults Selection
*
*
* Kernel is linux-2.6.x
*
*
* Libc is uClibc
*
*
* glibc Library Configuration
*

5. Press Enter to accept the default options for the remaining prompts.

#### Figure 5-2. Configuration Prompts

```
Default all settings (lose changes)
(DEFAULTS_OVERRIDE) [N/y] (NEW)
Customize Kernel Settings (DEFAULTS_KERNEL) [N/y]
(NEW)
Customize Application/Library Settings
(DEFAULTS_VENDOR) [N/y] (NEW)
Update Default Vendor Settings
(DEFAULTS_VENDOR_UPDATE) [N/y] (NEW)
...
```

#### NOTE

The build process may take several minutes to complete.

- Once the build process is complete, verify that the images listed below are under <install directory>/linux/images/.
  - \$ ls linux/images/

#### Figure 5-3. Installed Images

```
image.bin imageu.bin imagez.bin linux.bin linuxz.bin
image.without_header linux.without_header romfs.img
rootfs.img romfs-inst.log
```

7. Build the root file system for NFS from the installation directory.

```
$ mkdir linux/nfs
$ make
```

# 6. SDK Forum Information

The Lantronix Linux SDK forum Web site (<u>http://forums.lantronix.com</u>) is the primary resource to obtain updated revisions of the SDK. The SDK and related documentation are also available via the Downloads page (<u>www.lantronix.com/support/downloads</u>). Please visit the Lantronix Web site or the Forums page to determine if a more current version of the SDK is available.

Individual forum topics are monitored by Lantronix engineers and technical support staff and may be used to ask questions regarding any aspect of the SDK. Complete the registration process to obtain a logon ID and post your question. If enabled in your user profile, you will receive an email message when a response to your post is available. Other options for interacting with the forum are described on the forum site itself.

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com