


# **Rotary Hammer**

# 24 mm (15/16") MODEL HR2400



003093



# INSTRUCTION MANUAL

#### **WARNING:**

For your personal safety, READ and UNDERSTAND before using. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

www.makitatools.com

# **SPECIFICATIONS**

Mo	del	HR2400
Capacities	Concrete	24 mm (15/16")
	Steel	13 mm (1/2")
	Wood	38 mm (1-1/2")
No load speed (RPM)		0 - 1,200/min.
Blows per minute		0 - 4,200
Overall length		333 mm (13-1/8")
Net weight		2.3 kg (5 lbs)

- · Manufacturer reserves the right to change specifications without notice.
- · Specifications may differ from country to country.

# **GENERAL SAFETY RULES**

USA002-2

(For All Tools)

# **☆ WARNING:**

**Read and understand all instructions.** Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

# SAVE THESE INSTRUCTIONS

#### Work Area

- 1. Keep your work area clean and well lit. Cluttered benches and dark areas invite accidents.
- 2. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite the dust or fumes.
- 3. Keep bystanders, children, and visitors away while operating a power tool. Distractions can cause you to lose control.

#### **Electrical Safety**

4. Double insulated tools are equipped with a polarized plug (one blade is wider than the other.) This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install a polarized outlet. Do not change the plug in any way. Double insulation I eliminates the need for the three wire grounded power cord and grounded power supply system.

- Avoid body contact with grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is grounded.
- 6. Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
- Do not abuse the cord. Never use the cord to carry the tools or pull the plug from an outlet. Keep cord away from heat, oil, sharp edges or moving parts. Replace damaged cords immediately. Damaged cords increase the risk of electric shock.
- When operating a power tool outside, use an outdoor extension cord marked "W-A" or "W". These cords are rated for outdoor use and reduce the risk of electric shock.

#### **Personal Safety**

- 9. Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use tool while tired or under the influence of drugs, alcohol, or medication. A moment of inattention while operating power tools may result in serious personal injury.
- 10. Dress properly. Do not wear loose clothing or jewelry. Contain long hair. Keep your hair, clothing, and gloves away from moving parts. Loose clothes, jewelry, or long hair can be caught in moving parts.
- 11. Avoid accidental starting. Be sure switch is off before plugging in. Carrying tools with your finger on the switch or plugging in tools that have the switch on invites accidents.
- 12. Remove adjusting keys or wrenches before turning the tool on. A wrench or a key that is left attached to a rotating part of the tool may result in personal injury.

- 13. Do not overreach. Keep proper footing and balance at all times. Proper footing and balance enables better control of the tool in unexpected situations.
- 14. Use safety equipment. Always wear eye protection. Dust mask, non-skid safety shoes, hard hat, or hearing protection must be used for appropriate conditions. Ordinary eye or sun glasses are NOT eye protection.

#### **Tool Use and Care**

- 15. Use clamps or other practical way to secure and support the workpiece to a stable platform. Holding the work by hand or against your body is unstable and may lead to loss of control.
- 16. Do not force tool. Use the correct tool for your application. The correct tool will do the job better and safer at the rate for which it is designed.
- 17. Do not use tool if switch does not turn it on or off. Any tool that cannot be controlled with the switch is dangerous and must be repaired.
- 18. Disconnect the plug from the power source before making any adjustments, changing accessories, or storing the tool. Such preventive safety measures reduce the risk of starting the tool accidentally.
- 19. Store idle tools out of reach of children and other untrained persons. Tools are dangerous in the hands of untrained users.
- 20. Maintain tools with care. Keep cutting tools sharp and clean. Properly maintained tools with sharp cutting edges are less likely to bind and are easier to control.
- 21. Check for misalignment or binding of moving parts, breakage of parts, and any other condition that may affect the tools operation. If damaged, have the tool serviced before using. Many accidents are caused by poorly maintained tools.
- 22. Use only accessories that are recommended by the manufacturer for your

**model.** Accessories that may be suitable for one tool, may become hazardous when used on another tool.

## SERVICE

23. Tool service must be performed only by qualified repair personnel. Service or maintenance performed by unqualified personnel could result in a risk of injury.

24. When servicing a tool, use only identical replacement parts. Follow instructions in the Maintenance section of this manual. Use of unauthorized parts or failure to follow Maintenance instructions may create a risk of electric shock or injury.

**USE PROPER EXTENSION CORD:** Make sure your extension cord is in good condition. When using an extension cord, be sure to use one heavy enough to carry the current your product will draw. An undersized cord will cause a drop in line voltage resulting in loss of power and overheating. Table 1 shows the correct size to use depending on cord length and nameplate ampere rating. If in doubt, use the next heavier gage. The smaller the gage number, the heavier the cord.

Ampere Rating		Volts	Total length of cord in feet			
		120 V	25 ft.	50 ft.	100 ft.	150 ft.
More Than	Not More Than			AWG		
0	6		18	16	16	14
6	10		18	16	14	12
10	12		16	16	14	12
12	16		14	12	Not Reco	mmended

#### Table 1: Minimum gage for cord

# SPECIFIC SAFETY RULES

USB010-2

DO NOT let comfort or familiarity with product (gained from repeated use) replace strict adherence to rotary hammer safety rules. If you use this tool unsafely or incorrectly, you can suffer serious personal injury.

- Hold tools by insulated gripping surfaces when performing an operation where the cutting tool may contact hidden wiring or its own cord. Contact with a "live" wire will make exposed metal parts of the tool "live" and shock the operator.
- 2. Wear ear protectors when using the tool for extended periods. Prolonged exposure

to high intensity noise can cause hearing loss.

- Wear a hard hat (safety helmet), safety glasses and/or face shield. Ordinary eye or sun glasses are NOT safety glasses. It is also highly recommended that you wear a dust mask and thickly padded gloves.
- 4. Be sure the bit is secured in place before operation.

- 5. Under normal operation, the tool is designed to produce vibration. The screws can come loose easily, causing a breakdown or accident. Check tightness of screws carefully before operation.
- 6. In cold weather or when the tool has not been used for a long time, let the tool warm up for a while by operating it under no load. This will loosen up the lubrication. Without proper warm-up, hammering operation is difficult.
- Always be sure you have a firm footing. Be sure no one is below when using the tool in high locations.
- 8. Hold the tool firmly with both hands.


- 9. Keep hands away from moving parts.
- 10. Do not leave the tool running. Operate the tool only when hand-held.
- 11. Do not point the tool at any one in the area when operating. The bit could fly out and injure someone seriously.
- 12. Do not touch the bit or parts close to the bit immediately after operation; they may be extremely hot and could burn your skin.
- Some material contains chemicals which may be toxic. Take caution to prevent dust inhalation and skin contact. Follow material supplier safety data.

# SAVE THESE INSTRUCTIONS

# **∆** WARNING:

MISUSE or failure to follow the safety rules stated in this instruction manual may cause serious personal injury.

# FUNCTIONAL DESCRIPTION



1. Switch trigger

2. Lock lever

### **△** CAUTION:

• Always be sure that the tool is switched off and unplugged before adjusting or checking function on the tool.

# Switch action

## ▲ CAUTION:

- Before plugging in the tool, always check to see that the switch trigger actuates properly and returns to the "OFF" position when released.
- Switch can be locked in "ON" position for ease of operator comfort during extended use. Apply caution when locking tool in "ON" position and maintain firm grasp on tool.

To start the tool, simply pull the switch trigger. Tool speed is increased by increasing pressure on the switch trigger. Release the switch trigger to stop.

For continuous operation, pull the switch trigger and then slide the lock lever upward.


To stop the tool from the locked position, pull the switch trigger fully, then release it.

# Reversing switch action


This tool has a reversing switch to change the direction of rotation. Press the upper side (FWD side) of the reversing switch for clockwise rotation or the lower side (REV side) of the reversing switch for counterclockwise rotation.

### **△** CAUTION:

- Always check the direction of rotation before operation.
- Use the reversing switch only after the tool comes to a complete stop. Changing the direction of rotation before the tool stops may damage the tool.



1. Reversing switch



1. Action mode changing knob

#### Selecting the action mode

This tool employs an action mode changing knob. Select one of the three modes suitable for your work needs by using this knob.

For rotation only, turn the knob so that the arrow on the knob points toward the **a** mark on the tool body.

For hammering only, turn the knob so that the arrow on the knob points toward the  $\Upsilon$  mark on the tool body.

For rotation with hammering, turn the knob so that the arrow on the knob points toward the  $\Re r$  mark on the tool body.

### **△** CAUTION:

 Always set the knob correctly to your desired mode mark. If you operate the tool with the knob positioned halfway between the mode marks, the tool may be damaged.

## NOTE:

• When it is hard to turn the knob, pull the switch trigger halfway for running at low speed and turn the knob.

# **Torque limiter**

The torque limiter will actuate when a certain torque level is reached. The motor will disengage from the output shaft. When this happens, the bit will stop turning.


### ▲ CAUTION:

- As soon as the torque limiter actuates, switch off the tool immediately. This will help prevent premature wear of the tool.
- Hole saws, core bits, diamond core bits, etc. cannot be used with this tool. They tend to pinch or catch easily in the hole. This will cause the torque limiter to actuate too frequently.

ASSEMBLY

# **△** CAUTION:

• Always be sure that the tool is switched off and unplugged before carrying out any work on the tool.



Side grip
 Clamp screw

# Side grip (auxiliary handle)


The side grip swings around to either side, allowing easy handling of the tool in any position. Loosen the clamp screw on the side grip and swing the side grip to the desired position. Then tighten the clamp screw to secure the side grip.

# Bit grease (optional accessory)

Coat the bit shank head beforehand with a small amount of bit grease (about 0.5 -1 g; 0.02 - 0.04 oz.). This chuck lubrication assures smooth action and longer service life.


# Installing or removing the bit

Clean the bit shank and apply bit grease before installing the bit.



1. Bit shank

2. Bit grease




1. Bit

2. Chuck cover

Insert the bit into the tool. Turn the bit and push it in until it engages.


If the bit cannot be pushed in, remove the bit. Pull the chuck cover down a couple of times. Then insert the bit again. Turn the bit and push it in until it engages.

After installing, always make sure that the bit is securely held in place by trying to pull it out.



I. BIT

2. Chuck cover



- 1. Chisel adapter
- 2. Clamp screw
- 3. Chisel

To remove the bit, pull the chuck cover down all the way and pull the bit out.


# Using cold chisel or bull point

When using optional cold chisel or bull point, proceed as follows.

- 1. Unplug the tool.
- 2. Remove the side grip from the tool.
- 3. Set the action mode changing knob to "rotation with hammering" symbol.
- 4. Install the cold chisel or bull point and then the chisel adapter (optional accessory) on the tool.
- 5. Rotate the cold chisel toward the direction suitable for your work. Then secure the cold chisel and chisel adapter by using the clamp screw on the chisel adapter.
- Turn the action mode changing knob to "hammering only" symbol. Now you can use the cold chisel or bull point.

# ▲ CAUTION:

 Always use "hammering only" action when the chisel adapter is installed on the tool. If you use "rotation with hammering" or "rotation only" action, a malfunction and damage to the tool will result.




2. Depth gauge

### Depth gauge

The depth gauge is convenient for drilling holes of uniform depth. Insert the depth gauge into the hole in the grip base. Adjust the depth gauge to the desired depth and then tighten the clamp screw to secure the depth gauge.

### NOTE:

• The depth gauge cannot be used at the position where the depth gauge strikes against the tool body.



1. Dust cup

# **OPERATION**

# Dust cup (optional accessory)

Use the dust cup to prevent dust from falling over the tool and on yourself when performing overhead drilling operations. Attach the dust cup to the bit as shown in the figure. The size of bits which the dust cup can be attached to is as follows.

	Bit diameter		
Dust cup 5	6 mm (1/4") - 14.5 mm (9/16")		
Dust cup 9	12 mm (15/32") - 16 mm (5/8")		

# Hammer drilling operation

Set the action mode changing knob to the  $\Im$  symbol.

Position the bit at the desired location for the hole, then pull the switch trigger. Do not force the tool. Light pressure gives best results. Keep the tool in position and prevent it from slipping away from the hole.


Do not apply more pressure when the hole becomes clogged with chips or particles. Instead, run the tool at an idle, then remove the bit partially from the hole. By repeating this several times, the hole will be cleaned out and normal drilling may be resumed.

# ▲ CAUTION:

There is a tremendous and sudden twisting force exerted on the tool/bit at the time of hole break-through, when the hole becomes clogged with chips and particles, or when striking reinforcing rods embedded in the concrete. Always use the side grip (auxiliary handle) and firmly hold the tool by both side grip and switch handle during operations. Failure to do so may result in the loss of control of the tool and potentially severe injury.

# Blow-out bulb (optional accessory)

After drilling the hole, use the blow-out bulb to clean the dust out of the hole.



1. Blow-out bulb

# Chipping/Scaling/Demolition

Set the action mode changing knob to the  $\Upsilon$  symbol.

Hold the tool firmly with both hands. Turn the tool on and apply slight pressure on the tool so that the tool will not bounce around, uncontrolled. Pressing very hard on the tool will not increase the efficiency.

## Drilling in wood or metal

Use the optional drill chuck assembly. When installing it, refer to "Installing or removing the bit" described on the previous page.

Set the action mode changing knob to "rotation only".

You can drill up to 13 mm (1/2") diameter in metal and up to 38 mm (1 - 1/2") diameter in wood. (Note: When using a flat boring bit.)


### ▲ CAUTION:

- Never use "rotation with hammering" when the drill chuck assembly is installed on the tool. The drill chuck assembly may be damaged. Also, the drill chuck will come off when reversing the tool.
- Pressing excessively on the tool will not speed up the drilling. In fact, this excessive pressure will only serve to damage the tip of your bit, decrease the tool performance and shorten the service life of the tool.
- There is a tremendous twisting force exerted on the tool/ bit at the time of hole breakthrough. Hold the tool firmly and exert care when the bit begins to break through the workpiece.
- A stuck bit can be removed simply by setting the reversing switch to reverse rotation in order to back out. However, the tool may back out abruptly if you do not hold it firmly.
- Always secure small workpieces in a vise or similar holddown device.

# MAINTENANCE

# ▲ CAUTION:

 Always be sure that the tool is switched off and unplugged before attempting to perform inspection or maintenance.



1. Drill chuck assembly

To maintain product SAFETY and RELIABILITY, repairs, carbon brush inspection and replacement, any other maintenance or adjustment should be performed by Makita Authorized or Factory Service Centers, always using Makita replacement parts.

# ACCESSORIES

### **△** CAUTION:

 These accessories or attachments are recommended for use with your Makita tool specified in this manual. The use of any other accessories or attachments might present a risk of injury to persons. Only use accessory or attachment for its stated purpose.

If you need any assistance for more details regarding these accessories, ask your local Makita service center.

- SDS-Plus Carbide-tipped bits
- Bull point
- Cold chisel
- Chisel adapter assembly
- Drill chuck assembly
- Drill chuck S13
- · Chuck adapter
- Chuck key S13
- Bit grease
- Grip assembly
- Depth gauge
- Blow-out bulb
- Dust cup
- Dust extractor attachment
- Safety goggles
- Steel carrying case

First-Class Postage Required

Post Office will not deliver without proper postage.

Makita U.S.A., Inc. 14930 Northam Street La Mirada, CA 90638-5753

Ռեսիավիակեսիկեսիկաներ

Fold

I.

# MAIL THIS PORTION

# Your answers to the following questions are appreciated.

1. This product was purchased from:	3. How did you learn about this product:
Home Center Other () Hardware/Lumber Store Tool Distributor Industrial Supply	Magazine     Radio       From Dealer     Exhibition       Newspaper     From Friend       Store Display     Previous Usage
Construction Supply     Supply     Use of the product is intended for:	Catalog Other ( )
Construction Trade Industrial Maintenance Home Maintenance Other ()	Design       Repair Service         Features       Durability         Size       Power         Price       Other ()         Makita Brand
DATE PURCHASED MONTH DAY YEAR	MODEL NO.

SERIAL NO. STATUS SEX INTL. LAST NAME / COMPANY NAME F Married Single Μ STREET ADRESS CITY AREA CODE STATE ZIP CODE PHONE AGE: Under 19 20-29 30-39 40-49 50-60 Over 60 BE SURE TO COMPLETE THE CUSTOMER'S PORTION OF THIS FORM AND RETAIN FOR YOUR RECORDS.

# Please return this portion by facsimile or mail.

Facsimile No: (714) 522-8133

# **FACTORY SERVICE CENTERS**

## 1-800-4-MAKITA

# RETAIN THIS PORTION FOR YOUR RECORDS

ALABAMA 2365 Pelham Parkway Pelham, AL 35124 (205) 620-1791

ARIZONA 3707 E. Broadway Rd., Ste. 6 Phoenix, AZ 85040 (602) 437-2850

ARKANSAS Shackleford Shopping Center 240 South Shackleford Rd., Ste. C Little Rock, AR 72211 (501) 224-5733

CALIFORNIA 41850 Christy St. Fremont, CA 94538-5107 (510) 657-9881

1421 N. Clovis Ave., Ste. 112 Fresno, CA 93727 (559) 252-5166

14930 Northam St. La Mirada, CA 90638-5753 (714) 522-8088

1970 Fulton Avenue Sacramento, CA 95825 (916) 482-5197

1440 South "E" Street San Bernardino, CA 92408 (909) 885-1289

7674 Clairemont Mesa Blvd. San Diego, CA 92111 (858) 278-4471

1714 E.McFadden Ave., Unit M Santa Ana, CA 92705 (714) 667-5066

1565 Winchester B. Campbell, CA 95008-0501 (408) 379-0377

16735 Saticoy St., Ste. 105 Van Nuys, CA 91406 (818) 782-2440 COLORADO 11839 E. 51st Ave. Denver, CO 80239-2709 (303) 371-2850

CONNECTICUT 508 Spring St. Windsor Locks, CT 06096 (860) 292-6405

FLORIDA 620 Douglas Ave. Suite 1302 Altamonte Springs, FL 32714 (407) 774-6000

750 East Sample Road Pompano Beach, FL 33064 (954) 781-6333

Thompson Center Waters 5501 W. Waters Ave., Ste. 406 Tampa, FL 33634 (813) 886-8292

GEORGIA 4680 River Green Parkway Duluth, GA 30096-2566 (770) 476-8911

HAWAII 4510 Salt Lake Blvd., Suite A7 Honolulu, HI 96818 (808) 847-0038

ILLINOIS 1450 Feehanville Dr. Mt. Prospect, IL 60056-6011 (847) 297-3100

INDIANA 8403 Michigan Road, Unit 1 Indianapolis, IN 46268 (317) 334-9980

KANSAS 8819 W. 95th St. Overland Park, KS 66212 (913) 642-1111 KENTUCKY 1215 S. Hurstbourne Parkway Louisville, KY 40222 (502) 326-3740

LOUSIANA 5626 Jefferson Hwy. Harahan, LA 70123 (504) 733-4138

MARYLAND 7541 - 45 Ritchie Highway Glen Burnie, MD 21061 (410) 590-0160

MASSACHUSETTS 232 Providence Hwy. Westwood, MA 02090 (617) 461-9754

MICHIGAN 37454 Ann Arbor Trail Livonia, MI 48150 (313) 432-1012

MINNESOTA 6427 Penn Ave. South Richfield, MN 55423 (612) 869-5199

MISSOURI 9876 Watson Road St. Louis, MO 63126-2221 (314) 909-9889

NEBRASKA 4129 S. 84th St. Omaha, NE 68127 (402) 597-2925

NEVADA 3375 S. Decatur Blvd. Suites. 22 - 24 Las Vegas, NV 89102 (702) 368-4277

NEW JERSEY 251 Herrod Blvd. Dayton, NJ 08810-1539 (609) 655-1212 NEW MEXICO 5805 Menaul Blvd. NE Albuquerque, NM 87110 (505) 881-4619

NEW YORK 4917 Genessee Street Cheektowaga, NY 14225 (716) 685-9503

131-35 31st Ave. Flushing, NY 11354 (718) 886-0971

NORTH CAROLINA 3501-G S. Tryon St. Charlotte, NC 28217 (704) 527-0611

OHIO 6253 E. Main St. Columbus, OH 43213 (614) 860-0222

6379 Pearl Road Parma Heights, OH 44130 (440) 843-7555

1617 E. Kemper Rd. Sharonville, OH 45246 (513) 771-0788

OKLAHOMA 552 E. Memorial Road Oklahoma City, OK 73114 (405) 752-2655

OREGON 828 19th Avenue., N.W. Portland, OR 97209 (503) 222-1823

PENNSYLVANIA Springwater Plaza 364 Wilmington W. Chester Pike Glen Mills, PA 19342 (610) 459-4122

6200 Babcock Blvd Pittsburgh, PA 15237 (412) 366-6363 PUERTO RICO 200 Guayama St. Hato Rey, PR 00917 (787) 250-8776

TENNESSEE 4655 Nolensville Rd. Nashville, TN 37211 (615) 331-9922

TEXAS 12801 Stemmons Fwy Ste. 809 Farmers Branch, TX 75234 (972) 243-1150

12701 Directors Dr. Stafford, TX 77477-3701 (281) 565-8665

3453 IH-35 North, Ste. 101 San Antonio, TX 78219 (210) 228-0676

UTAH 145 E. 1300 S., Ste. 101 Salt Lake City, UT 84115 (801) 359-3410

VIRGINIA 5760 Northampton Blvd,. Ste. 102 Virginia Beach, VA 23455 (757) 460-0280

WASHINGTON 22220 84th Ave. So., Bldg. A Kent, WA 98032 (253) 395-8055

WISCONSIN Lincoln Plaza Shopping Ctr. 2245 S. 108th St. West Allis, WI 53227 (414) 541-4776

#### CUSTOMER'S RECORD

When you need service: Send complete tool (prepaid) to one of the Makita Factory Service Centers listed, or to an Authorized Makita Service Center. Be sure to attach a letter to the outside of the carton detailing the problem with your tool.

 
 vice: Send id) to one Service
 Date Purchased

 Dealer's Name & Address
 Dealer's Name & Address

 an Authorized er. Be sure he outside of he problem
 Model No.

 Serial No.
 Serial No.

# WARNING

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm. Some examples of these chemicals are:

- lead from lead-based paints,
- crystalline silica from bricks and cement and other masonry products, and
- arsenic and chromium from chemically-treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

# MAKITA LIMITED ONE YEAR WARRANTY

# Warranty Policy

Every Makita tool is thoroughly inspected and tested before leaving the factory. It is warranted to be free of defects from workmanship and materials for the period of ONE YEAR from the date of original purchase. Should any trouble develop during this one-year period, return the COMPLETE tool, freight prepaid, to one of Makita's Factory or Authorized Service Centers. If inspection shows the trouble is caused by defective workmanship or material, Makita will repair (or at our option, replace) without charge.

This Warranty does not apply where:

- repairs have been made or attempted by others:
- repairs are required because of normal wear and tear:
- the tool has been abused, misused or improperly maintained:
- alterations have been made to the tool.

IN NO EVENT SHALL MAKITA BE LIABLE FOR ANY INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES FROM THE SALE OR USE OF THE PRODUCT. THIS DISCLAIMER APPLIES BOTH DURING AND AFTER THE TERM OF THIS WARRANTY.

MAKITA DISCLAIMS LIABILITY FOR ANY IMPLIED WARRANTIES, INCLUDING IMPLIED WARRANTIES OF "MERCHANTABILITY" AND "FITNESS FOR A SPECIFIC PURPOSE," AFTER THE ONE-YEAR TERM OF THIS WARRANTY.

This Warranty gives you specific legal rights, and you may also have other rights which vary form state to state. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

# Makita Corporation

3-11-8, Sumiyoshi-cho,

# Anjo, Aichi 446-8502 Japan

883824D069

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com