

USER'S GUIDE

TABLE OF CONTENTS

Welcome	1
Safety Instructions	2-3
Installation	3
Controls At A Glance	4
Touch Control Panel	5
Operating Basics	6-10
Special Features	10-12
Care and Cleaning	13
Answers to Questions	13
Before You Call	14
Warranty	Back Page



Model: MMC5000A

Welcome



Welcome and congratulations on your purchase of a Maytag Microwave Oven! Your complete satisfaction is very important to us.

Read this manual for best results. It contains instructions to acquaint you with proper operating and maintenance procedures.



Save time and money. If something should go wrong, we suggest consulting the "Before You Call" section in the back of this book. It is designed to help you solve basic problems before consulting a servicer.

However, should you need assistance, it is helpful to:

1) Have complete model and serial number identification of your microwave. This is located on a data plate on the left side of the oven opening. Record these numbers below for easy access.

Model Number

Serial Number

2) Have proof of original date of purchase.
Please save your sales receipt.

For additional questions, please contact us:

Maytag Appliances Sales Company
Attn: CAIRSM Center
P.O. Box 2370
Cleveland, TN 37320-2370
1-800-688-9900 (USA)
1-800-688-2002 (CANADA)
1-800-688-2080 (U.S. TTY for deaf, hearing
impaired or speech impaired)
(Mon.–Fri., 8am–8pm Eastern Time)
Internet: <http://www.maytag.com>

For service and warranty information, see back page.

NOTE: In our continuing effort to improve the quality of our appliances, it may be necessary to make changes to the appliance without revising this guide.

PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- A. **Do not** attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy. It is important not to defeat or tamper with the safety interlocks.
- B. **Do not** place any object between the oven front face and the door or allow soil or cleaner residue to accumulate on sealing surfaces.
- C. **Do not** operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the: (1) door (bent), (2) hinges and latches (broken or loosened), (3) door seals and sealing surfaces.
- D. The oven should not be adjusted or repaired by anyone except properly qualified service personnel.

Registration

Federal law requires registration of all microwave ovens. To comply with the law, please fill out the CUSTOMER REGISTRATION CARD packaged in the oven.

1. Check the model and serial numbers on the card to see that they match the numbers on the data plate. The data plate is located on the left inside wall of the oven opening. If the numbers on the card are not the same as those on the data plate, cross out the numbers on the card and write in the numbers as they appear on the data plate.
2. Mail the card. The return address is included on the reverse side of card.

If you move or are not the original owner of this oven, you must by law renew the registration. Send the renewal registration information to: **Maytag Customer Service, Warranty Administration, P.O. Box 4970, Cleveland, TN 37320-4970.**

Renewal Registration information must provide: a) Your name and address and b) the microwave oven's model and serial numbers.

IMPORTANT SAFETY INSTRUCTIONS.....

When using electrical appliances, basic safety precautions should be followed, including the following:

⚠ WARNING — To reduce the risk of burns, electric shock, fire, injury to persons or exposure to excessive microwave energy:

1. Read all instructions before using the appliance.
2. Read and follow the specific “PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY” found on page 1.
3. This appliance must be grounded. Connect only to properly grounded outlet. See “GROUNDING INSTRUCTIONS” on page 3.
4. Install or locate this appliance in accordance with the provided installation instructions.
5. Some products such as whole eggs and sealed containers – for example, closed glass jars – may explode and should not be heated in this oven. In rare instances, poached eggs have been known to explode. Cover poached eggs and allow a standing time of one minute before cutting into them.
6. Foods with unbroken outer “skin” such as potatoes, sausages, tomatoes, apples, chicken livers and other giblets, and egg yolks (see previous caution) should be pierced to allow steam to escape during cooking. “Boilable” cooking pouches and tightly closed plastic bags should be slit, pierced, or vented.
7. Do not heat, store or use flammable materials in or near the oven. Fumes can create a fire hazard or explosion.
8. Use this appliance only for its intended use as described in this manual. Do not use corrosive chemicals or vapors in this appliance. This type of oven is specifically designed to heat, cook, or defrost food. It is not designed for industrial, laboratory, or commercial use. It is intended for home use only. Do not use for drying clothes, linens, newspaper, or similar non-food type items.
9. As with any appliance, close supervision is necessary when used by children.
10. Do not operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
11. This appliance should be serviced only by qualified service personnel. Contact nearest authorized Maytag service facility for examination, repair or adjustment.
12. Do not cover or block any openings on the appliance.
13. Do not use or store this appliance outdoors. Do not use this product near water – for example, near a kitchen sink, in a wet basement, or near a swimming pool, and the like.
14. Do not immerse cord or plug in water.
15. Keep cord away from heated surfaces.
16. Do not let cord hang over edge of table or counter.
17. When cleaning surfaces of door and oven that come together on closing the door, use only mild, non-abrasive soaps or detergents applied with a sponge or soft cloth.
18. To reduce the risk of fire in the oven cavity:
 - a. Do not overcook food. Carefully attend appliance if paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking. Avoid using recycled paper products. Do not use newspaper or other printed paper in the oven. Such products sometimes contain impurities which could ignite.
 - b. Remove wire twist-ties from paper or plastic bags before placing in oven.
 - c. If materials inside the oven should ignite, keep oven door closed, turn oven off, and disconnect the power cord, or shut off the power at the fuse or circuit breaker panel.
 - d. Do not use the oven for storage. Do not leave paper products, cooking utensils or food in the oven when not in use.
 - e. Do not pop popcorn except in a microwave approved popcorn popper or in a commercial package recommended especially for microwave ovens.
19. Do not operate the oven when empty or with an empty utensil.
20. Do not lean on the oven door. The door is designed to close tightly and seal properly for safe operation. Leaning on the door may warp or break the hinges.
21. To avoid exposure to dangerous high voltage, **DO NOT REMOVE THE SPLATTER SHIELD** inside the oven cavity.
22. Liquids heated in certain shaped containers (especially cylindrical-shaped containers) may become overheated and splash out with a loud noise. For best results, stir the liquid several times before heating. Always stir liquids several times between reheatings.

Continued on next page.

IMPORTANT SAFETY INSTRUCTIONS (cont.)

23. Read and follow specific microwave oven preparation instructions on food packages or containers (especially baby food). Above all, this is a cooking appliance designed to prepare food.
24. Use only cooking utensils and accessories made for use in the microwave and specifically described in this manual.
25. Microwave oven manufacturers do not recommend deep fat frying or frying in a microwave oven. Hot oil can damage oven parts and utensils and even result in skin burns.
26. Plastic wrap: Use only those types designed for microwave oven use and avoid forming an air-tight seal. Fold back a small corner or cut a small slit to allow steam to escape.
27. Stay near the appliance while it is in use and check cooking progress frequently. Leaving the appliance unattended may result in overcooked food and possibly a fire in your oven.
28. Built-in Installations: (Microwave must be built-in with a trim kit.) Do not mount any portion of the microwave oven over a sink or any other heating or cooking appliance unless the microwave oven has been approved for use above the heating appliance. See label on the trim kit for a list of approved heating appliances. See installation instructions for additional installation information.
29. TV dinners may be microwaved in foil trays less than 3/4" deep; remove top foil cover and return tray to box. When using metal in microwave oven, keep metal at least 1 inch away from the sides of the oven.
30. Do not defrost frozen beverages in narrow necked bottles.
31. Cookware may become hot because of heat transferred from the heated food. Potholders may be needed to handle the cookware.
32. Do not try to melt paraffin wax in the oven. Paraffin wax will not melt in a microwave oven because it allows microwaves to pass through it.
33. Never use sharp-edged utensils in or near the oven.

Installation Instructions

Remove all packing materials both outside and inside the oven before using the oven. The oven requires free movement of air for proper operation. Do NOT block air vents located underneath the oven. Also, do not remove the feet from the bottom of the oven.

Grounding Instructions

This appliance **must** be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into a 120v, 15amp. outlet that is properly installed and grounded.

WARNING – Improper use of the grounding plug can result in a risk of electric shock.

Consult a qualified electrician or service technician if the grounding instructions are not completely understood, or if doubt exists as to whether the appliance is properly grounded.

Do not use an extension cord. If the power supply cord is too short, have a qualified electrician or serviceman install an outlet near the appliance. OR,

SAVE THESE INSTRUCTIONS

If it is absolutely necessary to use an extension cord, use only a 3-wire extension cord that has a 3-blade grounding plug, and a 3 slot receptacle that will accept the plug on the appliance. The marked rating of the extension cord shall be equal to or greater than the electrical rating of the appliance.


Interference Note

Microwave ovens generate radio frequency energy during operation, and if not installed properly may cause interference to radio and television reception. You can determine if this unit is causing interference by turning it on and off while the interference is occurring. If interference occurs, it may be corrected by one or more of the following measures:

- clean door and sealing surfaces of the oven;
- reorient the television or radio receiving antenna;
- relocate the oven with respect to the television or radio receiver, and/or
- plug the oven into a different outlet so that it and the television or radio receiver are on different circuits.

If the interference persists, you may want to consult an experienced radio/television technician for additional suggestions.

Controls At A Glance



COOKING GUIDE LABEL

DATA PLATE

DISPLAY WINDOW

TOUCH CONTROL PANEL – (See more detailed diagram on page 5)

LIGHT


DOOR LEVER
– Push to open the door.

WINDOW – To view the foods while cooking. No microwaves can pass through the metal shield in this window.

SAFETY INTERLOCK SYSTEM
– Safety latches are in the microwave oven door. All ovens have at least two latches which stop the operation of the oven when the door is opened.

DOOR LATCH – These will slide into the interlock. If door is not completely closed, the oven will not operate.


TURNTABLE – Composed of glass tray and roller guide. The roller guide is placed first in the bottom of the microwave and supports the glass tray. Both parts must be in place when using the microwave oven. The turntable will rotate whenever the oven is in use.



Audible Signals

Audible Signals are available to guide you when setting and using your oven:

- **A programming beep** will sound each time you touch a pad.
- **One long beep** will sound when the oven is first plugged in.
- **Three long beeps** signal the end of a cooking cycle.
- **Three short beeps** signal an incorrect entry.
- **Series of three short beeps** signal you to check the food.



Operating Basics

Time-of-Day Clock

Basic Instructions

1. Touch the **Clock/Auto Start Pad**. The **Display** will show “12H”.
2. Set the time of day by touching the appropriate numbers. The set time will flash.
3. Touch the **Clock/Auto Start Pad**. The set numbers will stop flashing, however, the colon continues to flash.

- After plugging in the oven or after a power outage, the **Display** will show “:0”. Set the clock following the directions above.
- The “time-of-day” clock is a 12 hour clock.
- If set, the time of day will always be displayed when no other cooking function is being used.

Time Cooking

Basic Instructions


1. Enter the cooking time by using the number pads. For example, for 1 1/2 minutes touch numbers 1, 3, 0.*
2. Touch the **Start Pad**.
 - The cooking time will appear in the **Display Window**.
 - The oven will start cooking and time countdown will begin.
 - The oven will stop automatically when the time is done and beep three times.
 - The time of day will reappear in the **Display**.

* *Note: Full power is automatic. If you wish to use a different power level, follow the instructions on page 7.*

- Start with the shortest recommended time and add more time as needed.
- Check the food as it cooks.
- The oven door can be opened any time during operation. It will automatically stop and maintain the time setting until the door is closed and the **Start Pad** is touched again.

Quick 30 Seconds

The **Quick 30 Seconds Pad** provides a convenient way to heat foods at full power with one touch of a pad. The microwave starts automatically after the pad is touched. By repeatedly touching the pad, you can heat foods from 30 seconds to 5 minutes.



Operating Basics

Power Level Pad

Basic Instructions

1. Touch the **Power Level Pad**.*
2. Enter the power level.**
3. Enter the cooking time.
4. Touch the **Start Pad**.

* For HI, touch **Power Level Pad** Twice.

** See *Power Level Guide* below.

Example: If the recipe calls for cooking with 50% power for 3 minutes, you would touch: the **Power Level Pad**; then 5 (“50” will appear in **Display Window**); then the number pads 3, 0, 0; then **Start Pad**.

Power Level Guide*

Power Level	Power %	Name	Suggested Uses
HI	100		For vegetables; beverages; quick reheating (observe closely to avoid overcooking); generally for quickest cooking.
9	90		Sautéing vegetables.
8	80		For whole poultry, cheese and egg dishes; cooking certain seafood (clams, oysters or scallops).
7	70	Med Hi	For cakes, quick breads and muffins
6	60		Reheating leftovers or for cooking recipes using precooked or canned ingredients.
5	50	Med	Reheating larger amounts of leftovers; cooking roasts.
4	40		Stewing or developing flavor in main dishes, soups or sauces; cooking rice or pasta (after water is boiling); reheating pastries.
3	30	Lo	Defrosting; tenderizing less tender cuts of meat in liquid; cooking dried beans, lentils or peas in water.
2	20		Softening cheese, butter or chocolate.
1	10	Warm	Keeping food(s) warm or taking chill off refrigerated foods before serving.

* Guide gives percentage of magnetron “on” time at different power levels and suggested uses.

Defrost Pad

Use the defrost setting for defrost meats, poultry and seafood from .5 pounds to 6.5 pounds.

- Touch the **Defrost Pad** once for defrosting by weight.
- Touch the **Defrost Pad** twice for defrosting by time.

Defrost by Weight

Basic Instructions

1. Touch the **Defrost Pad** once.
2. Enter the weight.* The defrosting time and power levels are automatically calculated and appear in the **Display**.
3. Touch the **Start Pad**.

* Enter the weight in pounds and tenths of a pound. See *Conversion Chart* below.

- During defrosting, the oven will beep a series of short beeps to signal that the food needs to be turned or rearranged. Oven will continue operating if food is not turned or rearranged. Three beeps signal the end of defrosting.

Conversion Chart


If weight is in ounces –	then weight is converted to tenths-of-a-pound.
1 to 2-oz.	0.1
3 to 4-oz.	0.2
5-oz.	0.3
6 to 7-oz.	0.4
8-oz.	0.5
9 to 10-oz.	0.6
11 to 12-oz.	0.7
13-oz.	0.8
14 to 15-oz.	0.9

Defrosting by Time

Basic Instructions

1. Touch the **Defrost Pad** twice.
2. Enter the defrosting time.
3. Touch the **Start Pad**.

- When defrosting by time, the microwave oven cycles on and off, alternating defrost and standing times. See **Time Defrost Chart** on page 9 for specific times and procedures.
- When the **Start Pad** is touched, the **Time Defrost** indicator starts blinking to show that the oven is in the **Time Defrost** mode.
- The **Display** counts down the time to show how much defrosting time is left.
- During defrosting, the oven will beep a series of short beeps to signal that the food needs to be turned or rearranged. Oven will continue operating if food is not turned or rearranged. Three beeps signal the end of defrosting.



Operating Basics

Time Defrost Chart

Items and Weight	Defrosting Time	Standing Time	Procedures and Techniques
Beef			
Ground Beef/1 lb.	10-12 min.	5 min.	Break apart and remove thawed portions with fork.
Ground Beef/2 lbs.	18-20 min.	8-12 min.	Break apart and remove thawed portions with fork.
Beef Roast, boneless/3 lbs.	26-28 min.	7-10 min.	Turn over when oven beeps. Shield ends or thinner areas with foil.
Steaks/1" thick	7-8 min.	5-7 min.	Separate and rearrange once.
Pork			
Pork Roast, boneless/3 lbs.	26-28 min.	10-15 min.	Turn over when oven beeps. Shield ends or thinner areas with foil.
Pork Chops/1 lb.	7-8 min.	5-7 min.	Separate and rearrange once.
Ground Pork/1 lb.	10-12 min.	5-7 min.	Break apart and remove thawed portions with fork.
Spareribs/12 lbs.	15-16 min.	5-7 min.	Turn meat over and rearrange, separate once.
Poultry			
Whole Chicken/3 lbs.	20-22 min.	10-15 min.	Turn chicken over. Shield wing tips, leg ends and breast areas with foil. Breast side down.
Chicken Breasts boneless/1 lb.	7-8 min.	5-7 min.	Separate and rearrange once.
Chicken Thighs/2 lbs.	18-23 min.	8-13 min.	Separate and rearrange once.
Fish			
Fish Fillets/1 lb.	10-11 min.	5-7 min.	Separate and rearrange once. Shield as needed.

Defrosting Tips

- Do not defrost covered meat. Covering might allow cooking to take place. Always remove outer wrap and tray. Place food on a microwave-safe rack in a dish. During defrost, juices accumulate in dish and may become hot enough to cook the food. Elevating meat off of the dish will prevent the bottom and side from beginning to cook.
- Begin defrosting whole poultry breast-side-down. Begin defrosting roasts fat-side-down.
- The shape of the package alters the defrosting time. Shallow rectangular shapes defrost more quickly than a deep block.
- Defrost by Weight** is programmed for specific weights. Defrost results will be affected if you enter an incorrect weight.
- Defrost by Weight** is programmed for frozen food at 0° F. If food is stored at a higher temperature, expect shorter defrost times.
- After 1/3 of the defrost time has elapsed, check the food. You may wish to turn over, break apart, rearrange or remove thawed portions of the food.

7. **During defrost (weight or time), the oven will prompt you to turn the food over.** At this point, open oven door and check the food. Follow the techniques listed below for optimum defrost results. Then, close oven door, touch **Start Pad** to complete defrosting.

- **Turn Over:** Roast, ribs, whole poultry, turkey breasts, hot dogs, sausages, steaks, or chops.
- **Rearrange:** Break apart or separate steaks, chops, hamburger patties, ground meat, chicken or seafood pieces, chunks of meat such as stew beef.
- **Shield:** Use small strips of aluminum foil to protect thin areas, edges of unevenly shaped foods such as chicken wings. To prevent arcing, do not allow foil to come within 1-inch of oven walls or door.
- **Remove:** To prevent cooking, thawed portions should be removed from the oven at this point. This may shorten defrost time for foods weighing less than 3-lbs.

8. After defrosting, allow food to stand 10 to 20 minutes if there are any icy areas. If large solid roasts, such as sirloin tip or rump roasts, are not completely thawed after standing, return roast to oven and program **Defrost by Weight** for 1 lb.

Two Stage Cooking

This feature lets you program two sequential operations such as defrosting and cooking or cooking using two different power levels. It automatically changes power settings and cooking time.

Basic Instructions

1. Touch the **Power Level Pad**.*
2. Enter the power level.
3. Enter the cooking time.
4. Touch the **Power Level Pad**.**
5. Enter the power level.
6. Enter the cooking time.
7. Touch the **Start Pad**.

* If you wish to cook on HI, skip step 2.

** If you wish to cook on HI, skip steps 4 and 5.

- When the **Start Pad** is touched, both Memory 1 and 2 indicator lights come on in the **Display**. Memory 1 indicator light starts blinking during the first stage of cooking. At the end of the first stage of cooking, the oven will beep and Memory 2 indicator light starts blinking as the second stage of cooking starts.
- Three beeps signal the end of cooking.
- The audible beep between stages can serve as a reminder to add foods or ingredients.



Special Features

Popcorn Pad

Basic Instructions

1. Touch the **Popcorn Pad** once for 3.5 oz. package or
2. Touch the **Popcorn Pad** twice for 1.75 oz. package.

- The **Popcorn Pad** has been automatically set for the correct cook time for 3-3.5 oz. and 1.75 oz. bags of popcorn.
- Listen as the popcorn pops and stop the microwave when the popping slows down to 3 seconds apart.
- Do not try to repop unpopped kernels or reuse a bag.
- Pop only one package at a time.

Dinner Plate Pad

Basic Instructions

1. Touch **Dinner Plate Pad**.

- The display will briefly show "11" and then "2:20" as cooking begins.
- Place meat and dense vegetables to the outside of the plate.
- Place delicate foods in the center of the plate.
- Cover the plate with wax paper to hold steam around most foods except rare meats or vegetables with crisp exteriors.



Special Features.....

Frozen Pizza

Basic Instructions

1. Touch the **Frozen Pizza Pad**.
- The **Display** will briefly show “7” and then start cooking.
 - Cook only one pizza at a time weighing approximately 7 oz.
 - Follow manufacturer’s directions.
 - Use only frozen pizza labeled microwaveable.

Drink Pad

Basic Instructions

1. Touch the **Drink Pad** once for 1 cup/mug.
2. Touch the **Drink Pad** twice for 2 cups/mugs.
3. Touch the **Drink Pad** three times for 3 cups/mugs.

Auto Cook

Basic Instructions

1. Touch the **Auto Cook Pad** until the food category desired is displayed.*
2. Touch the **Weight Pad** until the number in the **Display** is the quantity desired.*

* *Note: See chart below or the cooking Guide Label on the front of the oven cavity.*

- **Auto Cook** has preset times and power levels for three food categories: baked potatoes, fresh vegetables and soup.
- The **Display** will show cooking time and the oven automatically starts cooking.

Auto Cook Code

Code	Food Item	Quantity
AC-1	Baked Potato	1-Touch Weight Pad once. 2-Touch Weight Pad twice. 3-Touch Weight Pad three times.
AC-2	Fresh Vegetable	8 oz. - Touch Weight Pad once. 12 oz. - Touch Weight Pad twice.
AC-3	Soup	8 oz. - Touch Weight Pad once. 12 oz. - Touch Weight Pad twice.

Auto Start

The **Auto Start** feature allows you to program your oven to begin cooking at a preset time of day – up to a delay of 11 hours and 59 minutes. You can program two sequential operations using two different power levels.

Basic Instructions

1. Touch the **Power Level Pad**.
2. Enter the power level.
3. Enter the cooking time.*
4. Touch the **Power Level Pad**.
5. Enter the power level.
6. Enter the cooking time.
7. Touch the **Clock/Auto Start Pad**.
8. Enter the clock time you want the oven to start.
9. Touch the **Start Pad****

* If you wish to cook with one Stage, omit steps 4, 5 & 6.

** The oven will start cooking at the set time. If the door is opened before the start time is reached, touch the **Start Pad** to resume the **Auto Start** option.

- You cannot use the **Auto Start** with the following options: **Popcorn, Frozen Pizza, Drink, Dinner Plate, Defrost** and **Auto Cook**.
- **Do not** use foods containing baking powder or yeast when using **Auto Start**. They will not rise properly.
- **Warning:** Do not use foods that will spoil while waiting for cooking to start, such as dishes with milk or eggs, cream soups and cooked meats or fish. Any food that has to wait for cooking to start should be very cold or frozen before it is put in the oven. **Unfrozen foods should never stand more than two hours before cooking starts.**

Do not allow food to remain in the oven for more than two hours after end of cooking cycle.

To check Auto Start Time

Touch the **Clock/Auto Start Pad**. The programmed **Auto Start** time will appear in the **Display** for 3 seconds.

Tips on setting Auto Start

- Before setting, check that the correct time of day is displayed.
- If you hear the fan start when you touch the **Start Pad**, you have not set the oven properly. Touch the **Clear/Off Pad** and start over.

Child Safety Lock

The oven operation can be locked to prevent a child from accidentally turning it on. All oven functions can be locked.

To set: Touch and hold the **Clear/Off Pad** for three seconds. The lock indicator lights and the oven beeps.

To cancel: Touch and hold the **Clear/Off Pad** for three seconds. The lock indicator light goes off and the oven beeps.



Care and Cleaning.....

Cleaning the Microwave Oven Interior

The oven interior should be cleaned after each use with a damp cloth to keep it free from grease and soil buildup. Stubborn soils can be removed with a plastic scrub pad. When cleaning interior surfaces and surfaces of door and oven that come together when the door is closed, use only mild, non-abrasive soaps or detergents applied with a sponge or soft cloth.

Odors can be eliminated from the inside of the oven by boiling a solution of one cup of water and several table-spoons of lemon juice in the oven for 5-7 minutes. This also helps loosen any dried soil in the oven. Wipe off excess moisture after use.

Do not spray or pour liquid cleansers directly onto a surface. Spray or pour cleanser onto a cloth or sponge and then clean.

Do not use abrasive cleaners, oven cleaners, abrasive cleaning pads or steel wool, as they can scratch or dull oven surfaces.

Do not remove or insert knife around the stirrer cover to clean, it may damage the cover or affect the cooking performance of your oven.

Oven Bottom

Wash oven bottom with hot sudsy water, rinse and dry. Do not use excessive amounts of water when cleaning the oven, especially around the turntable. Do not allow water or cleaning agents to seep into turntable gears located underneath.

Glass Tray/Turntable

Allow to cool before removing and cleaning. Wash in soapy water or dishwasher.

Roller Guide

Clean frequently to prevent excessive noise. Wash in soapy water or dishwasher.

Oven Light Bulb

This bulb is to be replaced by properly qualified service personnel.

Answers to Questions About Your Microwave Oven.....

Q. Can I open the door when the oven is operating?

A. The door can be opened anytime during the cooking operation. The oven will automatically stop cooking and the time setting will maintain until the door is closed and the **Start Pad** is touched.

Q. What causes the oven interior light and display to dim when using a Variable Power Level?

A. This is normal and indicates the oven is operating and cycling properly.

Q. Why does steam and/or vapor escape around the door and moisture droplets form on the inside of the oven door?

A. This is normal occurrence – as food cooks, steam is given off.

Q. What do the various beeps mean?

A. Short beep = any pad is touched.

Three short beeps = incorrect entry.

One long beep = oven plugged in.

Three long beeps = end of cooking (microwave will turn off).

Series of three short beeps = check food to see if turning or rearranging is needed.

Q. Can the oven be used with the glass tray or roller guide removed?

A. No. Both the glass tray and roller guide must always be used in the oven when cooking.



Before You Call.....

Check the following to be sure a service call is really necessary.

If nothing on the oven operates:

- check for a blown circuit fuse or a tripped main circuit breaker.
- check if oven is properly connected to electric circuit in house.
- check that controls are set properly.
- check that the cooking time is set.

If the oven interior light does not work:

- the light bulb may be loose or defective. Call a qualified servicicer.

If oven will not cook:

- check that control panel was programmed correctly.
- check that door is firmly closed.
- check that **Start Pad** was touched.
- **Auto Start** may have been set.
- the **Child Safety Lock** may have been set.

If oven takes longer than normal to cook or cooks too rapidly:

- be sure the **Power Level** is programmed properly.
- check instructions on food density, etc.
- verify that voltage to the microwave oven is not low.

If the time-of-day clock does not always keep correct time:

- check that the power cord is fully inserted into the outlet receptacle.
- check that the oven is properly grounded.
- try plugging the oven into an outlet on a separate electrical circuit.

If oven floor or glass tray are hot:

- this is normal. The floor is absorbing heat from the food.

If the interior of oven collects moisture:

- this is normal. Food gives off moisture when cooking and the steam collects on the door and the oven surface. Wipe off excess moisture from oven after each use.

If food cooks unevenly:

- refer to your recipe for proper cooking procedures.
- be sure food is evenly shaped.
- be sure food is completely defrosted before cooking.
- check placement of aluminum strips used to prevent overcooking.

If food is undercooked:

- check recipe to be sure all directions (amount, time, and power levels) were correctly followed.
- check household voltage.
- try plugging the oven into an outlet on a separate electrical circuit.
- be sure food was completely defrosted before cooking.

If food is overcooked:

- check recipe to be sure all directions (amount, time, and power levels) were correctly followed.
- the initial temperature of food may have been higher than normal.

If arcing (sparks) occur:

- be sure microwave-safe dishes were used.
- be sure wire twist ties weren't used.
- be sure oven wasn't operated when empty.

If the display shows a time counting down but the oven is not cooking:

- check that door is firmly closed.

*For further assistance contact your Maytag Dealer or call Maytag Customer Service:
U.S. 1-800-688-9900 or Canada 1-800-688-2002*



Microwave Oven Warranty.....

Full Two Year Warranty

For **two (2) years** from the date of original retail purchase, any part which fails in normal home use will be repaired or replaced free of charge.

Limited Parts Warranty

After the second year from the date of original retail purchase through the fifth year, the following parts which fail in normal home use will be repaired or replaced free of charge for the part itself, with the owner paying all other costs, including labor, when the appliance is located in the United States or Canada: (1) Touch pad and microprocessor, (2) Magnetron tube, (3) High voltage transformer, (4) High voltage capacitor (5) High voltage rectifier.

Limited Parts Warranty Outside the United States or Canada

For **one (1) year** from the date of original retail purchase, any part which fails in normal home use will be repaired or replaced free of charge for the part itself, with the owner paying all other costs, including labor, when the appliance is located outside the United States or Canada.

Canadian Residents

This warranty covers only those appliances installed in Canada that have been listed with Canadian Standards Association unless the appliances are brought into Canada due to transfer of residence from the United States to Canada.

What is Not Covered by These Warranties

1. Conditions and damages resulting from any of the following:
 - a. Improper installation, delivery or maintenance.
 - b. Any repair, modification, alteration, or adjustment not authorized by the manufacturer or an authorized servicer.
 - c. Misuse, abuse, accidents or unreasonable use.
 - d. Incorrect electric current, voltage or supply.
 - e. Improper setting of any control.
2. Warranties are void if the original serial numbers have been removed, altered, or cannot be readily determined.
3. Light bulbs.
4. Products purchased for commercial or industrial use.
5. The cost of service or service call to:
 - a. Correct installation errors.
 - b. Instruct the user on the proper use of the product.
 - c. Transport the appliance to the servicer.
6. Consequential or incidental damages sustained by any person as a result of any breach of these warranties.

Some states do not allow the exclusion or limitation of consequential or incidental damages, so the above exclusion may not apply.

If You Need Service

- Call the dealer from whom your appliance was purchased or call Maytag Appliances Sales Company, Maytag Customer Assistance at 1-800-688-9900, USA or 1-800-688-2002, CANADA to locate an authorized servicer.
- Be sure to retain proof of purchase to verify warranty status. Refer to WARRANTY (above) for further information on owner's responsibilities for warranty service.
- If the dealer or service company cannot resolve the problem, write to Maytag Appliances Sales Company, Attn: CAIRSM Center, P.O. Box 2370, Cleveland, TN 37320-2370, or call **1-800-688-9900, USA or 1-800-688-2002, CANADA.**

U.S. customers using TTY for deaf, hearing impaired or speech impaired, call 1-800-688-2080.

NOTE: When writing or calling about a service problem, please include the following information:

- a. Your name, address and telephone number;
 - b. Model number and serial number;
 - c. Name and address of your dealer or servicer;
 - d. A clear description of the problem you are having;
 - e. Proof of purchase (sales receipt).
- User's guides, service manuals and parts catalogs are available from Maytag Appliances Sales Company, Maytag Customer Assistance.

MAYTAG • One Dependability Square • Newton, Iowa 50208

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>