


## Operating instructions



## Ceramic hob with induction KM 418 KM 418-1

To avoid the risk of accidents or damage to the appliance it is **essential** to read these instructions before it is installed and used for the first time.

en - GB

M.-Nr. 05 621 621


# Contents

---

<b>Description of the appliance</b> . . . . .	3
Hob . . . . .	3
Cooking zone controls and displays . . . . .	4
<b>Warning and Safety instructions</b> . . . . .	5
<b>Caring for the environment</b> . . . . .	12
<b>Before using for the first time</b> . . . . .	13
General notes . . . . .	13
Cleaning and heating up for the first time . . . . .	13
<b>Operation</b> . . . . .	14
The induction principle . . . . .	14
Pans . . . . .	16
Function of the sensor switches . . . . .	17
Switching on . . . . .	17
Settings . . . . .	18
Auto heat-up . . . . .	19
Booster . . . . .	20
Switching off and residual heat indicators. . . . .	21
Safety lock . . . . .	22
Safety switch-off. . . . .	23
Overheating protection . . . . .	24
<b>Cleaning and care</b> . . . . .	26
<b>Problem solving guide</b> . . . . .	28
<b>Electrical connection</b> . . . . .	30
<b>After sales service</b> . . . . .	32
Data plate . . . . .	32

# Description of the appliance

## Hob



## Cooking zones

- ① Rear cooking zone  
( $\varnothing$  16 / 19.5 / 23 cm;  
Normal power level / with Booster  
2200 W / 3000 W)
- ② Front cooking zone  
( $\varnothing$  10 / 13 / 16 cm;  
Normal power level / when rear  
Booster switched on 1400 W /  
600 W)


## Control panel

- ③ Hob ON / OFF sensor switch
- ④ Sensor switch for safety lock
- ⑤ Safety lock indicator lamp
- ⑥ Cooking zone controls
- ⑦ Sensor switch for Booster function on  
the rear cooking zone
- ⑧ Mains cable
- ⑨ Plug  
(Depending on country of  
destination, the appliance may be  
supplied with or without a plug. The  
plug shown is for illustration only).

# Description of the appliance

---

## Cooking zone controls and displays



### ⑩ Displays:

- 0* = Cooking zone ready for use
- 1* to *9* = Power settings
- H* = Residual heat
- A* = Auto heat-up activated  
(alternating with the continued cooking setting selected)
- U* = No pan on cooking zone or pan unsuitable  
(see section on suitable pans)
- F* = Fault message (see "Problem solving guide")
- P* = Booster activated (only for the rear cooking zone)

### ⑪ sensor for setting the power level

# Warning and Safety instructions

---

This appliance complies with all relevant legal safety requirements. Improper use of the appliance can, however, present a risk of both personal injury and material damage.

To avoid the risk of accidents and damage to the appliance, read these instructions carefully before using it for the first time. They contain important notes on the installation, safety, operation and care of the appliance.

Keep these instructions in a safe place for reference and pass them on to any future user.

## Building in and connection

If the appliance is supplied without a plug, or if the plug is removed, it must be connected to the mains electricity supply by a suitably qualified and competent electrician in strict accordance with local and national safety regulations. The manufacturer cannot be held liable for damage caused by incorrect installation or connection.

► The electrical safety of this appliance can only be guaranteed when continuity is complete between it and an effective earthing system which complies with local and national safety regulations. It is most important that this basic safety requirement is present and tested regularly, and where there is any doubt, the household wiring system should be inspected by a qualified electrician. The manufacturer cannot be held liable for the consequences of an inadequate earthing system (e.g. electric shock).

► Do not connect the appliance to the mains electricity supply by an extension lead. Extension leads do not guarantee the required safety of the appliance (e.g. danger of overheating).

► This appliance must not be installed over a dishwasher, washing machine, tumble dryer, refrigerator, freezer or fridge-freezer. The high temperatures radiated by it could damage the appliance below and also impair the hob's ventilation system.

► This equipment may only be used in mobile installations such as ships, caravans, aircraft etc. if a risk assessment of the installation has been carried out by a suitably qualified engineer.

# Warning and Safety instructions

---

## Correct usage

► For safety reasons the appliance must only be operated after it has been built in. This is necessary to ensure that all electrical components are shielded.

► This appliance is intended for domestic use only and is not to be used for commercial purposes.

► Use this appliance for the preparation of food only. Any other usage is at the owner's risk and could be dangerous. The manufacturer cannot be held liable for damage caused by incorrect or improper use of the appliance.

► This appliance must not be set up or operated in the open air.

# Warning and Safety instructions

---

## Safety with children

▶ The appliance is only intended for use by adults who have read these operating instructions.

▶ This appliance is not a toy! To avoid the risk of injury keep children well away and do not let them play with it or use the controls. They will not understand the potential dangers posed by it. They should be supervised whenever you are working in the kitchen.

▶ Older children may use the appliance only when its operation has been clearly explained to them, and they are able to use it safely, recognising the dangers of misuse. Supervise its use by the elderly or infirm.

▶ Use the safety lock to prevent children operating the appliance or altering the settings.

▶ The appliance gets hot when in use and remains hot for quite a while after being switched off. To safeguard against burning, keep children well away from the appliance at all times.

▶ Do not store anything which might arouse a child's interest in storage areas above or next to the appliance. Otherwise they could be tempted into climbing onto the appliance with the risk of burning themselves.

▶ Keep all pans out of reach of children. Turn pan handles inwards away from the edge of the hob. Danger of burning or scalding.

▶ Packaging (e.g. cling film, polystyrene) and plastic wrappings must be kept out of the reach of babies and young children. Danger of suffocation. Dispose of or recycle all packaging safely as soon as possible.

▶ Old appliances must be disconnected from the power supply, any plug rendered useless and the cable cut off directly behind the appliance to ensure it presents no danger to children while being stored for disposal. This should be done by a competent person.

# Warning and Safety instructions

---

## Protecting the appliance from damage

▶ Do not drop anything on the ceramic surface. Even a light object such as a salt cellar, could cause damage in certain circumstances.

▶ Do not use pots or pans on the ceramic hob with bases with pronounced edges or ridges e.g. cast iron pans. These could scratch or scour the hob surface permanently. Grains of salt and sand can also scratch.

▶ Do not allow either solid or liquid sugar, or pieces of plastic or aluminium foil to get on the ceramic surface when it is hot. If this should occur, switch off the appliance and carefully, while they are still hot, scrape off all remains of these materials using a shielded scraper blade. Take care not to burn yourself. If residues are allowed to cool before being removed, the ceramic surface will be susceptible to pitting or even cracking.  
Clean the appliance once it has cooled down.

▶ To prevent the risk of spillages etc. burning on, remove any soiling as quickly as possible and ensure that pan bases are clean, dry and free of grease.

▶ Do not use a steam cleaner to clean this appliance. The steam could reach electrical components and cause a short circuit. Pressurised steam could also cause permanent damage to the surface and to other components, for which the manufacturer cannot accept liability.

▶ Never place hot pans near the control area. This can damage the electronics.

▶ If a drawer is fitted directly underneath the hob, ensure that there is sufficient space between the drawer and its contents and underside of the appliance in order to ensure sufficient ventilation for the hob.

▶ In countries where there are areas which may be subject to infestation by cockroaches or other vermin, pay particular attention to keeping the appliance and its surroundings in a clean condition at all times. Any damage which may be caused by cockroaches or other vermin will not be covered by the appliance guarantee.



## Protection from burning and scalding

▶ The surface of the appliance is hot when in use, and remains hot for quite a while after being switched off. There is a danger of burning until the residual heat indicators go out.

▶ For added protection it is advisable to use heat-resistant pot holders or gloves when using the appliance. Do not let them get damp or wet, as this causes heat to transfer through the material more quickly with the risk of scalding or burning yourself.

▶ Do not heat up unopened tins of food on the hob as pressure will build up in the tin and it can explode. This could result in injury and scalding or damage.

▶ Do not place objects other than pots and pans on the hob. Be especially careful not to place knives, forks or spoons etc, or other metallic items on the hob. If the hob is switched on, or if there is residual heat present, the metallic items can heat up and cause burning. Remember that metallic items can cause the cooking zone to heat up unintentionally! Depending on material, other non-metallic items can melt or burn if placed on the hob. Switch the hob off after use.

▶ Do not cover the appliance, e.g. with a cloth, kitchen foil, etc. This could be a fire hazard if the appliance is switched on by mistake.

▶ Never leave the appliance unattended when cooking with oil or fat as these are fire hazards if overheated. Very hot oil can catch fire and could even set a cooker hood above on fire. Always heat fat slowly, watching as it heats.

▶ If, despite this, oil or fat does catch fire, do not attempt to put out the flames with water. Use a suitable fire blanket, saucepan lid, damp towel or similar to smother the flames.

▶ Do not flambé under a cooker hood. The flames could set the cooker hood on fire.

# Warning and Safety instructions

---

## Appliance faults

► In the event of damage or a defect, switch off the appliance immediately. Disconnect completely from the electricity supply. If the appliance has not yet been fully installed, the electricity cable must be disconnected from the supply point. If connected via a plug and socket, switch off at the socket and withdraw the plug. Contact the Service Department. Do not reconnect the appliance to the mains electricity supply until after it has been repaired.

► If there is any damage to the ceramic surface the appliance must be disconnected from the mains electricity supply immediately and not used until it has been repaired. Danger of electric shock.

► Repairs must only be carried out by a suitably qualified and competent person. Repairs and other work by unqualified persons could be very dangerous and could damage the appliance. The manufacturer cannot be held liable for unauthorised work. Never open the housing of the appliance.

► While the appliance is under guarantee, repairs should only be undertaken by a service technician authorised by the manufacturer. Otherwise the guarantee is invalidated.

# Warning and Safety instructions

---

## Electromagnetic fields

- ▶ For people fitted with a heart pacemaker:  
Please note that the area immediately surrounding the hob is electromagnetically charged, and that this could affect a pacemaker. If in any doubt consult the manufacturer of the pacemaker or your doctor.
- ▶ Ensure pans are placed centrally over the cooking zone to prevent unnecessary exposure to the electromagnetic field.
- ▶ To prevent damage to items which are susceptible to magnetic fields, e.g. credit cards, diskettes, pocket calculators etc, do not leave them in the immediate vicinity of the hob.

## Further safety notes

- ▶ Ensure pans are placed centrally over the cooking zone to prevent unnecessary exposure to the electro-magnetic field.
- ▶ When using an electric socket near the appliance, care should be taken that the cable of the electrical appliance does not come into contact with the hot appliance. The insulation on the cable could become damaged, giving rise to an electric shock hazard.
- ▶ Always ensure that food is sufficiently cooked or reheated. Many factors will affect the overall cooking time, including the size and amount of food and its temperature. Some foods may contain micro-organisms which are only destroyed by thorough cooking; therefore when cooking or reheating foods such as poultry, it is particularly important that the food is completely cooked through. If in doubt, select a longer cooking or reheating time.
- ▶ Do not use plastic or aluminium foil containers. These melt at high temperatures and could damage the ceramic surface. Fire hazard.
- ▶ Spray canisters, aerosols and other inflammable substances must not be stored in a drawer under the hob. Cutlery inserts must be heat-resistant.

The manufacturer cannot be held liable for damage caused by non-compliance with these Warning and Safety instructions.

# Caring for the environment

---

## Disposal of the packing material


The transport and protective packing has been selected from materials which are environmentally friendly for disposal and can normally be recycled.

Packaging (e.g. cling film, polystyrene) and plastic wrappings must be kept out of the reach of babies and young children. Danger of suffocation.

Dispose of or recycle all packaging materials safely as soon as possible.

## Disposal of your old appliance

Electrical and electronic appliances often contain materials which, if handled or disposed of incorrectly, could be potentially hazardous to human health and to the environment. They are, however, essential for the correct functioning of your appliance. Please do not therefore dispose of your old appliance with your household waste.



Please dispose of it at your local community waste collection / recycling centre and ensure that it presents no danger to children while being stored for disposal.

It should be unplugged or disconnected from the mains electricity supply by a competent person. If connected by a plug, the plug must be rendered useless and the cable cut off directly behind the appliance to prevent misuse.

# Before using for the first time

---

## General notes

A dash (-) will appear in the display for the rear cooking zone and a 7 will appear in the display for the front cooking zone for a few seconds when the appliance is first connected to the power supply or after a power cut. The hob is ready for use as soon as these displays disappear.

This appliance operates using the induction principle. This means that the cooking zones will only work if they are covered by a pan with a magnetic base (see section "Suitable pans").

A light humming or clicking sound may be audible when the appliance is switched on. This is quite normal with induction heat.

Please stick the extra data plate for the appliance supplied with this documentation in the space provided in the "After sales service" section of this booklet.

## Cleaning and heating up for the first time

Before using for the first time clean the appliance with a damp cloth and then dry with a soft cloth.

Do not use washing up liquid to clean the ceramic surface as it can leave a blue sheen which may be difficult to remove.

Metal components have a protective coating which may give off a slight smell when the hob is heated up for the first time. The smell and any vapours will dissipate after a short time and do not indicate a faulty connection or appliance.

# Operation

---

## The induction principle


An induction coil is located under each cooking zone. When a zone is switched on this coil creates a magnetic field. This magnetic field in turn creates (induces) current in the base of the pan on it (which must be magnetic). This heats up the base of the pan. The cooking zone itself is heated up indirectly by the heat given back off by the pan.


The following points should be noted when cooking by induction:


- Induction cooking zones will only work when covered by a pan with a magnetic base (see "Suitable pans"). Unsuitable pans will not heat up.
- Induction cooking zones adapt their power output to the diameter of the pan base:


smaller diameter =  
smaller output  
larger diameter =  
greater output

However, for induction to take place, the diameter must not be too small (see "Suitable pans").

- Induction will not work if no pan is present, the pan is unsuitable or too small. In the above circumstances, the power setting selected will disappear from the cooking zone display and the  symbol will appear:



If, while the  is still lit up, a pan of suitable material and size is placed on the cooking zone, operation will recommence at the previously selected setting.

Otherwise the cooking zone will switch itself off automatically after 10 minutes and a  will appear in the display.

Do not place knives, forks or spoons etc., or other metallic items on the hob. If the hob is switched on, or if there is residual heat present, the metallic items can heat up and cause burning. Remember that metallic items can cause the cooking zone to heat up unintentionally!  
Switch the hob off after use.

## Noises

When using an induction hob, the following noises can occur in the pan, depending on what it is made of and how it has been constructed.

- On the higher power settings, it might buzz. This will decrease or cease altogether when the power setting is reduced.
- If the pan base is made of layers of different materials (e.g. in a sandwiched base), it might emit a cracking sound.
- Whistling might occur if both zones are being used on the highest setting at the same time, and the pans also have bases made of layers of different materials.
- You might hear a clicking sound from the electronic switches, especially on lower settings.

The appliance has a cooling fan to help extend the life of the electronics. When the hob is being used intensively, this will come on and you will hear a whirring sound. The fan may continue to run after the appliance has been switched off.

# Operation

## Pans

### Suitable pans

Induction cooking zones will only work when covered by a pan with a magnetic base.

### Suitable pans include:

- stainless steel pans with a magnetic base
- enamelled steel pans
- cast iron pans

### Unsuitable pans:

- stainless steel pans without a magnetic base
- aluminium and copper pans
- glass, ceramic or earthenware pots and pans

To test a pot or pan for suitability for use on an induction hob:

- Fill the pan with some water and place it on a cooking zone.
- Switch on the cooking zone and select a high cooking level.

If the pan is not suitable, the power setting selected will disappear from the cooking zone display after a few seconds and the  $\mathcal{U}$  symbol will appear.

Please be aware that the properties of the pan base can affect the evenness with which food heats up in the pan.

Unless the pan manufacturer states that you can do so, do not use pans with very thin bases on this hob and never heat up empty pans as they could get damaged. This could also damage the appliance.


### Pan size

The diameter of the pan base must be at least as big as the inner marking on the zone it is being used on. If the diameter of the pan is too small the induction heating will not work. A  $\mathcal{U}$  will appear in the cooking zone display.

Please note that the maximum diameter quoted by manufacturers often refers to the diameter of the top rim of the pot or pan. The diameter of the base (generally smaller) is more important.

### Tips on saving energy

Use a pan lid whenever possible to minimise heat loss.



uncovered

covered



## Function of the sensor switches

This hob is equipped with electronic sensor switches. They react to finger contact.

To operate a cooking zone touch the relevant sensor. An audible tone confirms when a sensor reacts to being touched.

Make sure that only one sensor is touched at a time (except: when switching off a cooking zone), and keep the control area clean. Do not put things down on it. The sensors may fail to react or they could mistake the article or any dirt for a finger tip contact, thereby activating a function or even leading to the hob switching itself off automatically (see the section on "Safety switch-off".) Never place hot pans on the sensor switches. This can damage the electronics.

## Switching on

The hob must be switched on before any of the zones can be used.

### To switch the hob on:

- Touch the ON / OFF sensor ①.

A **U** appears in the display for each of the zones. If no further entry is made, the hob will switch itself off after a few seconds for safety reasons.

### To switch a cooking zone on:

- Select a power setting between **1** and **9** by touching the - or + sensor.

# Operation

## Settings

The range of settings is the same for all cooking zones:

<b>Cooking process</b>	<b>Settings</b>
Melting butter, chocolate etc. Dissolving gelatine Preparing yoghurt	1 - 2
Thickening sauces containing egg yolk and butter Warming small quantities of food/liquid Keeping warm food which sticks easily Cooking rice	1 - 3
Warming liquid and semi-solid foods Thickening sauces, e.g. Hollandaise Making porridge Preparing omelettes, lightly fried eggs Steaming fruit	2 - 4
Defrosting deep frozen food Steaming vegetables, fish Cooking dumplings, potatoes, pulses Pulse soups and broths	3 - 5
Bringing to the boil and continued cooking of large quantities of food	5 - 6
Gentle braising (without overheating the fat) of meat, fish, vegetables, fried eggs etc.	7
Frying potato cakes, pancakes etc.	7 - 8
Boiling large quantities of water Bringing to the boil	9

These settings are guidelines only, based on approx. 4 helpings. With deep pans, large quantities or without the lid on, a higher setting is needed. With smaller quantities select a lower setting.

## Auto heat-up

When Auto heat-up has been activated, the cooking zone switches on automatically at the highest setting and then switches to the continued cooking setting which you have previously selected. The heat-up time depends on which continued cooking setting has been chosen (see chart).

As the higher continued cooking settings are generally used for frying food, only a relatively short heat-up time is needed to heat up the pan initially.

Taking a pan off the zone whilst Auto heat-up is in operation interrupts the Auto heat-up. It will resume if a pan is placed back on the zone within 10 minutes.

Continued cooking setting	Heat-up time in minutes and seconds (approx.)
1	1 : 15
2	1 : 40
3	2 : 10
4	3 : 00
5	5 : 05
6	7 : 40
7	1 : 40
8	2 : 10
9	-

## To activate Auto heat-up:


- Select setting **9** by pressing the **-** or **+** sensors.

- Press the **+** sensor (again).

An **H** will appear in the display for as long as the **+** is being pressed. When the sensor is released, power setting **9** will appear, alternating with **H**.

- While the **H** and **9** are flashing alternately, you can use the **-** control to select a continued cooking setting. If the display is no longer flashing, press the **+** sensor again.

During the heat-up time, the display will show **H** alternating with the continued cooking setting selected, e.g. **7**.



During the heat-up time the continued cooking setting can be increased using the **+** sensor. The heat-up time will increase accordingly.

The continued cooking setting can, however, only be reduced using the **-** sensor during the first few seconds after activating the Auto heat-up function. At the end of this time, reducing the continued cooking time will switch the Auto heat-up function off.

# Operation


## Booster

The rear cooking zone is equipped with a booster, i.e. an increase in the power level.

If activated, the cooking zone will operate on power setting **9** with an extra boost of power for a period of 10 minutes. This boost is intended for quickly bringing large quantities of water to the boil, e.g. when cooking pasta.

### Procedure:

- Switch the hob on.
- Press the **B** sensor.




A **P** will appear in the display for the rear cooking zone.

After 10 minutes, the zone will automatically revert to the normal power setting **9** and the **P** will go out.

The Booster can be cancelled early by

- pressing the **B** sensor again,
- pressing the - sensor on the rear cooking zone.

The extra boost of energy is only available by taking a proportion of energy away from the front cooking zone. Whilst the booster is engaged, the front cooking zone will operate at a maximum setting of **7**, even if a higher power setting, e.g. **8**, is selected. To indicate that this is happening, the **8** will flash alternately with the **7** until the Booster switches off again.



Engaging the Booster also automatically overrides any Auto heat-up function set for both cooking zones.

Taking a pan off the rear zone whilst the Booster is in operation, interrupts the Booster. It will resume if a pan is placed back on the zone within 10 minutes.

## Switching off and residual heat indicators

### To switch off a cooking zone:

- Touch the - and + sensors for the zone you want to switch off **at the same time**.

A **H** will light up in the display for that zone for a few seconds. If the cooking zone is still hot then residual heat will be indicated in the display.



### To switch off the hob:

- Touch the ON/OFF sensor ①.

This switches off all cooking zones. The residual heat indicator will appear in the display of any cooking zone which is still hot.

The residual heat indicator will not go out until the cooking zone is safe to touch.

Do not touch or place any heat-sensitive objects on the cooking zones while the residual heat indicators are on.  
Danger of burning and fire.

# Operation

---

## Safety lock


Keep children away from the hob for their own safety. In addition, your appliance is equipped with a safety lock to prevent children switching on the hob and cooking zones or altering the settings.

The safety lock can only be activated and de-activated when the hob is switched on.


When the safety lock is activated:

- the cooking zone power setting cannot be changed.
- the cooking zones and the hob can only be switched off by pressing the ON / OFF sensor ①.
- if the hob is then switched back on again, the cooking zones can no longer be operated.

## To activate the safety lock:

- Touch the sensor for the safety lock  until the indicator lamp above it comes on.

## To de-activate the safety lock:

- Touch the sensor for the safety lock  until the indicator lamp above it goes out.

## Safety switch-off

### Safety switch-off with an over-long cooking time

Your hob is fitted with a safety switch-off feature in case you forget to switch it off yourself.

If one of the cooking zones is heated for an unusually long period of time (see chart), and the power settings are not altered, the hob will switch itself off automatically and the appropriate residual heat indicator will appear.

Power setting	Maximum operating time in hours
1	10
2	5
3	5
4	4
5	3
6	2
7	2
8	2
9	1

- If you wish to use the cooking zones once again, switch the hob back on again in the usual way.

### Safety switch-off if the sensors are covered

Your hob will switch itself off automatically if one or several of the sensors remain covered for more than about 10 seconds, for example by finger contact, food boiling over, or by an object such as an oven glove or a tea towel. The residual heat symbol *H* will light up in the display of a cooking zone that is still hot.

- Clean the control area or remove the obstruction.
- Switch the hob back on again with the ON / OFF sensor ①. The cooking zones can now be used again as normal.

# Operation

---

## Overheating protection

The induction coil on a cooking zone can overheat if:

- the pan is not conducting heat properly
- fats or oils are heated up on the highest power setting.

The overheating protection works on the affected cooking zone in one of the following ways:

- If the rear cooking zone with the Booster function is affected and the Booster is switched on, then the Booster will be switched off.
- If power setting **9** has been set, the **9** will flash, alternating with the **8**, i. e. the cooking zone power level has been reduced to **8**.
- The affected cooking zone switches itself off automatically. The display first shows a **0** and then the residual heat indicator.

The cooking zone can be used again as soon as it has cooled down to a safe level.

To prevent the overheating protection from cutting in again:

- use pots and pans which conduct heat properly.
- heat fats or oils up on a medium power setting only.



## If the cooling elements overheat:

The cooking zone cooling elements can overheat if the appliance does not have sufficient ventilation.

The overheating protection affects the whole hob in one of the following ways:

- If the Booster is operating it will be switched off.
- If power setting **9** has been set, the **9** will flash, alternating with the **8**, i. e. the cooking zone power level has been reduced to **8**.
- All cooking zones switch themselves off automatically and the displays show a flashing **0**.

As soon as the cooling elements have cooled down sufficiently, the cooking zones will automatically continue to operate at the power setting previously selected.

## Note:

- If a drawer is fitted directly underneath the hob, ensure that there is sufficient space between the drawer and its contents and underside of the appliance in order to ensure sufficient ventilation for the hob.
- If the overheating protection is activated again contact the Service Department.

## Cleaning and care

---

Do not use a steam cleaner to clean this appliance. The steam could reach electrical components and cause a short circuit. Pressurised steam could also cause permanent damage to the surface and to components, for which the manufacturer cannot accept liability.

Do not use any sharp objects which could damage the seal between the ceramic surface and the surrounding frame and between the frame and the worktop.

Never use cleaners containing sand, soda, alkalis, acids or chlorides, oven sprays, dishwasher detergents, nor steel wool, abrasive cleaning agents, hard brushes, scouring pads and cloths. You should also avoid using sponges etc. which have previously been used with abrasive cleaning agents, as this will damage the surface.

Do not use washing up liquid to clean the ceramic surface as it can leave a blue sheen which may be difficult to remove.

### **E-Cloth**

A microfibre "E-Cloth" is available from the Miele UK Spare Parts Department which is suitable for cleaning surfaces such as stainless steel, glass, plastic and chrome without the use of chemicals.

Clean the appliance regularly, preferably after each use. Allow the hob to cool down before cleaning.

To prevent the risk of spillages burning on, remove any soiling as soon as possible, and ensure that pan bases are clean, dry and free of grease.

Most soiling can be wiped off using a damp cloth. Stubborn soiling may need to be removed with a shielded scraper blade.

After cleaning, dry thoroughly with a soft cloth to prevent a build-up of limescale deposits

To remove any limescale deposits, caused for example by water boiling over as well as metallic marks e.g. from saucepan bases, the ceramic surface can be cleaned using a proprietary cleaning agent for ceramic surfaces. Follow the manufacturer's instructions on the packaging and apply using a soft cloth or kitchen paper towel.

Finally, wipe the hob surface with a damp cloth and then dry it with a clean soft cloth. Ensure that every trace of cleaner has been removed from the surface. Any remaining trace could have a corrosive effect on the hob when it is next heated up.

Note that some cleaning agents contain a protective additive designed to prevent water marks and smears adhering to the surface.

Should any **sugar, plastic or aluminium foil** spill or fall on to a hot cooking zone while it is in use, first switch off the appliance. Then, **immediately**, while they are still hot, scrape off all remains of these materials using a shielded scraper blade. Take care not to burn yourself.

Allow the hob to cool down and then clean with a suitable proprietary ceramic cleaner.

# Problem solving guide

---

Repairs to electrical appliances must only be carried out by a suitably qualified and competent person in accordance with local and national safety regulations. Unauthorised repairs could be dangerous. The manufacturer cannot be held liable for unauthorised work.

However, some minor problems can be resolved as follows:

## What to do if ...

### **... the hob or cooking zones cannot be switched on**

Check whether

- the pans in use are suitable.
- the safety lock is activated.  
If necessary, deactivate it (see "Safety lock").
- the mains fuse has blown.

If none of the above is the case, then disconnect the appliance from the electricity supply for approx. 1 minute. To do this:

- switch it off at the isolator, or
- switch off at the socket and withdraw the plug, or
- withdraw the mains fuse.

Reconnect to the mains supply and switch the appliance on. If it still does not heat up then contact a qualified electrician or the Miele Service Department.

### **... an $\cup$ appears in the display for a cooking zone**

Check whether

- the zone was switched on by mistake without a pan on it.
- the pan being used is suitable for use on an induction zone, and that it is large enough (see "Suitable pans").

### **... an $F$ appears in the display for a cooking zone**

The temperature sensor for that cooking zone is defective.

Do not use this zone until it has been repaired.

Contact your nearest Service Dept. (See back page for address).

### **... an individual cooking zone or the whole hob has switched itself off automatically**

The safety switch-off feature or the overheating protection mechanism has been triggered (see "Safety switch-off" and "Overheating protection").

### **... one of the following faults has occurred:**

- The Booster function has automatically switched off early.
- The selected power setting of **9** flashes alternately in the display with the **8**.
- A **0** flashes in the display for all zones.

The overheating protection mechanism has been triggered (see "Overheating protection").

### **... the food in the pan hardly heats up or does not heat up at all when the Auto heat-up function is switched on**

This could be because:

- the pan is not conducting heat properly
- there is too much food in the pan.

Select a higher continued cooking setting next time or start cooking at the highest setting and then turn down to a lower setting manually later on.

### **... the cooling fan continues to run after the appliance has been switched off.**

This is not a fault. The fan will continue running until the appliance has cooled down. It will then switch itself off automatically.

# Electrical connection

---

All electrical work should be carried out by a suitably qualified and competent person in strict accordance with current local and national safety regulations (BS 7671 in the UK).

If the connection cable is damaged, it must be replaced by a special connection cable which can be obtained from the manufacturer or the Technical Service Department.

Installation, repairs and other work by unqualified persons could be dangerous. The manufacturer cannot be held liable for unauthorised work.

Ensure power is not supplied to the appliance until after installation or repair work has been carried out.

The appliance must only be operated when built-in. This is to ensure that all electrical parts are shielded. Live parts must not be exposed.

Do not connect the appliance to the mains electricity supply by an extension lead. These do not guarantee the required safety of the appliance.

Connection should be made via a suitable isolator or a double pole fused spur connection unit which complies with national and local safety regulations and the on/off switch should be easily accessible after the appliance has been built in.

If the switch is not accessible after installation (depending on country) an additional means of disconnection must be provided for all poles.

For extra safety it is advisable to install a residual current device (RCD), with a trip current of 30 mA.

When switched off there must be an all-pole contact gap of at least 3 mm in the isolator switch (including switch, fuses and relays).

## Important U.K.

The appliance is supplied for connection to a 230-240 V, 50 Hz supply with a 3-core cable.

The wires in the mains lead are coloured in accordance with the following code:

Green/yellow	= earth
Blue	= neutral
Brown	= live

**WARNING**  
**THIS APPLIANCE MUST BE**  
**EARTHED**

Please make sure that the connection data quoted on the data plate match the household mains supply.

### Important

The electrical safety of this appliance can only be guaranteed when continuity is complete between the appliance and an effective earthing system, which complies with local and national regulations. It is most important that this basic safety requirement is present and tested regularly and if there is any doubt the electrical wiring in the home should be inspected by a qualified electrician. The manufacturer cannot be held liable for the consequences of an inadequate earthing system such as an electric shock.

The manufacturer cannot be held liable for damage which is the direct or indirect result of incorrect installation or connection.

## After sales service

---

In the event of any faults which you cannot remedy yourself, please contact

– Your Miele Dealer

or


– The Miele Service Department (see address on back cover).

When contacting the Service Department, please quote the model and serial number of your appliance. These are given on the data plate.

Please note that telephone calls may be monitored and recorded for training purposes.

## Data plate

Space in which to stick the extra data plate supplied with the appliance. Ensure that the model number is the same as the one on the front of these operating instructions.











**United Kingdom:**

Miele Co. Ltd.  
Fairacres, Marcham Road  
Abingdon, Oxon, OX14 1TW  
Tel.: (01235) 554455  
Fax.: (01235) 554477  
Customer Contact Centre Tel.: (08707) 554466  
E-mail: info@miele.co.uk  
Internet: www.miele.co.uk

**Ireland:**

Miele Ireland Ltd.  
Broomhill Road, Tallaght, Dublin 24  
Tel: (01) 46 10 710, Fax: (01) 46 10 797  
Email: info@miele.ie  
Internet: http://www.miele.ie

**Australia:**

Miele Australia Pty. Ltd.  
A.C.N. 005635398  
1 Gilbert Park Drive, Knoxfield, VIC 3180  
Telephone: (03) 9764 7130  
Fax: (03) 9764 7149  
Internet: www.miele.com.au

**Distributor New Zealand:**

Steelfort Engineering Company. Ltd.  
500 Rangitikei Street, Palmerston North  
Telephone: (06) 350 1350  
Fax: (06) 356 1507

**South Africa:**

Miele (Pty) Ltd  
63 Peter Place, Bryanston 2194  
P.O. Box 69434, Bryanston 2021  
Tel.: (011) 548 1900  
Telefax (011) 548 1935  
E-mail: info@miele.co.za  
Internet: www.miele.co.za

The Miele logo is displayed in a bold, white, serif font against a black rectangular background.**Singapore:**

Miele Southeast Asia  
Miele Pte. Ltd.  
163 Penang Road  
# 04 - 02/03 Winsland House II  
Singapore 238463  
Tel : +65-67351191  
Fax: +65-67351161  
Email: infosea@miele.com.sg  
Internet: www.miele.sg

**Hong Kong:**

Miele (Hong Kong) Limited  
AIA Plaza, 24<sup>th</sup> Floor  
18 Hysan Avenue  
Causeway Bay  
Hong Kong  
Tel.: (852) 2610 1331  
Fax: (852) 2610 1013  
E-mail: mielehk@miele.com.hk

**Miele Shanghai Rep. Office**

Room 4105 - 6, 41<sup>st</sup> Floor  
Plaza 66, 1266 Nan-Jing Road/ West  
Shanghai 200040  
China  
Tel.: +86 21 6288 4200  
Fax: +86 21 6288 4100  
E-mail: mieleshanghai@cn.miele.com



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>