



OM-188 304AF

2007-10

Processes



MIG (GMAW) Welding
Pulsed MIG (GMAW-P)



Stick (SMAW) Welding


Description



Arc Welding Power Source With Built-In Synergic Control

Invision[®] 354MP

(230/460 And 460/575 Volt Models)



OWNER'S MANUAL

File: MIG (GMAW)



Visit our website at
www.MillerWelds.com

From Miller to You

Thank you and congratulations on choosing Miller. Now you can get the job done and get it done right. We know you don't have time to do it any other way.

That's why when Niels Miller first started building arc welders in 1929, he made sure his products offered long-lasting value and superior quality. Like you, his customers couldn't afford anything less. Miller products had to be more than the best they could be. They had to be the best you could buy.

Today, the people that build and sell Miller products continue the tradition. They're just as committed to providing equipment and service that meets the high standards of quality and value established in 1929.

This Owner's Manual is designed to help you get the most out of your Miller products. Please take time to read the Safety precautions. They will help you protect yourself against potential hazards on the worksite.

We've made installation and operation quick and easy. With Miller you can count on years of reliable service with proper maintenance. And if for some reason the unit needs repair, there's a Troubleshooting section that will help you figure out what the problem is. The parts list will then help you to decide the exact part you may need to fix the problem. Warranty and service information for your particular model are also provided.



Miller is the first welding equipment manufacturer in the U.S.A. to be registered to the ISO 9001:2000 Quality System Standard.

Miller Electric manufactures a full line of welders and welding related equipment. For information on other quality Miller products, contact your local Miller distributor to receive the latest full line catalog or individual specification sheets. **To locate your nearest distributor or service agency call 1-800-4-A-Miller, or visit us at www.MillerWelds.com on the web.**



Working as hard as you do – every power source from Miller is backed by the most hassle-free warranty in the business.



TABLE OF CONTENTS

SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING	1
1-1. Symbol Usage	1
1-2. Arc Welding Hazards	1
1-3. Additional Symbols For Installation, Operation, And Maintenance	3
1-4. California Proposition 65 Warnings	4
1-5. Principal Safety Standards	4
1-6. EMF Information	4
SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION	5
2-1. Symboles utilisés	5
2-2. Dangers relatifs au soudage à l'arc	5
2-3. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance	7
2-4. Proposition californienne 65 Avertissements	8
2-5. Principales normes de sécurité	9
2-6. Information EMF	9
SECTION 3 – INTRODUCTION	11
3-1. Specifications	11
3-2. Duty Cycle And Overheating	11
3-3. Volt-Ampere Curves	12
SECTION 4 – INSTALLATION	13
4-1. Selecting A Location	13
4-2. Weld Output Receptacles And Selecting Cable Sizes	14
4-3. Remote 14 Receptacle Information	15
4-4. Optional 115 Volt AC Duplex Receptacle And Circuit Breakers	15
4-5. Electrical Service Guide	16
4-6. Connecting 1-Phase Input Power	17
4-7. Connecting 3-Phase Input Power	18
SECTION 5 – OPERATION	19
5-1. Front Panel Controls	19
5-2. Meter Functions	20
5-3. Example Displays	21
5-4. Synergic Controls And Overview	22
5-5. Initial Display, Manual Pulse MIG Mode, MIG Mode, And Stick Mode	23
5-6. Setup Screens	24
5-7. Choosing Pulse Programs And Setting Parameters	25
5-8. How Manual Pulsed MIG Waveform Components Affect Arc And Burn-Off Rate	26
SECTION 6 – PROGRAMS	27
6-1. Overview Of Programs	27
6-2. Individual Program Information	27
SECTION 7 – MAINTENANCE & TROUBLESHOOTING	32
7-1. Routine Maintenance	32
7-2. Blowing Out Inside Of Unit	32
7-3. Voltmeter/Ammeter Help Displays	33
7-4. Error Codes	34
7-5. Troubleshooting	34
SECTION 8 – ELECTRICAL DIAGRAM	36
SECTION 9 – PARTS LIST	38
OPTIONS AND ACCESSORIES	
WARRANTY	

SECTION 1 – SAFETY PRECAUTIONS - READ BEFORE USING

som_2007-04

 Protect yourself and others from injury — read and follow these precautions.

1-1. Symbol Usage



DANGER! – Indicates a hazardous situation which, if not avoided, will result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury. The possible hazards are shown in the adjoining symbols or explained in the text.

NOTICE – Indicates statements not related to personal injury.

 Indicates special instructions.



This group of symbols means Warning! Watch Out! ELECTRIC SHOCK, MOVING PARTS, and HOT PARTS hazards. Consult symbols and related instructions below for necessary actions to avoid the hazards.

1-2. Arc Welding Hazards



The symbols shown below are used throughout this manual to call attention to and identify possible hazards. When you see the symbol, watch out, and follow the related instructions to avoid the hazard. The safety information given below is only a summary of the more complete safety information found in the Safety Standards listed in Section 1-5. Read and follow all Safety Standards.



Only qualified persons should install, operate, maintain, and repair this unit.



During operation, keep everybody, especially children, away.



ELECTRIC SHOCK can kill.

Touching live electrical parts can cause fatal shocks or severe burns. The electrode and work circuit is electrically live whenever the output is on. The input power circuit and machine internal circuits are also live when power is on. In semiautomatic or automatic wire welding, the wire, wire reel, drive roll housing, and all metal parts touching the welding wire are electrically live. Incorrectly installed or improperly grounded equipment is a hazard.

- Do not touch live electrical parts.
- Wear dry, hole-free insulating gloves and body protection.
- Insulate yourself from work and ground using dry insulating mats or covers big enough to prevent any physical contact with the work or ground.
- Do not use AC output in damp areas, if movement is confined, or if there is a danger of falling.
- Use AC output ONLY if required for the welding process.
- If AC output is required, use remote output control if present on unit.
- Additional safety precautions are required when any of the following electrically hazardous conditions are present: in damp locations or while wearing wet clothing; on metal structures such as floors, gratings, or scaffolds; when in cramped positions such as sitting, kneeling, or lying; or when there is a high risk of unavoidable or accidental contact with the workpiece or ground. For these conditions, use the following equipment in order presented: 1) a semiautomatic DC constant voltage (wire) welder, 2) a DC manual (stick) welder, or 3) an AC welder with reduced open-circuit voltage. In most situations, use of a DC, constant voltage wire welder is recommended. And, do not work alone!
- Disconnect input power or stop engine before installing or servicing this equipment. Lockout/tagout input power according to OSHA 29 CFR 1910.147 (see Safety Standards).
- Properly install and ground this equipment according to its Owner's Manual and national, state, and local codes.

- Always verify the supply ground – check and be sure that input power cord ground wire is properly connected to ground terminal in disconnect box or that cord plug is connected to a properly grounded receptacle outlet.
- When making input connections, attach proper grounding conductor first – double-check connections.
- Keep cords dry, free of oil and grease, and protected from hot metal and sparks.
- Frequently inspect input power cord for damage or bare wiring – replace cord immediately if damaged – bare wiring can kill.
- Turn off all equipment when not in use.
- Do not use worn, damaged, undersized, or poorly spliced cables.
- Do not drape cables over your body.
- If earth grounding of the workpiece is required, ground it directly with a separate cable.
- Do not touch electrode if you are in contact with the work, ground, or another electrode from a different machine.
- Do not touch electrode holders connected to two welding machines at the same time since double open-circuit voltage will be present.
- Use only well-maintained equipment. Repair or replace damaged parts at once. Maintain unit according to manual.
- Wear a safety harness if working above floor level.
- Keep all panels and covers securely in place.
- Clamp work cable with good metal-to-metal contact to workpiece or worktable as near the weld as practical.
- Insulate work clamp when not connected to workpiece to prevent contact with any metal object.
- Do not connect more than one electrode or work cable to any single weld output terminal.

SIGNIFICANT DC VOLTAGE exists in inverter-type welding power sources after removal of input power.

- Turn Off inverter, disconnect input power, and discharge input capacitors according to instructions in Maintenance Section before touching any parts.



HOT PARTS can cause severe burns.

- Do not touch hot parts bare handed.
- Allow cooling period before working on gun or torch.
- To handle hot parts, use proper tools and/or wear heavy, insulated welding gloves and clothing to prevent burns.



FUMES AND GASES can be hazardous.

Welding produces fumes and gases. Breathing these fumes and gases can be hazardous to your health.

- Keep your head out of the fumes. Do not breathe the fumes.
- If inside, ventilate the area and/or use local forced ventilation at the arc to remove welding fumes and gases.
- If ventilation is poor, wear an approved air-supplied respirator.
- Read and understand the Material Safety Data Sheets (MSDSs) and the manufacturer's instructions for metals, consumables, coatings, cleaners, and degreasers.
- Work in a confined space only if it is well ventilated, or while wearing an air-supplied respirator. Always have a trained watch-person nearby. Welding fumes and gases can displace air and lower the oxygen level causing injury or death. Be sure the breathing air is safe.
- Do not weld in locations near degreasing, cleaning, or spraying operations. The heat and rays of the arc can react with vapors to form highly toxic and irritating gases.
- Do not weld on coated metals, such as galvanized, lead, or cadmium plated steel, unless the coating is removed from the weld area, the area is well ventilated, and while wearing an air-supplied respirator. The coatings and any metals containing these elements can give off toxic fumes if welded.



ARC RAYS can burn eyes and skin.

Arc rays from the welding process produce intense visible and invisible (ultraviolet and infrared) rays that can burn eyes and skin. Sparks fly off from the weld.

- Wear an approved welding helmet fitted with a proper shade of filter lenses to protect your face and eyes when welding or watching (see ANSI Z49.1 and Z87.1 listed in Safety Standards).
- Wear approved safety glasses with side shields under your helmet.
- Use protective screens or barriers to protect others from flash, glare and sparks; warn others not to watch the arc.
- Wear protective clothing made from durable, flame-resistant material (leather, heavy cotton, or wool) and foot protection.




WELDING can cause fire or explosion.

Welding on closed containers, such as tanks, drums, or pipes, can cause them to blow up. Sparks can fly off from the welding arc. The flying sparks, hot workpiece, and hot equipment can cause fires and explosions. Accidental contact of electrode to metal objects can cause sparks, explosion, overheating, or fire. Check and be sure the area is safe before doing any welding.

- Remove all flammables within 35 ft (10.7 m) of the welding arc. If this is not possible, tightly cover them with approved covers.
- Do not weld where flying sparks can strike flammable material.
- Protect yourself and others from flying sparks and hot metal.
- Be alert that welding sparks and hot materials from welding can easily go through small cracks and openings to adjacent areas.
- Watch for fire, and keep a fire extinguisher nearby.
- Be aware that welding on a ceiling, floor, bulkhead, or partition can cause fire on the hidden side.
- Do not weld on closed containers such as tanks, drums, or pipes, unless they are properly prepared according to AWS F4.1 (see Safety Standards).
- Do not weld where the atmosphere may contain flammable dust, gas, or liquid vapors (such as gasoline).
- Connect work cable to the work as close to the welding area as practical to prevent welding current from traveling long, possibly unknown paths and causing electric shock, sparks, and fire hazards.

- Do not use welder to thaw frozen pipes.
- Remove stick electrode from holder or cut off welding wire at contact tip when not in use.
- Wear oil-free protective garments such as leather gloves, heavy shirt, cuffless trousers, high shoes, and a cap.
- Remove any combustibles, such as a butane lighter or matches, from your person before doing any welding.
- After completion of work, inspect area to ensure it is free of sparks, glowing embers, and flames.
- Use only correct fuses or circuit breakers. Do not oversize or bypass them.
- Follow requirements in OSHA 1910.252 (a) (2) (iv) and NFPA 51B for hot work and have a fire watcher and extinguisher nearby.




FLYING METAL or DIRT can injure eyes.

- Welding, chipping, wire brushing, and grinding cause sparks and flying metal. As welds cool, they can throw off slag.
- Wear approved safety glasses with side shields even under your welding helmet.




BUILDUP OF GAS can injure or kill.

- Shut off shielding gas supply when not in use.
- Always ventilate confined spaces or use approved air-supplied respirator.



MAGNETIC FIELDS can affect Implanted Medical Devices.


- Wearers of Pacemakers and other Implanted Medical Devices should keep away.
- Implanted Medical Device wearers should consult their doctor and the device manufacturer before going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations.



NOISE can damage hearing.

Noise from some processes or equipment can damage hearing.

- Wear approved ear protection if noise level is high.



CYLINDERS can explode if damaged.

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. Since gas cylinders are normally part of the welding process, be sure to treat them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks, and arcs.
- Install cylinders in an upright position by securing to a stationary support or cylinder rack to prevent falling or tipping.
- Keep cylinders away from any welding or other electrical circuits.
- Never drape a welding torch over a gas cylinder.
- Never allow a welding electrode to touch any cylinder.
- Never weld on a pressurized cylinder – explosion will result.
- Use only correct shielding gas cylinders, regulators, hoses, and fittings designed for the specific application; maintain them and associated parts in good condition.
- Turn face away from valve outlet when opening cylinder valve.
- Keep protective cap in place over valve except when cylinder is in use or connected for use.
- Use the right equipment, correct procedures, and sufficient number of persons to lift and move cylinders.
- Read and follow instructions on compressed gas cylinders, associated equipment, and Compressed Gas Association (CGA) publication P-1 listed in Safety Standards.

1-3. Additional Symbols For Installation, Operation, And Maintenance




FIRE OR EXPLOSION hazard.

- Do not install or place unit on, over, or near combustible surfaces.
- Do not install unit near flammables.
- Do not overload building wiring – be sure power supply system is properly sized, rated, and protected to handle this unit.




FALLING UNIT can cause injury.

- Use lifting eye to lift unit only, NOT running gear, gas cylinders, or any other accessories.
- Use equipment of adequate capacity to lift and support unit.
- If using lift forks to move unit, be sure forks are long enough to extend beyond opposite side of unit.




OVERUSE can cause OVERHEATING

- Allow cooling period; follow rated duty cycle.
- Reduce current or reduce duty cycle before starting to weld again.
- Do not block or filter airflow to unit.



FLYING SPARKS can cause injury.

- Wear a face shield to protect eyes and face.
- Shape tungsten electrode only on grinder with proper guards in a safe location wearing proper face, hand, and body protection.
- Sparks can cause fires — keep flammables away.



STATIC (ESD) can damage PC boards.

- Put on grounded wrist strap BEFORE handling boards or parts.
- Use proper static-proof bags and boxes to store, move, or ship PC boards.



MOVING PARTS can cause injury.

- Keep away from moving parts.
- Keep away from pinch points such as drive rolls.




WELDING WIRE can cause injury.

- Do not press gun trigger until instructed to do so.
- Do not point gun toward any part of the body, other people, or any metal when threading welding wire.




MOVING PARTS can cause injury.

- Keep away from moving parts such as fans.
- Keep all doors, panels, covers, and guards closed and securely in place.
- Have only qualified persons remove doors, panels, covers, or guards for maintenance as necessary.
- Reinstall doors, panels, covers, or guards when maintenance is finished and before reconnecting input power.




READ INSTRUCTIONS.

- Read Owner's Manual before using or servicing unit.
- Use only genuine replacement parts from the manufacturer.



H.F. RADIATION can cause interference.


- High-frequency (H.F.) can interfere with radio navigation, safety services, computers, and communications equipment.
- Have only qualified persons familiar with electronic equipment perform this installation.
- The user is responsible for having a qualified electrician promptly correct any interference problem resulting from the installation.
- If notified by the FCC about interference, stop using the equipment at once.
- Have the installation regularly checked and maintained.
- Keep high-frequency source doors and panels tightly shut, keep spark gaps at correct setting, and use grounding and shielding to minimize the possibility of interference.




ARC WELDING can cause interference.


- Electromagnetic energy can interfere with sensitive electronic equipment such as computers and computer-driven equipment such as robots.
- Be sure all equipment in the welding area is electromagnetically compatible.
- To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor.
- Locate welding operation 100 meters from any sensitive electronic equipment.
- Be sure this welding machine is installed and grounded according to this manual.
- If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.

1-4. California Proposition 65 Warnings


 **Welding or cutting equipment produces fumes or gases which contain chemicals known to the State of California to cause birth defects and, in some cases, cancer. (California Health & Safety Code Section 25249.5 et seq.)**

 **Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.**

For Gasoline Engines:

 **Engine exhaust contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.**

For Diesel Engines:

 **Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.**

1-5. Principal Safety Standards

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping, American Welding Society Standard AWS F4.1, from Global Engineering Documents (phone: 1-877-413-5184, website: www.global.ihs.com).

National Electrical Code, NFPA Standard 70, from National Fire Protection Association, P.O. Box 9101, Quincy, MA 02269-9101 (phone: 617-770-3000, website: www.nfpa.org and www.sparky.org).

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, from Compressed Gas Association, 4221 Walney Road, 5th Floor, Chantilly, VA 20151 (phone: 703-788-2700, website: www.cganet.com).

Code for Safety in Welding and Cutting, CSA Standard W117.2, from Canadian Standards Association, Standards Sales, 5060 Mississauga,

Ontario, Canada L4W 5NS (phone: 800-463-6727 or in Toronto 416-747-4044, website: www.csa-international.org).

Safe Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, from American National Standards Institute, 25 West 43rd Street, New York, NY 10036-8002 (phone: 212-642-4900, website: www.ansi.org).

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B, from National Fire Protection Association, P.O. Box 9101, Quincy, MA 02269-9101 (phone: 617-770-3000, website: www.nfpa.org).

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, from U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250-7954 (phone: 1-866-512-1800) (there are 10 Regional Offices—phone for Region 5, Chicago, is 312-353-2220, website: www.osha.gov).

1-6. EMF Information

Considerations About Welding And The Effects Of Low Frequency Electric And Magnetic Fields

Welding current, as it flows through welding cables, will cause electromagnetic fields. There has been and still is some concern about such fields. However, after examining more than 500 studies spanning 17 years of research, a special blue ribbon committee of the National Research Council concluded that: "The body of evidence, in the committee's judgment, has not demonstrated that exposure to power-frequency electric and magnetic fields is a human-health hazard." However, studies are still going forth and evidence continues to be examined. Until the final conclusions of the research are reached, you may wish to minimize your exposure to electromagnetic fields when welding or cutting.

To reduce magnetic fields in the workplace, use the following procedures:

1. Keep cables close together by twisting or taping them, or using a cable cover.
2. Arrange cables to one side and away from the operator.
3. Do not coil or drape cables around your body.
4. Keep welding power source and cables as far away from operator as practical.
5. Connect work clamp to workpiece as close to the weld as possible.

About Implanted Medical Devices:

Implanted Medical Device wearers should consult their doctor and the device manufacturer before performing or going near arc welding, spot welding, gouging, plasma arc cutting, or induction heating operations. If cleared by your doctor, then following the above procedures is recommended.

SECTION 2 – CONSIGNES DE SÉCURITÉ – LIRE AVANT UTILISATION

fre_som_2007-04

! Se protéger et protéger les autres contre le risque de blessure — lire et respecter ces consignes.

2-1. Symboles utilisés



DANGER! – Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.



Indique une situation dangereuse qui si on l'évite pas peut donner la mort ou des blessures graves. Les dangers possibles sont montrés par les symboles joints ou sont expliqués dans le texte.

NOTE – Indique des déclarations pas en relation avec des blessures personnelles.

 Indique des instructions spécifiques.



Ce groupe de symboles veut dire Avertissement! Attention! DANGER DE CHOC ELECTRIQUE, PIECES EN MOUVEMENT, et PIECES CHAUDES. Consulter les symboles et les instructions ci-dessous y afférant pour les actions nécessaires afin d'éviter le danger.

2-2. Dangers relatifs au soudage à l'arc



Les symboles représentés ci-dessous sont utilisés dans ce manuel pour attirer l'attention et identifier les dangers possibles. En présence de l'un de ces symboles, prendre garde et suivre les instructions afférentes pour éviter tout risque. Les instructions en matière de sécurité indiquées ci-dessous ne constituent qu'un sommaire des instructions de sécurité plus complètes fournies dans les normes de sécurité énumérées dans la Section 2-5. Lire et observer toutes les normes de sécurité.



Seul un personnel qualifié est autorisé à installer, faire fonctionner, entretenir et réparer cet appareil.



Pendant le fonctionnement, maintenir à distance toutes les personnes, notamment les enfants de l'appareil.



UNE DÉCHARGE ÉLECTRIQUE peut entraîner la mort.

Le contact d'organes électriques sous tension peut provoquer des accidents mortels ou des brûlures graves. Le circuit de l'électrode et de la pièce est sous tension lorsque le courant est délivré à la sortie. Le circuit d'alimentation et les circuits internes de la machine sont également sous tension lorsque l'alimentation est sur Marche. Dans le mode de soudage avec du fil, le fil, le dérouleur, le bloc de commande du rouleau et toutes les parties métalliques en contact avec le fil sont sous tension électrique. Un équipement installé ou mis à la terre de manière incorrecte ou impropre constitue un danger.

- Ne pas toucher aux pièces électriques sous tension.
- Porter des gants isolants et des vêtements de protection secs et sans trous.
- S'isoler de la pièce à couper et du sol en utilisant des housses ou des tapis assez grands afin d'éviter tout contact physique avec la pièce à couper ou le sol.
- Ne pas se servir de source électrique à courant électrique dans les zones humides, dans les endroits confinés ou là où on risque de tomber.
- Se servir d'une source électrique à courant électrique UNIQUEMENT si le procédé de soudage le demande.
- Si l'utilisation d'une source électrique à courant électrique s'avère nécessaire, se servir de la fonction de télécommande si l'appareil en est équipé.
- D'autres consignes de sécurité sont nécessaires dans les conditions suivantes : risques électriques dans un environnement humide ou si l'on porte des vêtements mouillés ; sur des structures métalliques telles que sols, grilles ou échafaudages ; en position coincée comme assise, à genoux ou couchée ; ou s'il y a un risque élevé de contact inévitable ou accidentel avec la pièce à souder ou le sol. Dans ces conditions, utiliser les équipements suivants, dans l'ordre indiqué : 1) un poste à souder DC à tension constante (à fil), 2) un poste à souder DC manuel (électrode) ou 3) un poste à souder AC à tension à vide réduite. Dans la plupart des situations, l'utilisation d'un poste à souder DC à fil à tension constante est recommandée. En outre, ne pas travailler seul !
- Couper l'alimentation ou arrêter le moteur avant de procéder à l'installation, à la réparation ou à l'entretien de l'appareil. Déverrouiller l'alimentation selon la norme OSHA 29 CFR 1910.147 (voir normes de sécurité).
- Installer le poste correctement et le mettre à la terre convenablement selon les consignes du manuel de l'opérateur et les normes nationales, provinciales et locales.
- Toujours vérifier la terre du cordon d'alimentation. Vérifier et s'assurer que le fil de terre du cordon d'alimentation est bien raccordé à la borne de terre du sectionneur ou que la fiche du cordon est raccordée à une prise correctement mise à la terre.
- En effectuant les raccordements d'entrée, fixer d'abord le conducteur de mise à la terre approprié et contre-vérifier les connexions.
- Les câbles doivent être exempts d'humidité, d'huile et de graisse; protégez-les contre les étincelles et les pièces métalliques chaudes.
- Vérifier fréquemment le cordon d'alimentation afin de s'assurer qu'il n'est pas altéré ou à nu, le remplacer immédiatement s'il l'est. Un fil à nu peut entraîner la mort.
- L'équipement doit être hors tension lorsqu'il n'est pas utilisé.
- Ne pas utiliser des câbles usés, endommagés, de grosseur insuffisante ou mal épissés.
- Ne pas enrouler les câbles autour du corps.
- Si la pièce soudée doit être mise à la terre, le faire directement avec un câble distinct.
- Ne pas toucher l'électrode quand on est en contact avec la pièce, la terre ou une électrode provenant d'une autre machine.
- Ne pas toucher des porte électrodes connectés à deux machines en même temps à cause de la présence d'une tension à vide doublée.
- N'utiliser qu'un matériel en bon état. Réparer ou remplacer sur-le-champ les pièces endommagées. Entretenir l'appareil conformément à ce manuel.
- Porter un harnais de sécurité si l'on doit travailler au-dessus du sol.
- S'assurer que tous les panneaux et couvercles sont correctement en place.
- Fixer le câble de retour de façon à obtenir un bon contact métal-métal avec la pièce à souder ou la table de travail, le plus près possible de la soudure.
- Isoler la pince de masse quand pas mis à la pièce pour éviter le contact avec tout objet métallique.
- Ne pas raccorder plus d'une électrode ou plus d'un câble de masse à une même borne de sortie de soudage.

Il reste une TENSION DC NON NÉGLIGEABLE dans les sources de soudage onduleur quand on a coupé l'alimentation.

- Arrêter les convertisseurs, débrancher le courant électrique et décharger les condensateurs d'alimentation selon les instructions indiquées dans la partie Entretien avant de toucher les pièces.



DES PIÈCES CHAUDES peuvent provoquer des brûlures graves.


- Ne pas toucher à mains nues les parties chaudes.
- Prévoir une période de refroidissement avant de travailler à l'équipement.
- Ne pas toucher aux pièces chaudes, utiliser les outils recommandés et porter des gants de soudage et des vêtements épais pour éviter les brûlures.



LES FUMÉES ET LES GAZ peuvent être dangereux.

Le soudage génère des fumées et des gaz. Leur inhalation peut être dangereux pour votre santé.


- Eloigner votre tête des fumées. Ne pas respirer les fumées.
- À l'intérieur, ventiler la zone et/ou utiliser une ventilation forcée au niveau de l'arc pour l'évacuation des fumées et des gaz de soudage.
- Si la ventilation est médiocre, porter un respirateur anti-vapeurs approuvé.
- Lire et comprendre les spécifications de sécurité des matériaux (MSDS) et les instructions du fabricant concernant les métaux, les consommables, les revêtements, les nettoyants et les dégraissants.
- Travailler dans un espace fermé seulement s'il est bien ventilé ou en portant un respirateur à alimentation d'air. Demander toujours à un surveillant dûment formé de se tenir à proximité. Des fumées et des gaz de soudage peuvent déplacer l'air et abaisser le niveau d'oxygène provoquant des blessures ou des accidents mortels. S'assurer que l'air de respiration ne présente aucun danger.
- Ne pas souder dans des endroits situés à proximité d'opérations de dégraissage, de nettoyage ou de pulvérisation. La chaleur et les rayons de l'arc peuvent réagir en présence de vapeurs et former des gaz hautement toxiques et irritants.
- Ne pas souder des métaux munis d'un revêtement, tels que l'acier galvanisé, plaqué en plomb ou au cadmium à moins que le revêtement n'ait été enlevé dans la zone de soudure, que l'endroit soit bien ventilé, et en portant un respirateur à alimentation d'air. Les revêtements et tous les métaux renfermant ces éléments peuvent dégager des fumées toxiques en cas de soudage.



LES RAYONS DE L'ARC peuvent provoquer des brûlures dans les yeux et sur la peau.

Le rayonnement de l'arc du procédé de soudage génère des rayons visibles et invisibles intense (ultraviolets et infrarouges) susceptibles de provoquer des brûlures dans les yeux et sur la peau. Des étincelles sont projetées pendant le soudage.


- Porter un casque de soudage approuvé muni de verres filtrants approprié pour protéger visage et yeux pendant le soudage (voir ANSI Z49.1 et Z87.1 énuméré dans les normes de sécurité).
- Porter des lunettes de sécurité avec écrans latéraux même sous votre casque.
- Avoir recours à des écrans protecteurs ou à des rideaux pour protéger les autres contre les rayonnements les éblouissements et les étincelles ; prévenir toute personne sur les lieux de ne pas regarder l'arc.
- Porter des vêtements confectionnés avec des matières résistantes et ignifuges (cuir, coton lourd ou laine) et des bottes de protection.



LE SOUDAGE peut provoquer un incendie ou une explosion.

Le soudage effectué sur des conteneurs fermés tel que des réservoirs, tambours ou des conduites peut provoquer leur éclatement. Des étincelles peuvent être projetées de l'arc de soudure. La projection d'étincelles, des pièces chaudes et des équipements chauds peut provoquer des incendies et des brûlures. Le contact accidentel de l'électrode avec des objets métalliques peut provoquer des étincelles, une explosion, un surchauffement ou un incendie. Avant de commencer le soudage, vérifier et s'assurer que l'endroit ne présente pas de danger.

- Déplacer toutes les substances inflammables à une distance de 10,7 m de l'arc de soudage. En cas d'impossibilité les recouvrir soigneusement avec des protections homologués.
- Ne pas souder dans un endroit où des étincelles peuvent tomber sur des substances inflammables.
- Se protéger et d'autres personnes de la projection d'étincelles et de métal chaud.
- Des étincelles et des matériaux chauds du soudage peuvent facilement passer dans d'autres zones en traversant de petites fissures et des ouvertures.
- Surveiller tout déclenchement d'incendie et tenir un extincteur à proximité.
- Le soudage effectué sur un plafond, plancher, paroi ou séparation peut déclencher un incendie de l'autre côté.
- Ne pas effectuer le soudage sur des conteneurs fermés tels que des réservoirs, tambours, ou conduites, à moins qu'ils n'aient été préparés correctement conformément à AWS F4.1 (voir les normes de sécurité).
- Ne soudez pas si l'air ambiant est chargé de particules, gaz, ou vapeurs inflammables (vapeur d'essence, par exemple).
- Brancher le câble de masse sur la pièce la plus près possible de la zone de soudage pour éviter le transport du courant sur une longue distance par des chemins inconnus éventuels en provoquant des risques d'électrocution, d'étincelles et d'incendie.
- Ne pas utiliser le poste de soudage pour dégeler des conduites gelées.
- En cas de non utilisation, enlever la baguette d'électrode du porte-électrode ou couper le fil à la pointe de contact.
- Porter des vêtements de protection dépourvus d'huile tels que des gants en cuir, une chemise en matériau lourd, des pantalons sans revers, des chaussures hautes et un couvre chef.
- Avant de souder, retirer toute substance combustible de vos poches telles qu'un allumeur au butane ou des allumettes.
- Une fois le travail achevé, assurez-vous qu'il ne reste aucune trace d'étincelles incandescentes ni de flammes.
- Utiliser exclusivement des fusibles ou coupe-circuits appropriés. Ne pas augmenter leur puissance; ne pas les ponter.
- Une fois le travail achevé, assurez-vous qu'il ne reste aucune trace d'étincelles incandescentes ni de flammes.
- Utiliser exclusivement des fusibles ou coupe-circuits appropriés. Ne pas augmenter leur puissance; ne pas les ponter.
- Suivre les recommandations dans OSHA 1910.252(a)(2)(iv) et NFPA 51B pour les travaux à chaud et avoir de la surveillance et un extincteur à proximité.



DES PIÈCES DE METAL ou DES SALETES peuvent provoquer des blessures dans les yeux.

- Le soudage, l'écaillage, le passage de la pièce à la brosse en fil de fer, et le meulage génèrent des étincelles et des particules métalliques volantes. Pendant la période de refroidissement des soudures, elles risquent de projeter du laitier.
- Porter des lunettes de sécurité avec écrans latéraux ou un écran facial.




LES ACCUMULATIONS DE GAZ risquent de provoquer des blessures ou même la mort.

- Fermer l'alimentation du gaz protecteur en cas de non-utilisation.
- Veiller toujours à bien aérer les espaces confinés ou se servir d'un respirateur d'adduction d'air homologué.



LES CHAMPS MAGNETIQUES peuvent affecter des implants médicaux.


- Porteur de simulateur cardiaque ou autre implants médicaux, rester à distance.
- Les porteurs d'implants doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de soudage par points, de gougeage, du coupage plasma ou de chauffage par induction.



LE BRUIT peut endommager l'ouïe.

Le bruit des processus et des équipements peut affecter l'ouïe.

- Porter des protections approuvées pour les oreilles si le niveau sonore est trop élevé.



LES BOUTEILLES peuvent exploser si elles sont endommagées.

Des bouteilles de gaz protecteur contiennent du gaz sous haute pression. Si une bouteille est endommagée, elle peut exploser. Du fait que les bouteilles de gaz font normalement partie du procédé de soudage, les manipuler avec précaution.


- Protéger les bouteilles de gaz comprimé d'une chaleur excessive, des chocs mécaniques, des dommages physiques, du laitier, des flammes ouvertes, des étincelles et des arcs.
- Placer les bouteilles debout en les fixant dans un support stationnaire ou dans un porte-bouteilles pour les empêcher de tomber ou de se renverser.
- Tenir les bouteilles éloignées des circuits de soudage ou autres circuits électriques.
- Ne jamais placer une torche de soudage sur une bouteille à gaz.
- Une électrode de soudage ne doit jamais entrer en contact avec une bouteille.
- Ne jamais souder une bouteille pressurisée – risque d'explosion.
- Utiliser seulement des bouteilles de gaz protecteur, régulateurs, tuyaux et raccords convenables pour cette application spécifique ; les maintenir ainsi que les éléments associés en bon état.
- Détourner votre visage du détendeur-régulateur lorsque vous ouvrez la soupape de la bouteille.
- Le couvercle du détendeur doit toujours être en place, sauf lorsque la bouteille est utilisée ou qu'elle est reliée pour usage ultérieur.
- Utiliser les équipements corrects, les bonnes procédures et suffisamment de personnes pour soulever et déplacer les bouteilles.
- Lire et suivre les instructions sur les bouteilles de gaz comprimé, l'équipement connexe et le dépliant P-1 de la CGA (Compressed Gas Association) mentionné dans les principales normes de sécurité.

2-3. Dangers supplémentaires en relation avec l'installation, le fonctionnement et la maintenance



Risque D'INCENDIE OU D'EXPLOSION.

- Ne pas placer l'appareil sur, au-dessus ou à proximité de surfaces inflammables.
- Ne pas installer l'appareil à proximité de produits inflammables.
- Ne pas surcharger l'installation électrique – s'assurer que l'alimentation est correctement dimensionnée et protégée avant de mettre l'appareil en service.




LES ÉTINCELLES VOLANTES risquent de provoquer des blessures.

- Porter un écran facial pour protéger le visage et les yeux.
- Affûter l'électrode au tungstène uniquement à la meuleuse dotée de protecteurs. Cette manœuvre est à exécuter dans un endroit sûr lorsque l'on porte l'équipement homologué de protection du visage, des mains et du corps.
- Les étincelles risquent de causer un incendie – éloigner toute substance inflammable.




LA CHUTE DE L'APPAREIL peut blesser.

- Utiliser l'anneau de levage uniquement pour soulever l'appareil, NON PAS les chariots, les bouteilles de gaz ou tout autre accessoire.
- Utiliser un équipement de levage de capacité suffisante pour lever l'appareil.
- En utilisant des fourches de levage pour déplacer l'unité, s'assurer que les fourches sont suffisamment longues pour dépasser du côté opposé de l'appareil.



LES CHARGES ÉLECTROSTATIQUES peuvent endommager les circuits imprimés.

- Établir la connexion avec la barrette de terre avant de manipuler des cartes ou des pièces.
- Utiliser des pochettes et des boîtes antistatiques pour stocker, déplacer ou expédier des cartes de circuits imprimés.



L'EMPLOI EXCESSIF peut SURCHAUFFER L'ÉQUIPEMENT.

- Prévoir une période de refroidissement ; respecter le cycle opératoire nominal.
- Réduire le courant ou le facteur de marche avant de poursuivre le soudage.
- Ne pas obstruer les passages d'air du poste.



DES ORGANES MOBILES peuvent provoquer des blessures.

- Ne pas s'approcher des organes mobiles.
- Ne pas s'approcher des points de coincement tels que des rouleaux de commande.




LES FILS DE SOUDAGE peuvent provoquer des blessures.

- Ne pas appuyer sur la gâchette avant d'en avoir reçu l'instruction.
- Ne pas diriger le pistolet vers soi, d'autres personnes ou toute pièce mécanique en engageant le fil de soudage.




DES ORGANES MOBILES peuvent provoquer des blessures.

- S'abstenir de toucher des organes mobiles tels que des ventilateurs.
- Maintenir fermés et verrouillés les portes, panneaux, recouvrements et dispositifs de protection.
- Seules des personnes qualifiées sont autorisées à enlever les portes, panneaux, recouvrements ou dispositifs de protection pour l'entretien.
- Remettre les portes, panneaux, recouvrements ou dispositifs de protection quand l'entretien est terminé et avant de rebrancher l'alimentation électrique.




LIRE LES INSTRUCTIONS.

- Lisez le manuel d'instructions avant l'utilisation ou la maintenance de l'appareil.
- N'utiliser que les pièces de rechange recommandées par le constructeur.
- Effectuer régulièrement le contrôle et l'entretien de l'installation.
- Maintenir soigneusement fermés les portes et les panneaux des sources de haute fréquence, maintenir les éclateurs à une distance correcte et utiliser une terre et un blindage pour réduire les interférences éventuelles.



LE RAYONNEMENT HAUTE FRÉQUENCE (H.F.) risque de provoquer des interférences.

- Le rayonnement haute fréquence (H.F.) peut provoquer des interférences avec les équipements de radio-navigation et de communication, les services de sécurité et les ordinateurs.
- Demander seulement à des personnes qualifiées familiarisées avec des équipements électroniques de faire fonctionner l'installation.
- L'utilisateur est tenu de faire corriger rapidement par un électricien qualifié les interférences résultant de l'installation.
- Si le FCC signale des interférences, arrêter immédiatement l'appareil.



LE SOUDAGE À L'ARC risque de provoquer des interférences.

- L'énergie électromagnétique risque de provoquer des interférences pour l'équipement électronique sensible tel que les ordinateurs et l'équipement commandé par ordinateur tel que les robots.
- Veiller à ce que tout l'équipement de la zone de soudage soit compatible électromagnétiquement.
- Pour réduire la possibilité d'interférence, maintenir les câbles de soudage aussi courts que possible, les grouper, et les poser aussi bas que possible (ex. par terre).
- Veiller à souder à une distance de 100 mètres de tout équipement électronique sensible.
- Veiller à ce que ce poste de soudage soit posé et mis à la terre conformément à ce mode d'emploi.
- En cas d'interférences après avoir pris les mesures précédentes, il incombe à l'utilisateur de prendre des mesures supplémentaires telles que le déplacement du poste, l'utilisation de câbles blindés, l'utilisation de filtres de ligne ou la pose de protecteurs dans la zone de travail.

2-4. Proposition californienne 65 Avertissements

⚠ Les équipements de soudage et de coupage produisent des fumées et des gaz qui contiennent des produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des malformations congénitales et, dans certains cas, des cancers. (Code de santé et de sécurité de Californie, chapitre 25249.5 et suivants)

⚠ Les batteries, les bornes et autres accessoires contiennent du plomb et des composés à base de plomb, produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des cancers et des malformations congénitales ou autres problèmes de procréation. Se laver les mains après manipulation.

Pour les moteurs à essence :

⚠ Les gaz d'échappement des moteurs contiennent des produits chimiques dont l'État de Californie reconnaît qu'ils provoquent des cancers et des malformations congénitales ou autres problèmes de procréation.

Pour les moteurs diesel :

⚠ Les gaz d'échappement des moteurs diesel et certains de leurs composants sont reconnus par l'État de Californie comme provoquant des cancers et des malformations congénitales ou autres problèmes de procréation.

2-5. Principales normes de sécurité

Safety in Welding, Cutting, and Allied Processes, ANSI Standard Z49.1, de Global Engineering Documents (téléphone : 1-877-413-5184, site Internet : www.global.ihc.com).

Recommended Safe Practices for the Preparation for Welding and Cutting of Containers and Piping, American Welding Society Standard AWS F4.1 de Global Engineering Documents (téléphone : 1-877-413-5184, site Internet : www.global.ihc.com).

National Electrical Code, NFPA Standard 70, de National Fire Protection Association, P.O. Box 9101, Quincy, MA 02269-9101 (téléphone : 617-770-3000, site Internet : www.nfpa.org).

Safe Handling of Compressed Gases in Cylinders, CGA Pamphlet P-1, de Compressed Gas Association, 4221 Walney Road, 5th Floor, Chantilly, VA 20151 (téléphone : 703-788-2700, site Internet : www.cganet.com).

Code for Safety in Welding and Cutting, CSA Standard W117.2, de Canadian Standards Association, 5060 Mississauga, Ontario, Canada

L4W 5NS (téléphone : 800-463-6727 ou à Toronto 416-747-4044, site Internet : www.csa-international.org).

Safe Practice For Occupational And Educational Eye And Face Protection, ANSI Standard Z87.1, de American National Standards Institute, 11 West 43rd Street, New York, NY 10036-8002 (téléphone : 212-642-4900, site Internet : www.ansi.org).

Standard for Fire Prevention During Welding, Cutting, and Other Hot Work, NFPA Standard 51B, de National Fire Protection Association, P.O. Box 9101, Quincy, MA 02269-9101 (téléphone : 617-770-3000, site Internet : www.nfpa.org).

OSHA, Occupational Safety and Health Standards for General Industry, Title 29, Code of Federal Regulations (CFR), Part 1910, Subpart Q, and Part 1926, Subpart J, de U.S. Government Printing Office, Superintendent of Documents, P.O. Box 371954, Pittsburgh, PA 15250-7954 (téléphone : 1-866-512-1800) (il y a 10 bureaux régionaux--le téléphone de la région 5, Chicago, est 312-353-2220, site Internet : www.osha.gov).

2-6. Information EMF

Considérations sur le soudage et les effets de basse fréquence et des champs magnétiques et électriques.

Le courant de soudage, pendant son passage dans les câbles de soudage, causera des champs électromagnétiques. Il y a eu et il y a encore un certain souci à propos de tels champs. Cependant, après avoir examiné plus de 500 études qui ont été faites pendant une période de recherche de 17 ans, un comité spécial ruban bleu du National Research Council a conclu : « L'accumulation de preuves, suivant le jugement du comité, n'a pas démontré que l'exposition aux champs magnétiques et champs électriques à haute fréquence représente un risque à la santé humaine ». Toutefois, des études sont toujours en cours et les preuves continuent à être examinées. En attendant que les conclusions finales de la recherche soient établies, il vous serait souhaitable de réduire votre exposition aux champs électromagnétiques pendant le soudage ou le coupage.

Pour réduire les champs magnétiques sur le poste de travail, appliquer les procédures suivantes :

1. Garder les câbles ensemble, les torsader, les scotcher, ou les recouvrir d'une housse.
2. Disposer les câbles d'un côté et à distance de l'opérateur.
3. Ne pas courber pas et ne pas entourer pas les câbles autour de votre corps.
4. Garder le poste de soudage et les câbles le plus loin possible de vous.
5. Connecter la pince sur la pièce aussi près que possible de la soudure.

En ce qui concerne les implants médicaux :

Les porteurs d'implants doivent d'abord consulter leur médecin avant de s'approcher des opérations de soudage à l'arc, de soudage par points, de gougeage, du coupage plasma ou de chauffage par induction. Si le médecin approuve, il est recommandé de suivre les procédures précédentes.


SECTION 3 – INTRODUCTION


3-1. Specifications

Rated Output at 60% Duty Cycle	Voltage Range in CV Mode	Amperage Range in CC Mode	Max. Open-Circuit Voltage	RMS Amps Input at Rated Load Output, 60 Hz 3-Phase at NEMA Load Voltages and Class I Rating		KVA**	KW**
				230 V	460 V		
300 A at 32 VDC, 3-Phase	10–35 V	5–400 A	90 VDC	30.5 (0.21*)	18.9 (0.10*)	12.2 (0.09*)	11.6 (0.04*)
225 A at 29 VDC, 1-Phase				47.4 (0.34*)	24.5 (0.14*)	11.3 (0.09*)	7.6 (0.04*)

*While idling
 ** Information based on 230 V, 3-phase input line.

3-2. Duty Cycle And Overheating





WELDING AMPERES

%DUTY CYCLE

3 PHASE & 460VAC SINGLE PHASE OPERATION


230VAC SINGLE PHASE OPERATION

Duty Cycle is percentage of 10 minutes that unit can weld at rated load without overheating.

If unit overheats, output stops, a Help message is displayed (see Section 7-3), and cooling fan runs. Wait fifteen minutes for unit to cool. Reduce amperage or voltage, or duty cycle before welding.


NOTICE – Exceeding duty cycle can damage unit and void warranty.

60% Duty Cycle



6 Minutes Welding 4 Minutes Resting

Overheating





Minutes OR Reduce Duty Cycle

sduty1 5/95 / SA-207 877

3-3. Volt-Ampere Curves

Volt-ampere curves show minimum and maximum voltage and amperage output capabilities of unit. Curves of other settings fall between curves shown.



va_curve1 4/95 - SA-188 537 / SA-178 653


SECTION 4 – INSTALLATION

4-1. Selecting A Location




Dimensions And Weight


76 lb (34.6 kg)



Movement




⚠ Do not move or operate unit where it could tip.



- 1 Lifting Handles
Use handles to lift unit.
- 2 Hand Cart
Use cart or similar device to move unit.
- 3 Rating Label
Use rating label to determine input power needs.
- 4 Line Disconnect Device
Locate unit near correct input power supply.

⚠ Special installation may be required where gasoline or volatile liquids are present – see NEC Article 511 or CEC Section 20.

Location



loc_2 3/96 - Ref. ST-151 556 / ST-802 167

4-2. Weld Output Receptacles And Selecting Cable Sizes



⚠️ ARC WELDING can cause Electromagnetic Interference.


To reduce possible interference, keep weld cables as short as possible, close together, and down low, such as on the floor. Locate welding operation 100 meters from any sensitive electronic equipment. Be sure this welding machine is installed and grounded according to this manual. If interference still occurs, the user must take extra measures such as moving the welding machine, using shielded cables, using line filters, or shielding the work area.



Weld Output Terminals

⚠️ Turn off power before connecting to weld output terminals.

⚠️ Do not use worn, damaged, undersized, or poorly spliced cables.



Output Receptacles

Weld Cable Size and Total Cable (Copper) Length in Weld Circuit Not Exceeding*****

	100 ft (30 m) or Less	150 ft (45 m)	200 ft (60 m)	250 ft (70 m)	300 ft (90 m)	350 ft (105 m)	400 ft (120 m)
100	4 (20)	4 (20)	4 (20)	3 (30)	2 (35)	1 (50)	1/0 (60)
150	3 (30)	3 (30)	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)
200	3 (30)	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)
250	2 (35)	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)
300	1 (50)	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)
350	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 3/0 (2x95)
400	1/0 (60)	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)
500	2/0 (70)	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 3/0 (3x95)
600	3/0 (95)	4/0 (120)	2 ea. 2/0 (2x70)	2 ea. 3/0 (2x95)	2 ea. 4/0 (2x120)	3 ea. 3/0 (3x95)	3 ea. 4/0 (3x120)




* This chart is a general guideline and may not suit all applications. If cable overheats use next size larger cable.

**Weld cable size (AWG) is based on either a 4 volts or less drop or a current density of at least 300 circular mils per ampere.
() = mm² for metric use

***For distances longer than those shown in this guide, call a factory applications representative at 920-735-4505.


S-0007-F-

4-3. Remote 14 Receptacle Information

	REMOTE 14	Socket*	Socket Information
	24 VOLTS AC  OUTPUT (CONTACTOR)	A	24 volts ac. Protected by circuit breaker CB2.
B		Contact closure to A completes 24 volts ac contactor control circuit.	
115 VOLTS AC  OUTPUT (CONTACTOR)	I	115 volts ac. Protected by circuit breaker CB1.	
	J	Contact closure to I completes 115 volts ac contactor control circuit.	
REMOTE OUTPUT CONTROL	C	Output to remote control; +10 volts dc.	
	D	Remote control circuit common.	
	E	0 to +10 volts dc input command signal from remote control.	
A/V AMPERAGE VOLTAGE	F	Current feedback; +1 volt dc per 100 amperes.	
	H	Voltage feedback; +1 volt dc per 10 output receptacle volts.	
GND	G	Circuit common for 24 and 115 volts ac circuits.	
	K	Chassis common.	

*The remaining sockets are not used.

4-4. Optional 115 Volt AC Duplex Receptacle And Circuit Breakers



1 115 V 10 A AC Receptacle
 Power is shared between duplex receptacle and Remote 14 receptacle (see Section 4-3).


2 Circuit Breaker CB1
 CB1 protects duplex receptacle and 115 volt ac portion of Remote 14 receptacle from overload.

3 Circuit Breaker CB2
 CB2 protects 24 volt ac portion of Remote 14 receptacle from overload.

Press button to reset breaker.

ST-801 245-A

4-6. Connecting 1-Phase Input Power



=GND/PE
Earth
Ground

L1
L2

- ⚠** Installation must meet all National and Local Codes – have only qualified persons make this installation.
- ⚠** Disconnect and lockout/tag-out input power before connecting input conductors from unit.
- ⚠** Always connect green or green/yellow conductor to supply grounding terminal first, and never to a line terminal.

ℹ The Auto-Link circuitry in this unit automatically links the power source to the primary voltage being applied. A 230/460 unit can be connected to either 230 or 460 VAC input power. A 460/575 model can be connected to either 460 or 575 VAC input power.

- 1 Black And White Input Conductor (L1 And L2)
- 2 Red Input Conductor
- 3 Green Or Green/Yellow Grounding Conductor
- 4 Insulation Sleeving
- 5 Electrical Tape

Insulate and isolate red conductor as shown.

- 6 Input Power Cord.
- 7 Disconnect Device (switch shown in the OFF position)
- 8 Disconnect Device Grounding Terminal
- 9 Disconnect Device Line Terminals

Connect green or green/yellow grounding conductor to disconnect device grounding terminal first.

Connect input conductors L1 and L2 to disconnect device line terminals.

10 Overcurrent Protection

Select type and size of overcurrent protection using Section 4-5 (fused disconnect switch shown).


Close and secure door on disconnect device. Remove lockout/tagout device, and place switch in the On position.

Tools Needed:



2/04 - Ref. 802 136-A / 801 192

4-7. Connecting 3-Phase Input Power



Tools Needed:



⚠ Installation must meet all National and Local Codes – have only qualified persons make this installation.

⚠ Disconnect and lockout/tagout input power before connecting input conductors from unit.

⚠ Always connect green or green/yellow conductor to supply grounding terminal first, and never to a line terminal.

ℹ The Auto-Link circuitry in this unit automatically links the power source to the primary voltage being applied. A 230/460 unit can be connected to either 230 or 460 VAC input power. A 460/575 model can be connected to either 460 or 575 VAC input power.

For Three-Phase Operation

- 1 Input Power Cord.
- 2 Disconnect Device (switch shown in the OFF position)
- 3 Green Or Green/Yellow Grounding Conductor
- 4 Disconnect Device Grounding Terminal
- 5 Input Conductors (L1, L2 And L3)
- 6 Disconnect Device Line Terminals

Connect green or green/yellow grounding conductor to disconnect device grounding terminal first.

Connect input conductors L1, L2, and L3 to disconnect device line terminals.

7 Overcurrent Protection


Select type and size of overcurrent protection using Section 4-5 (fused disconnect switch shown).

Close and secure door on disconnect device. Remove lockout/tagout device, and place switch in the On position.

SECTION 5 – OPERATION

5-1. Front Panel Controls

1 Power Switch

 The fan motor is thermostatically controlled and only runs when cooling is needed.

2 Voltmeter (see Section 5-2)

3 Ammeter/Trim Indicator (see Section 5-2)

4 Ammeter Light

Lights when display beneath is indicating

amperage.

5 Trim Indicator Light

Lights when display beneath is indicating trim.

6 Output Adjust Control


Controls various output values, depending on mode being used.

7 Increment Push Button (see Section 5-4)

8 Decrement Push Button (see Section 5-4)


9 Display (see Section 5-4)

10 Select Push Button (see Section 5-4)




Ref. ST-187 841


5-2. Meter Functions

 The meters display the actual weld output values for approximately three seconds after the arc is broken.


Mode	Meter Reading At Idle		Meter Reading While Welding	
MIG	V 24.5 Preset Volts	A Blank	V 24.5 Actual Volts	A 250 Actual Amps
Pulsed MIG	V Blank	Trim 50 Pulse Display	V 24.5 Actual Volts	A 250 Actual Amps
Stick- Contactor Remote	V Blank	A 85 Preset Amps	V 24.5 Actual Volts	A 85 Actual Amps
Stick- Contactor ON	V 80.0 Actual Volts (OCV)	A 85 Preset Amps	V 24.5 Actual Volts	A 85 Actual Amps
Manual Pulse	V PPS Pulses Per Second	A 200	V 24.5 Actual Volts	A 85 Actual Amps

5-3. Example Displays


 Values shown are hypothetical.
The "A" (Amperage) and "Trim" lights illuminate as shown.




Amperage preset display for Stick welding mode.




Voltage preset display for MIG welding mode.




Display while welding.




Preset trim display for Pulse welding mode.



Preset pulses per second (PPS) display for Manual Pulse welding mode.

 The Stick mode provides the Adaptive Hot Start™ feature, which automatically increases the output amperage at the start of a weld should the start require it. This eliminates electrode sticking at arc start.

5-4. Synergic Controls And Overview



Controls

1 Display

2 Parameter Select Push Button

Press button to move > on display. The parameter indicated by > is selected.

3 Increment Push Button

Press increment button to increase selected parameter.

4 Decrement Push Button

Press decrement button to decrease selected parameter.

See example at left.

Overview

The built-in synergic control provides four modes of operation:

Manual Pulse MIG – control functions as a discrete pulsed MIG CC control.

Mig – control functions as a remote voltage control.

Stick – unit is placed in CC mode for SMAW welding.

Synergic Pulser – programs that use factory-entered values are used to control process.

Setup screens (see Section 5-6) allow programs or modes to be made inaccessible (locked out) to the operator, and the language used in the displays (English, French, etc.) to be defined.

Example

To select Program 7, set to Non Adaptive, and set Arc Length to 36, proceed as follows:

Select top line by pressing Select push button until > is on top line. Press Increment button until Program 7 appears.



```
> P r g 7 0 3 5 A l 5 3 5 6 A r
  A d a p t i v e P u l s e
```


Press Select push button to select second line, and press Increment or Decrement button so Non Adaptive appears.



```
P r g 7 0 3 5 A l 5 3 5 6 A r
> N o n - A d a p t i v e P u l s e
```

Turn Output Adjust control to set arc length to 36.



O A  TRIM

36

5-5. Initial Display, Manual Pulse MIG Mode, MIG Mode, And Stick Mode



```

I N V I S I O N   3 5 4 M P
C O P Y R I G H T ( C ) 2 0 0 1
M I L L E R   E l e c t r i c
M f g   C o . X X X X X X
    
```

1

With > on top line, press Increment or Decrement button until Manual Pulse MIG appears.

2

```

> P r g 1 3   M a n u a l   P u l s e
   3 4 6   A m p s   P e a k
       7 8   A m p s   B a c k g r o u n d
   1 . 7 3   m s   P u l s e   W i d t h
    
```

Display scrolls to show line 5.

```

   3 4 6   A m p s   P e a k
       7 8   A m p s   B a c k g r o u n d
   1 . 7 3   m s   P u l s e   W i d t h
> 4 0 0   A m p s   S t a r t
    
```

With > on top line, press Increment or Decrement button until MIG appears.

3

```

> P r g 1 4   M I G
   2 5 %   I n d u c t a n c e
    
```

With > on top line, press Increment or Decrement button until STICK appears.

4

```

> P r g 1 5   S T I C K
   C o n t a c t o r   R E M O T E
       2 5 %   D i g
    
```

1 Software Program Number

When power is applied, initial display with software number appears momentarily, and then last program to be viewed before control was shut down appears.

2 Manual Pulse MIG Mode

The synergic control functions as a discrete pulsed MIG CC control in this mode.

Select top line of display, and press Increment or Decrement button until Manual Pulse MIG is displayed.

Select Amps Peak line, and use Increment or Decrement button to set peak amperage from 100–400 amps, but always at least 1 amp more than background amperage.

Select Amps Background line, and use Increment or Decrement button to set background amperage (min: 10 amps; max: 300 amps, but always at least 1 amp less than peak setting).

Select ms Pulse Width line, and use Increment or Decrement button to set pulse width (1 - 5 ms, but max setting may be less depending on Frequency setting).

Select Amps Start line, and use Increment or Decrement button to set starting amperage (150 - 530 amperes). This amperage value is used at the start of the weld or when an arc is restarted.

Use Output Adjust control to set pulse frequency. The range is 30 - 300 pulses per second, but max setting may be less depending on Pulse Width setting.

3 MIG Mode

The synergic control provides voltage control.

Select top line of display, and press Increment or Decrement button until MIG is displayed. Select Inductance line, and use Increment or Decrement button to set inductance (0–100% in increments of one). Use Output Adjust control to set voltage value (10–35 volts).

4 Stick Mode

In the Stick mode, the user can select contactor control (remote or On) and the Dig value.

Select contactor control line and press Increment or Decrement button to select Remote contactor control or On. The contactor is On at all times when On is selected.

Select Dig line, and use Increment or Decrement button to set Dig value (min: 0%; max: 100%). Dig helps arc starting and reduces sticking while welding. The higher the dig value defined, the more the short-circuit amperage increases at low arc voltage.

5-6. Setup Screens



1

```
S e t u p
  A c c e s s i b l e   P r o g r a m s
  M a n u a l   P u l s e   M i g
> O f f
```

2

```
S e t u p
  L a n g u a g e
> E n g l i s h
```

To access Setup screens: turn welding power source Off, press and hold Select push button, turn unit On, and hold push button down until initial screen leaves.

To exit Setup screens, turn welding power source Off and then On again. Parameters that are displayed when the Setup screens are exited are active.

1 Accessible Programs Screen

Select second line of display, and press Increment or Decrement button until Accessible Programs is displayed.

Select third line of display and press Increment or Decrement button to access each program and the three modes as desired. Select the fourth line and press Increment or Decrement button to define each option On (accessible) or Off (not accessible).

Programs and modes that are defined Off are not shown when the operator scrolls through the displays in normal operation.

2 Language Screen

Select second line of display, and press Increment or Decrement button until Language is displayed. Select third line of display and press Increment or Decrement button until desired language is shown. The choices are English, French, Italian, Spanish, and German.


5-7. Choosing Pulse Programs And Setting Parameters



Choosing Pulse Program:

Pulse programs are pre-written and cannot be changed by the user. See Section 6 for program parameters and recommended gas mixtures.

Choose program depending on the type and size of wire, and type of shielding gas used. For example, the program shown below is for .045 steel wire using Ar/CO₂ gas.



Choosing Adaptive Or Non Adaptive:

Adaptive: Pulse frequency is automatically regulated to maintain a constant arc length, regardless of changes in wire stickout.

Non Adaptive: Constant pulse frequency is maintained, regardless of the arc length.

Choose mode which best applies to your application.

















Setting Arc Length:

Arc length is adjusted with the Output Adjust control. Displayed preset Trim values (0 – 100) are for reference only.


Adjustment normally needed if wire feed speed or type of weld joint is changed.

Set arc length that best applies to your application.

5-8. How Manual Pulsed MIG Waveform Components Affect Arc And Burn-Off Rate

	CHANGES TO ARC	COMMENTS
 <p>Reference Waveform</p>		<p>A Electrode extension (stickout) B Arc length C Contact tube-to-work distance should be 3/8 in. to 3/4 in. Recommended gun angle is 10° to 20° from vertical.</p>
 <p>Increase Peak Amperage Only</p>  <p>Decrease Peak Amperage Only</p>	 	<p>Increasing peak amperage only: Increases burn-off rate, which directly affects arc length Increases average amperage slightly Increases heat input slightly</p> <p><i>Note: A good fine tuning parameter for arc length. Assuming a constant pulse width (peak time), peak amperage should be high enough to achieve a spray transfer. Too low of a peak current often results in a globular transfer. High peak amperages result in smaller droplets, and a more forceful or driving arc.</i></p>
 <p>Increase Background Amperage Only</p>  <p>Decrease Background Amperage Only</p>	 	<p>Increasing background amperage only: Increases arc length Increases average amperage Increases heat input and penetration Increases puddle fluidity</p> <p><i>Note: This current level is largely responsible for arc stabilization, and must be high enough to maintain the arc between peak current pulses.</i></p>
 <p>Increase Pulse Width (Time) Only</p>  <p>Decrease Pulse Width (Time) Only</p>	 	<p>Increasing pulse width (time) only: Increases arc length Increases heat input and penetration Increases arc cone width Increases average amperage</p>
 <p>Increase Pulses Per Second Only</p> <p>Decrease Pulses Per Second Only</p>		<p>Increasing pulses per second only: Increases arc length Increases average amperage Increases heat input</p> <p><i>Note: A good fine tuning parameter for arc length. Typically, this variable is adjusted to control the Burn-off rate of the wire as it is fed into the arc.</i></p>

SECTION 6 – PROGRAMS

 **Synergic Information:** The manufacturer makes no warranties, express or implied, that welds made using the synergic parameters of this equipment will meet the requirements of the application.

The synergic parameters contained in this equipment are intended only to be a general guideline. The choice and use of any synergic setting must be tested as to its suitability for the application.

6-1. Overview Of Programs

Program #	Wire Type	Wire Size	Shielding Gas	IPM: Min	IPM: Max
1	Steel	.035 in	Argon/CO ₂	100	780
2	Steel	.045 in	Argon/CO ₂	80	550
3	Stainless	.035 in	98% Argon/2% CO ₂	100	780
4	Stainless	.045 in	98% Argon/2% CO ₂	90	620
5	4043AL	.035 in	Argon	140	870
6	4043AL	.047 in	Argon	100	730
7	5356AL	.035 in	Argon	180	880
8	5356AL	.047 in	Argon	140	730
9	Nickel	.035 in	75% Argon/25% Helium	80	780
10	Silicon Bronze	.035 in	Argon	120	780
11	Metal Core	.045 in	Argon/CO ₂	100	550
12	Metal Core	.052 in	Argon/CO ₂	60	450

6-2. Individual Program Information

Program 1 -- .035 ER70S-3 Mild Steel -- Recommended Gases: Argon/CO ₂ Gas: Argon/CO ₂ mixes up to 10% CO ₂ ; Argon/O ₂ mixes up to 5% O ₂						
IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
100	0	288	43	49	1.55	451
168	10	304	54	93	1.61	491
236	20	332	67	110	1.73	501
304	30	353	80	124	1.86	529
372	40	360	84	155	1.96	529
440	50	375	88	180	2.05	529
508	60	385	98	195	2.13	529
576	70	390	101	208	2.21	529
644	80	345	109	215	2.30	529
712	90	398	114	240	2.38	529
780	100	400	121	260	2.48	529

**Program 2 -- .045 ER70S-3 Mild Steel -- Recommended Gases: Argon/CO₂
 Gas: Argon/CO₂ mixes up to 10% CO₂;
 Argon/O₂ mixes up to 5% O₂**

IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
80	0	323	48	56	2.20	498
127	10	342	61	91	2.28	529
174	20	370	84	108	2.38	529
221	30	388	95	134	2.53	529
268	40	390	108	155	2.65	529
315	50	400	119	175	2.73	529
362	60	400	139	183	2.83	529
409	70	400	152	200	2.86	529
456	80	400	178	215	2.93	529
503	90	400	219	230	2.99	529
550	100	400	277	250	3.10	529

**Program 3 -- .035 309L Stainless Steel -- Recommended Gases: 98% Argon/2% CO₂
 Alternative Gases: Argon/CO₂ mixes up to 10% CO₂;
 Argon/O₂ mixes up to 5% O₂**

IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
100	0	257	26	57	1.62	400
168	10	266	44	82	1.75	430
236	20	282	70	91	1.85	456
304	30	298	84	106	1.97	482
372	40	315	89	123	2.02	503
440	50	328	95	135	2.08	520
508	60	349	107	144	2.19	529
576	70	362	112	171	2.25	529
644	80	376	118	180	2.30	529
712	90	395	122	183	2.33	529
780	100	400	123	190	2.43	529

**Program 4 -- .045 309L Stainless Steel -- Recommended Gases: Argon/CO₂
 Gas: Argon/CO₂ mixes up to 10% CO₂;
 Argon/O₂ mixes up to 5% O₂**

IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
95	0	295	35	90	1.80	448
147	10	318	54	105	2.00	481
198	20	351	75	125	2.00	508
250	30	359	97	143	2.20	529
301	40	379	100	160	2.40	529
353	50	390	109	175	2.50	529
404	60	400	117	185	2.50	529
456	70	400	133	200	2.65	529
507	80	400	149	220	2.70	529
559	90	400	166	240	2.83	529
610	100	400	175	260	2.80	529

Program 5 -- .035 Aluminum 4043 -- Argon						
IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
140	0	194	29	60	1.10	400
213	10	196	53	76	1.15	501
286	20	205	80	98	1.20	529
359	30	249	103	109	1.35	529
432	40	272	134	118	1.50	529
505	50	298	150	125	1.70	529
578	60	320	170	135	1.90	529
651	70	340	191	145	2.10	529
724	80	360	214	155	2.25	529
797	90	381	225	165	2.40	529
870	100	400	240	175	2.55	529

Program 6 -- .047 Aluminum 4043 -- Argon						
IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
100	0	250	39	50	1.20	529
163	10	250	75	65	1.20	529
226	20	271	116	75	1.30	529
289	30	299	163	105	1.80	529
352	40	320	185	126	2.15	529
415	50	351	205	135	2.45	529
478	60	373	225	148	2.75	529
541	70	387	235	171	3.05	529
604	80	400	246	195	3.35	529
667	90	400	257	212	3.55	529
730	100	400	268	227	3.70	529

Program 7 -- .035 Aluminum 5356 -- Argon						
IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
180	0	221	32	50	1.30	484
250	10	230	43	71	1.35	510
320	20	240	61	85	1.40	529
390	30	250	78	95	1.45	529
460	40	260	87	105	1.55	529
530	50	276	100	115	1.65	529
600	60	291	117	120	1.75	529
670	70	310	139	130	1.85	529
740	80	334	150	140	2.00	529
810	90	354	160	150	2.20	529
880	100	374	170	160	2.30	529

Program 8 -- .047 Aluminum 5356 -- Argon						
IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
140	0	274	45	50	1.30	529
199	10	280	73	60	1.40	529
258	20	294	95	70	1.60	529
317	30	310	111	95	1.85	529
376	40	323	122	107	2.10	529
435	50	337	141	116	2.30	529
494	60	349	155	129	2.50	529
553	70	359	175	140	2.70	529
612	80	368	192	156	2.90	529
671	90	389	221	166	3.10	529
730	100	400	260	222	3.30	529

Program 9 -- .035 Nickel -- 75% Argon/25% Helium						
IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
80	0	221	14	40	1.90	458
141	10	268	36	60	2.10	505
212	20	294	58	84	2.40	529
283	30	327	73	96	2.50	529
354	40	337	89	114	2.65	529
425	50	346	105	124	2.72	529
496	60	368	111	139	2.84	529
567	70	382	122	149	2.90	529
638	80	395	138	170	3.00	529
709	90	400	152	182	3.16	529
780	100	400	169	167	3.55	529

Program 10 -- .035 Silicon Bronze -- Argon						
IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
120	0	238	21	61	1.20	503
186	10	272	43	71	1.30	529
252	20	282	61	95	1.43	529
318	30	301	78	110	1.51	529
384	40	324	95	129	1.50	529
450	50	341	106	136	1.70	529
516	60	363	114	138	1.82	529
582	70	378	128	143	1.88	529
648	80	387	134	148	1.96	529
714	90	400	144	160	2.10	529
780	100	400	144	194	2.16	529

**Program 11 -- .045 Metal Core -- Recommended Gases: Argon/CO₂
Gas: Argon/CO₂ mixes up to 20% CO₂**

IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
100	0	310	45	50	2.30	529
145	10	330	61	65	2.45	529
190	20	354	70	90	2.55	529
235	30	365	78	110	2.65	529
280	40	370	89	130	2.75	529
325	50	376	100	150	2.85	529
370	60	381	111	165	3.00	529
415	70	385	122	180	3.15	529
460	80	390	138	190	3.25	529
505	90	395	155	200	3.35	529
550	100	400	175	205	3.45	529

**Program 12 -- .052 Metal Core -- Recommended Gases: Argon/CO₂
Gas: Argon/CO₂ mixes up to 20% CO₂**

IPM	Trim	Peak Amp	Background Amp	Freq.	Pulse Width	Starting Amps
60	0	360	36	40	2.00	529
99	10	365	70	50	2.10	529
138	20	370	94	73	2.20	529
177	30	374	116	94	2.35	529
216	40	379	133	112	2.50	529
255	50	384	147	129	2.65	529
294	60	387	160	144	2.85	529
333	70	390	174	159	3.00	529
372	80	393	186	174	3.15	529
411	90	396	199	189	3.35	529
450	100	400	210	204	3.50	529

SECTION 7 – MAINTENANCE & TROUBLESHOOTING

7-1. Routine Maintenance


		Disconnect power before maintaining.		<i>Maintain more often during severe conditions.</i>	
3 Months					
Replace Damaged Or Unreadable Labels		Repair Or Replace Cracked Cables		Replace Cracked Torch Body	
				Repair Or Replace Cracked Cables And Cords	
				Clean And Tighten Weld Connections	
6 Months					
Blow Out Inside					

7-2. Blowing Out Inside Of Unit

		Do not remove case when blowing out inside of unit. To blow out unit, direct airflow through front and back louvers as shown.
--	--	---

ST-802 167

7-3. Voltmeter/Ammeter Help Displays



All directions are in reference to the front of the unit. All circuitry referred to is located inside the unit.

1 Help 0 Display

Indicates a shorted thermistor RT2 on the left side of the unit. If this display is shown, contact a Factory Authorized Service Agent.

2 Help 1 Display

Indicates a malfunction in the primary power circuit. If this display is shown, contact a Factory Authorized Service Agent.

3 Help 2 Display

Indicates a malfunction in the thermal protection circuitry located on the left side of the unit. If this display is shown, contact a Factory Authorized Service Agent.

4 Help 3 Display

Indicates the left side of the unit has overheated. The unit has shut down to allow the

fan to cool it (see Section 3-2). Operation will continue when the unit has cooled.

5 Help 4 Display

Indicates a malfunction in the thermal protection circuitry located on the right side of the unit. If this display is shown, contact a Factory Authorized Service Agent.

6 Help 5 Display

Indicates the right side of the unit has overheated. The unit has shut down to allow the fan to cool it (see Section 3-2). Operation will continue when the unit has cooled.

7 Help 6 Display

Indicates that the input voltage is too low and the unit has automatically shut down. Operation will continue when the voltage is within the acceptable lower range limit (15% below the applicable input voltage). If this display is

shown, have an electrician check the input voltage.

8 Help 7 Display

Indicates that the input voltage is too high and the unit has automatically shut down. Operation will continue when the voltage is within the acceptable upper range limit (15% above the applicable input voltage). If this display is shown, have an electrician check the input voltage. Help 7 can also indicate a bus voltage imbalance.


9 Help 8 Display

Indicates a malfunction in the secondary power circuit of the unit. If this display is shown, contact a Factory Authorized Service Agent.

10 Help 9 Display

Indicates a shorted thermistor RT1 on the right side of the unit. If this display is shown, contact a Factory Authorized Service Agent.

7-4. Error Codes



1

ERROR

Program CRC

Memory Will Be Reset

Press Parm. Select

2

ERROR

Program Range

Memory Will Be Reset

Press Parm. Select


1 Program CRC Error

2 Program Range Error

If either error code appears, reset the display to factory settings as follows:

Press Parameter Select push button or turn welding power source Off and back On. Change settings and continue.

7-5. Troubleshooting



Trouble	Remedy
No weld output; unit completely inoperative.	Place line disconnect switch in On position (see Sections 4-6 and 4-7).
	Check and replace line fuse(s), if necessary, or reset circuit breaker (see Sections 4-6 and 4-7).
	Check for proper input power connections (see Sections 4-6 and 4-7).
No weld output; meter display On.	Input voltage outside acceptable range of variation (see Section 4-5).
	Check, repair, or replace remote control.
	Unit overheated. Allow unit to cool with fan On (see Section 3-2).
	If unit contains optional ground current sensor, excessive current in the ground circuit may have been detected. Have electrician check input power circuit.
Erratic or improper weld output.	Check to make sure correct program is selected for welding wire and shielding gas used.
	Use proper size and type of weld cable (see Section 4-2).
	Clean and tighten all weld connections.
No 115 volts ac output at duplex receptacle, Remote 14 receptacle.	Reset circuit breaker CB1 (see Section 4-4).
No 24 volts ac output at Remote 14 receptacle.	Reset circuit breaker CB2 (see Section 4-4).

SECTION 8 - ELECTRICAL DIAGRAM




Figure 8-1. Circuit Diagram For Welding Power Source (230/460 Volt Models)





Figure 8-2. Circuit Diagram For Welding Power Source (460/575 Volt Models)

SECTION 9 – PARTS LIST

 Hardware is common and not available unless listed.




Figure 9-1. Parts Assembly

802 166-K

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------

Figure 9-1. Parts Assembly

1		+175 148	Wrapper	1
		178 551	Insulator, Side Lh	1
		175 256	Insulator, Side Rh	1
2		195 585	Handle	2
3		138 442	Label, Caution Falling Equipment	2
4	HD1	182 918	Transducer, Current 400A	1
5		203 342	Bus Bar, Current Sensor	1
6		203 341	Bus Bar, Output Rectifier	1
7		181 853	Insulator, Screw	4
8	D1,2	201 531	Kit Diode, Power Module	2
9		179 276	Bushing, Snap-In Nyl 1.000 Id X 1.375Mtg Hole	2
10	C5,6 R1	232 296	Resistor/Capacitor Assy	1
11	RT1,2	173 632	Thermistor, Ntc 30K Ohm	2
12		185 835	Label, Warning Exploding Parts	2
13		+183 551	Windtunnel, Lh	1
14		◆604 176	Receptacle, Str Dx Grd Sp3W 15A 125V	1
15		234 126	Nut, Conduit 1.000 Npt Knurled	1
16	CB1	089 807	Circuit Breaker, Man Reset 1P 2.5A 250VAC	1
16	CB1	◆083 432	Circuit Breaker, Man Reset 1P 10A 250VAC	1
17	CB2	083 432	Circuit Breaker, Man Reset 1P 10A 250VAC	1
18		206 460	Panel, Rear	1
18		◆175 147	Panel, Rear W/Aux Power	1
19		215 980	Bushing, Strain Relief .709/.984 Id X1.375 Mtg Hole	1
20		183 308	Plate, Ident Rear (Order By Model And Serial Number)	1
20		◆183 309	Plate, Ident Rear W/Aux Power (Order By Model And Serial Number)	1
21		◆217 297	Cover, Receptacle Weatherproof Duplex Rcpt	1
22		219 487	Cable, Pwr 12Ft	1
23		175 138	Box, Louver	2
24		148 329	Label, Caution Incorrect Voltage (230/460)	1
24		182 227	Label, Caution Incorrect Voltage (460/575)	1
25		192 853	Bracket, Mtg Contactor/Capacitor/PC Board	1
26	PC1	213 664	Circuit Card, Control (230/460)	1
26	PC1	215 045	Circuit Card, Control (460/575)	1
	PLG2	131 056	Connector & Sockets (RC2)	1
	PLG3	130 203	Connector & Sockets (RC3)	1
	PLG4	115 094	Connector & Sockets (RC4)	1
	PLG5	115 091	Connector & Sockets (RC5)	1
	PLG6, PLG8	131 054	Connector & Sockets (RC6, RC8)	2
	PLG7	115 093	Connector & Sockets (RC7)	1
	PLG9	131 204	Connector & Sockets (RC9)	1
	PLG10	166 680	Connector & Sockets (RC10)	1
27	RC10	166 679	Connector & Sockets	1
28	W1,2	211 493	Contactor, Def Prp 40A 8P Dual 24VAC Coil W/Interl (230/460 Only)	1
		173 763	Stand-Off, No. 10-32 X 1.418 (230/460 Only)	8
29	T2	201 684	Transformer, Control (230/460)	1
29	T2	◆193 774	Transformer, Control (230/460)	1
		◆183 549	Bracket, Mtg Aux Transformer	2
29	T2	204 256	Transformer, Control (460/575)	1
31		+207 727	Windtunnel, Rh	1
32		153 403	Bushing, Snap-In Nyl .750 Id X 1.000Mtg	2
33		177 547	Bushing, Snap-In Nyl 1.125Mtg	1
34	CT1	175 199	Transformer, Current	1
35		025 248	Stand-off, Insul	2
36	C1	186 015	Capacitor, Polyp Film .34Uf 1000VAC (230/460)	1
36	C1	193 858	Capacitor, Polyp Film .27Uf 1000VAC (460/575)	1
37	C3,4	192 935	Capacitor, Elctlt 2700Uf 450VDC (230/460)	2
37	C3,4	206 756	Kit, Capacitor Elctlt Replacement (Includes)	1
		193 738	Capacitor, Elctlt 1800 UF 500 VDC	2
		217 040	Nut, Nylon M12 Thread Capacitor Mounting	2

Item No.	Dia. Mkgs.	Part No.	Description	Quantity
----------	------------	----------	-------------	----------

Figure 9-1. Parts Assembly (continued)

... 38	PC2	+212 210	.. Circuit Card Assy, Interconnecting W/Cmpnts (230/460)	1
... 38	PC2	+208 783	.. Circuit Card, Interconnect (460/575)	1
.....	PLG13	131 204	.. Connector & Sockets (RC1)	1
.....	PLG14,21	115 093	.. Connector & Sockets (RC2, RC3)	2
... 39		175 140	.. Bracket, DI/DT	1
... 40		175 482	.. Coil, DI/DT	2
... 41		109 056	.. Core	2
... 42	SR1	179 629	.. Kit Diode, Power Module	1
... 43	PM1,2	233 043	.. Kit, Transistor IGBT Module	1
... 44	Z1	173 570	.. Stabilizer	1
... 45	L1	173 563	.. Inductor, Input	1
... 46		207 725	.. Heat Sink, Power Module	1
... 47	T1	173 811	.. Transformer, Hf (230/460)	1
... 47	T1	180 952	.. Transformer, Hf (460/575)	1
... 48		207 467	.. Heat Sink, Rect	1
... 49		175 255	.. Insulator, Rectifier	1
.....		110 386	.. Relay, 24VAC (460/575 Only)	1
... 50		173 693	.. Foot, Mtg Unit	4
... 51		176 736	.. Screw, Mtg Foot	4
... 52		175 132	.. Base	1
... 53	PC3	213 145	.. Circuit Card, Front Panel & Display	1
.....	PLG11	115 091	.. Connector & Sockets (RC2)	1
.....	PLG17, PLG18	131 054	.. Connector & Sockets (RC4) (RC5)	2
... 54	FM	175 084	.. Motor, Fan 24VDC 3000RPM	1
... 55	RC1	189 886	.. Receptacle, W/Leads & Plug	1
... 56		178 548	.. Terminal, Connector Friction	2
... 57	C7,8	222 488	.. Capacitor, Assembly	2
... 58		187 896	.. Panel, Front	1
... 59		129 525	.. Receptacle, Twlk Insul Fem	2
... 60		187 841	.. Nameplate, (Order By Model And Serial Number)	1
... 61		174 715	.. Knob, Pointer 1.250	1
.....		167 633	.. Washer, Shldr Nylon	1
.....		188 308	.. Washer, Flat Nylon	1
.....		159 264	.. Ring, Rtnng Ext .625	1
... 62		175 855	.. Door, Front	1
... 63		153 169	.. Actuator, Switch	3
... 64		176 226	.. Insulator, Switch Power	1
... 65	S1	231 191	.. Switch, Tgl 3Pst 50A 600VAC Scr Term Wide Tgl	1
... 66		134 327	.. Label, Warning General Precautionary	2
... 67		199 840	.. Bus Bar, Diode	2
... 68		190 125	.. Label, Warning Electric Shock Power Cord	1

+When ordering a component originally displaying a precautionary label, the label should also be ordered.

◆Part of 115V Aux Power Option.

To maintain the factory original performance of your equipment, use only Manufacturer's Suggested Replacement Parts. Model and serial number required when ordering parts from your local distributor.

TRUE BLUE[®]

WARRANTY

Effective January 1, 2007

(Equipment with a serial number preface of "LH" or newer)

This limited warranty supersedes all previous Miller warranties and is exclusive with no other guarantees or warranties expressed or implied.

LIMITED WARRANTY – Subject to the terms and conditions below, Miller Electric Mfg. Co., Appleton, Wisconsin, warrants to its original retail purchaser that new Miller equipment sold after the effective date of this limited warranty is free of defects in material and workmanship at the time it is shipped by Miller. THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.

Within the warranty periods listed below, Miller will repair or replace any warranted parts or components that fail due to such defects in material or workmanship. Miller must be notified in writing within thirty (30) days of such defect or failure, at which time Miller will provide instructions on the warranty claim procedures to be followed.

Miller shall honor warranty claims on warranted equipment listed below in the event of such a failure within the warranty time periods. All warranty time periods start on the delivery date of the equipment to the original end-user purchaser, and not to exceed one year after the equipment is shipped to a North American distributor or eighteen months after the equipment is shipped to an International distributor.

1. 5 Years Parts — 3 Years Labor
 - * Original main power rectifiers
2. 3 Years — Parts and Labor
 - * Transformer/Rectifier Power Sources
 - * Plasma Arc Cutting Power Sources
 - * Process Controllers
 - * Semi-Automatic and Automatic Wire Feeders
 - * Inverter Power Sources (Unless Otherwise Stated)
 - * Water Coolant Systems (Integrated)
 - * Intellitig
 - * Engine Driven Welding Generators
(NOTE: Engines are warranted separately by the engine manufacturer.)
3. 1 Year — Parts and Labor Unless Specified
 - * Motor Driven Guns (w/exception of Spoolmate Spoolguns)
 - * Positioners and Controllers
 - * Automatic Motion Devices
 - * RFCS Foot Controls
 - * Induction Heating Power Sources, Coolers, and Electronic Controls/Recorders
 - * Water Coolant Systems (Non-Integrated)
 - * Flowgauge and Flowmeter Regulators (No Labor)
 - * HF Units
 - * Grids
 - * Spot Welders
 - * Load Banks
 - * Arc Stud Power Sources & Arc Stud Guns
 - * Racks
 - * Running Gear/Trailers
 - * Plasma Cutting Torches (except APT & SAF Models)
 - * Field Options
(NOTE: Field options are covered under True Blue[®] for the remaining warranty period of the product they are installed in, or for a minimum of one year — whichever is greater.)
 - * Bernard-Branded Mig Guns (No Labor)
 - * Weldcraft-Branded TIG Torches (No Labor)
 - * Subarc Wire Drive Assemblies
4. 6 Months — Batteries
5. 90 Days — Parts
 - * MIG Guns/TIG Torches and Subarc (SAW) Guns

- * Induction Heating Coils and Blankets, Cables, and Non-Electronic Controls
- * APT & SAF Model Plasma Cutting Torches
- * Remote Controls
- * Accessory (Kits)
- * Replacement Parts (No labor)
- * Spoolmate Spoolguns
- * Canvas Covers

Miller's True Blue[®] Limited Warranty shall not apply to:

1. **Consumable components; such as contact tips, cutting nozzles, contactors, brushes, slip rings, relays or parts that fail due to normal wear. (Exception: brushes, slip rings, and relays are covered on Bobcat, Trailblazer, and Legend models.)**
2. Items furnished by Miller, but manufactured by others, such as engines or trade accessories. These items are covered by the manufacturer's warranty, if any.
3. Equipment that has been modified by any party other than Miller, or equipment that has been improperly installed, improperly operated or misused based upon industry standards, or equipment which has not had reasonable and necessary maintenance, or equipment which has been used for operation outside of the specifications for the equipment.

MILLER PRODUCTS ARE INTENDED FOR PURCHASE AND USE BY COMMERCIAL/INDUSTRIAL USERS AND PERSONS TRAINED AND EXPERIENCED IN THE USE AND MAINTENANCE OF WELDING EQUIPMENT.

In the event of a warranty claim covered by this warranty, the exclusive remedies shall be, at Miller's option: (1) repair; or (2) replacement; or, where authorized in writing by Miller in appropriate cases, (3) the reasonable cost of repair or replacement at an authorized Miller service station; or (4) payment of or credit for the purchase price (less reasonable depreciation based upon actual use) upon return of the goods at customer's risk and expense. Miller's option of repair or replacement will be F.O.B., Factory at Appleton, Wisconsin, or F.O.B. at a Miller authorized service facility as determined by Miller. Therefore no compensation or reimbursement for transportation costs of any kind will be allowed.

TO THE EXTENT PERMITTED BY LAW, THE REMEDIES PROVIDED HEREIN ARE THE SOLE AND EXCLUSIVE REMEDIES. IN NO EVENT SHALL MILLER BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING LOSS OF PROFIT), WHETHER BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY.

ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTY OR REPRESENTATION AS TO PERFORMANCE, AND ANY REMEDY FOR BREACH OF CONTRACT TORT OR ANY OTHER LEGAL THEORY WHICH, BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE, WITH RESPECT TO ANY AND ALL EQUIPMENT FURNISHED BY MILLER IS EXCLUDED AND DISCLAIMED BY MILLER.

Some states in the U.S.A. do not allow limitations of how long an implied warranty lasts, or the exclusion of incidental, indirect, special or consequential damages, so the above limitation or exclusion may not apply to you. This warranty provides specific legal rights, and other rights may be available, but may vary from state to state.

In Canada, legislation in some provinces provides for certain additional warranties or remedies other than as stated herein, and to the extent that they may not be waived, the limitations and exclusions set out above may not apply. This Limited Warranty provides specific legal rights, and other rights may be available, but may vary from province to province.

miller_warr 2007-01

Warranty Questions?

Call
1-800-4-A-MILLER
for your local
Miller distributor.

Your distributor also gives you ...

Service

You always get the fast, reliable response you need. Most replacement parts can be in your hands in 24 hours.

Support

Need fast answers to the tough welding questions? Contact your distributor. The expertise of the distributor and Miller is there to help you, every step of the way.





Owner's Record

Please complete and retain with your personal records.

Model Name

Serial/Style Number

Purchase Date

(Date which equipment was delivered to original customer.)

Distributor

Address

City

State

Zip



For Service

Contact a DISTRIBUTOR or SERVICE AGENCY near you.

Always provide Model Name and Serial/Style Number.

Contact your Distributor for:

Welding Supplies and Consumables

Options and Accessories

Personal Safety Equipment

Service and Repair

Replacement Parts

Training (Schools, Videos, Books)

Technical Manuals (Servicing Information and Parts)

Circuit Diagrams

Welding Process Handbooks

To locate a Distributor or Service Agency visit www.millerwelds.com or call 1-800-4-A-Miller

Contact the Delivering Carrier to:

File a claim for loss or damage during shipment.

For assistance in filing or settling claims, contact your distributor and/or equipment manufacturer's Transportation Department.

Miller Electric Mfg. Co.

An Illinois Tool Works Company
1635 West Spencer Street
Appleton, WI 54914 USA

International Headquarters—USA

USA Phone: 920-735-4505 Auto-Attended
USA & Canada FAX: 920-735-4134
International FAX: 920-735-4125

European Headquarters – United Kingdom

Phone: 44 (0) 1204-593493
FAX: 44 (0) 1204-598066

www.MillerWelds.com



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>