

6212-I1 4-Port Router

User's Guide

Document No. 6212-A2-GB23-00

September 2005

**Copyright 2005 Paradyne Corporation.
All rights reserved.
Printed in U.S.A.**

Notice

This publication is protected by federal copyright law. No part of this publication may be copied or distributed, transmitted, transcribed, stored in a retrieval system, or translated into any human or computer language in any form or by any means, electronic, mechanical, magnetic, manual or otherwise, or disclosed to third parties without the express written permission of Paradyne Corporation, 8545 126th Ave. N., Largo, FL 33773.

Paradyne Corporation makes no representation or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Further, Paradyne Corporation reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation of Paradyne Corporation to notify any person of such revision or changes.

Changes and enhancements to the product and to the information herein will be documented and issued as a new release to this manual.

Warranty, Sales, Service, and Training Information

Contact your local sales representative, service representative, or distributor directly for any help needed. For additional information concerning warranty, sales, service, repair, installation, documentation, training, distributor locations, or Paradyne worldwide office locations, use one of the following methods:

- **Internet:** Visit the Paradyne World Wide Web site at www.paradyne.com. (Be sure to register your warranty at www.paradyne.com/warranty.)
- **Telephone:** Call our automated system to receive current information by fax or to speak with a company representative.
 - Within the U.S.A., call 1-800-795-8004
 - Outside the U.S.A., call 1-727-530-2340

Document Feedback

We welcome your comments and suggestions about this document. Please mail them to Technical Publications, Paradyne Corporation, 8545 126th Ave. N., Largo, FL 33773, or send e-mail to userdoc@paradyne.com. Include the number and title of this document in your correspondence. Please include your name and phone number if you are willing to provide additional clarification.

Trademarks

Acculink, ADSL/R, Bitstorm, Comsphere, DSL the Easy Way, ETC, Etherloop, FrameSaver, GranDSLAM, GrandVIEW, Hotwire, the Hotwire logo, iMarc, Jetstream, MVL, NextEDGE, Net to Net Technologies, OpenLane, Paradyne, the Paradyne logo, Paradyne Credit Corp., the Paradyne Credit Corp. logo, Performance Wizard, ReachDSL, StormPort, TruePut are registered trademarks of Paradyne Corporation.

Connect to Success, Hotwire Connected, JetFusion, JetVision, MicroBurst, PacketSurfer, Quick Channel, Reverse Gateway, Spectrum Manager, and StormTracker are trademarks of Paradyne Corporation.

All other products or services mentioned herein are the trademarks, service marks, registered trademarks, or registered service marks of their respective owners.

Important Safety Instructions

1. Read and follow all warning notices and instructions marked on the product or included in the manual.
2. Slots and openings in the cabinet are provided for ventilation. To ensure reliable operation of the product and to protect it from overheating, these slots and openings must not be blocked or covered.
3. Do not allow anything to rest on the power cord and do not locate the product where persons will walk on the power cord.
4. Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous high voltage points or other risks. Refer all servicing to qualified service personnel.
5. General purpose cables are used with this product for connection to the network. Special cables, which may be required by the regulatory inspection authority for the installation site, are the responsibility of the customer. Use a UL Listed, CSA certified, minimum No. 24 AWG line cord for connection to the Digital Subscriber Line (DSL) network.
6. When installed in the final configuration, the product must comply with the applicable Safety Standards and regulatory requirements of the country in which it is installed. If necessary, consult with the appropriate regulatory agencies and inspection authorities to ensure compliance.
7. A rare phenomenon can create a voltage potential between the earth grounds of two or more buildings. If products installed in separate buildings are interconnected, the voltage potential may cause a hazardous condition. Consult a qualified electrical consultant to determine whether or not this phenomenon exists and, if necessary, implement corrective action prior to interconnecting the products.
8. Input power to this product must be provided by one of the following: (1) a UL Listed/CSA certified power source with a Class 2 or Limited Power Source (LPS) output for use in North America, or (2) a certified transformer, with a Safety Extra Low Voltage (SELV) output having a maximum of 240 VA available, for use in the country of installation.
9. In addition, since the equipment is to be used with telecommunications circuits, take the following precautions:
 - Never install telephone wiring during a lightning storm.
 - Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
 - Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
 - Use caution when installing or modifying telephone lines.
 - Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
 - Do not use the telephone to report a gas leak in the vicinity of the leak.

CE Marking

When the product is marked with the CE mark on the equipment label, a supporting Declaration of Conformity may be downloaded from the Paradyne World Wide Web site at www.paradyne.com. Select *Library* → *Technical Manuals* → *CE Declarations of Conformity*.

FCC Part 15 Declaration

An FCC Declaration of Conformity may be downloaded from the Paradyne World Wide Web site at www.paradyne.com. Select Support -> Technical Manuals -> Declarations of Conformity.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The authority to operate this equipment is conditioned by the requirement that no modifications will be made to the equipment unless the changes or modifications are expressly approved by the responsible party.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Notice to Users of the United States Telephone Network

The following notice applies to versions of the modem that have been FCC Part 68 approved.

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the Administrative Council for Terminal Attachment (ACTA). On the bottom side of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to the Telephone Company.

This equipment is intended to connect to the Public Switched Telephone Network through a Universal Service Order Code (USOC) type RJ11C jack. A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It has been designed to be connected to a compatible modular jack that is also compliant.

The Ringer Equivalence Number (or REN) is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the local Telephone Company. The REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point. For example, 03 represents a REN of 0.3.

If the modem causes harm to the telephone network, the Telephone Company will notify you in advance that temporary discontinuance of service may be required. But if advance notice is not practical, the Telephone Company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The Telephone Company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens, the Telephone Company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service. If trouble is experienced with the modem, refer to the repair and warranty information in this document.

If the equipment is causing harm to the telephone network, the Telephone Company may request that you disconnect the equipment until the problem is resolved.

The user may make no repairs to the equipment.

Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information.

If the site has specially wired alarm equipment connected to the telephone line, ensure the installation of the modem does not disable the alarm equipment. If you have questions about what will disable alarm equipment, consult your Telephone Company or a qualified installer.

Notice to Users of the Canadian Telephone Network

NOTICE: This equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation IC before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment.

NOTICE: The Ringer Equivalence Number (REN) for this terminal equipment is labeled on the equipment. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed five.

If your equipment is in need of repair, contact your local sales representative, service representative, or distributor directly.

CANADA - EMI NOTICE:

This Class B digital apparatus meets all requirements of the Canadian interference-causing equipment regulations.

Cet appareil numérique de la classe B respecte toutes les exigences du règlement sur le matériel brouilleur du Canada.

Japan Notices

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラス B 情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。
取扱説明書に従って正しい取り扱いをして下さい。

This is a Class B product based on the standard of the Voluntary Control Council for Interference from Information Technology Equipment (VCCI). If this is used near a radio or television receiver in a domestic environment, it may cause radio interference. Install and use the equipment according to the instruction manual.

Contents

About This Guide

- Document Purpose and Intended Audience v
- Document Summary v
- Product-Related Documents vi

1 Introduction

- Introduction 1-1
- Features 1-1
- System Requirements 1-1
- Parts List 1-2
- Front Panel 1-3
- Rear Panel 1-4

2 Hardware Installation and PC Setup

- Overview 2-1
- Connecting the Hardware 2-2
- Configuring Your Computer 2-4
 - Windows XP 2-5
 - Windows 2000 2-7
 - Windows ME 2-7
 - Windows 95 and Windows 98 2-8
 - Windows NT 4.0 2-9
- Logging in to Your Router 2-10

3 Device Information

- Status Summary 3-1
- WAN 3-2
- LAN Statistics 3-3
- WAN Statistics 3-3
- ATM Statistics 3-4
- ADSL Statistics 3-4
- ADSL BER Test 3-5
- Route 3-6

- ARP 3-6

4 Quick Setup

- Quick Setup with Auto-Connect Enabled 4-1
- Quick Setup with Auto-Connect Disabled 4-3

5 Advanced Setup

- WAN 5-1
 - Add Function – ATM PVC Configuration 5-2
 - Connection Type Screen 5-3
 - WAN Setup - Summary 5-4
 - Remove Function 5-4
 - Finish Function 5-5
- Local Area Network (LAN) Setup 5-5
- NAT 5-6
 - Virtual Servers 5-6
- Port Triggering 5-7
- DMZ Host 5-9
- Firewall 5-9
 - IP Filtering – Outgoing 5-9
 - IP Filtering – Incoming 5-11
 - Firewall – MAC Filtering 5-12
 - Parental Control 5-14
- Port Mapping 5-15
- Quality of Service 5-16
- Routing – Default Gateway 5-17
- Routing – Static Route 5-18
- Routing – RIP 5-19
- DNS Server 5-20
- Dynamic DNS 5-20
- ADSL 5-21
 - Modulation Methods 5-22
 - Phone Line Pair 5-22
 - Capability 5-22
- DSL Advanced Settings 5-23
- Tone Selection 5-24

6 Diagnostics

- Testing the DSL Connection 6-1

7 Management

- Saving and Restoring the Configuration 7-1
- Backing Up Configuration Settings 7-1
- Restoring Configuration Settings 7-3
- Restoring Default Settings 7-5
- System Log 7-6
 - View System Log 7-7
 - Configure System Log 7-8
- SNMP 7-9
- Internet Time 7-10
- Access Control – Services 7-11
- Access Control – IP Addresses 7-11
- Access Control – Passwords 7-12
- Update Software 7-13
- Reboot Router 7-14

A Specifications

Index

About This Guide

Document Purpose and Intended Audience

This guide contains detailed information about the 6212-I1 router. It is intended for all users of the router.

Document Summary

Section	Description
Chapter 1, Introduction	Describes the features of the router.
Chapter 2, Hardware Installation and PC Setup	Shows how to connect the router and set up your PC to manage the router.
Chapter 3, Device Information	Explains how to use the web interface to obtain statistics and other information about the router.
Chapter 4, Quick Setup	Describes the Quick Setup configuration process.
Chapter 5, Advanced Setup	Describes configuration of the advanced router features.
Chapter 6, Diagnostics	Describes the test screen.
Chapter 7, Management	Describes the management functions of the router, including backing up and restoring configuration settings, viewing the system log, configuring access control, and upgrading software.
Appendix A, Specifications	Lists the specifications of the router.
Index	Lists key terms, concepts, and sections in alphabetical order.

A master glossary of terms and acronyms used in Paradyne documents is available online at www.paradyne.com. Select *Support* → *Technical Manuals* → *Technical Glossary*.

Product-Related Documents

Complete documentation for Paradyne products is available online at **www.paradyne.com**. Select *Support* → *Technical Manuals*.

To order a paper copy of a Paradyne document, or to speak with a sales representative, please call 1-727-530-2000.

Introduction

1

Introduction

Congratulations on becoming the owner of a 6212 ADSL router.

This User's Guide will show you how to set up the router, and how to customize its configuration to get the most out of this product.

Features

The 6212 router has the following features:

- Built-in ADSL modem which offers G.Dmt, G.lite, T1.413, ADSL2, Annex L, and ADSL2+ to meet different linking speeds from your ISP.
- Four 10/100BaseT Ethernet ports to provide Internet connectivity to all computers on your LAN.
- Easy-to-use configuration program accessible through a standard web browser.

System Requirements

In order to use the 6212 ADSL router for Internet access, you must have the following:

- ADSL service subscription from your ISP
- A PC with:
 - An Ethernet 10/100BaseT network interface card
 - A processor equivalent to or faster than a Pentium II 133 MHz
 - 32 MB RAM or greater
 - Windows 95b, 98, 98SE, 2000, ME, NT, or XP (Note: Windows 95 requires the installation of the Winsock program, not included.)
 - (Optional) An Ethernet hub or switch, if you wish to connect the router to several computers on an Ethernet network.

- For system configuration using the supplied web-based program: a web browser such as Internet Explorer Version 6.0 or later. Netscape is not supported.

Parts List

In addition to this document, your 6212 ADSL router should come with the following:

- 6212 ADSL router
- Power adapter
- Ethernet cable (RJ45, straight-through type)
- Phone cable (RJ11)

Front Panel

The front panel contains LED indicators that show the status of the unit.




Figure 1-1. Front Panel LEDs

Table 1-1. Front Panel Label and LEDs

Label	Color	Function
xDSL LNK	Green	On: ADSL link is established.
		Flashing: ADSL link is established and active.
		Off: No ADSL link.
xDSL ACT	Green	Off: No PPP connection is established or the connection is not used.
		Blinking: a PPP connection is being attempted.
		Solid: A PPP connection is established.
		Flickering: There is activity over the link.
LAN 1–4	Green	On: The Ethernet interface is successfully connected to a device through the LAN port.
		Flashing: Data transfer at LAN connection
		Off: No LAN link
ALARM	Red	On: ADSL is not connected.
		Off: ADSL is connected.
POWER	Green	On: Unit is powered on.
		Off: Unit is powered off.

Rear Panel




Figure 1-2. Back Panel

The rear panel contains the ports for the router's data and power connections.

Table 1-2. Rear Panel Labels and Connectors

Label	Function
LINE	Connects to your ADSL line
LAN 1-4	Connects the router to Ethernet devices on your LAN, such as your PC's Ethernet port, or the uplink port on a hub or switch
RESET/DEFAULT	To reset the router to its default settings
POWER	Connects to the supplied power adapter

Hardware Installation and PC Setup

2

Overview

This chapter provides basic instructions for connecting the router to a computer or a LAN and to the Internet using DSL. The first part provides instructions to set up the hardware, and the second part describes how to prepare your PC for use with the router.

It is assumed that you have already subscribed to DSL service with your Internet service provider (ISP).

Connecting the Hardware

Shut down your PC and any other equipment before connecting it to the router. To connect your router:

► Procedure

1. Verify that the router's power switch is in the Off (outward) position. Verify that any PCs and other LAN devices you will attach (such as hubs or switches) are turned off.
2. Use the provided modular phone cable to connect the LINE jack of the router to your RJ11 wall jack.
3. Use the provided Ethernet cable to connect your computer to the router. Attach one end of the Ethernet cable to one of the LAN ports on the back of the router and connect the other end to the Ethernet port or Network Interface Card (NIC) in your PC.

Connect any other PCs, hubs, and switches to the remaining LAN ports. Either a crossover or a straight-through Ethernet cable can be used: the router determines the type of signal required.

4. Connect the cylindrical power plug into the POWER connector on the back of the device. Next:
 - If you have a wall-mount adapter, plug the AC adapter into a wall outlet or a power strip.
 - If you have a table-top adapter, use the AC power cord to connect the adapter to a wall outlet or power strip.

The supplied power adapter may look different than the one illustrated here.




Figure 2-1. Hardware Installation

5. Turn on your PC and any other LAN devices, such as hubs or switches.
6. Turn on the router using its power switch.
7. Verify that the router's LEDs are illuminated as shown in [Table 2-1](#).

Table 2-1. LED Indicators

This LED . . .	Should be:
POWER	Solid green to indicate that the device is turned on. If this light is not on, check if the power adapter is attached to the router and plugged into an AC power source.
STATUS	Solid green to indicate that the router can communicate with your ISP via ADSL, or flashing when the router is trying to connect to your ISP.
ACTIVITY	Flashing when the device is sending or receiving data over the ADSL connection.
LAN	Solid green to indicate that the device can communicate with your PC via Ethernet, or flashing when the router is sending or receiving data over Ethernet.

If the LEDs are illuminated as expected, the router is working properly.

Configuring Your Computer

Before you can access the router over the LAN you have to configure your PC's TCP/IP address to be 192.168.1.x (where x is any number between 3 and 254), with a subnet mask of 255.255.255.0. Your router's default IP address is 192.168.1.1.

If you know the version of Windows that you use, go to the appropriate section below to learn how to set the IP address of your PC. To determine the version of Windows running on your PC, click on the Windows Start button, then click on Run... in the Start menu. Type **winver** in the Open selection box and click on OK.




Figure 2-2. Windows Run Dialog

The Windows version is displayed.



Figure 2-3. Windows Version

Windows XP

1. In the Windows task bar, click on the Start button, and then click on Control Panel.
2. Double-click on the Network Connections icon.
3. In the LAN or High-Speed Internet window, right-click on the icon corresponding to your network interface card (NIC), and select Properties. (Often this icon is labeled Local Area Connection). The Local Area Connection dialog box displays with a list of currently installed network items.
4. Ensure that the check box to the left of the item labeled Internet Protocol (TCP/IP) is checked, and click on Properties.




Figure 2-4. Network Connections (Windows XP)




Figure 2-5. Local Area Connection Properties (Windows XP)

5. In the Internet Protocol (TCP/IP) Properties dialog box, click on the radio button labeled Use the following IP address. Type an address between 192.168.1.3 and 192.168.1.254 in the IP Address field (192.168.1.20 is shown here as an example) and 255.255.255.0 in the Subnet Mask field.




Figure 2-6. TCP/IP Properties (Windows XP)

6. Click on OK twice to confirm your changes, and close the Control Panel.

Windows 2000

1. In the Windows task bar, click on the Start button, point to Settings, and then click on Control Panel.
2. Double-click on the Network and Dial-up Connections icon.
3. In the Network and Dial-up Connections window, right-click on the Local Area Connection icon, and then select Properties.

The Local Area Connection Properties dialog box display a list of currently installed network components. If the list includes Internet Protocol (TCP/IP), the protocol has already been enabled; skip to [Step 10](#).

4. If Internet Protocol (TCP/IP) does not appear as an installed component, click on Install.
5. In the Select Network Component Type dialog box, select Protocol, and then click on Add.
6. Select Internet Protocol (TCP/IP) in the Network Protocols list, and then click on OK.

You may be prompted to install files from your Windows 2000 installation CD or other medium. Follow the instructions to install the files.

7. If prompted, click on OK to restart your computer with the new settings.
8. After restarting your PC, double-click on the Network and Dial-up Connections icon in the Control Panel.
9. In Network and Dial-up Connections window, right-click on the Local Area Connection icon, and then select Properties.
10. In the Local Area Connection Properties dialog box, select Internet Protocol (TCP/IP), and then click on Properties.
11. In the Internet Protocol (TCP/IP) Properties dialog box, click on the radio button labeled Use the following IP address. Type an address between 192.168.1.3 and 192.168.1.254 in the IP Address field and 255.255.255.0 in the Subnet Mask field.
12. Click on OK twice to confirm and save your changes, and then close the Control Panel.

Windows ME

1. In the Windows task bar, click on the Start button, point to Settings, and then click on Control Panel.
2. Double-click on the Network and Dial-up Connections icon.
3. In the Network and Dial-up Connections window, right-click on the Network icon, and then select Properties.

The Network Properties dialog box displays a list of currently installed network components. If the list includes Internet Protocol (TCP/IP), the protocol has already been enabled; skip to [Step 11](#).

4. If Internet Protocol (TCP/IP) does not appear as an installed component, click on Add.
5. In the Select Network Component Type dialog box, select Protocol, and then click on Add.
6. Select Microsoft in the Manufacturers box.
7. Select Internet Protocol (TCP/IP) in the Network Protocols list, and then click on OK.

You may be prompted to install files from your Windows Me installation CD or other media. Follow the instructions to install the files.

8. If prompted, click on OK to restart your computer with the new settings.
9. After restarting your PC, double-click on the Network and Dial-up Connections icon in the Control Panel.
10. In Network and Dial-up Connections window, right-click on the Network icon, and then select Properties.
11. In the Network Properties dialog box, select TCP/IP, and then click on Properties.
12. In the TCP/IP Settings dialog box, click on the radio button labeled Use the following IP address. Type an address between 192.168.1.3 and 192.168.1.254 in the IP Address field and 255.255.255.0 in the Subnet Mask field.
13. Click on OK twice to confirm and save your changes, and then close the Control Panel.

Windows 95 and Windows 98

1. In the Windows task bar, click on the Start button, point to Settings, and then click on Control Panel.
2. Double-click on the Network icon.

The Network dialog box displays a list of currently installed network components. If the list includes TCP/IP, the protocol has already been enabled. Skip to step 9.
3. If TCP/IP does not appear as an installed component, click on Add. The Select Network Component Type dialog box appears.

4. Select Protocol, and then click on Add.

The Select Network Protocol dialog box appears.

5. Click on Microsoft in the Manufacturers list box, and then click on TCP/IP in the Network Protocols list box.
6. Click on OK to return to the Network dialog box, and then click on OK again.

You may be prompted to install files from your Windows 95/98 installation CD. Follow the instructions to install the files.

7. Click on OK to restart the PC and complete the TCP/IP installation.

8. After restarting your PC, open the Control Panel window, and then click on the Network icon.
9. Select the network component labeled TCP/IP, and then click on Properties.
If you have multiple TCP/IP listings, select the listing associated with your network card or adapter.
10. In the TCP/IP Properties dialog box, click on the IP Address tab.
11. Click in the radio button labeled Use the following IP address. Type an address between 192.168.1.3 and 192.168.1.254 in the IP Address field and 255.255.255.0 in the Subnet Mask field.
12. Click on OK twice to confirm and save your changes. You will be prompted to restart Windows. Click on Yes.

Windows NT 4.0

1. In the Windows NT task bar, click on the Start button, point to Settings, and then click on Control Panel.
2. In the Control Panel window, double click on the Network icon.
3. In the Network dialog box, click on the Protocols tab.
The Protocols tab displays a list of currently installed network protocols. If the list includes TCP/IP, the protocol has already been enabled. Skip to [Step 9](#).
4. If TCP/IP does not appear as an installed component, click on Add.
5. In the Select Network Protocol dialog box, select TCP/IP, and then click on OK.
You may be prompted to install files from your Windows NT installation CD or other medium. Follow the instructions to install the files.
After all files are installed, a window appears to inform you that a TCP/IP service called DHCP can be set up to dynamically assign IP information.
6. Click on Yes to continue, and then click on OK, if prompted, to restart your computer.
7. After restarting your PC, open the Control Panel window, and then double-click on the Network icon.
8. In the Network dialog box, click on the Protocols tab.
9. In the Protocols tab, select TCP/IP, and then click on Properties.
10. In the Microsoft TCP/IP Properties dialog box, click on the radio button labeled Use the following IP address. Type an address between 192.168.1.3 and 192.168.1.254 in the IP Address field and 255.255.255.0 in the Subnet Mask field.
11. Click on OK twice to confirm and save your changes, and then close the Control Panel.

Logging in to Your Router

This section shows how to connect to the router's web interface, configure settings, and observe some statistics of your Internet connection.

1. Open your Web browser, and type the following URL in the address/location box, and press Enter:

http://192.168.1.1

This is the default IP address for the LAN port on the router.

A login screen appears.




Figure 2-7. Login Screen

If you have problem connecting to the router, verify that your PC is properly configured within the subnet of the router's default IP address 192.168.1.1. Setup is described in [Configuring Your Computer](#) on page 2-4.

2. Enter your user name and password, and then click on OK to display the home page of the router's web interface. There are two default user name and password combinations:

Table 2-2. Default User Names and Passwords

User Name	Password	Capability
user	user	Can display device status, but cannot change or save configuration options.
admin	admin	Can perform all functions.

You can change the passwords at any time.

The home page is shown in [Figure 2-8](#).




Figure 2-8. Web Interface Home Page

Device Information

3

Status Summary

Display the general status report for the router by clicking on Summary under Device Info (Figure 3-1).

The screenshot displays a web interface for a router. On the left, a navigation tree shows 'Device Info' expanded, with 'Summary' highlighted. The main content area is titled 'Device Info' and contains two tables. The first table lists device specifications, and the second table, preceded by a note, lists DSL connection parameters.

Device Info	
Board ID:	R4P
Software Version:	3-00-03-0400.A2p8018b2.d15h
Bootloader (CFE) Version:	1.0.37-0.7

This information reflects the current status of your DSL connection.

Line Rate - Upstream (Kbps):	800
Line Rate - Downstream (Kbps):	8000
LAN IP Address:	192.168.1.1
Default Gateway:	
Primary DNS Server:	192.168.1.1
Secondary DNS Server:	192.168.1.1

Figure 3-1. Status Summary

WAN

Display the WAN status report from the by clicking on WAN under Device Info (Figure 3-3).




Figure 3-2. WAN Status

When a WAN connection is configured, the screen looks like Figure 3-3.




Figure 3-3. WAN Status with WAN Connection

LAN Statistics

Display LAN statistics by clicking on LAN under Statistics (Figure 3-4).

The screenshot shows a network management interface. On the left is a tree view with the following items: Welcome, Device Info, Summary, WAN, Statistics (expanded), LAN (selected), WAN, ATM, ADSL, Route, ARP, Quick Setup, Advanced Setup, Diagnostics, and Management. The main content area is titled 'Statistics -- LAN' and contains a table with the following data:

Interface	Received				Transmitted			
	Bytes	Pkts	Errs	Drops	Bytes	Pkts	Errs	Drops
Ethernet	1852	15	0	0	3266	15	0	0

Below the table is a 'Reset Statistics' button.

Figure 3-4. LAN Statistics

WAN Statistics

Display WAN statistics by clicking on WAN under Statistics (Figure 3-5).

The screenshot shows a network management interface. On the left is a tree view with the following items: Welcome, Device Info, Summary, WAN, Statistics (expanded), LAN, WAN (selected), ATM, ADSL, Route, ARP, Quick Setup, Advanced Setup, Diagnostics, and Management. The main content area is titled 'WAN Statistics' and contains a table with the following data:

Service	VPI/VCI	Protocol	Interface	Received				Transmitted			
				Bytes	Pkts	Errs	Drops	Bytes	Pkts	Errs	Drops
pppoe_3_40_1	3/40	PPPoA	ppp_3_40_1	64	4	0	0	82	4	0	0
mer_3_41	3/41	MER	nas_3_41	0	0	0	0	954	3	0	0

Below the table is a 'Reset Statistics' button.

Figure 3-5. WAN Statistics

ATM Statistics

Display ATM statistics by clicking on ATM under Statistics (Figure 3-6).




Figure 3-6. ATM Statistics

ADSL Statistics

Display ADSL statistics by clicking on ADSL under Statistics (Figure 3-7).




Figure 3-7. ADSL Status

ADSL BER Test

The ADSL Bit Error Rate (BER) test determines the quality of the ADSL connection. The test is performed by transferring idle cells containing a known pattern and comparing the received data with this known pattern to check for any errors (Figure 3-8 and Figure 3-9).

► Procedure

To run a BER test:

1. Click on the ADSL BER Test button.
2. Select the test duration and click on Start
3. Check the result.




Figure 3-8. ADSL BER Test — Start




Figure 3-9. ADSL BER Test — Result

Route

Obtain the Routing status report by clicking on the Route item under Device Info (Figure 3-10)

The screenshot shows a web interface with a navigation tree on the left and a main content area on the right. The navigation tree includes: Welcome, Device Info (expanded), Summary, WAN, Statistics (expanded), LAN, WAN, ATM, ADSL, Route (highlighted), ARP, Quick Setup, Advanced Setup, Diagnostics, and Management. The main content area is titled "Device Info -- Route" and contains a legend for flags: U - up, I - reject, G - gateway, H - host, R - reinstate, D - dynamic (redirect), M - modified (redirect). Below the legend is a table with the following data:

Destination	Gateway	Subnet Mask	Flags	Metric	Service	Interface
192.168.1.0	0.0.0.0	255.255.255.0	U	0		br0

Figure 3-10. Route Information

ARP

Display the ARP status report by clicking on ARP under Device Info (Figure 3-11)

The screenshot shows a web interface with a navigation tree on the left and a main content area on the right. The navigation tree includes: Welcome, Device Info (expanded), Summary, WAN, Statistics (expanded), LAN, WAN, ATM, ADSL, Route, ARP (highlighted), Quick Setup, Advanced Setup, Diagnostics, and Management. The main content area is titled "Device Info -- ARP" and contains a table with the following data:

IP Address	Flags	HW Address	Device
192.168.1.177	Complete	00:08:98:82:16:60	br0

Figure 3-11. ARP Status

Quick Setup

4

Quick Setup with Auto-Connect Enabled

Auto-connect will automatically detect the first usable PVC and automatically detect PPPoE, PPPoA, and Bridge Protocol (with DHCP Server available). To use auto-connect:

► Procedure

1. Select Quick Setup. The Quick Setup initial screen appears.




Figure 4-1. Quick Setup Initial Screen

2. Select DSL Auto-Connect, then click on Next. The progress information screen appears.




Figure 4-2. Detecting Available PVC




Figure 4-3. Detecting available PVC – Available PVC Detected

Quick Setup with Auto-Connect Disabled

► Procedure

1. Select Quick Setup. The Quick Setup initial screen appears.
2. Verify that DSL Auto-Connect is not selected. Entry boxes for VPI and VCI appear when DSL Auto-Connect is not selected.
3. Specify VPI and VCI as directed by your ISP.

The screenshot shows the 'Quick Setup' configuration page. On the left is a navigation tree with 'Quick Setup' selected. The main content area is titled 'Quick Setup' and contains the following sections:

- ATM PVC Configuration:** A checkbox for 'DSL Auto-connect' is unchecked. Below it, two input fields are shown: 'VPI: [0-255]' with the value '0' and 'VCI: [32-65535]' with the value '35'.
- Enable Quality Of Service:** A checkbox for 'Enable Quality Of Service' is unchecked.

A 'Next' button is located at the bottom right of the configuration area.

Figure 4-4. Specifying VPI and VCI

4. Click on Next. The Connection Type screen appears.

The screenshot shows the 'Connection Type' configuration page. On the left is a navigation tree with 'Quick Setup' selected. The main content area is titled 'Connection Type' and contains the following sections:

- Protocol Selection:** Five radio button options are listed: 'PPP over ATM (PPPoA)' (selected), 'PPP over Ethernet (PPPoE)', 'MAC Encapsulation Routing (MER)', 'IP over ATM (IPoA)', and 'Bridging'.
- Encapsulation Mode:** A dropdown menu is set to 'VCMUX'.

'Back' and 'Next' buttons are located at the bottom right of the configuration area.

Figure 4-5. Connection Type

5. Select the protocol and encapsulation type required by your ISP.

- Click on Next. Further parameters for the selected protocol are presented. For example, if you selected PPPoA, the PPP Username and Password screen appears.

PPP Username and Password

PPP usually requires that you have a user name and password to establish your connection. In the boxes below, enter the user name and password that your ISP has provided to you.

PPP Username: (Do not use *<>%\^{}'+,=#&.:)

PPP Password: (Do not use *<>%\^{}'+,=#&.:)

Authentication Method:

Dial on demand (with idle timeout timer)

PPP IP extension

Keep Alive

Use the following default gateway:

Use IP Address:

Use WAN Interface:

Back Next

Figure 4-6. PPP Username and Password

- Click on Next. The Network Address Translation Settings screen appears.

Network Address Translation Settings

Network Address Translation (NAT) allows you to share one Wide Area Network (WAN) IP address for multiple computers on your Local Area Network (LAN).

Enable NAT

Enable Firewall

Enable IGMP Multicast, and WAN Service

Enable IGMP Multicast

Enable WAN Service

Service Name:

Back Next

Figure 4-7. NAT Settings

8. Enter the settings specified by your ISP and click on Next. The Device Setup screen appears.

Welcome

- Device Info
 - Summary
 - WAN
 - Statistics
 - LAN
 - WAN
 - ATM
 - ADSL
 - Route
 - ARP
- Quick Setup
- Advanced Setup
 - WAN
 - LAN
 - NAT
 - Firewall
 - Port Mapping
 - Quality of Service
 - Routing
 - DNS
 - DNS Server
 - Dynamic DNS
 - ADSL
 - Diagnostics
 - Management

Device Setup

Configure the DSL Router IP Address and Subnet Mask for LAN interface.

IP Address:

Subnet Mask:

Disable DHCP Server

Enable DHCP Server

Start IP Address:

End IP Address:

Leased Time (hour):

Configure the second IP Address and Subnet Mask for LAN interface

Figure 4-8. Device Setup

9. If desired, configure the DSL Router IP address and Subnet Mask for the LAN interface to correspond to your LAN's IP Subnet. If you want the DHCP server to automatically assign IP addresses, then enable the DHCP server and enter the range of IP addresses that the DHCP server can assign to your computers. Disable the DHCP server if you would like to manually assign IP addresses.

If you have a second IP address and subnet mask for the LAN interface, click on the checkbox to configure it.

- Click on Next to continue. The WAN Setup Summary screen displays all WAN settings that you have made. Check that the settings are correct before clicking on the Save / Reboot button. Clicking on Save / Reboot saves your settings and restarts your router.

Welcome

- Device Info
 - Summary
 - WAN
- Statistics
 - LAN
 - WAN
 - ATM
 - ADSL
- Route
 - ARP
- Quick Setup
- Advanced Setup
 - WAN
 - LAN
 - NAT
 - Firewall
 - Port Mapping
 - Quality of Service
 - Routing
 - DNS
 - DNS Server
 - Dynamic DNS
 - ADSL
- Diagnostics
- Management

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP.

VPI / VCI:	3 / 40
Connection Type:	PPPoA
Service Name:	pppoa_3_40_1
Service Category:	UBR
IP Address:	Automatically Assigned
Service State:	Enabled
NAT:	Enabled
Firewall:	Disabled
IGMP Multicast:	Disabled
Quality Of Service:	Disabled

Click "Save/Reboot" to save these settings and reboot router. Click "Back" to make any modifications.
NOTE: The configuration process takes about 1 minute to complete and your DSL Router will reboot.

Back Save/Reboot

Figure 4-9. WAN Setup - Summary

Advanced Setup

5

WAN

Set up WAN parameters as directed by your ISP.

WAN Setup

Choose Add, Edit, or Remove to configure WAN interfaces.
Choose Finish to apply the changes and reboot the system.

VPI/VCI	Con. ID	Category	Service	Interface	Protocol	IGMP	QoS	State	Remove	Edit	Action
3/40	1	UBR	pppoa_3_40_1	ppp_3_40_1	PPPoA	Disabled	Disabled	Enabled	<input type="checkbox"/>	Edit	Down
3/41	1	UBR	mer_3_41	nas_3_41	MER	Disabled	Disabled	Enabled	<input type="checkbox"/>	Edit	

Add Remove Finish

Figure 5-1. WAN Setup Screen

Add Function – ATM PVC Configuration

If you want to add a new rule for the WAN interface, click on the Add button. The ATM PVC Configuration screen appears. The ATM PVC Configuration screen allows you to configure an ATM PVC identifier (VPI and VCI) and select a service category.




Figure 5-2. ATM PVC Configuration Screen

Verify the following values with your ISP before you change them.

- VPI (Virtual Path Identifier) – The valid range is 0 to 255.
- VCI (Virtual Channel Identifier) – The valid range is 32 to 65535.
- Service Category – Five classes of traffic defined are defined:
 - UBR Without PCR (Unspecified Bit Rate without Peak Cell Rate)
 - UBR With PCR (Unspecified Bit Rate with Peak Cell Rate) – UBR service is suitable for applications that can tolerate variable delays and some cell loss, such as data transfer, messaging, distribution, and retrieval, and remote terminal applications such as telecommuting.
 - CBR (Constant Bit Rate) – Used by applications that require a fixed data rate that is continuously available during the connection time. It is commonly used for uncompressed audio and video information such as videoconferencing, interactive audio (telephony), and audio and video distribution and retrieval.
 - Non-Realtime VBR (Non-Real-time Variable Bit Rate) – Can be used for data transfers that have critical response-time requirements such as airline reservations, banking transactions, and process monitoring.
 - Realtime VBR (Real-time Variable Bit Rate) – Used for time-sensitive applications such as real-time video. Rt-VBR service allows the network more flexibility than CBR.

Connection Type Screen

1. Select the type of network protocol and encapsulation mode over the ATM PVC that your ISP has instructed you to use, then click on Next button.




Figure 5-3. Connection Type Screen

2. Select a connection type and click on Next. In this example, the Bridge Service screen appears.




Figure 5-4. Bridge Service Screen

3. Enter or select the parameters presented for the service type, and click on Next. The WAN Setup - Summary screen appears.

WAN Setup - Summary

1. Make sure that the settings on the WAN Setup - Summary screen match the settings provided by your ISP. If all settings are correct, click on the Save button to save these settings; if not, click on the Back button to make any modifications. If you want to change any item after saving, click on the Edit button to make any modifications.

WAN Setup - Summary

Make sure that the settings below match the settings provided by your ISP.

VPI / VCI:	0 / 35
Connection Type:	Bridge
Service Name:	br_0_35
Service Category:	UBR
IP Address:	Not Applicable
Service State:	Enabled
NAT:	Disabled
Firewall:	Disabled
IGMP Multicast:	Not Applicable
Quality Of Service:	Disabled

Click "Save" to save these settings. Click "Back" to make any modifications.
NOTE: You need to reboot to activate this WAN interface and further configure services over this interface.

Back Save

Figure 5-5. WAN Setup Summary

2. Activate this WAN interface by clicking on the Finish button and further configuring services over this interface. The router supports up to five WAN connections.

Remove Function

If you want to delete a connection from the listed WAN setup, click in the Remove check box next to the item, then click on the Remove button.

WAN Setup

Choose Add, Edit, or Remove to configure WAN interfaces.
Choose Finish to apply the changes and reboot the system.

VPI/VCI	Con. ID	Category	Service	Interface	Protocol	IGMP	QoS	State	Remove	Edit	Action
0/35	1	UBR	br_0_35	nas_0_35	Bridge	N/A	Disabled	Enabled	<input type="checkbox"/>	Edit	

Add Remove Finish

Figure 5-6. WAN Setup List

Finish Function

After you change any item in WAN Setup, remember to click on the Finish button to apply the changes and reboot the system.

Local Area Network (LAN) Setup

You can configure the DSL Router IP address and Subnet Mask for the LAN interface to conform your LAN's IP Subnet. If you want the DHCP server to automatically assign IP addresses, then enable the DHCP server and enter the range of IP addresses that the DHCP server can assign to your computers. Disable the DHCP server if you would like to manually assign IP addresses.

The Save button only saves the LAN configuration data. The Save/Reboot button saves the LAN configuration data and reboots the router to make the new configuration effective.

Local Area Network (LAN) Setup

Configure the DSL Router IP Address and Subnet Mask for LAN interface. Save button only saves the LAN configuration data. Save/Reboot button saves the LAN configuration data and reboots the router to make the new configuration effective.

IP Address:

Subnet Mask:

Disable DHCP Server
 Enable DHCP Server

Start IP Address:

End IP Address:

Leased Time (hour):

Configure the second IP Address and Subnet Mask for LAN interface

Save Save/Reboot

Figure 5-7. LAN Setup

NAT

You can configure the Virtual Server, Port Triggering, and DMZ Host when NAT is enabled.

Virtual Servers

A virtual server allows you to direct incoming traffic from the WAN side to a specific IP address on the LAN side. Click on the Add button to add a virtual server.




Figure 5-8. NAT Virtual Server Setup

You can select a Service or make new one. Enter the Server IP Address, then click on Save/Apply to submit your configuration.




Figure 5-9. Virtual Server Add Screen

On this screen you can view and delete servers. Click in the check box under Remove and click on the Remove button to delete selected virtual servers.

Server Name	External Port Start	External Port End	Protocol	Internal Port Start	Internal Port End	Server IP Address	Remove
Age of Empires	47624	47624	TCP	47624	47624	192.168.1.10	<input checked="" type="checkbox"/>
Age of Empires	6073	6073	TCP	6073	6073	192.168.1.10	<input checked="" type="checkbox"/>
Age of Empires	2300	2400	TCP	2300	2400	192.168.1.10	<input type="checkbox"/>
Age of Empires	2300	2400	UDP	2300	2400	192.168.1.10	<input type="checkbox"/>

Figure 5-10. Removing Selected Virtual Servers

Port Triggering

Click the on the Add button to add Port Triggering for your Internet application.

Application	Trigger		Open		Remove	
	Name	Protocol	Port Range	Protocol		Port Range
			Start	End	Start	End

Figure 5-11. Port Triggering Setup Page

You can select an application every time or create new one for your application. Then click on Save/Apply to save your settings.




Figure 5-12. Port Triggering Add Page

On this screen you can view and delete applications. Click in the check box under Remove and click on the Remove button to delete selected applications.




Figure 5-13. Port Triggering List

DMZ Host

You can define the IP address of the DMZ Host on this screen. Enter the IP address and click on Save/Apply.




Figure 5-14. DMZ Host Setup

Firewall

For security reasons, firewall options can be configured only from the LAN side of the router.

IP Filtering – Outgoing

The outgoing filter will block the traffic from the LAN side to the WAN side. Click on Add to create filters.



Figure 5-15. IP Filtering – Outgoing Filter Setup

Input the filter name, source information (from the LAN side), and Destination information (from the WAN side). Then click on Save/Apply.




Figure 5-16. IP Filtering - Outgoing Filter Add Page

You can view and delete the outgoing filter settings on this screen.




Figure 5-17. IP Filtering - Outgoing Filter Setup List

IP Filtering – Incoming

Incoming filter filters the traffic from the WAN side to the LAN side. Click on Add to add incoming filter settings.




Figure 5-18. IP Filtering – Incoming Filter Setup Page

Enter a filter name, information about the source address (from the WAN side), and information about the destination address (to the LAN side). Select the protocol and WAN interface. Then click on Save/Apply to add the setting.




Figure 5-19. IP Filtering - Incoming Filter Add

You can view and delete the incoming filter settings from this screen.




Figure 5-20. IP Filtering - Incoming Filtering List

Firewall – MAC Filtering

MAC filtering can forward or block traffic by MAC address. You can change the policy or add settings to the MAC filtering table using the MAC Filtering Setup screen.




Figure 5-21. IP Filtering - MAC Filtering Setup

If you click on Change Policy, a confirmation dialog lets you verify your change.




Figure 5-22. IP Filtering - MAC Filtering Policy Change Confirmation

If you want to add a setting to the MAC filtering table, enter the Source and Destination MAC address, and select protocol type, frame direction, and WAN interface. Then click on Save/Apply to save it.

Add MAC Filter

Create a filter to identify the MAC layer frames by specifying at least one condition below. If multiple conditions are specified, all of them take effect. Click "Apply" to save and activate the filter.

Protocol Type:

Destination MAC Address:

Source MAC Address:

Frame Direction:

WAN Interfaces (Configured in Bridge mode only)

Select All

br_0_35/has_0_35

Figure 5-23. IP Filtering - MAC Filtering Add Page

On this screen you can view and delete MAC filtering rules.

MAC Filtering Setup

MAC Filtering Global Policy: **FORWARDED**

MAC Filtering is only effective on ATM PVCs configured in Bridge mode. **FORWARDED** means that all MAC layer frames will be **FORWARDED** except those matching with any of the specified rules in the following table. **BLOCKED** means that all MAC layer frames will be **BLOCKED** except those matching with any of the specified rules in the following table.

Choose Add or Remove to configure MAC filtering rules.

VPI/VCI	Protocol	Destination MAC	Source MAC	Frame Direction	Remove
ALL	IPv4	00:11:22:33:44:55	00:55:44:33:22:11	LAN<=>WAN	<input type="checkbox"/>

Figure 5-24. IP Filtering - MAC Filtering List

Parental Control

Use the Parental Control feature to restrict the days and times a particular device is allowed to access the Internet.




Figure 5-25. Parental Control Screen

To set up parental controls:

1. Click on Add. The Time of Day Restriction screen appears.




Figure 5-26. Parental Control – Time of Day Restrictions

2. Enter a User Name to identify the target of the restrictions.
3. Enter the MAC address of the network adapter to be restricted, and, optionally, another MAC address.
4. Select the days of the week the restriction is in force.
5. Specify the start and end times the restriction is in force. Use the form hh:mm, where 23:59, for example, is one minute before midnight.
6. Click on Save/Apply.

Port Mapping

Use the Port Mapping screen to map multiple ports to a PVC and create bridging groups. Each group will perform as an independent network.




Figure 5-27. Port Mapping

To create a new mapping group:

1. Click on Add. The Port Mapping Configuration screen appears.




Figure 5-28. Creating a Port Mapping Entry

2. Enter a unique Group name.
3. Select interfaces from the available interface list and add them to the grouped interface list using the arrow buttons to create the required mapping of the ports.
4. Click on Save/Apply.

Quality of Service

You can configure the Quality of Service to apply different priorities to traffic on the router.




Figure 5-29. Quality of Service Setup

Click on Add and the Add Network Traffic Class Rule screen appears. To add a rule:

1. Give a name to this traffic class.
2. Assign a priority level-low, medium, and high-to this traffic class.
3. Select an IP precedence from the range of 0–7.
4. Enter an IP Type of Service from the following selections-
 - Normal Service
 - Minimize Cost
 - Maximize Reliability
 - Maximize Throughput
 - Minimize Delay
5. Last, enter the traffic conditions for the class such as the protocol (TCP / UDP, TCP, UDP, or ICMP) to be used.
6. Click on Save / Apply to save the settings.

Add Network Traffic Class Rule

The screen creates a traffic class rule to classify the upstream traffic, assign queuing priority and optionally overwrite the IP header TOS byte. A rule consists of a class name and at least one condition below. All of the specified conditions in this classification rule must be satisfied for the rule to take effect. Click 'Save/Apply' to save and activate the rule.

Traffic Class Name:

Assign Priority and/or IP Precedence and/or Type Of Service for the class
If non-blank value is selected for 'IP Precedence' and/or 'IP Type Of Service', the corresponding TOS byte in the IP header of the upstream packet will be overwritten by the selected value.

Priority:

IP Precedence:

IP Type Of Service:

Specify Traffic Conditions for the class
Enter the following conditions either for IP layer or for the IEEE 802.1p priority.

Protocol:

Source IP Address:

Source Subnet Mask:

Source Port (port or port:port):

Destination IP Address:

Destination Subnet Mask:

Destination Port (port or port:port):

802.1p Priority:

Figure 5-30. Quality of Service Add Screen

Routing – Default Gateway

You can change the Default Gateway on the Routing - Default Gateway screen. By default the Enable Automatic Assigned Default Gateway box is checked.

Routing -- Default Gateway

If Enable Automatic Assigned Default Gateway checkbox is selected, this router will accept the first received default gateway assignment from one of the PPPoA, PPPoE or MER/DHCP enabled PVC(s). If the checkbox is not selected, enter the static default gateway AND/OR a WAN interface. Click 'Save/Apply' button to save it.

NOTE: If changing the Automatic Assigned Default Gateway from unselected to selected, You must reboot the router to get the automatic assigned default gateway.

Enable Automatic Assigned Default Gateway

Figure 5-31. Default Gateway Setup

If you want to specify the default gateway address, then uncheck the box as seen below. Enter the default gateway address and, optionally, the WAN interface you will use. Click on Save / Apply to save the settings.

If you add or change the default gateway address, you must reboot the router to put the new default gateway IP address into effect.




Figure 5-32. Default Gateway Setup

Routing – Static Route

Use the Routing - Static Route screen to add a static route to the routing table.



Figure 5-33. Static Route Setup

Enter the route information and click on Save/Apply to make it active. No reboot is required.

Routing -- Static Route Add

Enter the destination network address, subnet mask, gateway AND/OR available WAN interface then click "Save/Apply" to add the entry to the routing table.

Destination Network Address:

Subnet Mask:

Use Gateway IP Address

Use Interface

Figure 5-34. Static Route Add

Routing – RIP

If RIP is enabled, the router operation can be configured as Active or Passive.

Routing -- RIP Configuration

To activate RIP for the device, select the 'Enabled' radio button for Global RIP Mode. To configure an individual interface, select the desired RIP version and operation, followed by placing a check in the 'Enabled' checkbox for the interface. Click the 'Apply' button to save the configuration, and to start or stop RIP based on the Global RIP mode selected.

Global RIP Mode Disabled Enabled

Interface	VPI/VCI	Version	Operation	Enabled
br0	(LAN)	2	Active	<input type="checkbox"/>
ppp_3_40_1	3/40	2	Passive	<input type="checkbox"/>
nas_3_41	3/41	2	Passive	<input type="checkbox"/>

Figure 5-35. RIP Setup

DNS Server

Use the DNS Server screen to request automatic assignment of a DNS or to specify a primary and secondary DNS.




Figure 5-36. DNS Setup

Dynamic DNS

Use the Dynamic DNS screen to alias a dynamic IP address to a static hostname, allowing your router to be easily accessed from anywhere on the Internet.




Figure 5-37. Dynamic DNS

To set up a Dynamic DNS entry:

1. Click on Add. The Add Dynamic DNS screen appears.

Figure 5-38. Adding a Dynamic DNS Entry

2. Select a D-DNS Provider from the drop-down list.
3. Enter the Hostname you have selected for the interface.
4. Select the router Interface from the drop-down list.
5. Enter the information you used to register with the dynamic DNS service: for DynDNS, enter your Username and Password; for TOZ, enter your E-mail address and Key.
6. Click on Save/Apply.

ADSL

There are three major items in the ADSL settings.

Figure 5-39. DSL Settings

Modulation Methods

The following modulation methods are supported by the 6212 ADSL router:

- G.dmt Enabled
- G.lite Enabled
- T1.413 Enabled
- ADSL Enabled
- Annex L Enabled
- ADSL2+ Enabled.

Do not change this setting unless so directed by your ISP.

Phone Line Pair

The 6212 ADSL router supports phone lines on pins 2 and 3 or pins 1 and 4 to connect your ADSL line. If your phone system uses pins 2 and 3, attach a normal RJ11 cable to the router and select "Inner pair" on the screen; if your phone system uses pins 1 and 4, attach the phone with the supplied RJ11 cable and select "Outer pair" on the screen.

Capability

The following are included under Capability:

- Bitswap Enable
- SRA (Seamless Rate Adaptation) Enable

Do not change these settings unless so directed by your ISP.

DSL Advanced Settings

Do not change the DSL Advanced Settings unless so directed by your ISP. To view the DSL Advanced Settings screen, click on the Advanced Settings button on the DSL Settings screen (see [Figure 5-39](#)).

There are five test modes between the router and your ISP:

- Normal test: Puts the router in a test mode in which it only sends a Normal signal.
- Reverb test: Puts the router in a test mode in which it only sends a Reverb signal.
- Medley test: Puts the router in a test mode in which it only sends a Medley signal.
- No Retrain: In this mode the router will try to establish a connection as in normal mode, but once the connection is up it will not retrain if the signal is lost.
- L3: Puts the router into the L3 power state.

Select a test mode and click on Apply. Then click on Tone Selection.




Figure 5-40. DSL Advanced Settings

Tone Selection

To view the ADSL Tone Settings screen, click on the Tone Selection button of the DSL Advanced Settings screen (see [Figure 5-40](#)).

The frequency band of ADSL is split up into 256 separate tones, each spaced 4.3125 kHz apart. With each tone carrying separate data, the technique operates as if 256 separate modems were running in parallel. The tone range is from 0 to 31 for upstream and from 32 to 255 for downstream.

Do not change these settings unless so directed by your ISP.




Figure 5-41. Tone Settings

Diagnostics

6

Testing the DSL Connection

The diagnostics screen allows you to run diagnostic tests to check your DSL connection. The screen shows test results for three connections:

- Connection to your local network
- Connection to your DSL service provider
- Connection to your Internet service provider

Use the Test and Test with OAM F4 buttons to retest if necessary.

The screenshot shows a web interface for diagnostics. On the left is a navigation tree with 'Diagnostics' highlighted. The main content area is titled 'pppoa_3_40_1 Diagnostics' and contains the following text and tables:

Your modem is capable of testing your DSL connection. The individual tests are listed below. If a test displays a fail status, click "Rerun Diagnostic Tests" at the bottom of this page to make sure the fail status is consistent. If the test continues to fail, click "Help" and follow the troubleshooting procedures.

Test the connection to your local network

Test your Ethernet Connection:	PASS	Help
--------------------------------	------	----------------------

Test the connection to your DSL service provider

Test ADSL Synchronization:	PASS	Help
Test ATM OAM F5 segment ping:	PASS	Help
Test ATM OAM F5 end-to-end ping:	PASS	Help

Test the connection to your Internet service provider

Test PPP server session:	PASS	Help
Test authentication with ISP:	PASS	Help
Test the assigned IP address:	PASS	Help
Ping default gateway:	PASS	Help
Ping primary Domain Name Server:	PASS	Help

At the bottom right, there are three buttons: 'Test', 'Test With OAM F4', and 'Next Connection'.

Figure 6-1. Diagnostics

Management

7

Saving and Restoring the Configuration

The configuration of your router can be backed up to a file, and also can be restored from a file. You can also restore the router to its factory default configuration.

Backing Up Configuration Settings

To back up your settings, select Management -> Settings -> Backup Settings.




Figure 7-1. Back Up Settings Screen

Verify that you would like to save the file.




Figure 7-2. Backup Settings Upload Confirmation

Select the location where you want to save the file.




Figure 7-3. Backup Settings File Location

Restoring Configuration Settings

To restore saved settings, select Management -> Settings -> Restore User Settings.




Figure 7-4. Restore User Settings Screen

Select the backup file you want to restore and click on Update Settings.




Figure 7-5. Restore Settings File Location

The router will restore settings and reboot to activate the restored settings.




Figure 7-6. Upload in Progress Screen

Restoring Default Settings

Restore Default will erase all current settings and restore the router to factory default settings.

To restore the router to factory default settings, select Management -> Settings -> Restore Default.




Figure 7-7. Restore Default Settings Screen

Reply OK to the confirmation dialog.




Figure 7-8. Restore Default Confirmation Dialog

The router will restore the default settings and reboot.



Figure 7-9. Restore Default Settings Reboot

System Log

The System Log dialog allows you to view the System Log and configure the System Log options.




Figure 7-10. System Log

View System Log

Click on the "View System Log" button to check the log file.

System Log			
Date/Time	Facility	Severity	Message
Jan 1 00:00:16	syslog	emerg	BCM96345 started: BusyBox v1.00 (2005.06.15-04:26+0000)
Jan 1 00:00:17	kern	crit	kernel: eth0 Link UP.
Jan 1 00:00:24	kern	crit	kernel: ADSL G.994 training
Jan 1 00:00:29	kern	crit	kernel: ADSL G.992 started
Jan 1 00:00:31	kern	crit	kernel: ADSL G.992 channel analysis
Jan 1 00:00:36	kern	crit	kernel: ADSL link up, fast, us=800, ds=8000
Jan 1 00:00:39	kern	crit	pppd[285]: PPP LCP UP.
Jan 1 00:00:40	kern	crit	pppd[285]: Received valid IP address from server. Connection UP.
Jan 1 00:02:49	kern	crit	kernel: OAM loopback response not received on VPI/VCI 3/41.
Jan 1 00:02:50	kern	crit	kernel: OAM loopback response not received on VPI/VCI 3/41.
Jan 1 00:03:01	kern	crit	kernel: OAM loopback response not received on VPI/VCI 3/3.
Jan 1 00:03:03	kern	crit	kernel: OAM loopback response not received on VPI/VCI 3/4.

Figure 7-11. View System Log

Configure System Log

If the log is enabled, the system will log selected events: Emergency, Alert, Critical, Error, Warning, Notice, Informational, and Debugging. All events above or equal to the selected log levels will be logged (maintained in the system log file) and displayed.

If the selected mode is Remote or Both, events will be sent to the specified IP address and UDP port of a remote system log server. If the selected mode is Local or Both, events will be recorded in the local memory.




Figure 7-12. System Log Configuration

Select the desired values and click on the "Save/Apply" button to configure the system log options.

SNMP

Simple Network Management Protocol (SNMP) allows a management application to retrieve statistics and status from the SNMP agent in the router. Use the SNMP screen to set up parameters for SNMP access.

The screenshot shows a web-based configuration interface for a router. On the left is a navigation tree with categories like Welcome, Device Info, Quick Setup, Advanced Setup, Wireless, Diagnostics, Management, and Settings. The 'SNMP' option under 'Management' is highlighted. The main content area is titled 'SNMP - Configuration' and contains the following text and form elements:

SNMP - Configuration

Simple Network Management Protocol (SNMP) allows a management application to retrieve statistics and status from the SNMP agent in this device.

Select the desired values and click "Apply" to configure the SNMP options.

SNMP Agent: Disable Enable

Read Community:

Set Community:

System Name:

System Location:

System Contact:

Trap Manager IP:

Save/Apply

Figure 7-13. SNMP Screen


Select the desired values and click on Save/Apply to configure the SNMP options.

Internet Time

Use the Internet Time screen to specify whether the router uses Simple Network Time Protocol (SNTP) to obtain the time of day from NTP servers on the Internet.

To set up the router to obtain time from an NTP server:

1. Select "Automatically synchronize with Internet time servers". The SNTP fields appear.



The screenshot shows the 'Internet Time' configuration page. On the left is a navigation tree with 'Internet Time' selected. The main content area is titled 'Time settings' and includes a description: 'This page allows you to the modem's time configuration.' There is a checked checkbox for 'Automatically synchronize with Internet time servers'. Below this are two NTP server fields: 'First NTP time server' with a dropdown menu showing 'clock.fmt.he.net' and an empty text field; 'Second NTP time server' with a dropdown menu showing 'None' and an empty text field. A 'Time zone offset' dropdown menu is set to '(GMT-12:00) International Date Line West'. A 'Save/Apply' button is located at the bottom right.

Figure 7-14. Internet Time Screen

2. Select NTP servers.
3. Specify the time zone offset for your router's location.
4. Click on Save/Apply.

Access Control – Services

You can enable or disable some services of your router by LAN or WAN. If no WAN connection is defined, only the LAN side can be configured.



Figure 7-15. Services Setup

Access Control – IP Addresses

Web access to the router can be limited when Access Control Mode is enabled. The IP addresses of allowed hosts can be added using Access Control -> IP Address.




Figure 7-16. IP Address Setup

To assign the IP address of the management station that is permitted to access the local management services, enter the IP address in the box and click on the Save/Apply button.




Figure 7-17. Access Control – IP Address Add Screen

Access Control – Passwords

Use Access Control -> Passwords to change a password. Select an account and enter the current password and the new password. Then click on Save/Apply.




Figure 7-18. Access Control – Passwords Screen

Update Software

If your ISP releases new software for this router, follow these steps to perform an upgrade.

1. Obtain an updated software image file from your ISP.
2. Enter the path to the image file location or click on the "Browse" button to locate the image file.
3. Click on the Update Software button once to upload the new image file.




Figure 7-19. Update Software

Note

The update process takes about two minutes to complete, and your router will reboot automatically.

Reboot Router

Select Management -> Reboot Router to reboot the router using the web interface. The router will save the current configuration and reboot itself using the new configuration. The rebooting process takes about two minutes to complete.



Figure 7-20. Reboot Router Screen

Specifications



Specifications are subject to change without notice.

Table A-1. 6212-I1 Specifications

Specification	Criteria
Environment	Operating Temperature: 32° F to 104° F (0° C to 40° C) Storage Temperature: -4° F to 149° F (-20° C to 65° C) Humidity: 5% to 95%, non-condensing
Interfaces	DSL Line: RJ11 Ethernet: 10/100BaseT, RJ45
Power	100 VAC, 50 Hz 110 VAC, 60 Hz 220 VAC, 50/60 Hz
Protocol Support	ANSI T1.413 (Full Rate ADSL) ITU G.992.1 (DMT) ITU G.992.2 (G.lite) ITU G.992.3 (ADSL2) ITU G.992.5 (ADSL2+) ITU G.994.1 (G.hs) ITU G.997.1
Size	1.2" High x 6.5" Wide x 4.4" Deep (3.0 cm High x 16.5 cm Wide x 11.2 cm Deep)
Weight (Shipping)	1.5 lbs (0.7 kg)

Index

A

- About This Guide, v
- Access Control
 - IP Addresses, 7-11
 - Passwords, 7-12
 - Services, 7-11
- ADSL, 5-21
 - BER Test, 3-5
 - Statistics, 3-4
- Advanced Settings, DSL, 5-23
- Advanced Setup, 5-1
- ARP, 3-6
- ATM
 - PVC Configuration, 5-2
 - Statistics, 3-4

B

- Backing Up Configuration Settings, 7-1
- BER Test, 3-5
- Bridge Service, 5-4
- Bridging groups, 5-15

C

- Cables
 - Installing, 2-2
- Capability, 5-22
- CE Marking, B
- Configuring
 - PC, 2-4
 - System Log, 7-8
- Connecting Hardware, 2-2
- Connection Type, 5-3

D

- Default Gateway, 5-17
- Default IP Address, 2-4
- Definitions, 1-1
- Device Information, 3-1
- Diagnostics, 6-1
- Dimensions, A-1
- DMZ Host, 5-9
- DNS, 5-20
 - Dynamic, 5-20

Document

- Feedback, A
- Purpose and Intended Audience, v
- Summary, v
- Domain Name Server, 5-20
- Dynamic DNS, 5-20

E

- EMI Notice
 - Canada, D
 - Japan, D
- Environment, A-1
- Ethernet
 - cable, 2-2

F

- FCC Part 15 Declaration, B
- Features, 1-1
- Firewall, 5-9
 - MAC Filtering, 5-12
- Firmware Update, 7-13
- Front Panel, 1-3

G

- Gateway, Default, 5-17

H

- Hardware
 - Connections, 2-2
 - Installation, 2-1

I

- Important Safety Instructions, B
- Installing
 - Hardware, 2-2
- Interfaces, A-1
- Internet
 - Restricting access, 5-14
- Internet Time, 7-10
- Introduction, 1-1
- IP Address
 - Access Control, 7-11
 - Of Router, 2-4

IP Filtering

- Incoming, 5-11
- Outgoing, 5-9

J

Japan Notices, D

L

LAN

- ports, connecting, 2-2

Local Area Network (LAN)

- Setup, 5-5
- Statistics, 3-3

Logging In, 3-1

M

MAC Filtering, 5-12

Management, 7-1

Mapping ports, 5-15

Modulation Methods, 5-22

N

NAT, 5-6

Network Interface Card, 2-2

Notice

- to Users of the Canadian Telephone Network, D
- to Users of the United States Telephone Network, C

O

Operating Environment, A-1

P

Parental Control, 5-14

Parts List, 1-2

Password

- Access Control, 7-12
- Default, 2-10

PC Setup, 2-1

Phone Line Pair, 5-22

Port Mapping, 5-15

Port Triggering, 5-7

Power

- Specifications, A-1
- Supply, 2-2

Product-Related Documents, vi

Protocols Supported, A-1

PVC

- Adding, 5-2
- Configuring, 5-2
- Detecting, 4-1

Q

Quality of Service, 5-4, 5-16

Quick Setup, 4-1

R

Rear Panel, 1-4

Reboot Router, 7-14

Restoring

- Configuration Settings, 7-3
- Default Settings, 7-5

Restricting access to Internet, 5-14

RIP, 5-19

Route status, 3-6

Routing

- Default Gateway, 5-17
- RIP, 5-19
- Static Route, 5-18

S

Sales, Service, and Training Information, A

Saving and Restoring Configuration, 7-1

Services

- Access Control, 7-11

Shipping Weight, A-1

Size, A-1

SNTP, 7-10

Specifications, A-1

Static Route, 5-18

Statistics

- ADSL, 3-4
- ATM, 3-4
- LAN, 3-3
- WAN, 3-3

Status

- ARP, 3-6
- Route, 3-6
- Summary, 3-1
- WAN, 3-2

System Log, 7-6

- Configuring, 7-8

System Requirements, 1-1

T

Test

- BER, 3-5
- DSL Connection, 6-1

Time, 7-10

Tone Selection, 5-24

Trademarks, A

U

Update Software, 7-13
User Name, Default, 2-10

V

View System Log, 7-7
Virtual Servers, 5-6

W

WAN, 3-2, 5-1
 Setup, 5-4
 Statistics, 3-3
 Status, 3-2

Warranty, A
Web Interface
 Home Page, 2-11
 Using, 3-1
Weight, A-1
Windows 2000, 2-7
Windows 95, 2-8
Windows 98, 2-8
Windows ME, 2-7
Windows NT, 2-9
Windows XP, 2-5

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>