

Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course!

Shop online at www.omega.com

TEMPERATURE

- ✓ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ✓ Wire: Thermocouple, RTD & Thermistor
- ✓ Calibrators & Ice Point References
- ✓ Recorders, Controllers & Process Monitors
- ✓ Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- ✓ Transducers & Strain Gages
- ✓ Load Cells & Pressure Gages
- ✓ Displacement Transducers
- ✓ Instrumentation & Accessories

FLOW/LEVEL

- ✓ Rotameters, Gas Mass Flowmeters & Flow Computers
- ✓ Air Velocity Indicators
- ✓ Turbine/Paddlewheel Systems
- ✓ Totalizers & Batch Controllers

pH/CONDUCTIVITY

- ✓ pH Electrodes, Testers & Accessories
- ✓ Benchtop/Laboratory Meters
- ✓ Controllers, Calibrators, Simulators & Pumps
- ✓ Industrial pH & Conductivity Equipment

DATA ACQUISITION

- ✓ Data Acquisition & Engineering Software
- ✓ Communications-Based Acquisition Systems
- ✓ Plug-in Cards for Apple, IBM & Compatibles
- ✓ Datalogging Systems
- ✓ Recorders, Printers & Plotters

HEATERS

- ✓ Heating Cable
- ✓ Cartridge & Strip Heaters
- ✓ Immersion & Band Heaters
- ✓ Flexible Heaters
- ✓ Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- ✓ Metering & Control Instrumentation
- ✓ Refractometers
- ✓ Pumps & Tubing
- ✓ Air, Soil & Water Monitors
- ✓ Industrial Water & Wastewater Treatment
- ✓ pH, Conductivity & Dissolved Oxygen Instruments



User's Guide



Shop online at

omega.com

Ω OMEGA®

www.omega.com

e-mail: info@omega.com



HHT21A Laser Tachometer

M3942/0303



OMEGAnet® Online Service
www.omega.com

Internet e-mail
info@omega.com

Servicing North America:

USA:
ISO 9001 Certified

One Omega Drive, P.O. Box 4047
Stamford CT 06907-0047
TEL: (203) 359-1660 FAX: (203) 359-7700
e-mail: info@omega.com

Canada:

976 Bergar
Laval (Quebec) H7L 5A1, Canada
TEL: (514) 856-6928 FAX: (514) 856-6886
e-mail: info@omega.ca

For immediate technical or application assistance:

USA and Canada:

Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®
Customer Service: 1-800-622-2378 / 1-800-622-BEST®
Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®
TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA

Mexico:

En Español: (001) 203-359-7803 e-mail: espanol@omega.com
FAX: (001) 203-359-7807 info@omega.com.mx

Servicing Europe:

Benelux:

Postbus 8034, 1180 LA Amstelveen, The Netherlands
TEL: +31 (0)20 3472121 FAX: +31 (0)20 6434643
Toll Free in Benelux: 0800 0993344
e-mail: sales@omeganga.nl

Czech Republic:

Frystatska 184/46, 733 01 Karviná, Czech Republic
TEL: +420 (0)59 6311899 FAX: +420 (0)59 6311114
Toll Free: 0800-1-66342 e-mail: info@omegashop.cz

France:

11, rue Jacques Cartier, 78280 Guyancourt, France
TEL: +33 (0)1 61 37 29 00 FAX: +33 (0)1 30 57 54 27
Toll Free in France: 0800 466 342
e-mail: sales@omega.fr

Germany/Austria:

Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
TEL: +49 (0)7056 9398-0 FAX: +49 (0)7056 9398-29
Toll Free in Germany: 0800 639 7678
e-mail: info@omega.de

United Kingdom:

ISO 9002 Certified

One Omega Drive, River Bend Technology Centre
Northbank, Irlam, Manchester
M44 5BD United Kingdom
TEL: +44 (0)161 777 6611 FAX: +44 (0)161 777 6622
Toll Free in United Kingdom: 0800-488-488
e-mail: sales@omega.co.uk

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, human applications.



WARRANTY/DISCLAIMER

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE. AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS/INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR NON-WARRANTY REPAIRS, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2003 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.



Safeguards and Precautions



1. Read and follow all instructions in this manual carefully, and retain this manual for future reference.
2. Do not use this instrument in any manner inconsistent with these operating instructions or under any conditions that exceed the environmental specifications stated.
3. Making measurements in close proximity to rotating equipment can be dangerous. Keep all loose clothing and hair away from exposed moving machinery. Properly replace all machinery guards after completing measurement.
4. The socket on the front of the instrument is for use with a remote charger. Only use model R-5 (115 Vac) or R-6 (230 Vac) rechargers to charge the instrument.
5. The HHT21A has a laser beam light source. Do not view the laser beam directly as it could be hazardous to the eyes. Do not point the laser beam into another person's eyes. Do not view the laser beam with telescopic devices.
6. With exception of replacing the batteries, this instrument is not user serviceable. For technical assistance, contact the sales organization from which you purchased the product.




TABLE OF CONTENTS

SPECIFICATIONS	1
OVERVIEW	2
OPERATION	2
USING THE HHT21A WITH A REMOTE OPTICAL SENSOR (HHT20-ROS)	3
CALIBRATION AND SELF-TEST	3
BATTERIES	5
CLEANING	5

of the way. It may also be convenient to keep a spare supply of reflective tape in the free area underneath this cover.

The instrument will provide six to eight hours of continuous operation on a single set of batteries, depending on the type used. The instrument is provided with a built-in charging network, which works in conjunction with the optional NiCad batteries. The optional recharger plugs into the single jack located next to the optical lens at the front end of the instrument. Fourteen to sixteen hours is required for a complete recharge. When the battery voltage in the HHT21A is getting low, the display will blink "LO BAT" to indicate that the batteries need to be replaced.

NOTE: Only use model R-5B (115 Vac) or R-6B (230 Vac) rechargers with NiCad batteries. Do not attempt to charge non-rechargeable batteries.

ALWAYS DISPOSE OF BATTERIES IN A SAFE AND RESPONSIBLE MANNER.

CLEANING

To clean the instrument, wipe with a damp cloth using mild soapy solution.




Figure 1 HHT21A-R
with Optional Remote Sensor (HHT20-ROS)

CALIBRATION AND SELF-TEST

The HHT21A SERIES is a crystal controlled digital instrument that requires no calibration. However, the accuracy of the instrument can be checked at any time by aiming it at an old style fluorescent light and observing 7200 ± 2 RPM. In countries with 50 Hz. power line frequency, the display will read 6000 ± 2 RPM.

NOTE: The Tachometer will not correctly read on energy-efficient fluorescent lights.

BATTERIES


The HHT21A SERIES operates from four 'AA' size batteries which are located under the hinged top of the instrument. To access these batteries, grip the tapered cover at the optical lens end of the instrument and pull up. The cover is hinged at the display end of the instrument and pivots fully out

SPECIFICATIONS

This product is designed for indoor or outdoor use under the following conditions (per IEC1010-1):

Speed Range:	5 RPM to 100,000 RPM
Accuracy:	± 1 RPM or .01% of reading
Resolution:	1 RPM
Display:	6-digit 0.45" high liquid crystal
Display Update:	Twice per second
On-Target Indication:	Target (Bullseye) on lower left of display
Operating Distance:	Range: Up to 10 feet [3.1 m] from leading edge of reflective tape Angle: Up to 45° from perpendicular to leading edge of reflective tape
Power-On Switch:	Pistol grip trigger - may be locked on with latching push-button for longer duration measurements Auto hold of last measurement for 90 seconds Visible laser light source

Optical System:



WARNING:

Do not view the laser beam directly as it could be hazardous to the eyes. Do not point the laser beam into another person's eyes. Do not view the laser beam with telescopic devices.

Time Base:	Crystal controlled
Power Source:	4 "AA" batteries; Recharger socket provided for optional rechargeable batteries
Recharger Input:	Max input 7.8 Vdc @ 50mA
Temperature:	41 °F [5 °C] to 104 °F [40 °C]
Humidity:	Maximum relative humidity 80% for temperature up to 88 °F [31 °C] decreasing linearly to 50% relative humidity at 104 °F [40 °C]

Dimensions (LxWxH): 6.13" x 3.25" x 1.75 " plus 4.75" handle
[155.7 mm x 82.6 mm x 44.5 mm x 120.7 mm]
Weight: 1.25 lbs [0.57 kg]

OVERVIEW

The HHT21A SERIES combines the accuracy and safety of a non-contact optical tachometer with the convenience and ease of operation of a pistol grip instrument. The instrument provides non-contact measurement of rotational speed to an accuracy of .01% of reading. It reads RPM directly to the nearest RPM, and a 'on-target' indicator is provided to verify the instrument is properly aligned on a target and receiving valid information.

OPERATION

The HHT21A measures rotational speed from a single pulse per revolution. This pulse is supplied by marking the rotating shaft with a visible reflective tape target. The HHT21A is equipped with a built-in laser light source providing a bright red beam which is aimed at the reflective tape located on the rotating shaft. The pulse from the reflective tape is received back through a single lens reflex optical system and detected by a photocell inside the instrument. The HHT21A then computes the rotational speed and displays it to a resolution of 1 RPM.

To operate the instrument, simply aim it at the reflective tape while holding it at a distance of 1 inch [25.4 mm] to 10 feet [3.1 m] making sure to observe laser safety precautions. Squeeze the pistol grip trigger, and read the indicated speed. The on-target indicator must be on. The display is updated up to twice per second.

For longer duration measurements, the trigger latch on the side of the pistol grip handle can be depressed after pulling the trigger, and the instrument may be mounted on the 1/4-20 threaded bushing at the base of the handle.

When the trigger is released, the HHT21A will hold the last measurement taken and display it for up 90 seconds.

On very small shafts, the HHT21A will work down to a reflective tape size of approximately 1/8 inch [3.2 mm] square. However, with this small tape size, it would be necessary to operate the instrument very close to the rotating shaft and insure it is held steady. For normal operation, a tape size of approximately 1/2 inch [12.7 mm] square or larger is recommended, and on very large diameter shafts or for very high-speed applications, a larger size piece of tape may be required. It is also recommended that the reflective tape be viewed just slightly off the perpendicular. The HHT21A will operate at angles from 0 to 45 degrees, but best results are obtained by aiming the instrument at the reflective tape at approximately a 10 to 20 degree angle. This insures that only pulses from the reflective tape are received by the instrument and minimizes the problem of interference from a highly polished surface or varying ambient lighting.

USING THE HHT21A-R WITH A REMOTE OPTICAL SENSOR

The HHT21A-R version of the tachometer has a provision for using the optional HHT20-ROS Remote Optical Sensor. In addition to the standard built-in optics of the HHT21A SERIES, a 1/8 inch [3.5 mm] phone jack is provided on the front panel of the Tachometer to accept a remote optical sensor plug. A toggle switch on the optics panel selects internal or remote operation.

For applications requiring the remote optical sensor, move the Remote/Internal switch to the remote position to disable the internal optics of the Tachometer. When the trigger is pulled or latched, the remote optical sensor can be used for measurements. The HHT20-ROS Remote Optical Sensor operates 3 feet [0.9 m] and $\pm 45^\circ$ from the reflective tape.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>