

**DX1000 Series
Digital Video Recorder**

**Installation/
Operation Manual**

C680M-G (7/01)

Pelco • 3500 Pelco Way • Clovis, CA 93612-5699 USA • www.pelco.com
In North America and Canada: Tel (800) 289-9100 • FAX (800) 289-9150
International Customers: Tel +1(559) 292-1981 • FAX +1(559) 348-1120

CONTENTS

Section	Page
IMPORTANT SAFEGUARDS AND WARNINGS	3
DESCRIPTION	3
MODELS	3
FRONT PANEL CONTROLS	4
INSTALLATION	4
PROGRAMMING	6
CAMERA MENU	7
ALL RESOLUTION MENU	10
ALARM OUTPUT MENU	11
TIME MENU	13
PASSWORD MENU	14
HELP	15
OPERATION	16
VIEWING CAMERAS	16
RECORDING	16
MANUAL RECORDING	16
AUTOMATIC SCHEDULED RECORDING	16
AUTOMATIC EVENT RECORDING	16
RECORDING EXAMPLE	17
SAVING VIDEO	17
PLAYBACK	18
START PLAYBACK	18
SEARCH	18
FAST PLAYBACK	18
PAUSE PLAYBACK	18
FRAME-BY-FRAME PLAYBACK	18
CHANGE CAMERA BEING PLAYED BACK	18
STOP PLAYBACK	19
PLAYBACK FOLLOWING TIME CHANGES	19
POWER FAILURE	19
ALARM OPERATION	20
ALARM RELAY OUTPUT OPERATION	20
TROUBLESHOOTING	22
SPECIFICATIONS	22
REGULATORY NOTICES	23
WARRANTY AND RETURN INFORMATION	24

LIST OF ILLUSTRATIONS

Figure	Page
1 DX1000 Series DVR Front Panel	4
2 DX1000 Series DVR Installation	4
3 Menu Tree	6
4 Recording and Playback When Hour Is Set Back	19

LIST OF TABLES

Table	Page
A Video Coaxial Cable Requirements	5
B Maximum Frames per Second	8
C Average Recording Times	17

IMPORTANT SAFEGUARDS AND WARNINGS

Prior to installation and use of this product, the following WARNINGS should be observed.

1. Installation and servicing should only be done by qualified service personnel and conform to all local codes.
2. Unless the unit is specifically marked as a NEMA Type 3, 3R, 3S, 4, 4X, 6 or 6P enclosure, it is designed for indoor use only and it must not be installed where exposed to rain and moisture.
3. The installation method and materials should be capable of supporting four times the weight of the unit.
4. To reduce fire or shock hazard, do not expose the unit to rain or moisture.

The product and/or manual may bear the following marks:



This symbol indicates that dangerous voltage constituting a risk of electric shock is present within this unit.



This symbol indicates that there are important operating and maintenance instructions in the literature accompanying this unit.

CAUTION:

TO REDUCE THE RISK OF ELECTRIC SHOCK
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED
SERVICE PERSONNEL.

AVIS:

RISQUE DE CHOC ELECTRIQUE.
NE PAS OUVRIR.

Please thoroughly familiarize yourself with the information in this manual prior to installation and operation.

DESCRIPTION

The DX1000 Series Digital Video Recorder (DVR) is a compact recorder that can store and play back images from four cameras. The DVR can be placed on a shelf or desktop for easy access to the front panel controls for operation and programming.

Live video from all four cameras can be viewed while recording. Recording can be done continuously or for a scheduled time in a 24-hour period. Each camera has its own alarm input for alarm recording.

Two models, one with a 30 GB hard drive and the second with a 60 GB hard drive, generally allow continuous recording up to two or four weeks respectively under the most common recording conditions. Recording time will vary depending on image size, number of cameras recorded, resolution selection, and record rate.

Recording can be stopped at any time to play back video. Search functions during playback allow frame-by-frame viewing, fast playback, and playback of alarm events.

The DVR uses proprietary compression algorithms to prevent alteration of the video image, as well as password protection to guard against unauthorized or unintentional recording or playback.

MODELS

DX1004-030	Four-channel digital video recorder, 30 GB hard drive, simplex operation (cannot record and play back video at the same time), 80-240 VAC, NTSC/PAL
DX1004-060	Same as the DX1004-030, except has 60 GB hard drive

FRONT PANEL CONTROLS




Figure 1. DX1000 Series DVR Front Panel

INSTALLATION

The following parts are supplied:

- 1 DX1000 Series DVR (refer to Figure 1)
- 1 Induced Voltage Protector (refer to item 4c in Figure 2)
- 1 230 VAC power cord adapter




Figure 2. DX1000 Series DVR Installation

00947

WARNING: Adequate ventilation is required for proper operation of the DVR. Allow two inches of space above the unit and on each side for air circulation.

- ❶ Connect cameras to the CAMERA INPUT connectors (BNC) on the rear of the DVR. Refer to Table A for video coaxial cable distances.
- ❷ Connect a monitor to the MONITOR OUTPUT connector (BNC) on the rear of the DVR. Refer to Table A for video coaxial cable distances.
- ❸ To save data from the DVR, connect a peripheral recording device to the VIDEO PRINTER OUTPUT connector (BNC) on the rear of the DVR. Refer to Table A for video coaxial cable distances.

Table A. Video Coaxial Cable Requirements

Cable Type*	Maximum Distance
RG59/U	750 ft (229 m)
RG6/U	1,000 ft (305 m)
RG11/U	1,500 ft (457 m)

* Minimum cable requirements:
 75 ohms impedance
 All-copper center conductor
 All-copper braided shield with 95% braid coverage

- ❹ Connect alarm inputs and alarm relay output as follows:
 - a. Inputs – Connect wiring (not supplied) to your alarms (not supplied). Two wires are required for each alarm. You can have one alarm for each camera.
 - b. Output – Connect wiring (not supplied) to a 12 VDC light or buzzer (not supplied). Two wires are required.
 - c. Bring the alarm input and output wiring to the back of the DVR and thread the wiring through the Induced Voltage Protector (supplied). Loop the wiring over the voltage protector and thread it through the voltage protector a second time.
 - d. Connect the alarm input wires to the SENSOR connectors.
 - e. Connect the light or buzzer to the ALARM output connectors.
- ❺ Connect the recorder to power.
 - a. Place the NTSC/PAL switch in the proper mode.
 - b. If applicable, connect the 230 VAC adapter to the end of the power cord. Plug in the power cord.
 - c. Turn on the DVR. When the recorder is turned on for the first time, the Help screens will appear on the monitor. To bypass the Help screens, press the Play/Pause button.
- ❻ Turn on the cameras and monitor. The DVR begins recording the cameras.

IMPORTANT– If you have any unused camera inputs, the video appears washed out. The degree of washout depends on how many inputs have no cameras connected to them. If only one camera is connected, the video is completely washed out. When you program the DVR (step 9), you must **turn off any unused camera inputs**. Video will then appear normal.
- ❼ Go to *Time Menu* in the *Programming* section and set the time and date.
- ❽ Initialize the DVR. Refer to the instructions on a separate sheet.

This is a necessary step as the DVR may not operate properly during playback and search operation if there are conflicts in the date and time. Initializing the DVR erases all data on the hard disk drive so that you start with a clean file management system for your recordings.
- ❾ Proceed to the *Programming* section to set up the recording parameters and enter a password (optional).

PROGRAMMING

Programming allows you to configure camera and alarm operation, set the system date and time, and define a password.




Figure 3. Menu Tree

00946


CAMERA MENU

Use this menu to define the following:


- Which cameras the DVR will record
- Whether starting and stopping of recording will be done manually or automatically
- What the record rate (frames per second) will be
- What the recording resolution (low to high) will be
- Whether live video can be viewed in record mode
- Starting and stopping times for scheduled recording

Skip steps 1 and 2 if you are already in the Setup Menu.


1. Press and hold the Function button. The Function Key List appears. Keep holding the Function button.



2. Press and release the 0 button, and then release the Function button. Enter the password if requested. The Setup Menu appears.



3. Use the Search (<</>>) buttons to move around within the menu. Highlight Camera and then press the Play/Pause button to select. The Camera menu appears.



4. If the Preview field shows On, live video from the cameras will appear on the monitor while the DVR is recording or is in recording standby mode (not recording).

If the Preview field shows Off, live video will not be shown.

To change the Preview status, use the Search (<</>>) buttons to highlight Preview, and then press the Play/Pause button to toggle between On and Off.

TIP: You can return to the previous menu at any time by pressing the Stop button.


- The fps (Frame Per Second) field shows the recording rate for all cameras.

To change the fps, use the Search (<</>) buttons to highlight fps, and then use the number keypad to enter the frames per second. The maximum frames per second is determined by the number of cameras being recorded and whether the Preview feature is on or off. Refer to Table B for the maximum frames per second. Refer to Table C in the *Operation* section for recording times.

Table B. Maximum Frames per Second

Cameras	Preview On	Preview Off
1	15	30
2	5	7
3	3	5
4	2	3

- To configure any of the four cameras, use the Search (<</>) buttons to highlight the camera number, and then press the Play/Pause button. The menu for that camera appears.



* Same menu for cameras 2-4.

00424

IMPORTANT NOTE: *If camera inputs are not used, make sure Camera Operation is OFF. Video washout occurs if unused inputs are left on. The degree of washout depends on how many inputs have no cameras connected to them. The most severe case is when all inputs are turned on but only one camera is connected; in this case the video is completely washed out.*

CAMERA OPERATION


- Use the Search (<</>) buttons to highlight Camera Operation, and then press the Play/Pause button to toggle between On or Off. On means the DVR will record video for that channel, and Off means it will not record video, even if a camera is connected.

AUTOMATIC RECORDING

- Use the Search (<</>) buttons to highlight Automatic Recording, and then press the Play/Pause button to toggle between On or Off. On means the DVR will record automatically during the times you will select in the following steps. Off means you will manually turn the recorder on and off.

AUTOMATIC RECORDING TIME CHANGE

- Use the Search (<</>) buttons to highlight Automatic Recording Time Change, and then press the Play/Pause button to select. The Automatic Recording Time Change menu appears.



00426

NOTE: Recording and event recording times should be set for different time periods. For example, you may want to record continuously in the daytime when there is a lot of activity, but record only alarms at night.

10. Use the Search (<</>) buttons to highlight each field in the menu.

Recording Times

The recorder will record continuously between the specified times. Use the number buttons to enter the hour of the starting time and ending time. Enter two digits. Enter the hours in 24-hour format. For example, enter 08 for 8 a.m. and 15 for 3 p.m. For 24-hour recording, enter a start time of 00 and an ending time of 24. For no recording, enter a start time of 24 and an end time of 00.

Event Recording Times

Event recording means the recorder will only record if there are alarms during the specified time period. Use the number buttons to enter the hour of the starting time and ending time. Enter two digits. Enter the hours in 24-hour format. For example, enter 08 for 8 a.m. and 15 for 3 p.m. For 24-hour recording, enter a start time of 00 and an ending time of 24. For no recording, enter a start time of 24 and an end time of 00.

Event Recording Duration

This is the time the recorder will continue recording after the alarm goes away. The time can be set from 0 to 200 seconds.

Recording Bar

At the bottom of the screen is a bar that shows when recording will occur. Red is for continuous recording, blue is for event recording, and white is for no recording. If you overlap the continuous and event recording times, the bar will be red.

Quit

When you finish entering the times, use the Search (<</>) buttons to highlight Quit, and then press the Play/Pause button to select. The Camera Number menu appears.


RESOLUTION

11. In this step the camera's resolution is set. You can set each camera's resolution individually, allowing you to use different resolutions for the different cameras. Or you can set the resolution for all cameras at one time; in this case, the resolution will be the same for all cameras.

To set each camera's resolution individually, follow the steps below.

If you want to use the same resolution for all cameras, skip this step and proceed to step 12 to finish the individual setup of cameras. Then set the resolution for all cameras in the All Resolution menu (next section).

- a. Use the Search (<</>) buttons to highlight Resolution, and then press the Play/Pause button to select. The Resolution menu appears.



- b. Use the Search (<</>) buttons to highlight a resolution, and then press the Play/Pause button. When one resolution is turned On, all others are set to Off.
 - c. Use the Search (<</>) buttons to highlight Quit, and then press the Play/Pause button to select. The Camera Number menu appears.
 - d. Use the Search (<</>) buttons to highlight Quit, and then press the Play/Pause button to select. The Camera menu appears.
12. Repeat steps 6-11 to configure other cameras. When you finish configuring all cameras, press the Stop button as many times as necessary to return to the Setup Menu. Highlight another menu item in the Setup Menu and then press the Play/Pause button to select it, or highlight Exit and then press the Play/Pause button to end the programming session.

ALL RESOLUTION MENU

NOTE: Setting the resolution in this menu will overwrite all camera resolution settings made in the individual camera settings (step 11 of previous section).


NOTE: Higher resolutions require more disk storage space, reducing the recording time; lower resolutions need less disk space, increasing the recording time.

TIP: Pressing the Stop button also returns you to the Setup Menu.


Use this menu to set the resolution for all cameras. If you want to use different resolutions for the cameras, set the resolutions in the Camera menu (previous section).

Skip steps 1 and 2 if you are already in the Setup Menu.


1. Press and hold the Function button. The Function Key List appears. Keep holding the Function button.



2. Press and release the 0 button, and then release the Function button. Enter the password if requested. The Setup Menu appears.



3. Use the Search (<</>) buttons to highlight All Resolution, and then press the Play/Pause button to select. The All Resolution menu appears.



4. Use the Search (<</>) buttons to highlight a resolution, and then press the Play/Pause button. When one resolution is turned On, all others are set Off.
5. Use the Search (<</>) buttons to highlight Quit, and then press the Play/Pause button to select. The Setup Menu appears.
6. Use the Search (<</>) buttons to highlight another menu item in the Setup Menu and then press the Play/Pause button to select it, or highlight Exit and then press the Play/Pause button to end the programming session.

ALARM OUTPUT MENU

NOTE: *The alarm output programming does not affect recording. It only affects the operation of the alarm output relay. For event (alarm) recording, refer to Recording in the Operation section.*

The ALARM output on the rear panel is a single-pole, normally open, latching, dry contact. This output can be used to notify you if there has been an alarm event that might require review. The alarm output can be enabled or disabled (armed/disarmed) manually, or it can be programmed to enable (arm) or disable (disarm) at the same time automatically every day.

If the output is enabled and an alarm input is activated, the output relay will latch closed after a 20-second delay and will remain closed until it is manually disabled. The 20-second delay allows you to enter your premises and disable the alarm output before it is activated.

The alarm output menu is used to set up automatic arming and disarming of the relay at specified times each day. (For manual operation, refer to *Alarm Relay Output Operation* in the *Operation* section.) This feature may be used in conjunction with the event recording capabilities of the DX1000 to notify you that an alarm event was recorded.

Application example:

A company has a rear door that is not to be opened for any reason between 5 p.m. and 7 a.m. During the day, the area around this door is recorded continuously, but to conserve disk space, the area is only recorded at night if the door is opened. The owner does not want to review the video unless the door was opened after hours.


In this case, the alarm output would be programmed to enable at 5 p.m. and disable at 7 a.m. The DX1000 would also be programmed for automatic (continuous) recording from 7 a.m. to 5 p.m. and event recording from 5 p.m. to 7 a.m. (refer to *Camera Menu* in the *Programming* section).

At 5 p.m. continuous recording would cease. If an alarm input is activated, the DVR would immediately begin recording the associated camera. The relay would latch closed after the 20-second delay. When the owner returned in the morning, a light attached to the relay output would be on, indicating that there was an alarm during the night. A search for recorded video starting at 5 p.m. would immediately take you to the first alarm event. All other events could be reviewed in sequence.


To program the relay for automatic arming/disarming:

Skip steps 1 and 2 if you are already in the Setup Menu.


1. Press and hold the Function button. The Function Key List appears. Keep holding the Function button.



2. Press and release the 0 button, and then release the Function button. Enter the password if requested. The Setup Menu appears.



3. Use the Search (<</>) buttons to move around within the menu. Highlight Alarm Output and press the Play/Pause button to select. The Alarm Output menu appears.



00425

4. Use the Search (<</>) buttons to highlight the fields for starting and ending times. When you highlight a field, use the number buttons to enter the time. The starting and ending times refer to the hour. Enter two digits. Enter the hours in 24-hour format. For example, enter 08 for 8 a.m. and 15 for 3 p.m.

At the bottom of the screen is a bar that shows the hours when the alarm output will be enabled. Red means enabled and white means disabled.

5. Use the Search (<</>) buttons to highlight Automatically Enable Alarm Output, and then press the Play/Pause button to toggle between On or Off.
6. When you finish, use the Search (<</>) buttons to highlight Quit, and then press the Play/Pause button to select. The Setup Menu appears.
7. Use the Search (<</>) buttons to highlight another menu item in the Setup Menu and then press the Play/Pause button to select it, or highlight Exit and then press the Play/Pause button to end the programming session.

TIP: Pressing the Stop button also returns you to the Setup Menu.


TIME MENU

The DVR uses the time and date to index video on the hard disk drive so you can find it later. Changing the time can cause the DVR to work improperly when you try to play back video. If you set the hour ahead, this is not a problem. But if you set the hour back, there will be more than one recording at the same time. Therefore, you should refrain from making frequent changes as this will complicate searching by time and date. For more information, refer to *Playback Following Time Changes* in the *Operation* section.


To set the system time and date:

Skip steps 1 and 2 if you are already in the Setup Menu.


1. Press and hold the Function button. The Function Key List appears. Keep holding the Function button.




2. Press and release the 0 button, and then release the Function button. Enter the password if requested. The Setup Menu appears.



3. Use the Search (<</>>) buttons to move around within the menu. Highlight Time and press the Play/Pause button to select. The Time menu appears.



OR



4. There are five fields for entering the date and time. The fields, from left to right, are for the year, month, day, hour, and minute. Use the Search (<</>>) buttons to move between the fields. In each field enter two digits. For numbers below 10, enter a 0 as the first digit. Enter the hour in 24-hour format; for example, 08 is 8 a.m. and 15 is 3 p.m.
5. Use the Search (<</>>) buttons to highlight Daylight Saving Time, and then press the Play/Pause button to toggle between On or Off. If your unit is set for PAL operation, also enter the starting and ending times.
6. Use the Search (<</>>) buttons to highlight Quit, and then press the Play/Pause button to select. The Setup Menu appears.
7. Use the Search (<</>>) buttons to highlight another menu item in the Setup Menu and then press the Play/Pause button to select it, or highlight Exit and then press the Play/Pause button to end the programming session.


TIP: Pressing the Stop button also returns you to the Setup Menu.

PASSWORD MENU


Use this menu to change the password (optional).

Skip steps 1 and 2 if you are already in the Setup Menu.


1. Press and hold the Function button. The Function Key List appears. Keep holding the Function button.




2. Press and release the 0 button, and then release the Function button. Enter the password if requested. The Setup Menu appears.



3. Use the Search (<</>) buttons to move around within the menu. Highlight Password and press the Play/Pause button to select. The Password menu appears.



4. Use the Search (<</>) buttons to highlight User Level Password Protection, and then press the Play/Pause button to toggle between On or Off.



5. Use the Search (<</>) buttons to highlight Password Change, and then press the Play/Pause button to select. The Enter Password screen appears.
6. The DVR ships from the factory with a password of 0000. Enter four numbers for a new password.
7. You will be prompted to verify your password by entering it a second time. If the two passwords agree, "Registered" appears on the screen and then the Password menu reappears. If the passwords do not agree, "Registration Cancelled" appears on the screen and then the Password menu reappears.
8. Use the Search (<</>) buttons to highlight Quit, and then press the Play/Pause button to select. The Setup Menu appears.
9. Use the Search (<</>) buttons to highlight another menu item in the Setup Menu and then press the Play/Pause button to select it, or highlight Exit and then press the Play/Pause button to end the programming session.


TIP: Pressing the Stop button also returns you to the Setup Menu.

HELP


If the Help function is enabled, the Help screens appear on the monitor whenever power is turned on.

Skip steps 1 and 2 if you are already in the Setup Menu.

1. Press and hold the Function button. The Function Key List appears. Keep holding the Function button.



2. Press and release the 0 button, and then release the Function button. Enter the password if requested. The Setup Menu appears.



3. Use the Search (<</>>) buttons to highlight Help, and then press the Play/Pause button to select ON or OFF.

OPERATION

The Record LED on the front panel indicates what the DVR is doing.

Recording:	Red (blinking)
Playback:	Green (steady)
Fast Playback:	Green (blinking)
Alarm Event Recording Enabled:	Yellow (steady)
Stop:	Off

VIEWING CAMERAS

If the Preview feature in the Camera menu is On, you can view live video on the monitor. Video is displayed full-screen only if one camera is turned on. If more than one camera is turned on, video is shown in a quad view.

If the Preview feature in the Camera menu is Off, you cannot view live video on the monitor.

RECORDING

NOTE: *Automatic Recording in the Camera menu must be OFF.*

MANUAL RECORDING

1. Press and hold the Function button. The Function Key list appears. Keep holding the Function button.

FUNCTION KEY LIST	
0 :	Setup
1 :	Camera 1 recording/stop
2 :	Camera 2 recording/stop
3 :	Camera 3 recording/stop
4 :	Camera 4 recording/stop
5 :	All the cameras recording
6 :	All the cameras stop
◀◀ :	Alarm On
▶▶ :	Alarm Off

2. Press buttons 1-6 to start or stop recording. Buttons 1-4 are toggle switches: if a camera is recording, pressing a button will stop recording; if a camera is not recording; pressing a button will start recording.
3. Release the Function button. Cameras set to record will record continuously until you repeat steps 1 and 2 and stop recording.

AUTOMATIC SCHEDULED RECORDING

Scheduled recording allows you to program the DVR to turn on and off at specified times each day. This way you record only when you need to and can conserve hard disk drive space. When the hard disk drive is full, the DVR starts to overwrite the oldest data. Refer to Table C to determine approximately how much data can be stored on the hard disk drive and when you should back up your data.

Refer to *Camera Menu* in the *Programming* section to set the start and stop times for recording.

If you need to stop recording a camera before the programmed end time, you must go back into the programming menus and turn off the automatic recording for that camera.

AUTOMATIC EVENT RECORDING

Event recording allows you to program the DVR to record only when an alarm input is activated. The DVR will record for as long as the alarm input is active. After the alarm goes away, the DVR will continue to record for the programmed time. Event recording allows you to conserve even more hard disk drive space than scheduled recording. When the hard disk drive is full, the DVR starts to overwrite the oldest data. Refer to Table C to determine approximately how much data can be stored on the hard disk drive and when you should back up your data.

Refer to *Camera Menu* in the *Programming* section to set the start and stop times for recording.

If you need to stop recording a camera before the programmed end time, you must go back into the programming menus and turn off the automatic recording for that camera.

NOTE: *Turning off cameras does not save video for those cameras. All that does is provide more disk space to record other cameras. When the hard disk drive is full, the DVR will start overwriting the oldest video recorded.*

RECORDING EXAMPLE

A company has a rear door that is not to be opened for any reason between 5 p.m. and 7 a.m. During the day, the area around this door is recorded continuously (scheduled recording), but to conserve disk space, the area is only recorded at night if the door is opened (event recording).

In this case, the recorder would be programmed for scheduled (continuous) recording from 7 a.m. to 5 p.m. and event recording from 5 p.m. to 7 a.m. (refer to *Camera Menu* in the *Programming* section).

SAVING VIDEO

When the hard disk drive is full, the DVR starts to overwrite the oldest data. Refer to Table C to determine approximately how much data can be stored on the hard disk drive and when you should back up your data. Data should be backed up on a regular basis to ensure that important video is not lost.

NOTE: *Turning off cameras does not save video for those cameras. All that does is provide more disk space to record other cameras. When the hard disk drive is full, the DVR will start overwriting the oldest video recorded.*

To save video:

1. Connect a peripheral recording device, such as a VCR or video printer, to the PHOTO PRINTER connector on the rear of the DVR.
2. Turn on the peripheral recording device. If the DVR is in the record mode, the video also will be recorded on the peripheral device. If the DVR is in the playback mode, the video will be recorded on the peripheral device.

Table C. Average Recording Times

DX1004-030

Resolution	Cameras	Frames/Sec. Per Camera	Days*	Frames/Sec. Per Camera	Days*	Frames/Sec. Per Camera	Days*
Lowest	4	1	22	2	11	3	7
Low	4	1	17	2	9	3	6
Standard	4	1	14	2	7	3	5
High	4	1	11	2	5	3	4
Highest	4	1	9	2	4	3	3

DX1004-060

Resolution	Cameras	Frames/Sec. Per Camera	Days*	Frames/Sec. Per Camera	Days*	Frames/Sec. Per Camera	Days*
Lowest	4	1	43	2	22	3	14
Low	4	1	35	2	17	3	12
Standard	4	1	29	2	14	3	10
High	4	1	22	2	11	3	7
Highest	4	1	17	2	9	3	6

* Based on 24-hour recording

The recording times in Table C depend on the file size for each recorded picture. The file size can vary with the scene, amount of motion, and other factors. The figures in Table C represent the average recording times and do not guarantee recording times in a particular application.


NOTE: *Values indicating video storage capacity are estimates only. These estimates are to be used as guidelines in determining proper hard drive requirements. Many user selectable factors such as image quality, recording rate, image content/motion, and video noise will all affect the total amount of video that can be stored on a hard drive. These video storage duration estimates will vary based on actual use. These estimates are not an implied or expressed guarantee of actual performance.*

PLAYBACK

START PLAYBACK

To begin playback:

1. Press the Play/Pause button.
2. Enter the password if requested.
3. The Play window appears.



PLAY SCREEN

4. Press a number button (1-4) to select the camera to view. The camera channel appears on the screen.
5. Press the Search (>>) button to go to the time and date fields. Select the time and date you want to play back. At the top of the window, the "From" and "to" fields show the time period that is recorded on the hard drive. You may choose the playback time within this period.

At the bottom of the window are five fields for entering the playing time. The fields, from left to right, are for the year, month, day, hour, and minute. Use the Search (<</>>) buttons to move between the fields. In each field enter two digits. For numbers below 10, enter a 0 as the first digit. Enter the hour in 24-hour format; for example, 08 is 8 a.m. and 15 is 3 p.m.

6. Press the Play button. Playback begins. "PLAY" appears on the screen.

SEARCH

To search during playback, use the Search (<</>>) buttons. Press and hold the button for the direction you want to search. As you hold the button, the search increases speed. Release the button when you find the video you want to view.

FAST PLAYBACK

To increase the playback speed, press the Search (>>) button once.

To resume playback at normal speed, press the Pause/Play button once.

PAUSE PLAYBACK

To pause playback:

1. Press the Play/Pause button to pause playback. "Pause" appears on the screen.
2. Press the Play/Pause button again to resume playback.

FRAME-BY-FRAME PLAYBACK

To play back one frame at a time:

1. Press the Play/Pause button to pause playback. "Pause" appears on the screen.
2. Use the Search (>>) buttons to move forward one frame at a time.
2. Press the Play/Pause button again to resume normal playback.

CHANGE CAMERA BEING PLAYED BACK

To view a different camera during playback, press the number button (1-4) of the camera you want to observe. Playback starts at the beginning of the search time selected.

STOP PLAYBACK

To stop playback:

Press the Stop button. Playback stops and recording resumes if the DVR is programmed for automatic recording. Live video appears on the monitor if the Preview feature is turned on.

PLAYBACK FOLLOWING TIME CHANGES

The DVR uses the time and date to index video on the hard disk drive so you can find it later. Changing the time can cause the DVR to work improperly when you try to play back video. If you set the hour ahead, this is not a problem. But if you set the hour back, there will be more than one recording at the same time.

Figure 4 shows what happens when you set the hour back from 2 a.m. to 1 a.m., such as during the October Daylight Saving Time changeover. If you try to search for video between 1 a.m. and 2 a.m., the recorder may not operate properly because there will be two hours of recorded video during this time period. To view video during this overlapping time period, you must start playback before 1 a.m.; then the recorder will play both hours between 1 a.m. and 2 a.m., as shown in Figure 4.

You cannot do a backward search through the overlapping time period. You can, however, do a forward search.




Figure 4. Recording and Playback When Hour Is Set Back

POWER FAILURE

In the event of a power failure, the DVR has battery backup to save the time and date and menu settings. The battery is good for three years.

ALARM OPERATION

When an alarm input on the rear of the DVR is triggered, two things can happen:

- The DVR will start recording.
- The alarm output relay will turn on a light or other device to alert you that there has been an alarm.

Application example:

A company has a rear door that is not to be opened for any reason between 5 p.m. and 7 a.m. During the day, the area around this door is recorded continuously, but the area is only recorded at night if the door is opened. The owner does not want to review the video unless the door was opened after hours.

In this case, the alarm output relay would be programmed to enable at 5 p.m. and disable at 7 a.m. (refer to *Alarm Output Menu* in the *Programming* section). The DX1000 would also be programmed for automatic (continuous) recording from 7 a.m. to 5 p.m. and event (alarm) recording from 5 p.m. to 7 a.m. (refer to *Camera Menu* in the *Programming* section).

At 5 p.m. continuous recording would cease. If an alarm input is activated, the DVR would immediately begin recording the associated camera. The relay would latch closed after the 20-second delay. When the owner returned in the morning, a light attached to the relay output would be on, indicating that there was an alarm during the night. A search for recorded video starting at 5 p.m. would immediately take you to the first alarm event. All other events could be reviewed in sequence.

ALARM RELAY OUTPUT OPERATION

Once the relay is triggered, it remains on until you manually turn it off. You can set the relay to arm itself automatically or you can manually arm the relay.


This relay operates independently of the event (alarm) recording in the camera setup menus. The relay does not start alarm recording. It only operates the device connected to the ALARM connectors on the rear panel.

Arming the Relay

Automatic arming is done in the Alarm Output menu, in which you specify the hours that the relay will operate if there is an alarm.

To manually arm the relay:

1. Press and hold the Function button. The Function Key List appears. Keep holding the Function button.



2. Press and release the Search backward (<<) button, and then release the Function button. A 60-second countdown begins (the numbers appear on the screen) before the relay is armed. This is an exit feature that allows you to leave the area without tripping the alarm. Once the relay is armed, it remains armed until it is triggered or you disarm it.


Relay Operation

When an alarm input is activated, a 20-second countdown begins before the relay turns on the warning light or buzzer. The numbers appear on the screen. This is an entry feature that allows you to disarm the alarm when you enter your own premises.

Once the relay operates, the light or buzzer remains on until you manually turn off the relay.

Turning Off the Relay

1. Press and hold the Function button. The Function Key List appears. Keep holding the Function button.



2. Press and release the Search forward (>>) button, and then release the Function button.

The relay is now turned off.

If you are manually controlling the operation of the relay, another alarm will not activate the relay. To arm the relay again, refer to the procedure in this section under *Arming the Relay*.

If the relay has been programmed to operate in the Alarm Output menu, another alarm will operate the relay as long as it is still within the programmed time period.

TROUBLESHOOTING

Symptom: You cannot stop recording even after pushing the Stop button.

Check the Camera menu for the camera(s) that will not stop recording. Make sure the Automatic Recording feature is turned off.

Symptom: There is no video on the monitor while the DVR is recording or is in recording standby mode (not recording).

Check the Camera menu for the camera(s). Make sure Preview is turned on.

SPECIFICATIONS

ELECTRICAL/VIDEO

Input Voltage:	80-240 VAC, 50/60 Hz
Power Consumption:	20 watts
Signal System:	NTSC or PAL
Video Compression:	MPEG
Resolution:	352 x 240 pixels, true color
Recording Speed:	1-30 fps, depending on system setup
Video Storage	
DX1004-030:	30 GB hard drive
DX1004-060:	60 GB hard drive
Video Inputs:	4
Video Outputs:	2 (1 monitor, 1 video printer)
Alarm Inputs:	4, normally open dry contact
Alarm Output:	1, normally open, latching, Form A

MECHANICAL

Connectors	
Alarm Inputs:	4 pairs, push-in
Alarm Output:	1 pair of relay contacts, push-in
Camera Inputs:	4, BNC
Monitor Output:	1, BNC
Video Printer Output:	1, BNC

GENERAL

Operating Temperature:	41° to 104°F (5° to 40°C)
Relative Humidity:	Maximum 80% non-condensing
Dimensions:	2.8 (H) x 9.1 (W) x 14.6 (D) inches (7 x 23 x 37 cm)
Weight:	7 lb (3.18 kg)

(Design and product specifications subject to change without notice.)

REGULATORY NOTICES

This equipment has been tested and found to comply with the limits of a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try and correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

PRODUCT WARRANTY AND RETURN INFORMATION

WARRANTY

Pelco will repair or replace, without charge, any merchandise proved defective in material or workmanship **for a period of one year** after the date of shipment.

Exceptions to this warranty are as noted below:

- Five years on FT/FR8000 Series fiber optic products.
- Three years on Genex® Series products (multiplexers, server, and keyboard).
- Three years on Camclosure® and fixed camera models, except the CC3701H-2, CC3701H-2X, CC3751H-2, CC3651H-2X, MC3651H-2, and MC3651H-2X camera models, which have a five-year warranty.
- Two years on standard motorized or fixed focal length lenses.
- Two years on Legacy®, CM6700/CM6800/CM9700 Series matrix, and DF5/DF8 Series fixed dome products.
- Two years on Spectra®, Esprit®, ExSite™, and PS20 scanners, including when used in continuous motion applications.
- Two years on Esprit® and WW5700 Series window wiper (excluding wiper blades).
- Eighteen months on DX Series digital video recorders, NVR300 Series network video recorders, and Endura™ Series distributed network-based video products.
- One year (except video heads) on video cassette recorders (VCRs). Video heads will be covered for a period of six months.
- Six months on all pan and tilts, scanners or preset lenses used in continuous motion applications (that is, preset scan, tour and auto scan modes).

Pelco will warrant all replacement parts and repairs for 90 days from the date of Pelco shipment. All goods requiring warranty repair shall be sent freight prepaid to Pelco, Clovis, California. Repairs made necessary by reason of misuse, alteration, normal wear, or accident are not covered under this warranty.

Pelco assumes no risk and shall be subject to no liability for damages or loss resulting from the specific use or application made of the Products. Pelco's liability for any claim, whether based on breach of contract, negligence, infringement of any rights of any party or product liability, relating to the Products shall not exceed the price paid by the Dealer to Pelco for such Products. In no event will Pelco be liable for any special, incidental or consequential damages (including loss of use, loss of profit and claims of third parties) however caused, whether by the negligence of Pelco or otherwise.

The above warranty provides the Dealer with specific legal rights. The Dealer may also have additional rights, which are subject to variation from state to state.

If a warranty repair is required, the Dealer must contact Pelco at (800) 289-9100 or (559) 292-1981 to obtain a Repair Authorization number (RA), and provide the following information:

1. Model and serial number
2. Date of shipment, P.O. number, Sales Order number, or Pelco invoice number
3. Details of the defect or problem

If there is a dispute regarding the warranty of a product which does not fall under the warranty conditions stated above, please include a written explanation with the product when returned.

Method of return shipment shall be the same or equal to the method by which the item was received by Pelco.

RETURNS

In order to expedite parts returned to the factory for repair or credit, please call the factory at (800) 289-9100 or (559) 292-1981 to obtain an authorization number (CA number if returned for credit, and RA number if returned for repair).

All merchandise returned for credit may be subject to a 20% restocking and refurbishing charge.

Goods returned for repair or credit should be clearly identified with the assigned CA or RA number and freight should be prepaid. Ship to the appropriate address below.

If you are located within the continental U.S., Alaska, Hawaii or Puerto Rico, send goods to:

Service Department
Pelco
3500 Pelco Way
Clovis, CA 93612-5699

If you are located outside the continental U.S., Alaska, Hawaii or Puerto Rico and are instructed to return goods to the USA, you may do one of the following:

If the goods are to be sent by a COURIER SERVICE, send the goods to:

Pelco
3500 Pelco Way
Clovis, CA 93612-5699 USA

If the goods are to be sent by a FREIGHT FORWARDER, send the goods to:

Pelco c/o Expeditors
473 Eccles Avenue
South San Francisco, CA 94080 USA
Phone: 650-737-1700
Fax: 650-737-0933

REVISION HISTORY

Manual #	Date	Comments
C680M	12/00	Original version.
C680M-A	01/01	Changed LED designation from "Statues" to "Record." Added All Resolution menu. Removed TEST connector. Added <i>Help</i> section. Revised monitor installation. Changed "Scheduled" in menus to "Automatic."
C680M-B	01/01	Added note to set Camera Operation off if camera inputs are not used.
C680M-C	2/01	Added Attention page; added information about VCR hookup, saving video, playback after time changes, power failure, menu bars for recording times and alarm output times, and initialization/reinitialization; revised installation instructions for induced voltage protector and camera resolution setup; revised <i>Recording</i> and <i>Alarm Operation</i> sections and Function Key List screen.
C680M-D	3/01	Added daylight saving time option; revised Initialization/Reinitialization procedure; revised rear panel.
C680M-E	6/01	Added PAL features. Revised Figure 2. Revised step 10 in <i>Camera Menu</i> section. Added notes to <i>All Resolution Menu</i> and <i>Manual Recording</i> sections. Moved Table C.
C680M-F	7/01	Removed ground terminal in Figure 2. Revised PAL Time menu.
C680M-G	7/01	Revised <i>Important Safeguards and Warnings</i> .

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>