



Directions for Use



Need Help? Call us!

Philips representatives are ready to help you with any questions about your new product. We can guide you through Connections, First-time Setup, or any of the Features. We want you to start enjoying your new product right away!

CALL US BEFORE YOU CONSIDER RETURNING THE PRODUCT.

1-800-464-1131

or

**Visit us on the web at
www.philips.com**

Let's make things better.



PHILIPS

3111 176 51221

PHILIPS

Congratulations on your purchase, and welcome to the "family!"

Dear PHILIPS product owner:

Thank you for your confidence in PHILIPS. You've selected one of the best-built, best-backed products available today. And we'll do everything in our power to keep you happy with your purchase for many years to come.


As a member of the PHILIPS "family," you're entitled to protection by one of the most comprehensive warranties and outstanding service networks in the industry.

What's more, your purchase guarantees you'll receive all the information and special offers for which you qualify, plus easy access to accessories from our convenient home shopping network.

And most importantly you can count on our uncompromising commitment to your total satisfaction.

All of this is our way of saying welcome-and thanks for investing in a PHILIPS product.


Sincerely,


 Lawrence J. Blanford
President and Chief Executive Officer

Know these

safety symbols



 This "bolt of lightning" indicates uninsulated material within your unit may cause an electrical shock. For the safety of everyone in your household, please do not remove product covering.

 The "exclamation point" calls attention to features for which you should read the enclosed literature closely to prevent operating and maintenance problems.

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS EQUIPMENT TO RAIN OR MOISTURE.



PHILIPS

Visit our World Wide Web Site at <http://www.philips.com>

Table of Contents

General Information		Remote Control Setup	
Table of Contents	3	Programming the Universal Remote Control	
Introduction	3	Manual Programming	11
Safety Information	4	Automatic Search	12
Getting Started		Universal Codes	13-15
Package Contents	5	Limited Warranty	16
Connections	6		
Remote Control Set-up	7		
Remote Control Functions			
Satellite Functions	8		
TV Functions	9		
VCR/DVD Functions	10		

Introduction

The RC136/17 is an accessory to the Philips satellite receivers, model DSX5500 and DSX5540. It will provide remote control of the satellite receiver using RF in addition to IR signals, that allows for convenient placement of the equipment without the need for line-of-sight access. Other components, including TV, VCR, and DVD Players, are controlled using line-of-sight infrared only.

The RF receiver can be easily placed on top of the TV set or other convenient locations. Simply affix the IR emitter to the front of the DSX5500 or DSX5540, plug in the AC adapter, and the installation process is complete.


Safety Instructions- Read Before Operating Equipment

WARNING: TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE ANY ELECTRICAL EQUIPMENT TO RAIN OR MOISTURE.


1. **Read Instructions** – All the safety and operating instructions should be read before the appliance is operated.
2. **Retain Instructions** – The safety and operating instructions should be retained for future reference.
3. **Heed Warnings** – All warnings on the appliance and in the operating instructions should be adhered to.
4. **Follow Instructions** – All operating and use instructions should be followed.
5. **Attachments** – Do not use attachments not recommended by the manufacturer as they may cause hazards.
6. **Water and Moisture** – Do not use this product near water – for example, near a bath tub, wash bowl, kitchen sink, or laundry tub, in a wet basement, near a swimming pool, etc.
7. **Accessories** – Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the appliance. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer or sold with the product. Any mounting of the appliance should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.
8. **Power Sources** – This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your appliance dealer or local power company.
9. **Power Cord Protection** – Route power supply cords so that they are not likely to be walked on or pinched by items placed upon or against them. Pay particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.
11. **Overloading** – Do not overload wall outlets and extension cords as this can result in a risk of fire or electric shock.
12. **Object and Liquid Entry** – Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
13. **Servicing** – Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
14. **Damage Requiring Service** – Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:
 - a. When the power supply cord or plug is damaged.
 - b. If liquid has been spilled, or objects have fallen into the product.
 - c. If the product has been exposed to rain or water.
 - d. If the product does not operate normally when following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
 - e. If the product has been dropped or the cabinet has been damaged in any way.
 - f. When the product exhibits a distinct change in performance – this indicates a need for service.
15. **Replacement Parts** – When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or which have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.
16. **Safety Check** – Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
17. **Carts and Stands** – The appliance should be used only with a cart or stand recommended by the manufacturer.
18. **Heat** – The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products that produce heat.

Philips is a registered trademark of Koninklijke Philips Electronics, NV.

Package Contents




User Manual




Infrared (IR)
Universal with RF for
the Satellite Receiver*



IR Emitter



RF Receiver




AC Adapter

*The Remote Control uses 3 AAA batteries (not supplied).


Connections

Example of placement of RF Receiver on the DSX5500/5540 Receiver.



1. Locate the IR sensor on your DSX5500/5540 unit. It is positioned 0.5 inches to the right of the red LED showing when the satellite receiver is powered on. Remove the backing on the IR emitter supplied with the RC136/17, and affix to the bezel in front of the IR sensor as shown in the illustration above.
2. Connect the other end of the IR emitter cable into the IR emitter jack on the RF receiver.
3. Plug the power cord to the RF receiver, and plug the AC adapter into a wall power outlet, as shown in the illustration below.

Note: As long as the IR emitter cable reaches the IR sensor, you are not limited as to where you place the RF receiver.




Note: For instructions on connecting the receiver to your TV or changing the remote control ID, please refer to the Owner's Manual for the DSX5500/5540.

Remote Control Set-Up

Preparing Your Remote Control

Battery Installation

1. Remove the battery compartment cover.
Insert three batteries (type LR6/AAA - 1.5 V) not supplied.
2. Position them in the battery compartment, as shown in the diagram.
3. Replace the cover.



Caution



CAUTION: DO NOT MIX OLD AND NEW BATTERIES, AND NEVER MIX DIFFERENT TYPES OF BATTERIES (STANDARD, ALKALINE, AND SO ON).

In many countries, exhausted batteries may not be disposed of with your household waste. Please dispose of exhausted batteries according to local regulations.

Satellite Functions

SAT
Press SAT to control the DSX5500 Receiver. LED will blink when other buttons are pressed while in satellite mode.

POWER
Switches the DSX5500 receiver between active and standby modes.

MOVIES, SPORTS, NEWS, KIDS
Predefined SmartSurf buttons (refer to the DSX5500 Owner's Manual).

SmartSurf
Displays categories you can use with Guide and channel surfing.

FAVORITES
Allows you to select one of four custom lists to view or edit.

GUIDE
Switches between the "DIRECTV ADVANCED PROGRAM GUIDE" and the "Guide Menu".

OK
Confirms a selection.

CH+ / CH-
Displays the next or previous channel. While in the guide or menu, allows you to page up and down.

DIRECTV INTERACTIVE™
powered by WINK Communications™. Press this button when the DIRECTV INTERACTIVE icon appears on the screen to access interactive services.

PPV
Use the EZ Search PPV function to view list of PPV programs and events for purchasing.

SOURCE
Switches between the inputs of the AV Matrix.

MENU
Displays the Main Menu.

EXIT
Returns to video and cancels the transaction.

INFO
Displays program or channel information.

0-9
Lets you enter numeric values or channels.

BACK
While in menu or guide, returns you to the previous screen. While watching TV, pressing BACK will jump you to the previous channel.

TV Functions

Once programmed, your Universal RF Remote Control should control certain functions of your TV. Be sure to press the TV button before operating your TV.

TV

Press to put the remote control in TV mode. LED will blink when other buttons are pressed while in TV mode.

POWER

Press to turn TV on or off.

VOL +/-

Increases and decreases volume.

CH+ / CH-

Change channel up or down.

MUTE


Switches audio on and off.

0-9

Allows direct number entry for tuning to a channel.

TV INPUT

Switch through TV inputs (if applicable).



Note: Some buttons may not work with your specific brand or products. The remote must be setup to operate your brand or product.

VCR/DVD Functions

Once programmed, your Universal RF Remote Control should control certain functions of your VCR/DVD Player. Be sure to press the VCR or DVD button before operating your TV.

VCR

Press to put the remote control in VCR mode. LED will blink when other buttons are pressed while in VCR mode.

◀ REWIND

VCR - When tape playback is stopped, press to rewind at high speed. During tape playback, press to rewind the tape while the picture stays on the screen.

DVD - Press and release to select previous chapter. Press and hold to scan backwards.

■ STOP

Press to stop the tape or disc.

● RECORD (VCR only)

Press once to start a recording.

0-9

Allows direct number entry for tuning to a channel or chapter.

⏻ POWER

Press to turn VCR or DVD on or off.

DVD

Press to put the remote control in DVD mode. LED will blink when other buttons are pressed while in DVD mode.

▶▶ FAST FORWARD

VCR - When tape playback is stopped, press to advance the tape at high speed. During tape playback, press to advance the tape while the picture stays on the screen.

DVD - Press and release to select next chapter. Press and hold to scan forward.

▶ PLAY


Press to play a tape or disc.

⏸ PAUSE

Press to pause a tape or disc.

CH+ / CH- (VCR only)

Change channel up or down.



Note: Some buttons may not work with your specific brand or products. The remote must be setup to operate your brand or product.

Programming the Universal Remote Control

Manually Setting the Remote to Operate a TV, VCR or DVD Player

Your remote control **may** already operate your TV, VCR, or DVD player. If the remote control does not operate your TV, VCR, or DVD player, follow the steps below. These instructions guide you through setting the remote control to operate your TV. For VCR and DVD player, follow the same steps, but press the VCR or DVD button at step 3.

1. Point the remote control at your TV and press the TV button. Then, press the POWER button. If your TV turns on or off, try the other TV function buttons (see page 9). If the other functions work, the remote is ready to operate the TV without any more steps. If your TV does not turn on or off, or if the other buttons do not work, go to step 2.
2. Find the brand of your TV pages 13-15, and list the 3-digit number here: ___.
3. Press and hold the TV button until LED lights.
4. Press and hold the number 1 and number 3 buttons simultaneously for 3 seconds. The LED will blink twice and remain on.
5. Enter the 3-digit code from step 2 within 60 seconds. The LED will blink after each button press. Note: If the 3-digit code is not entered within one minute, the LED will turn off and the remote control will return to the previously programmed code.
6. After a valid 3-digit code has been entered, the LED will turn off and blink twice to confirm the new 3-digit code has been programmed. The LED will then turn off.
7. If an invalid 3-digit code has been entered, the LED will turn off.
8. Press the POWER button. If the remote control operates your TV, you're finished.
9. If the remote control doesn't operate your TV, repeat steps 2-8. If your TV brand has more than one 3-digit code, try using the next code number.
10. For future reference, list the 3-digit code numbers you programmed into your remote control:
TV code: ___
VCR code: ___
DVD code: ___
11. If you cannot find a code that operates your TV, VCR, or DVD Player, follow the Automatic Search Steps (see page 12).

Note: If the 3-digit code is not entered within 60 seconds, the LED will turn off and the remote control will return to the previously programmed code.

Programming the Universal Remote Control (cont'd)

Automatic Search

To automatically program your remote control to operate your TV, VCR, or DVD Player, follow the steps below. For a VCR or DVD Player, follow the same steps but press the VCR or DVD button at step 1.

1. Turn on your TV. Stand close to your TV (5 to 10 feet) and point your remote control towards the remote sensor on your TV. Press TV button until LED lights. Press and hold the number 1 and the number 3 buttons simultaneously for 3 seconds. The LED will blink twice and remain on.
2. Press the POWER button. The LED will turn off. **Note:** If the Power button is not pressed within one minute, the remote will return to the previously programmed code. The automatic search will begin after the Power button has been released.
3. Each time a code is transmitted, the LED will blink. This process could take several minutes.
4. When the correct code is found, the TV should turn off. Immediately press the POWER button. The LED will blink twice, then turn off. If all codes have been tried and the TV has not turned on or off the LED will stay on briefly, then turn off.

Note: To stop the search process at any time, press any button other than the POWER button. The LED will give a long blink and turn off. There is no guarantee that the remote control will work with your TV, VCR, or DVD player.

Helpful Hint

- If the 3-digit code is not entered within 60 seconds, the LED will turn off and the remote control will return to the previously programmed code.
- If the batteries are left out of the remote for more than two minutes, you may have to reprogram the remote control.

Universal Remote Codes

TV CODES

Admiral ..001, 156, 188	Envision171, 186	LXI ..000, 006, 045, 056,
Aiko015	Fisher004, 006	.065, 066, 067, 146, 163,
Akai002	Fisher044, 045, 046,185
Anam National .003, 036,146, 162	Magnavox .004, 006, 008,
.....172, 173, 174	Fujitsu042	.018, 056, 062, 063, 068,
AOC ..004, 005, 006,	Funai036, 042	.069, 070, 079, 116, 117,
.....007, 158, 159, 175	GE ..000, 003, 004, 006,	.118, 119, 120, 165, 196,
Audiovox036	.020, 047, 048, 049, 078,198
Bell & Howell ..001, 076,	.147, 148, 149, 150, 151,	Majestic076
.....146163, 190	Marantz ..004, 006, 053,
Celebrity002	Goldstar .004, 005, 006,056, 071
Centurion009011, 018, 050, 051,	Memorex .001, 006, 075,
Citizen ..004, 006, 008,	.052, 139, 140, 154, 155076, 146
.....015, 036, 095, 146,	Hallmark004, 006	MGA 004, 005, 006, 018,
.....154, 189	Hitachi ...004, 006, 011,	.020, 046, 072, 073, 075
Colortyme .004, 006, 010	.012, 013, 053, 054, 055,	Mitsubishi .004, 005, 006,
Contec/Cony ..011, 012,	.121, 122, 123, 124, 125,	.018, 020, 046, 072, 073,
.....013, 036	.126, 127, 128, 129, 130,074, 075, 112
Crown036, 056	.131, 132, 134, 161, 177,	Montgomery Ward ..076
Curtis Mathes .000, 004,178	Motorola003, 156
.....006, 014, 095, 146,	Infinity056	MTC .004, 005, 006, 095
.....154, 189	Janeil157	Multitech036
Daewoo ..004, 005, 006,	JBL056	NAD .006, 065, 066, 166
.....015, 016, 017, 113,	JC Penney 000, 004, 005,	NEC .003, 004, 005, 006,
.....154, 176	.006, 008, 020, 047, 048,179
Daytron ..004, 006, 154	.052, 057, 058, 066, 078,	Nikko006, 015
Dimensia000	.095, 114, 154, 155, 163,	Onwa036
Dumont004, 135180	Optimus166
Electroband002	Jensen004, 006	Optonica086, 156
Electrohome .003, 004,	JVC011, 012, 013,	Orion033, 171
.....006, 018, 019, 020	.048, 054, 059, 060, 061,	Panasonic .003, 048, 056,
Emerson004, 006,141, 142, 143, 164153, 191
.011, 021, 022, 023, 024,	Kenwood .004, 006, 018	Philco 003, 004, 005, 006,
.025, 026, 027, 028, 029,	Kloss Novabeam ..036,	.008, 011, 018, 056, 062,
.030, 031, 032, 033, 034,063, 157, 165063, 068, 070, 165
.035, 036, 037, 038, 039,	KTV .036, 064, 154, 160	Philips 003, 004, 008, 011,
.040, 041, 042, 043, 110,	Loewe056	.018, 056, 062, 063, 068,
.111, 146, 154, 160, 161,	Logik076077, 078, 079, 080
	Luxman004, 006	

Universal Remote Codes (cont'd)

TV CODES Cont'd...		
Pioneer .. 004, 006, 081,082, 083, 161, 166	.068, 069, 070, 079, 104,145, 165	Colortyme007
Price Club095	Symphonic ..031, 036, 169	Curtis Mathes .000, 007, .011, 014, 016, 019, 020,022, 110, 124
Prism048	Tandy156	Daewoo ..013, 015, 017, .023, 024, 025, 026, 105
Proscan000, 163	Tatung003	Daytron105
Proton 004, 006, 011, 084	Technics048	Dimensia 000, 124
Quasar .003, 048, 064, 085	Techwood 004, 006, 048	Electrohome ..012, 027
Radio Shack/Realistic 000, .004, 006, 011, 036, 045,086, 146, 154, 155	Telecaption105	Emerson . 010, 012, 013, .019, 022, 023, 024, 027, .028, 029, 030, 031, 032, .033, 034, 035, 036, 037, .038, 039, 040, 041, 042, .043, 044, 062, 108, 111,112, 123
RCA 000, 003, 004, 005, .006, 007, 018, 087, 088, .089, 090, 091, 092, 093, .115, 161, 163, 167, 168, .170, 181, 182, 192, 197	Toshiba ..045, 065, 066, .095, 099, 105, 106, 144,146	Fisher 009, 021, 045, .046, 047, 048, 049, 113
Runco135	Totevision154	Fuji019, 114
Sampo 004, 006, 154, 155	Universal 047, 078	Funai024
Samsung ..004, 005, 006, .011, 014, 018, 094, 096,154, 155, 183	Wards ..000, 001, 004, .005, 006, 018, 022, 031, .042, 047, 056, 062, 063, .068, 069, 076, 078, 079,086, 107, 108	Garrard024
Sansui171	Yamaha ..004, 005, 006,018	GE .. 000, 001, 011, 019,020, 110, 115, 124
Sanyo 004, 044, 045, 073, .097, 098, 146, 152, 162	Zenith ... 004, 076, 135, .136, 137, 138, 187, 194	Goldstar .. 007, 012, 016,051, 054
Sears 000, 004, 006, 012, .013, 018, 042, 044, 045, .046, 060, 065, 066, 099, .100, 146, 162, 163, 169	VCR CODES	
Sharp..... 004, 006, 011, .027, 086, 101, 102, 103,109, 154	Admiral 125	Gradiente024
Sony 002, 184, 193, 195	Aiko025	Harman Kardon ...007
Sounddesign ..004, 006,008, 036, 042	Aiwa024	Harwood058
Starlite036	Akai .002, 003, 004, 005,006, 106, 107, 108	Hitachi ... 052, 053, 054,102, 106, 115, 116
Supre-Macy157	Audiovox012	JC Penney007, 008, .009, 011, 012, 019, 020, .052, 053, 055, 056, 057,058, 059, 102, 113
Sylvania004, 006, .008, 018, 056, 062, 063,	Bell & Howell009	Jensen ...052, 053, 106
	Broksonic 010, 023	JVC 007, 008, 009, 016, 106, 117
	Calix012	
	Canon ...019, 020, 109	
	Capehart 018, 105	
	Carver059	
	CCE025, 058	
	Citizen ..011, 012, 013, .014, 015, 016, 017, 025	

Universal Remote Codes (cont'd)

VCR CODES Cont'd...

Kenwood .007, 008, 009,
014, 016, 106, 117
 KLH058
 Kodak012, 019
 Logik058
 LXI012
 Magnavox . 019, 020, 059,
 .. 060, 099, 100, 103, 118
 Marantz . .007, 008, 009,
 .. 014, 016, 019, 059, 061
 Matshushita019
 Memorex . .009, 011, 012,
 .. 019, 021, 024, 099, 125
 MGA027, 062, 108
 Minolta ...052, 053, 102
 Mitsubishi 027, 052, 053,
 .062, 063, 064, 065, 066,
 .067, 068, 069, 070, 071,
101, 108, 117
 Montgomery Ward 072, 125
 Motorola019, 125
 MTC011, 120
 Multitech. . . .011, 014,
 024, 050 058
 NEC.007, 008, 009,
014, 016, 061, 073,
 074, 075, 106, 117
 Nikko012
 Noblex011
 Olympus019
 Optimus012, 125
 Optonica092
 Panasonic .019, 020, 104,
119, 120, 121
 Pentax ...014, 052, 053,
102, 115
 Pentax Research ...016

Philco. . 019, 020, 059, 060
 Philips 019, 059, 092, 118
 Pioneer .. 008, 052, 076,
077, 117
 Proscan .. .000, 001, 124
 Quasar .. .019, 020, 119
 Radio Shack/Realistic
009, 011, 012, 019,
 .020, 021, 024, 027, 046,
047, 092, 125
 Radix 012
 RCA000, 001, 002,
 .011, 019, 052, 053, 078,
 .079, 080, 081, 082, 083,
 .084, 085, 086, 087, 102,
110, 115, 119, 124
 Realistic .. 009, 011, 013,
 .019, 020, 021, 024, 027,
046, 047, 092, 125
 Ricoh122
 Runco099
 Samsung .. 004, 011, 013,
031, 050, 107
 Sansui 008, 088, 106, 117
 Sanyo009, 011, 021
 Sears 009, 012, 019, 021,
 .045, 046, 047, 048, 052,
053, 102, 113
 Sharp 015, 027, 090, 091,
092, 093, 125
 Shintom 003, 053, 058, 094
 Singer019, 058, 122
 Sony .003, 094, 095, 114
 STS019, 102
 Sylvania ..019, 020, 024,
059, 060, 062, 118
 Symhonic024
 Tandy009

Tashiko012
 Tatung106
 Teac024, 081, 106
 Technics019, 104
 Toshiba. . .013, 046, 048,
052, 062, 089, 108
 Totevision011, 012
 Unitech011
 Vector Research ...007,
008, 013, 014
 Video Concepts ...007,
008, 013, 014, 108
 Wards ..011, 012, 013,
 .019, 021, 024, 027, 052,
 .053, 058, 092, 096, 097,
098, 102, 111, 125
 Yamaha ..007, 008, 009,
016, 106
 Zenith003, 094,
099, 114, 122

DVD CODES

Aiwa009
 GE000
 Hitachi008
 JVC002, 010
 Konka011, 012
 Magnavox003
 Mitsubishi004
 Panasonic013
 Philips 003, 019, 021, 022
 Pioneer005
 Proscan000
 RCA000, 001
 Sanyo014
 Sony006, 015, 016
 Toshiba ...007, 017, 020
 Zenith018

Limited Warranty

ACCESSORY

90 Days Carry-In Exchange

WHO IS COVERED?

You must have proof of purchase to receive warranty service. A sales receipt or other document showing that you purchased the product is considered proof of purchase.

WHAT IS COVERED?

Warranty coverage begins the day you buy your product. For 90 days thereafter, a defective or inoperative product will be replaced with a new, renewed or comparable product at no charge to you. A replacement product is covered only for the remainder of the original warranty period. When the warranty on the original product expires, the warranty on the replacement product also expires.

WHAT IS EXCLUDED?

Your warranty does not cover:

- labor charges for installation or setup of the product, adjustment of customer controls on the product, and installation or repair of antenna systems outside of the product.
- product repair and/or part replacement because of misuse, accident, unauthorized repair or other cause not within the control of Philips.
- reception problems caused by signal conditions or cable or antenna systems outside the unit.
- a product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications.
- incidental or consequential damages resulting from the product. (Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you. This includes, but is not limited to, pre-recorded material, whether copyrighted or not copyrighted.)
- damage caused by the use of non-VHS tapes or tapes that have not been tested and labeled for use in two, four, six and eight hour VHS recorders.
- a product used for commercial or institutional purposes.

WHERE IS EXCHANGE AVAILABLE?

You may exchange the product in all countries where the product is officially distributed by Philips. In countries where Philips does not distribute the product, the local Philips service organization will attempt to provide a replacement

product (although there may be a delay if the appropriate product is not readily available).

MAKE SURE YOU KEEP...

Please keep your sales receipt or other document showing proof of purchase. Attach it to this owner's manual and keep both nearby. Also keep the original box and packing material in case you need to return your product.

BEFORE REQUESTING EXCHANGE...

Please check your owner's manual before requesting service. Adjustments of the controls discussed there may save you a service call.

EXCHANGING A PRODUCT IN THE U.S....

Ship the product freight prepaid and insured with proof of purchase to the Philips.

Philips Exchange Program
1001 Snapp Ferry Road
Greeneville, TN 37745

(In the U.S., all implied warranties, including implied warranties of merchantability and fitness for a particular purpose, are limited in duration to the duration of this express warranty. But, because some states do not allow limitations on how long an implied warranty may last, this limitation may not apply to you.)

No other warranties are expressed or implied, including any implied warranties of merchantability or fitness for a particular purpose. Philips is not liable under any circumstances for any direct, indirect, special, incidental or consequential damages, howsoever incurred, even if notified of the possibility of such damages.

REMEMBER...

Please record below the model and serial numbers found on the product. Also, please fill out and mail your warranty registration card promptly. It will be easier for us to notify you if necessary.

MODEL # _____

SERIAL # _____

This warranty gives you specific legal rights. You may have other rights which vary from state/province to state/province..

EL5060E006 / 3-02

Philips, P.O. Box 520890, Miami, FL 33152 (402) 536-4171

Printed in Batam, Indonesia

3111 176 51221

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>