

Setting up your DVD/CD Receiver

Caution When connecting this system or changing connections, be sure to switch the power off with the **STANDBY/ON** button, and disconnect the power cord from the AC outlet. Do not use these speakers with any other system or amplifier as this may result in damage or fire.

1 Check that you have all the accessories, then put the batteries in the remote control.

Batteries and remote control

Power cord*
* Illustration shows the Taiwan model

Video cord

FM antenna

AM loop antenna

Microphone (for Auto MCACC setup)

2 Connect the AM and FM antennas to the rear panel of the DVD/CD receiver.

- 1 Pull off the protective shields of both AM antenna wires.
- 2 Push open the tabs, then insert one wire fully into each terminal.
- 3 Release the tabs to secure the AM antenna wires.
- 4 Fix the AM loop antenna to the attached stand. To fix the stand to the antenna, bend in the direction indicated by the arrow (fig. A) then clip the loop onto the stand (fig. B).

Note: If you plan to mount the AM antenna to a wall or other surface, secure the stand with screws (fig. C) before clipping the loop to the stand. Make sure the reception is clear.

6 Connect the FM wire antenna to the FM UNBAL 75Ω antenna terminal.

For best results, extend the FM antenna fully and fix to a wall or door frame. Don't drape loosely or leave coiled up.

Note: The signal earth (⊕) is designed to reduce noise that occurs when an antenna is connected. It is not an electrical safety earth.

Using the remote control

The remote control can be used within a range of about 7 meters from the remote sensor on the front panel, and within a 30 degree angle.

Precautions:

- The remote control may not work if there is an obstacle between the remote control and the display unit, or if the remote control is not directed towards the remote sensor of the display unit at the correct angle.
- The remote control may not work properly if strong light such as direct sunlight or fluorescent light is shining onto the unit's remote sensor.
- The remote control may not work properly when this unit is used near devices emitting infrared rays, or when remote controls of other devices which use infrared rays are used. Also, the use of this remote control may cause other devices to work improperly.
- When the operating range of the remote becomes too short, replace the batteries.

Remote control battery caution

Incorrect use of batteries may cause leakage or rupture.

Always be sure to follow these guidelines:

- Always insert batteries into the battery compartment correctly matching the positive (+) and negative (-) polarities, as shown by the display inside the compartment.
- Never mix new and used batteries.
- Batteries of the same size may have different voltages, depending on brand. Do not mix different brands of batteries.
- When disposing of used batteries, please comply with governmental regulations or environmental public instruction's rules that apply in your country or area.
- In order to prevent battery leakage, remove the batteries when not using the remote control for an extended period (one month or more). If leakage occurs, carefully wipe away any battery fluid inside the compartment, and replace the batteries with new ones.
- Do not allow books or other objects to rest on top of the remote control, since the buttons may be depressed, causing faster exhaustion of the batteries.

Additional notes on connecting antennas

- Keep antenna cables away from the main unit and other cables.
- To assure optimum reception, pull the FM antenna so that it is fully extended and not coiled or hanging at the rear of the unit.
- If reception with the supplied antenna is poor; see the **Other connections** section in the main operating instructions for details on connecting outdoor antennas.

Additional notes on speaker placement

If your listening room is of adequate size, place the speakers as shown in step 3 to achieve the optimum surround sound effect. If you are listening in a fairly small room and a typical surround speaker setup is not possible, see **Home theater sound setup** in the instruction manual and the **Speaker Setup guide** for information on the Front surround 3-spot setup option.

When using the standard surround speaker setup as shown in step 3, please observe the following guidelines:

- Install the main front left and right speakers at an equal distance from the TV.
- For optimum effect, install the rear speakers slightly above ear level.
- Install the center speaker above or below the TV so that the sound of the center channel is localized at the TV screen.

Precautions:

- When installing the center speaker on top of the TV, be sure to secure it with tape or some other suitable means. Otherwise, the speaker may fall from the TV due to external shocks such as earthquakes, endangering those nearby or damaging the speaker.
- Do not connect the supplied speakers with any other amplifier. This may result in malfunction or fire.
- The front, center and surround speakers supplied with this system are magnetically shielded. However, depending on the installation location, color distortion may occur if the speaker is installed extremely close to the screen of a television set. If this happens, turn the power switch of the television set OFF, and turn it ON after 15 to 30 minutes. If the problem persists, place the speaker system away from the television set.
- The subwoofer is not magnetically shielded and so should not be placed near a TV or monitor. Since it is not magnetically shielded, do not place any magnetic storage media (such as floppy disks and tape or video cassettes) close to the subwoofer.
- Do not fix the subwoofer and center speaker to the wall or ceiling; they could cause injury if they fell.

3 Connect each speaker using the color-coded speaker cords. Match them to the colored speaker terminals on the rear panel of the DVD/CD receiver.

Connect each speaker as shown below.

- 1 Twist and pull off the protective shields on each wire.
- 2 Connect the wires to the speaker. Match the colored wire with the color-coded label (above the tabs), then insert the colored wire into the red (+) tab and the other wire with the black (-) tab.
- 3 Connect the other end to the color-coded speaker terminals on the rear of the DVD/CD receiver (as shown at left). Make sure to insert completely. The small lug at the wire-end of the speaker plug should face up or down depending on whether it's being plugged into one of the upper or lower three speaker terminals. Please make sure to connect correctly.

Caution

These speaker terminals can be hazardous when live. When you connect or disconnect the speaker cables, to prevent the risk of electric shock, do not touch uninsulated parts before disconnecting the power cord.

For the best surround sound, setup your speakers as above. The front left and right speakers should be about 1.8–2.7 m apart.

4 Connect the DVD/CD receiver to your TV, then connect the supplied power cord.

- 1 Connect one end to a video input on your TV. Use the supplied video cord.
- 2 Connect the other end to the video output of the DVD/CD receiver. This player is equipped with copy protection technology. Do not connect this player to your TV via a VCR using AV cables, as the picture from this player will not appear properly on your TV.
- 3 Connect the power cord to the AC inlet.

Caution

Do not connect the supplied speakers with any other amplifier. This may result in malfunction or fire.

Congratulations! You're done setting up.

Speaker Setup guide

Check that you have all the speaker accessories.

- Front speakers x 2
- Center speaker x 1
- Surround speakers x 2
- Subwoofer x 1
- Speaker cords x 6
- Non-skid pads (large) Taiwan model x 4, All other models x 6
- Non-skid pads (small) x 12
- Mounting brackets x 4*
- Screws (for mounting brackets) x 4*

* Please refer to *Wall-mounting the front and surround speaker system* in the operating instructions for installation.

Choose your subwoofer placement (Taiwan model only)

The subwoofer supplied with this system can be placed upright or on its side (flat). Choose the position that works best for your room, then attach the large non-skid pads as shown at right.

Standard surround 5-spot setup

This is a standard multichannel surround sound speaker setup for optimal 5.1 channel home theater sound.

1 Attach the smaller non-skid pads to the base of each of the front and center speakers.

Use the adhesive to attach 4 pads to the base of each speaker.

2 Connect the speaker system.

Refer to *Setting up your DVD/CD Receiver* (the other part of this setup guide) to connect the speakers properly. Place them as shown in the diagram at far left for optimal surround sound.

The base of each surround speaker fits into the circular groove on the top of the front speakers as shown.

Attach the large non-skid pads to the base of the subwoofer (Singapore/Indonesia/Hong Kong/Philippines/Malaysia models)

Use the supplied adhesive to attach 6 pads to the base of subwoofer.

Front surround 3-spot setup

This setup is ideal when rear surround speaker placement isn't possible or you want to avoid running long speaker cables in your listening area.

1 Attach the smaller non-skid pads to the base of each of the front and center speakers.

Use the adhesive to attach 4 pads to the base of each speaker.

2 Connect the speaker system.

Refer to *Setting up your DVD/CD Receiver* (the other part of this setup guide) to connect the speakers properly. Place them as shown in the diagram at far left for optimal surround sound.

The base of each surround speaker fits into the circular groove on the top of the front speakers as shown.

3 Secure the speaker wire.

After testing for the slack necessary to turn the speaker (see the following step), use the groove provided to secure the speaker wire as shown. Leave 5 cm of slack from the speaker terminals so the upper (surround) speaker can turn freely.

4 Turn the surround speakers towards the closest wall, lining the arrows up for optimal Front Surround.

Turn each surround speaker so that the ▼ arrow at the base is lined up with the ▲ FRONT SURROUND arrow on the front speaker. This is only necessary with the **FrtMovie** or **FrtMusic** modes. With **ExtPower** (Extra Power), line up the ▼ arrow with the ▲ EXTRA POWER arrow (the surround speakers should be in the same direction as the front speakers). See the operating instructions for more on the Front Surround modes.

Caution

- To prevent accidents, make sure the surround speaker is placed securely on top of the front speaker.
- Please don't attach the speakers to the wall or speaker stands for Front surround 3-spot setup.

ExtPower **FrtMovie / FrtMusic**

Caution

- To prevent accidents, make sure the surround speaker is placed securely on top of the front speaker.
- Please don't attach the speakers to the wall or speaker stands for Front surround 3-spot setup.

設定您的DVD/CD接收機

注意 連接本系統或變更接線方式時，請確實利用STANDBY/ON按鍵先將電源關閉，並將電源線自AC電源插座上脫離。切勿將這些揚聲器搭配其他的系統或擴大機使用，此種作法可能會導致損壞或引起火災。

1 檢查所有配件並無短缺，接著再將電池裝入遙控器內。

電池及遙控器

電源線*
*圖示以台灣機種為例

視頻線

FM天線

AM環型天線

麥克風 (Auto MCACC設置專用)

2 將AM及FM天線裝設至DVD/CD接收機的背面板。

- 1 扯下AM天線兩條導線上的保護外皮。
- 2 將凸耳推開，接著將每條導線完全的插入每個端子內。
- 3 將凸耳放回以固定AM天線導線。
- 4 將AM環型天線固定在安裝底座上。
欲將底座固定在天線上，則請對著箭頭所指的方向折彎(圖A)，接著將環型天線繫於腳座上(圖B)。

附註：若您打算將AM天線裝於牆上或其他的表面上，則請在將環型天線繫於腳座之前，先利用螺絲將腳座上緊(圖C)。完成安裝後請確定收音情形清晰良好。

- 5 將AM天線置於平坦的表面上，並對準收音狀況最佳的方向。切勿讓天線觸及金屬物體，同時應遠離電腦、電視機或其他電氣設備的範圍擺設。
- 6 將FM線型天線裝設到FM UNBAL 75Ω天線端子上。
為得到最佳的收音效果，請將FM天線完全展開固定於牆上或門框上。切勿放鬆垂下或捲成圈狀。

附註：信號接線(赤)在設計上，主要是減少天線在裝設後所產生的雜訊。此線不作電氣安全地線用途。

3 使用標示顏色的揚聲器插頭接至每只揚聲器上。將這些插頭對照DVD/CD接收機後面板上的顏色端子接上。

請依照下列步驟連接每只揚聲器。

- 1 將每條導線上的保護外皮扭轉後扯下。
- 2 將導線接至揚聲器上。將標示顏色的導線對照著標示顏色的標識(凸耳上方)，接著將有色導線插入紅色(+)的凸耳內，而另一條導線則插入黑色(-)的凸耳內。
- 3 將另一端連接至DVD/CD接收機後面板上的顏色端子(如左圖所示)。請確實完全插入。在揚聲器插頭線端處的小型接頭應視其為連接上方或下方三個當中的端子，再行決定應正面朝上或朝下。請確實正確接上。

注意
這些揚聲器端子在通電時是具有危險性的。在將線接上或脫離時，為避免受到電擊的危險，切勿在脫離電源線之前，觸及到未絕緣的部份。

4 將DVD/CD接收機接至個人電視機上，然後接上隨附的電源線。

- 1 將接收機一端接至個人電視機上的視頻輸入。連接時利用隨附的視頻線。
- 2 將接收機另一端接至DVD/CD接收機的視頻輸出上。
本機為採用防盜拷技術。切勿使用AV傳輸線將本機透過VCR的方式接至個人的電視機，如此一來，經由本機所傳送的畫面便有可能無法正常的在電視上顯示。
- 3 將電源線接上AC電源插座。

恭喜！現在您已設定完成。

3 使用標示顏色的揚聲器插頭接至每只揚聲器上。將這些插頭對照DVD/CD接收機後面板上的顏色端子接上。

為產生最佳的環繞音效，請照上圖方式佈置個人的揚聲器。左前置及右前置揚聲器二者應相距1.8-2.7公尺。

揚聲器設定指南

請清點所有揚聲器配件

- 前置揚聲器 x 2
- 中置揚聲器 x 1
- 環繞揚聲器 x 2
- 重低音 x 1
- 揚聲器線 x 6
- 防滑墊(大) 台灣機種 x 4 其他機種 x 6
- 安裝托架 x 4 *
- 螺絲(安裝托架用) x 4 *
- 防滑墊(小) x 12

*關於牆壁安裝前置及環繞揚聲器系統的安裝請參考操作手冊

選擇重低音的擺設方式(僅適用於台灣機種)

隨本系統附贈的重低音可以直立或側放(平放)。請選擇最適合您房間的擺設方式，然後將大防滑墊按右圖方法貼上：

標準環繞立體聲5點設置

採用此標準方式放置多聲道環繞立體聲揚聲器，可享受理想的5.1聲道家庭影院音響效果。

*圖示以台灣機種為例

1 將小的防滑墊貼到每只前置揚聲器及中置揚聲器的基座上。

請用黏著劑將四片防滑墊貼到每只揚聲器的基座上。

2 連接揚聲器系統。

請參閱設置您的DVD/CD接收機的內容(其他設置指南的部份)，以正確連接揚聲器。請按照最左圖中所示方式擺置，以獲得最佳的環繞聲效果。

按照右圖方式將每只環繞揚聲器的基座正對前置揚聲器上方的圓形凹槽接上。

將大的防滑墊貼到重低音的基座上(新加坡/印尼/香港/菲律賓/馬來西亞機種)

請用隨機附贈的黏著劑將六片防滑墊貼到重低音的基座上。

前置式環繞立體聲3點設置

如果無法將環繞立體聲揚聲器放置在收聽位置後方，或避免在收聽範圍內鋪設太長的揚聲器電纜，這種設置方式就最適合。

*圖示以台灣機種為例

1 將小的防滑墊貼到每只前置揚聲器及中置揚聲器的基座上。

請用黏著劑將四片防滑墊貼到每只揚聲器的基座上。

2 連接揚聲器系統。

請參閱設置您的DVD/CD接收機的內容(其他設置指南的部份)，以正確連接揚聲器。請按照最左圖中所示方式擺置，以獲得最佳的環繞聲效果。

按照右圖方式將每只環繞揚聲器的基座正對前置揚聲器上方的圓形凹槽接上。

3 固定揚聲器線。

在測試好轉動揚聲器所需多出的線長後(參閱下述步驟)，請利用所提供的凹槽來固定揚聲器線。從揚聲器端子多保留5公分的線長，好讓上方(環繞)揚聲器能夠自由轉動。

4 將揚聲器轉向最近一面的牆壁，對齊箭頭標示，以獲得最佳的前環繞音響。

轉動每只環繞揚聲器使基座上的▼箭頭標示對齊前置揚聲器上的▲ FRONT SURROUND 箭頭標示。這作法只有在用FrtMovie或FrtMusic時才有必要。使用ExtPower(加大功率)時，將▼箭頭對齊▲ EXTRA POWER頭(環繞揚聲器應與前置揚聲器同方式)。請參閱操作手冊以了更多關於Front Surround模式的資訊。

注意

- 為了避免意外發生，務請確定環繞揚聲器已確實固定在前置揚聲器上。
- 前環繞3點式設置時，請不要將揚聲器安裝到牆上或揚聲器座上。

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>