



**Internet Telephony Gateway**  
**VIP-050 / VIP-450**  
**User's Manual**

**Rev 2.0**

### **FCC Notice**

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed in accordance with the instruction manual, may cause harmful interference to radio communication. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at the user's own expense.

### **Disclaimer**

PLANET Technology does not warrant that the hardware will work properly in all environments and applications, and makes no warranty and representation, either implied or expressed, with respect to the quality, performance, merchantability, or fitness for a particular purpose.

PLANET has made every effort to ensure that this User's Manual is accurate; PLANET disclaims liability for any inaccuracies or omissions that may have occurred.

Information in this User's Manual is subject to change without notice and does not represent a commitment on the part of PLANET. PLANET assumes no responsibility for any inaccuracies that may be contained in this User's Manual. PLANET makes no commitment to update or keep current the information in this User's Manual, and reserves the right to make improvements to this User's Manual and/or to the products described in this User's Manual, at any time without notice. If you find information in this manual that is incorrect, misleading, or incomplete, we would appreciate your comments and suggestions.

### **CE Declaration of conformity**

This equipment complies with the requirements relating to electromagnetic compatibility, EN 55022 class A for ITE and EN 50082-1. This meets the essential protection requirements of the European Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility.

### **Trademarks**

All brand, company and product names are trademarks or registered trademarks of their respective companies.

### **Revision**

PLANET VIP-050 / VIP-450 User's Manual

Revision: 2.0

Nov. 2004

Part No. EM-VIPSV2

## How to Use This Manual

This manual was designed for the technical and non-technical users of PLANET Internet telephony gateway VIP-050 / VIP-450. It contains information about the functions of VIP and instructions for its installation, basic configuration and operation in related chapters, and introduces more advanced command line interface, firmware upgrade and appendix information. Read this section carefully for important information about the manual's organization.

### **Chapter 1: Overview**

This chapter provides conceptual overview and description of VIP, explanation of how VIP interacts with each for enabling VoIP services, and an overview of the required tasks

### **Chapter 2: Installing VIP**

This chapter describes required steps to properly and safely install and configure VIP on your network

### **Chapter 3: VIP Concepts**

This chapter gives information about VIP technology and describes basic concepts using VIP for providing telephony services over IP network

### **Chapter 4: Configuring VIP from Web Browser**

This chapter explains procedures for configuring VIP from a web browser

### **Chapter 5: Making a Call with VIP**

This chapter explains how to make Internet calls from telephony devices connected to VIP directly or indirectly.

### **Chapter 6: Command Line Interface**

This chapter describes how to access the command line interface. It also contains information about the commands used to configure VIP.

### **Chapter 7: Upgrading VIP**

This chapter explains how to download new revision software and upgrade VIP.

### **Appendix A: Technical Specifications**

This appendix lists VIP specifications and the assignment of pins of all the interface ports.

### **Appendix B: CLI Commands**

This appendix provides a short description of each CLI command with a reference to the pages that contain detailed information on the command.

### **Appendix C: Factory Default Settings**

This appendix lists factory settings of VIP.

## Important Safety Instructions

Before plugging VIP into an electrical outlet, carefully read all the installation instructions in Chapter 2.

For your own safety and the safety of your equipment, always take the following precautions:

- Follow instructions and warnings in the documentation.
- Never push any object through the fan vent or other openings in the equipment. Such action may produce a short circuit, causing fire, electric shock, or equipment damage.
- Keep VIP away from all chemicals and sources of liquids.

## Warning

- Connection of the RJ45 connector from a VIP to TNV circuits can cause permanent damage to VIP.
- Incorrectly connecting telephony devices to the RJ11 port on the Telephony Interface Module can cause permanent damage to the module.

## Documentation Abbreviations

Throughout this guide, the user will come across a number of abbreviations that are common throughout the industry. The user should be familiar with the following abbreviations:

<b>ATPM</b>	Address Translation and Parsing Manager
<b>CLI</b>	Command Line Interface
<b>DSP</b>	Digital Signal Processor
<b>DTMF</b>	Dual Tone Multi-Frequency
<b>E&amp;M</b>	Ear & Mouth
<b>FXO</b>	Foreign Exchange Office
<b>FXS</b>	Foreign Exchange Subscriber
<b>SIP</b>	ITU specification for multimedia transmission over IP networks
<b>ICMP</b>	Internet Control Message Protocol
<b>IMTC</b>	International Multimedia Telecommunications Consortium
<b>IP</b>	Internet Protocol
<b>ITG</b>	Internet Telephony Gateway
<b>KTS</b>	Key Telephone System
<b>LAN</b>	Local Area Network
<b>NVS</b>	Non-Volatile Storage

<b>LED</b>	Light Emitting Diode
<b>PBX</b>	Private Branch Exchange
<b>PSTN</b>	Public Switched Telephone Network
<b>RTP</b>	Real-Time Transport
<b>SIP</b>	Session Initialization Protocol
<b>TCID</b>	Telephony Channel Identifier
<b>TFTP</b>	Trivial File Transfer Protocol
<b>TIM</b>	Telephony Interface Modules
<b>TNV</b>	Telephone Network Voltage
<b>UDP</b>	User Datagram Protocol
<b>UTP</b>	Unshielded Twisted Pair
<b>VAD</b>	Voice Activity Detection
<b>WAN</b>	Wide Area Network

## Notation Conventions

Throughout this guide, different type styles and characters are used. These serve a variety of purposes as described below:

<b>Convention</b>	<b>Description</b>
<b>boldface</b>	Commands and keywords are in <b>boldface</b> .
<i>italic</i>	Arguments for which you supply values are in italics.
courier	Messages that VIP CLI displays are in plain courier font.
[ ]	Elements in square brackets are optional.
{ x   y   z }	Alternative but required elements are grouped in braces ( { } ) and separated by vertical bars (   ).
[ x   y   z ]	Optional alternative keywords are grouped in brackets ( [ ] ) and separated by vertical bars (   ).
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.

## Table of Contents

<b>Chapter 1 Overview</b>	<b>1</b>
1.1 Features	1
1.2 Networking Protocols	1
1.3 Package Contents	2
1.4 Front Panel	2
1.5 Rear Panel	3
<b>Chapter 2 Installing VIP</b>	<b>5</b>
2.1 Network Requirements	5
2.2 Installing VIP	5
2.3 Connecting to the telephony devices	5
2.4 Connecting to the Network	5
2.5 Providing Power to VIP	6
2.6 Assigning IP address to VIP	6
<b>Chapter 3 VIP Concepts</b>	<b>7</b>
3.1 How VIP Operates	7
3.2 ATPM	7
3.3 Destination	7
3.4 Hunt Group	8
3.5 Dial Plan	8
3.6 DTMF Relay	9
3.7 Voice Codecs	9
<b>Chapter 4 Configuring VIP from a Web Browser</b>	<b>11</b>
4.1 Http setting mode	11
4.1.1 Dial Plan/ Dial Settings	13
4.1.2 Clear DialPlan	19
4.1.3 Restore DialPlan	20
4.1.4 Save to NVRAM	20
4.2 View System Configurations	21
4.2.1 Firmware Version Information	21
4.2.2 SIP Parameters	21
4.2.3 Voice Coder Type	22
4.2.4 Voice Coder Information	22

4.2.5 Channel Parameters	23
4.2.6 Network Connection	24
4.3 Configure System Settings	28
4.3.1 IP Settings	30
4.3.2 SIP Parameters	30
<b>Chapter 5 Troubleshooting Tips</b>	<b>34</b>
<b>Chapter 6 Command Line Interface</b>	<b>35</b>
6.1 Connection through Serial Port	35
6.2 Connection through Telnet	35
6.3 Command Help	36
6.4 Designating IP Address	36
6.5 Designating Port Number	36
6.6 Command Reference	37
6.7 Utility Commands	38
6.8 Network Commands	39
6.9 Configuration Management Commands	44
6.10 Voice Coding Profile Configuration Commands	48
6.10.1 Common Coding Profile Configuration Commands	48
6.10.2 Voice Coding Profile Configuration Commands	49
6.11 Dial Plan Management Commands	52
6.12 Tel Commands	57
<b>Chapter 7 Upgrading and resetting VIP</b>	<b>59</b>
7.1 Firmware upgrade	59
7.2 CLI Commands in Download Mode	64
7.3 Restore default configuration	65
<b>Appendix A Technical Specifications</b>	<b>69</b>
A.1 VIP Technical Specifications	69
A.2 Console Port	70
A.3 LAN Port	70
A.4 FXO Port Pin Assignments	71
A.5 FXS Port Pin Assignments	71
<b>Appendix B CLI Commands</b>	<b>73</b>
B.1 Normal Mode Commands	73

B.2	Download Mode Commands	74
<b>Appendix C</b>	<b>Factory Default Settings</b>	<b>75</b>



## Chapter 1 Overview

This chapter illustrates an overview of PLANET Internet Telephony Gateway Family – VIP-050 / VIP-450 and a detailed product description of features and capabilities.

### 1.1 Features

Via growth of Internet technology, Internet telephony service plays and turns into a cost-effective and highly reliable substitution system of the old-time traditional PBX system. PLANET VoIP (Voice over IP) system – VIP-050 / VIP-450 offer toll quality voice and real-time fax data over IP networks. With optimized SIP architecture, PLANET VIP series are ideal solution for various VoIP applications such as Headquarter and Branch Office communication, and IDD cost-effective solution. With its intuitive user-friendly interface, PLANET VIP series may be installed easily conveniently, and dramatically down cost the huge amount of IDD fee.

With embedded, efficient Real-Time Operating System, VIP series provides efficiency and feature enhancement capabilities; being programmed with updated firmware users may have the most flexibility and functionality to meet different kind of application requirement. It comes equipped with remote management capabilities, configurable signaling to work with PBX, KTS, and/or telephone. Building on state-of-the-art advanced VoIP related technology. PLANET VVIP series offers various features: echo cancellation, Voice Activity Detection (VAD) , Comfort Noise Generation (CNG) , lost packet recovery algorithms and optimized voice and FAX coders to bring users superior voice quality, and best compatibility with major Internet telephony service providers.

### 1.2 Networking Protocols

VIP supports several industry-standard networking protocols required for voice communication. The following table describes these protocols.

Networking Protocol	Description
Internet Protocol (IP)	IP is a messaging protocol that addresses and sends packets across the network. To enable IP protocol, VIP must have a static IP address, subnet, and gateway assigned to it.
Voice over IP Protocol (VoIP)	VoIP enables VIP to transfer voice communications over an IP network. VIP employs ITU-T SIP protocol for setting up call with one another.
Trivial File Transfer Protocol (TFTP)	TFTP allows you to transfer files over the network. VIP implements a TFTP client allowing you to download new revision firmware from a TFTP server. The TFTP client requires a TFTP server in your network.
Real-Time Transport (RTP)	RTP is a standard for transporting real-time data over IP network. VIP uses RTP protocol to send digitized and compressed voice packets.

## 1.3 Package Contents

The contents of your product should contain the following items:

### VIP-050

- 2-slot Internet Telephony Gateway
- Power cord
- 9-pin straight through RS-232 cable
- Quick Installation Guide
- User's Manual CD
- Rack mount Accessories

### VIP-450

- 4-port Internet Telephony Gateway
- Power cord
- 9-pin straight through RS-232 cable
- Quick Installation Guide
- User's Manual CD

## 1.4 Front Panel

The front panel of VIP contains a RJ-45 Ethernet port, one DB9 RS-232 interface port, a push button and 16 LED indicators. The following figure illustrates the front panel of VIP.




Figure 1-1 VIP-050 Front Panel




Figure 1-2 VIP-450 Front Panel

### LED Indicators

The LED indicators on the front panel display the current status of VIP as described in the following table:

Indicator	Color	Activity	Indication
-----------	-------	----------	------------

PWR	Green	On	Power is supplied to the gateway.
SYSTEM	Green	Blinking	The system is running. (Heartbeat LED)
LAN • ACT • 100M  • LNK • COL	Green Green  Green Green	On On Off On On	Data is presented on LAN. The gateway is connected to LAN at 100Mb/s. The gateway is connected to LAN at 10Mb/s. The gateway is connected to LAN. Data collision is occurring on the network connection.
Slot A/B Channels 1-4	Green	Off On Blinking	The line is idle. The line is being used. The line is ringing.

## Ports

VIP is equipped with an Ethernet interface with 10/100 Mbps auto-negotiation capability. The Ethernet interface port is located on the front panel. In addition to the Ethernet interface port, there is a 9-pin RS-232 interface port on the front panel. Their functions are described below:

Port	Label	Function
RJ45	LAN	Connecting VIP to a 10/100 Mbps Ethernet network
9-pin RS-232	User Console	Connecting VIP to a VT-100 terminal or terminal emulator for configuring VIP

## Reset Button

There is a push button located behind a small hole next to the SYSTEM LED. **This button allows you to reset VIP or force VIP to enter firmware upgrade mode.**

### Reset


Push a small, stiff object into the hole until the SYSTEM LED stops blinking, then release the button.

### Force firmware download mode:

Powering on the gateway while pressing down the button for **5** seconds forces VIP to enter download mode

## 1.5 Rear Panel

The rear panel of VIP-050 has two slots allowing the installation of up to two Telephony-Interface-Module (TIM) . Each module is equipped with 4 telephony interface ports. Depending on the type of the telephony interface module, the telephony interface ports may be connected to telephony devices, such as PBX, KTS, and telephone sets of central office. VIP-450 equips with two FXO and two FXS ports. In addition to the TIM slots (ports), there is an AC power receptacle and a power switch (power adapter: VIP-450) on the rear panel.



Note: For VIP-050, three modules available, VIP-FXS, VIP-FXO and VIP-E&M. Modules are not included, please consult your local dealer for the information of the modules.

## Chapter 2 Installing VIP

This chapter gives information on how to install VIP.

### 2.1 Network Requirements

For VIP successfully operate in your network, your network must meet the following requirements:

1. A working 10/100 Base-T Ethernet. VIP connects to Internet via an Ethernet LAN.
2. IP network that supports gateway, and subnet mask. You'll need one static IP address to assign VIP.

### 2.2 Installing VIP

VIP can be used in a desktop configuration. Ensure that VIP is placed in a clean, well-ventilated, and vibration-free environment.

When VIP is placed on a desktop, be certain that the unit is placed on a sturdy, flat surface, near a grounded power outlet. At least three inches of clearance must be provided on both sides of VIP for well ventilation.

### 2.3 Connecting to the telephony devices

VIP-050 supports three types of TIM. One is FXO, FXS and the other is E&M. Each module has four ports for connecting to telephony devices. VIP-450 equips two FXO and two FXS interfaces to have the great flexibility of PBX connection (FXO), and telephone or FAX machine connection (FXS).

VIP-FXO module is designed for connecting to PBXs (extension line) or central office switches (CO line).

VIP-FXS module is designed for connecting to analog telephone sets or G3 fax machines. Connecting the telephony devices to the appropriate RJ11 ports on the TIM.

**Warning:** *connection of incorrect telephony devices to the ports on the TIM can cause permanent damage to the TIM and/or VIP.*

### 2.4 Connecting to the Network

The RJ45 network port on the front panel supports 10/100 Mbps half-duplex connection to Ethernet Network. You can use either category 3 or 5 straight-through UTP cable for 10 Mbps connections, but use Category 5 for 100 Mbps connections. To connect to Ethernet, insert one end of the Ethernet cable to the RJ45 port on the front panel of VIP and other end of the cable to an Ethernet switching hub or repeater hub.

## 2.5 Providing Power to VIP

To provide AC power to VIP complete the following steps:

1. Turn the power switch on the rear panel of VIP to the off position.
2. Connect one end of the power cord that came with VIP to the power receptacle on the rear panel.
3. Connect the other end of the power cord to an AC power outlet.
4. Turn the power switch on. VIP will perform power on self-test. After completing the self-test, the SYSTEM LED blinks continuously and the TIM indicators on the front panel will turn on.

## 2.6 Assigning IP address to VIP

The IP address is the unique logical address identifying each IP node, such as VIP, on an IP network. An IP address is a 32-bit number expressed as four decimal numbers from 0 to 255 separated by periods. VIP needs a static IP address and be aware of the subnet mask and default gateway (typically a router) of your network to be able to send to and receive data from the IP network. Consult your network manager to obtain a unique and static IP address for VIP, the IP subnet mask and default gateway of your network, and fill out the work sheet in Appendix D before configuring the gateway. Procedures for assigning IP address, default gateway and subnet mask is available in Chapter 4.

## Chapter 3 VIP Concepts

VIP enables the transmission of voice and fax traffic over any IP network by digitizing voice and fax signals, encapsulating the information within IP packets, and then sending the packets across the IP network

### 3.1 How VIP Operates

1. The TIM inside VIP digitizes analog voice signals at 8 Kbps.
2. VIP system software handles the:
  - Capture of telephone number presented as DTMF tones.
  - Mapping the telephone number to the IP address of remote VIP.
  - Setting up calls with remote VIPs utilizing SIP call control protocol.
  - Digitizing, compressing and encapsulating the voice into IP packets and transmission of the IP packets onto the Ethernet LAN.
3. A router attached to the LAN forwards the IP packets across the WAN, where they will be received by another VIP at the remote.
4. The process is reversed at the remote VIP.

### 3.2 ATPM

To allow you to easily dial a telephone or fax on the network, VIP maps a series of dialed digits to the IP address of the remote VIP whose phone or fax you are calling. This mapping information is contained in a database inside each VIP called the dial plan.

Based on the dial plan the Address Translation and Parsing Manager (ATPM) inside VIP translates telephony numbers to IP addresses of remote VIPs. The ATPM collects telephone number dialed by users, decides whether the dial string is part of the dial plan and, if it is, maps it a remote VIP. When the call is set up to the destination, a substring of the original dial string will be sent along to the remote VIP.

### 3.3 Destination

The destination is where a call is terminated. Typically, for inbound calls from IP network, VIP terminates the call at one of the telephony ports. The destination for the call is the telephony port where the call terminated. For calls initiated from telephony ports, VIP forward the call to a remote VIP via IP network, and the remote VIP terminal the call. The destination of the call is the remote VIP.

### 3.4 Hunt Group

Instead of directly mapping a phone number to a destination, the ATPM first maps the phone number to a group of destinations known as a Hunt Group. A hunt group is a group of destinations that are equivalent. For example, the customer support group of a company might have 20 people who can handle support calls. Access to customer support is through a single phone number but the next available support person is actually connected upon each incoming call. These 20 phones would be configured as a hunt group. A hunt group consists of a phone number and a list of destinations (members of the group). When an incoming phone number matches the phone number of the hunt group, VIP attempts to terminate the call at each of the destinations in the hunt group, one at a time until a call is successfully completed.

Every destination that can be reached by dialing a phone number is a member of at least one hunt group. When an address is presented to ATPM for lookup, the output is a hunt group ID number. As a second step, the hunt group ID is presented to ATPM to get the list of members. To effectively bypass the hunt group feature, simply make a unique hunt group for each destination and one member in each hunt group.

### 3.5 Dial Plan

The dial plan is a database inside VIP for the ATPM to map telephony numbers users dialed to the IP address of remote VIPs. The dial plan consists of the destination table, hunt group table and the address table. Users need to setup these tables, so that VIP knows how to setup calls with remote VIPs.

#### Address Table

The address table maps a phone number to a hunt group. The table contains entries that specify the following information:

- Telephone number
- The hunt group the phone number maps to.
- The minimum number of digits to collect before the ATPM starting address lookup.
- The maximum number of digits the ATPM collects before it considers the dial string is complete.
- Number of digits forward to the destination.

Address table sample:

Address Entry	Hunt Grp_Id	Min. Digits	Max. Digits	Prefix strip	Prefix Address
200	1	3	3	0	None
201	3	3	3	0	None
899	11	3	3	0	None
8	11	3	3	0	None
0	5	1	1	0	None
03	5	10	10	2	"0"



### Hunt Group Table

The hunt group table maps a hunt group to a list of destinations.

Hunt group sample

Group id	Type	#Members	Member ids
1	2	1	1
3	2	1	2
5	2	1	4
11	2	1	11

### Destination Table

The destination table maps a destination to a telephony port or the IP address of a remote VIP.

Destination table sample

Dest id	Mode	Destination
1	Local	PORT = 0
3	Local	PORT = 2
5	Local	PORT = 4
11	SIP	Dest = 192.168.0.55/ 5060
12	DNS	Dest = planetvip.dyndns.org /5060

## 3.6 DTMF Relay

Voice from PSTN is compressed by VIP before sending across the IP network and then decompressed by the destination VIP. The voice coders supported by VIP are designed for ideally compressing and decompressing human voice. If the compression / decompression process is performed on DTMF tone which needs to be conveyed across IP network, distortion might be too significant to be not cognizable in the receiving end. To overcome the shortcoming that the voice coders cannot perfectly encode DTMF tone, VIP encodes DTMF tone into special packets. The packets are then sent to the destination VIP via a separate IP connection. The destination VIP decodes the packets, generates the DTMF tone, and then sends the tone to the PSTN. The way VIP handles DTMF tone is so called DTMF relay.

VIP handles DTMF relay per SIP specifications. Certain third party VoIP devices may handle DTMF relay per IMTC standard. For VIP to interoperate with those VoIP devices, users need to specify which remote VoIP devices uses IMTC conforming DTMF relay technique. Refer to CLI command for detailed information on how to select DTMF relay mode.

## 3.7 Voice Codecs

Voice codecs supported by VIP include G.711, G.723.1 5.3kbps, G.723.1 6.3kbps and G.729 AB. When setting up a call, two VIP automatically negotiate with each other until an agreed upon codec is determined.



## Chapter 4 Configuring VIP from a Web Browser

This chapter explains procedures for configuring VIP from the web browser.


### 4.1 Http setting mode

This section describes the processes for setting up Internet Telephony Gateway once it has been installed. Microsoft Explorer version 4 or higher, or Navigator version 4.5 or higher can be used in this section to view and change parameters.


#### PC Setup

In order to configure VIP, PC needs to have TCP/IP protocol and a compatible IP Address.


1. Connect VIP to network with a RJ-45 UTP cable. Power it on.
2. Find a PC, for example, Windows 2000. Under Windows 2000, select the *Network Neighborhood* icon on the desktop, then select *Properties*. We will see a screen like below:



3. If a line like the one highlighted ("TCP/IP -> Network Card") is not listed, select *Add-Protocol-Microsoft-TCP/IP-OK* to add it.
4. Select *Properties* for the "TCP / IP -> Network card" entry. You will see a screen like the following:



5. On the *IP Address* table, enter values as follows:
  - *Specify an IP address* set ON.
  - *IP Address*: 192.168.0.2
  - *Subnet Mask*: 255.255.255.0Restart your PC and Start your WEB browser.
6. In the *Address* box, enter the following:  
<http://192.168.0.1> (default IP address of the Voice Gateway)
7. Press enter to confirm and you should find the screen below.



8. The User Name is **administrator** (all lower case). Password is **123**. Both **administrator** and **123** are default strings from factory). For security reasons, please change and memorize the new password after this first setup.
9. Click "OK". The main screen will appear as below.



### 4.1.1 Dial Plan/ Dial Settings

#### Main Menu Function Briefings

1. **Dial Plan Settings**, which helps you configure the dial plan. You should complete the dial plan work sheets before working on this menu.
2. **View System Configurations**, which includes the specific information related to version, network, SIP, coder, and the channel of the gateway you are using.
3. **Configure System Settings**, which allows you to modify the system parameters as you wish.

Select Main Menu\Dial Plan Settings, we can find the following Dial Plan Menu.



<b>Dial Settings</b>	The Setup screen of the Dial Plan including: <ul style="list-style-type: none"> <li>• <b>Telephone Settings</b>, which allows one to Add, Delete, Find, or List telephone numbers.</li> <li>• <b>Hunt Group Settings</b>, which allows one to Add, Delete, Find, or List hunt group settings</li> <li>• <b>Destination Settings</b>, which allows one to Add, Delete, Find, or List destination settings</li> </ul>
<b>Common Dial Parameters</b>	Defines the desired total dial time, first digit wait time, inter-digit wait time, and the termination digit
<b>Clear Dial Plan</b>	Clears all telephone numbers, hunt groups, and destinations settings, for both old and new ones
<b>Restore Dial Plan</b>	Retrieves all dial plan settings from the flash while temporary settings will be cleared
<b>Store to NVRAM</b>	Stores all settings that you have specified permanently

#### 4.1.1.1 Phone number

Please select **Main Menu\Dial Plan\Phone/Hunt Group/Destination Settings**, we can find **Phone/Hunt Group/Dest. Setting Menu**. We are doing VIP telephone address table management.

We can add (delete, find or list) desired telephone number mapping to hunt group at this menu.



<b>Telephone Number</b>	Telephone number to match. This is only part of the total dialed string.
<b>Hunt Group ID</b>	For each hunt group ID, you need to assign it a unique identifier between 0 and 99.
<b>Min. Digits</b>	Minimum number of digits to be collected before the ATPM starting matching the dial string with entries in the address table.
<b>Max. Digits</b>	Maximum number of digits to be collected before the ATPM starting matching the dialed string with entries in the address table.
<b>Strip Length</b>	The number of digits to be stripped at the beginning of the collected dial string before forwarding the string to the destination.
<b>Append Prefix</b>	(Optional) Digit to be added before the beginning of the collected dial string before forwarding it to the destination.

**Add Telephone Numbers**

Telephone Number 0:

Hunt Group ID:

Min. Digits:

Max. Digits:

Strip Length:

Append Prefix:

To list the phone numbers, click on "List" and select "Telephone", the screen will displayed as below:





### List All Phone Numbers Result:

<

Phone #	Hunt Group ID	Min. Digits	Max. Digits	Strip	Prefix
0	9	0	10	1	None
01	9	0	4	1	None
02	9	0	4	1	None
03	9	0	4	1	None
05	9	0	4	1	None
06	9	0	4	1	None
09	9	0	10	0	0
1	2	0	1	0	None

To delete / find a Telephone, select the option and telephone, you can key in the phone number to find or delete. The right bottom screen will show the result.





**PLANET**  
Networking & Communication  
Internet Telephony Gateway

Main Menu  
Dial Plan Settings  
Dial Settings

Find  
Telephone  
Select

Help

### Find A Telephone Number

Find Telephone Number:

### Find Telephone Number Result:

Phone #	Hunt Group ID	Min. Digits	Max. Digits	Strip	Prefix
205	5	1	3	3	None

#### 4.1.1.2 Hunt Group

Please select Main Menu\Dial Plan\Phone/Hunt Group/Destination Settings, we can find Phone/Hunt Group/Dest. Setting Menu. We are doing VIP hunt group table management.



**PLANET**  
Networking & Communication  
Internet Telephony Gateway

Main Menu  
Dial Plan Settings  
Dial Settings

Add  
HuntGroup  
Select

### Add Hunt Group IDs

Hunt Group ID:

Destination ID 0:

We can add (delete, find or list) desired hunt group ID mapping to destination ID at this menu. If you want to make the port calls to the secondary receiver, you can click one "More Destinations" you can then add the second, third receiver if the desired port/phone is busy.

We can add (delete, find or list) desired hunt group ID mapping to destination ID at this menu.



### 4.1.1.3 Destination IP/ Destination Channel

Please select Main Menu\Dial Plan\Phone/Hunt Group/Destination Settings, we can find Phone/Hunt Group/Dest. Setting Menu. We are doing VIP destination table management. One is Remote Destination IP, one is Remote Host Name and the other is Local Destination Channel.

The screenshot displays the 'Add Remote Destination ID' configuration page in the Planet Internet Telephony Gateway web interface. The left sidebar contains navigation links: 'Main Menu', 'Dial Plan Settings', 'Dial Settings', 'Add', 'Remote\_Destination\_IP', 'Select', and 'Help'. The main content area has the following fields and controls:

- Destination ID:** Input field containing '12'.
- IP Address:** Input field (empty) followed by 'or'.
- Host Name:** Input field containing 'testvip.planet.com.tw'.
- Note:** Red text stating: 'Note: If both IP Address and Host Name are defined, only IP Address will be recognized.'
- Company/Location:** Input field containing 'PLANET Technology'.
- Buttons:** 'Complete' and 'Clear All Changes'.

Below the configuration area, the 'Add Destination ID Result:' section shows a confirmation message: 'The Destination ID 12 is bound to Host Name testvip.planet.com.tw for H.323 VoIP application.'

The screenshot displays the PLANET Internet Telephony Gateway web interface. On the left is a blue sidebar with the PLANET logo and navigation links: Main Menu, Dial Plan Settings, Dial Settings, Add (with a dropdown menu showing Local\_Destination\_Channel and Select), and Help. The main content area is light blue and titled 'Add Local Destination ID'. It contains two input fields: 'Destination ID' with the value '13' and 'Channel Number' with the value '1'. Below these fields are two buttons: 'Complete' and 'Clear All Changes'. At the bottom of the main area, the text 'Add Destination ID Result:' is followed by a message: 'The Destination ID 13 is bound to local channel 1.'

We can add (delete, find or list) desired destination ID mapping to Remote Destination IP, Domain Name or Local Destination Channel at this menu.

Please back to Dial Plan Menu.

#### 4.1.1.4 Common Parameter

Please select Main Menu\Dial Plan\Common Parameter Settings

**Common Dial Parameters Settings**

Total Dial Time:  ms  
First Digit Wait Time:  ms  
Inter Digit Wait Time:  ms  
Termination Digit:

**Current Common Parameter Settings Are:**

System Info: Total dial time = 30000ms, First digit wait = 10000ms, Interdigit wait = 5000ms, Dial term digit = None

This Common Parameter Settings is the same as previous ATPM system parameters description. .

### 4.1.2 Clear DialPlan

Please select Main Menu\Dial Plan\Clear All Dial Plan Settings

**Clear All Dial Plan Settings**

**Caution!** Clear Dial Plan Settings will clear ALL the settings you made before.

However, the 'Clear All' is only temporary if you do not store to the Flash Memory afterwards.

That is, to restore all the settings from the Flash Memory, you need only to click on the 'Restore Dial Plan' on the left frame, or to reboot the system (the settings can be restored ONLY IF YOU DID NOT STORE the entries).

Are you sure?


**Clear All Dial Plan Settings will clear all the settings you made before.** However, the 'Clear All' is only temporary if you do not store to the Flash Memory afterwards.

That is, to restore all the settings from the Flash Memory, you need only to click on the 'Restore All Entries' on the left frame, or to reboot the system (the settings can be restored ONLY IF YOU DID NOT STORE the entries).

### 4.1.3 Restore DialPlan

#### Please select Main Menu\Dial Plan\Restore All Dial Plan Settings

Retrieve all dial plan settings from the flash memory. All temporary settings will be cleared.



### 4.1.4 Save to NVRAM

#### Please select Main Menu\Dial Plan\ Save to NVRAM


Ready to store Dial Plan settings to Flash Memory



Please Back To Main Menu

## 4.2 View System Configurations

Please select Main Menu\View System Config.



**View System Config. Function Briefings.** Six options available

1. **Firmware Version Information**, which shows the versions of each firmware component
2. **Network Settings**, which shows the IP-related settings, and the status of associated management tools
3. **SIP Parameter Settings**, which shows the SIP-related parameters associated with the gateway
4. **Coding Profile Information**, which shows the configurations related to a specific coding profile
5. **Channel Settings**, which shows the configurations associated with a specific channel
6. **Network Connection**, which shows type of connection enabled in VIP

### 4.2.1 Firmware Version Information

Please select Main Menu\View System Config.\Firmware Version Info.

This will show current VIP firmware version information.

Firmware Information:

```
Internet Telephony Gateway (PLA) Version: s1.0
Boot Loader Version: 4.13
RTOS Version: 2.5.0/BE
SIP Stack Version: 2.1.1.4
DSP image Version: 8.1.2.1.
TSG Version: R8.0 Gateway (Build 4)
```

### 4.2.2 SIP Parameters

Please select Main Menu\View System Config.\SIP Parameter Settings

The SIP Parameters Settings:

SIP Addr Configuration:  
UDP ctl addr = 192.168.0.99/5060  
RTP data addr = 192.168.0.99/2070

Domain name server = 168.95.192.1  
Info switch is off  
nat\_call is on  
auto\_reg is off  
outboundproxy : None

### 4.2.3 Voice Coder Type


**Please select Main Menu\View System Config.\Coder Type**

The Voice Coder For Each Line Module:

Voice coder is G.723 for Line Module 1.

### 4.2.4 Voice Coder Information

**Please select Main Menu\View System Config.\Coder Information**



The screenshot displays the web interface for the Planet Internet Telephony Gateway. On the left is a blue sidebar with the Planet logo and a list of menu items: Dial Plan Settings, View System Configuration, Firmware Version, SIP Parameters, Voice Coder Type, and Coder Information. The main content area has a light blue header with the title "Coder Selection". Below the header, the text "Please Select A Desired Coder Below:" is followed by a dropdown menu showing "G.723" and a "Select" button.

## 4.2.5 Channel Parameters

**Please select Main Menu\View System Config.\Channel Parameters**

This command can show the desired channel setting of VIP.



## 4.2.6 Network Connection

**Please select Main Menu\View System Config\Network Connection**

This command can display the type of connection currently enabled in VIP.

### 4.2.6.1 DHCP Settings

Display current DHCP status in VIP



DHCP Status

DHCP : disable.

[Click here](#) to change DHCP Status

**Command Line Interface reference:**

#### net set dhcp

**net set dhcp** command configures VIP to be DHCP client in order to obtain TCP/IP related parameters from ISP while VIP is deployed in DHCP environment.

#### Syntax Description

<i>on</i>	Turn on DHCP client
<i>off</i>	Turn off DHCP client

**If DHCP client is enabled/disabled, VIP has to be rebooted to make the DHCP service started/stopped.**



### 4.2.6.2 PPPoE Settings

Display current PPPoE status in VIP



PPPoE Status

- PPPoE : disable.
- User name : .
- password : .
- Fixed IP : 0.0.0.0

[Click here](#) to change PPPoE Status



PPPoE Settings

- PPPoE :
- User Name :
- Password :

OK

**Command Line Interface reference:**

#### net set pppoe

The **net set pppoe** command configures PPPoE related parameters while VIP is deployed in PPPoE environment.

#### Syntax Description

<b>on</b>	Turn on PPPoE client
<b>off</b>	Turn off PPPoE client
<b>username</b>	PPPoE connection username provided by ISP

<i>password</i>	PPPoE connection password provided by ISP
<i>fix_ip</i>	Fixed IP address provided by ISP

**If PPPoE client is enabled/disabled, VIP has to be rebooted to make the PPPoE service started/stopped.**

### 4.2.6.3 DDNS Settings

Display current DDNS status in VIP




Dyn-DNS Status

- DDNS : disable.

Dyn-DNS HOST SETTINGS :

- dyndns serv= dyndns
- host = planetvip
- user = XXXXXXXXXX
- password = XXXXXXXX

[Click here](#) to change DDNS Status



Dynamic DNS Settings

- Dyn-DNS :
- Server Name :
- Host Name :
- User Name :
- Set User Password :

OK

- DynDNS setting completed.
- DynDNS server name setting OK.
- DynDNS host name setting OK.
- DynDNS user name setting OK.
- DynDNS user password setting OK.

[Store the settings.](#)

Be certain that PPPoE has enabled.

**Command Line Interface reference:**

**net set dyndns**

DDNS service can help users to find each other in dynamic/static IP environment, and enable two VIPs call each other with registered host names. To be fully functional, DNS server **MUST** be added into SIP configuration while DDNS service is enabled.

DDNS clients supported in VIP are [www.dyndns.org](http://www.dyndns.org) and [www.dtdns.com](http://www.dtdns.com) currently.

If VIP DDNS client is enabled, users **MUST** register a DDNS name from the sites listed above before proceeding any further.

#### Syntax Description

<i>on</i>	Turn on DDNS client
<i>off</i>	Turn off DDNS client

**If DDNS client is enabled, VIP has to be rebooted to make the DDNS service effective.**

**sub commands:**

**set dyndns add [serv\_name] [host\_name] [user\_name] [password]**

Adding applied DDNS name into VIP database.

**Note:** if multiple DDNS names are inserted, only the first one will be updated.

#### Syntax Description

<i>serv_name</i>	DDNS service server ( <b>MUST</b> be “ <b>dyndns</b> ” or “ <b>dtdns</b> ” for now)
<i>host_name</i>	DDNS name registered from DDNS service provider
<i>user_name</i>	Username used to update DDNS account
<i>password</i>	Password used to update DDNS account


**set dyndns delete [host\_name]all**

Delete specified or all DDNS name(s) configured in VIP.

**DDNS related parameters must be saved via commands: “config activate, config store” in order to be effective.**

## 4.3 Configure System Settings

Please select Main Menu\Configure System Settings



**System Config. Settings Function Briefings**

1. **IP Settings**, which allows one to set the gateway's IP address, its subnet mask, and its Default Gateway IP address.
2. **SIP Parameter Settings**, which allows one to set the SIP parameters, such as communication ports, SIP registration settings, outbound proxy server settings ..... etc.
3. **Channel Parameter Settings**, which allows one to set parameters associated with each port, such as transmission/receive gains, comfort noise level, etc.
4. **Voice Coder Type Selection**, which allows one to set the desired coder type, such as G.711, G.723 or G.729A, in a per line module base.
5. **Network Connection**, which allows user to buildup Internet connection according to different connection type, currently connection types supported in VIP are DHCP, PPPoE connections.

### 4.3.1 IP Settings

Please select Main Menu\Configure System Settings\IP Settings

**IP Address Settings**

- IP Address:
- Subnet Mask:
- Default IP Gateway Address:   
(If a Default IP Gateway is not desired, please enter 0.0.0.0)

Save The Changes      Clear The Changes

This screen can setup your VIP IP Address, Subnet Mask and Default IP Gateway Address. These values will be valid after VIP reboot.

### 4.3.2 SIP Parameters

Please select Main Menu\Configure System Settings\SIP Parameter Settings

There are SIP Configuration Settings, Registration Server Settings, Outbound Proxy Server configurations, Domain name server configurations, and Other settings..

#### 4.3.2.1 SIP Configuration Settings

Please select Main Menu\Configure System Settings\SIP Parameter Settings\SIP Configuration Settings

**Address Port Configuration Settings**

- UDP Port Number:
- RTP Port Number:

OK

### 4.3.2.2 SIP Registration Server settings

Please select Main Menu\Configure System Settings\SIP Parameter Settings\SIP Registration Server Settings


The screenshot shows the 'Registration Server Settings' page in the Planet SIP Gateway web interface. On the left is a blue sidebar with the Planet logo and a navigation menu. The main content area is light blue and contains the following elements:

- Registration Server Settings** (Section Header)
- Buttons:  Add  Del
- Configuration items:
  - Expire Time :  seconds
  - Local Phone Numbers :
- Information of Registration Server** (Section Header)
- A table with 4 columns: Registration Server IP Address, Port number, User Name, and Password. Each column has a corresponding empty text input field below it.
- An  button centered below the table.



### 4.3.2.2 SIP Outbound Proxy Server Settings

Please select Main Menu\Configure System Settings\SIP Parameter Settings\SIP Outbound Proxy Server Settings




The screenshot shows the 'Outbound Proxy Server Settings' page. On the left is a blue sidebar with the 'PLANET' logo and a menu. The main content area has a title 'Outbound Proxy Server Settings' and a table with two columns: 'Index' and 'Outbound Proxy Server IP Address', and a 'Port number' column. The table contains one row with the index '1'. Below the table is an 'OK' button.

Index	Outbound Proxy Server IP Address	Port number
1	<input type="text"/>	<input type="text"/>

OK

### 4.3.2.3 SIP Domain Name Server Settings

Please select Main Menu\Configure System Settings\SIP Parameter Settings\SIP Domain Name Server Settings




The screenshot shows the 'Domain Name Server Settings' page. On the left is a blue sidebar with the 'PLANET' logo and a menu. The main content area has a title 'Domain Name Server Settings' and a single configuration item: 'Domain Name Server:' followed by a text input field. Below the input field is an 'OK' button.

Domain Name Server:

OK



#### 4.3.2.4 Other SIP Settings



## Chapter 5 Troubleshooting Tips

This section provides solutions for problems you may possibly encounter while installing and connecting your Internet Telephony Gateway.

### Power (PWR) LED is not illuminate

1. Check the power adapter connection.
2. If the power adapter or power cord is connected to the gateway, check that the cord is securely plugged into the power socket on the rear of the console.
3. Check that the other end of the power adapter or power cord is securely plugged into the power outlet.
4. If both ends of the power cord are properly connected and there is still no power, the gateway might have a faulty power outlet, power adapter, or power cord.
5. Change to another power outlet or obtain another power adapter or power cord.

### LNK LED is not illuminate

1. Check VIP was connected correctly:
  - a. Powered on
  - b. Correctly connected
2. Check if the cable connect to an end device is a standard straight through network Ethernet cable.
3. Make sure connectors at both end are securely seated.
4. Check VIP IP setting is correct

### There is no dial tone when pick up the phone

1. Check line module port LED illuminate
2. Check the RJ11 telephone line is connected correctly between phone set and line module port

There is an out-of-service tone when dialing destination phone number

1. Check the dial plan setting (address table, hunt group table and destination table) at the destination phone number

### There is no connected tone when dialing destination phone number

1. Check the IP network (Ethernet cable, Ethernet port and GW IP setting) is connected correctly
2. Check the destination VIP and phone is available

### Final Steps

If the procedures in this section have not solved the problem, reset the gateway several times by turning the power on and off. If the problem still exists, contact customer support.

## Chapter 6 Command Line Interface

VIP has a built-in command line interpreter and provides users a Command Line Interface (CLI). You can configure VIP by entering commands from the CLI.

You can access the CLI from a VT-100 terminal or terminal emulator connected to the RS-232 port on the front panel or through a Telnet session.

### 6.1 Connection through Serial Port

The serial port of VIP is fixed at the following settings:

Baud rate	19,200
Number of data bit	8
Parity check	None
Number of stop bit	1
Flow control	None

To access VIP through the RS-232 serial port, follow the steps below:

1. Insert one end of the serial cable that came with VIP into the 9-pin RS-232 port (labeled User Console) on the front panel.
2. Insert the other end of the cable into your terminal's serial port.
3. Configure the terminal so that settings for baud rate, number of data bit, parity check, number of stop bit and flow control capability exactly match VIP's serial interface. (Refer to your terminal documentation for more information about setting up these features).
4. Press <Return> from the terminal.
5. VIP displays the following prompts on the terminal and you are ready to access the CLI then.

EVIP>

### 6.2 Connection through Telnet

To use Telnet, you must have previously set the IP address using the **net set ip** command for VIP. Refer to the section describing the **net set** command later in this chapter for information about setting the IP address. Up to two sessions through Telnet are possible. To access VIP from a remote host with Telnet, perform the following tasks:

Task	Prompt	Type
From the remote host, enter the <b>telnet</b> command followed by the IP address of VIP you want to access.	None	<b>telnet ip_addr</b>
When VIP prompts " <b>Login:</b> ", enter the user name " <b>administrator</b> "	Login:	<b>administrator</b>
When VIP prompts "Password:", enter the password. The default password is " <b>123</b> " unless a password was previously established using the <b>net set user_pw</b> command (Refer to the section describing <b>net set user_pw</b> command later in this chapter for details about the setting password).	Password:	<i>password</i>

Upon successfully entered the password, VIP displays greeting message and the following prompts and you are ready to access the CLI commands.

ITG>

### 6.3 Command Help

Help for commands is provided by the CLI. Type **help** to see a listing of the top-level commands. On most cases, if you enter a command using the wrong number of arguments or inappropriate arguments, the CLI will give further usage.

### 6.4 Designating IP Address

Some commands require an IP address, which must be designated in a standard format. The IP address format is 32 bits, written as four octets separated by periods (dotted decimal format) that are made up of a network section, an optional subnet section, and a host section, as shown in the following example:

192.168.0.1

### 6.5 Designating Port Number

Some commands require a telephony port number. VIP designates the first port telephony interface as port number 0, the 2<sup>nd</sup> port as port number 1 and so on.

## 6.6 Command Reference

The following table list the CLI command in alphabetic order.

Command	Description
atpm	Dial plan management command
clrscr	Clear screen
config	Configuration management command
download	Download new revision code image from TFTP server
help	Display help screen
net	Set or display network parameters
ping	Ping another Internet host
set	Set system configuration
tel	Set or display telephony port options

For the ease of understanding and explaining these commands, the commands are categorized into the following command sets and the following sections explaining each set of the commands.

Command Set	Commands	Function
Utility	clrscr download help ping	General purpose utility commands
Network	net	Commands for setting or displaying network related parameters
Configuration management	config show set	Commands for configuring VIP or displaying configuration
Dial plan management	atpm	Commands for setting or displaying dial plan
Telephony	tel	Commands for setting or displaying telephony related options

## 6.7 Utility Commands

### clrscr

The **clrscr** command to clear the screen

#### Syntax Description

This command has no arguments or keywords

### download

Use the **download** command to enter download mode for reading code image from a TFTP server and program it to flash memory. Refer to 0 for detailed information on how to upgrade the system software.

#### Syntax Description

This command has no arguments or keywords

#### Note

This command is available from serial interface. It is not available from Telnet unless the TFTP loader is version 3.00 or higher.

### help

The **help** command lists the top-level commands.

#### Syntax Description

This command has no arguments or keywords

### ping

The **ping** command sends Internet Control Message Protocol (ICMP) echo request packets to another node on the network.

**ping** *host\_ip\_addr*

**ping -s** *host\_ip\_addr count/timeout*

#### Syntax description

<b>-s</b>	Causes ping to send one datagram per second, printing one line of output for every response received.
<b><i>host_ip_addr</i></b>	The IP address or IP alias of the host.
<b><i>count</i></b>	(Optional) The number of packets to send
<b><i>timeout</i></b>	(Optional) Timeout value for the ping in millisecond

## 6.8 Network Commands

### net reset

Use the **net reset** command to reset VIP. The CLI will prompt you to confirm the command before resetting VIP.

#### Syntax Description

This command has no arguments or keywords

### net set gateway ip\_addr

Use the **net set gateway** command to assign a default gateway (router) for VIP. The default gateway routes packet data outside of your IP subnet.

#### Syntax description

<b>ip_addr</b>	The IP address of the default gateway. IP address of 0.0.0.0 stands for no default gateway.
----------------	---

#### Note

The new setting will not take effect until VIP is reset.

### net set http {on|off}

VIP allows you enable or disable its built-in HTTP server. Use the **net set http** command to enable or disable the HTTP server.

#### Syntax description

<b>on</b>	Enable HTTP server. This allows users to access VIP from web browser.
-----------	---

<b>off</b>	Disable HTTP server.
------------	----------------------

### net set telnet {on|off}

VIP allows you enable or disable its built-in Telnet server. Use the **net set telnet** command to enable or disable the Telnet server.

#### Syntax description

<b>on</b>	Enable Telnet server. This allows users to access VIP from web browser.
-----------	---

<b>off</b>	Disable Telnet server.
------------	------------------------

### net set ip ip\_addr

Use the **net set ip** command to assign a static IP address to VIP.

#### Syntax description

<b>ip_addr</b>	The IP address of VIP.
----------------	------------------------

#### Note

The new IP address will not take effect until VIP is reset.

### **net set ip\_preced ip\_preced**

VIP allows you to set the 8-bit Service Type field in the IP header for all the voice packets it sends out. The Service Type field is broken down into five subfields, among which four subfields are user configurable. This command is used to set these subfields.

```
net set ip_preced ip_preced [d] [t] [r]
```

#### Syntax description

<b>ip_preced</b>	The 3-bit PRECEDENCE subfield ranging from 0 through 7.
<b>d</b>	The <i>D</i> bit subfield, either 0 or 1.
<b>t</b>	The <i>T</i> bit subfield, either 0 or 1.
<b>r</b>	The <i>R</i> bit subfield, either 0 or 1.

#### Default

*ip\_preced*: 0

*d*: 0

*t*: 0

*r*: 0

#### Notes

The new setting will not take effect until the VIP is reset.

### **net set mask ip\_mask**

Use the **net set mask** command to set the IP subnet mask for VIP.

#### Syntax description

<b>ip_mask</b>	The subnet mask of your network.
----------------	----------------------------------

#### Note

The new setting will not take effect until VIP is reset.

### **net set speed {10|100|auto}**

VIP allows you set the link speed for its Ethernet interface. Use the **net set speed** command to set the Ethernet link speed.

#### Syntax description

<b>10</b>	Fixed the Ethernet speed at 10 Mbps
<b>100</b>	Fixed the Ethernet speed at 100 Mbps



<b>auto</b>	Enable the 10/100 Mbps auto-negotiation capability.
-------------	---

### **net set user\_pw password password**

Use the **net set user\_pw** command to change the password for Telnet user.

#### **Syntax description**

<b>password</b>	The new password. The password must be equal to or less than 7 alphanumeric characters. It must be identically typed twice for VIP to be certain about the new password.
-----------------	--

### **net show**

The **net show** command displays all the network settings.

#### **Syntax Description**

This command has no arguments or keywords

#### **Example**

The following example shows how to display network settings:

```
ITG> net show <Enter>
***** Net Parameters *****
PPPoE =          disabled
DYN DNS =        enabled
DHCP client =    disabled
Configured IP address = 192.168.0.99.
Configured IP subnet mask = 255.255.255.0.
Default gateway IP address = 192.168.0.253.
Current active IP address = 192.168.0.99.
Current active subnet mask = 255.255.255.0.
IP precedence =   0 0 0 0
Ethernet MAC address = 00-30-4f-00-29-20
Ethernet speed setting = 10/100 Mbps auto-negotiation
USER password =   123
HTTP server =     enabled
Telnet server =   enabled
Ethernet speed setting = 10/100 Mbps auto-negotiation
USER password =   123
```

```

HTTP server =      enabled
Telnet server =    enabled

*****
ITG>

```

## net show hwstat

The **net show hwstat** command displays the hardware configuration of VIP.

### Syntax Description

This command has no arguments or keywords

### Example

The following example shows how to display hardware configuration:

```

ITG>net show hwstat <Enter>
***** Hardware Configuration *****
Flash:   type-MX29L1611 32 sectors 64 KB/sector
RAM:     8 MB 512K x 16
LAN:     100 Mbps half duplex. Link UP
TIM slot A: type-FXO2S2 DSP-C5409 codec-PEB2466 Diag-OK
*****
ITG>

```

## net set pppoe

The **net set pppoe** command configures PPPoE related parameters while VIP is deployed in PPPoE environment.

### Syntax Description

<b>on</b>	Turn on PPPoE client
<b>off</b>	Turn off PPPoE client
<b>username</b>	PPPoE connection username provided by ISP
<b>password</b>	PPPoE connection password provided by ISP
<b>fix_ip</b>	Fixed IP address provided by ISP

## net set dhcp

**net set dhcp** command configures VIP to be DHCP client in order to obtain TCP/IP related parameters from ISP while VIP is deployed in DHCP environment.

### Syntax Description

<i>on</i>	Turn on DHCP client
<i>off</i>	Turn off DHCP client

### net set dyndns

DDNS service can help users to find each other in dynamic/static IP environment, and enable two VIPs call each other with registered host names. To be fully functional, DNS server **MUST** be added into SIP configuration while DDNS service is enabled.

DDNS clients supported in VIP are [www.dyndns.org](http://www.dyndns.org) and [www.dtdns.com](http://www.dtdns.com) currently.

If VIP DDNS client is enabled, users **MUST** register a DDNS name from the sites listed above before proceeding any further.

#### Syntax Description

<i>on</i>	Turn on DDNS client
<i>off</i>	Turn off DDNS client

#### sub commands:

**set dyndns add [serv\_name] [host\_name] [user\_name] [password]**

Adding applied DDNS name into VIP database.

**Note:** if multiple DDNS names are inserted, only the first one will be updated.

#### Syntax Description

<i>serv_name</i>	DDNS service server ( <b>MUST</b> be “ <b>dyndns</b> ” or “ <b>dtdns</b> ” for now)
<i>host_name</i>	DDNS name registered from DDNS service provider
<i>user_name</i>	Username used to update DDNS account
<i>password</i>	Password used to update DDNS account

**set dyndns delete [host\_name]all**

Delete specified or all DDNS name(s) configured in VIP.

#### Syntax Description

This command has no arguments or keywords.

## 6.9 Configuration Management Commands

The configuration management commands allow the user to set values for system configuration parameters. In addition, it provides mechanisms to allow a user to control when new parameter values are put in use.

The CLI maintains three areas where the parameters are stored:

- Temporary
- Active
- Non-volatile Storage (NVS)

When a **set** command is entered and processed, it changes the parameter value in the Temporary area. This does not affect current operation of VIP, which is using the values in the Active area. The **config activate** command moves configuration data from the Temporary area to the Active area, where it can actually be used. Thus a user can make multiple changes in the Temporary area using **set** commands, then put them into use with a single **config activate** command. (Note that the **config activate** command may only be used between calls, and will usually tear down any in-progress calls when invoked.)

Configuration data in the Active area is only available while VIP remains in operation. If VIP is reset, the Active area is reloaded from the data stored in NVS. Data in the Active area may be saved to NVS by entering the **config store** command.

For most of the SIP parameter, settings won't take effect until VIP reset. To ensure the SIP setting to take effect, it is recommended to reset VIP after changing the settings using the **set** command.

In summary:

- Use **set** commands to make configuration parameters changes in the Temporary area
- Use the **config activate** command to move the new values into the Active area, available for use
- Use the **config store** command to save the new Active values in NVS
- Reset VIP after changing SIP settings and storing the setting to NVS.

### config {activate|store|erase}

Use the **activate** command to manage the configuration data. A sequence of **set** command is typically preceded by and/or followed by the **config** command for the **set** command to become active.

#### Syntax description

<b>activate</b>	Move the configuration from temporary area to active area.
<b>store</b>	Store the active configuration data into non-volatile storage.
<b>erase</b>	Erase the configuration from non-volatile storage.

### SIP related commands

## show sip

The **show SIP** command displays the settings of the parameter that are related to SIP signaling protocol.

### Syntax Description

This command has no arguments or keywords

### Example

The following example shows how to display the SIP parameters:

```
ITG>show sip
SIP Addr Configuration:
  UDP ctl addr    = 192.168.0.99/5060
  RTP data addr  = 192.168.0.99/2070
Domain name server = 168.95.192.1
Info switch is off
nat_call is on
auto_reg is off
outboundproxy : None
```

## show sip reg

- Displays the information of registration

## show sip cfg

- Displays the configuration of registration

## show sip proxy

- Displays the configuration of proxy server

## show sip dns\_ip

- Displays the configuration of DNS server

## show sip info\_sw

- Displays the information switch

## show sip auto\_reg

- Displays auto-registration on/off when reboot

### show sip nat\_call

- Displays nat\_call switch

### show sip outboundproxy

- Displays the outbound proxy

### set sip reg add

- used to add registration information

**set sip reg add** [reg\_num] [expires] [#registrar] [ip] [port] {name | 0} {passwd | 0} {ip port ...}

#### Syntax description

<b>reg_num</b>	the phone number to be registered
<b>expires</b>	how long the reg_num is to re-register
<b>#registrar</b>	the number of registrar
<b>ip</b>	IP of the registrar
<b>port</b>	port of the registrar
<b>name</b>	[the name for authentication   0 for no authentication]
<b>passwd</b>	[the password for authentication   0 for no authentication]

### set sip reg del

- used to delete registration information

**set sip reg del** [reg\_num]

#### Syntax description

<b>reg_num</b>	the phone number to be deleted
----------------	--------------------------------

### set sip cfg

- used to set the configuration of sip

**set sip cfg** [udp\_ctl\_port] [rtp\_data\_port]

#### Syntax description

<b>udp_ctl_port</b>	<udp control port> ( 0 : default port will be used)
<b>rtp_data_port</b>	<rtp data port> ( 0 : default port will be used)

### set sip proxy

- used to set the configuration of sip

**set sip proxy** [#proxy\_svr] [ proxy svr-1 nwa ] { proxy svr-2 nwa }...

#### Syntax description

<b>#proxy_svr</b>	number of proxy server   0 to remove existing server
-------------------	--

proxy svr nwa <ip> <port>

### set sip actreg

- used to send out the registration

**set sip actreg**

### set sip dns\_ip

- used to set the domain name server. The IP domain should be in numerical format

**set sip dns\_ip [ip]**

#### Syntax description

**ip** <x.x.x.x> | 0 to remove dns ip

### set sip info\_sw

- used to set the sip process information switch

**set sip info\_sw [on/off]**

### set sip auto\_reg

- used to set registration auto start when reboot in the condition of registration server is set

**set sip auto\_reg [on/off]**

### set sip nat\_call

- used to set nat\_call switch on/off whether the gateway in public IP is to receive calls from the private IP or not. The default value is on.

**set sip nat\_call [on/off]**

### set sip outboundproxy add

- used to add outbound proxy

**set sip outboundproxy add [ip/hostname] [port]**

### set sip outboundproxy del

- used to delete outbound proxy

**set sip outboundproxy del**

### set sip name [Registrar\_ID] [name]

- used to setup SIP Caller ID information. You may use "show sip reg" to show the Registrar ID and setup the corresponding Caller ID parameter. The Caller ID is the [name] field.

## 6.10 Voice Coding Profile Configuration Commands

Coding profile is used to store coding parameters for voice and fax coding p that can be used by telephony port on VIP. VIP has built-in coding profiles, each having a unique profile ID and parameters for specific voice, fax or modem coder. Among these coding profiles, there are five may be used for voice or fax applications. The following table summarizes coding profiles available for voice and fax applications.

Coding profile ID	Coder
0	G.723 6.3 kbps voice coder
1	G.729ab voice coder
2	G723 5.3 kbps voice coder
5	Proprietary fax coder
6	G.711 $\mu$ -law voice coder
10	Standard T.38 fax coder

This session will introduce commands for setting the parameters for a particular coding profile. All the commands in this session are of the same syntax as follows:

```
set coding profile_id option [option] . . .
```

**Syntax** for the *profile\_id* is as follows:

<b>profile_id</b>	ID of the coding profile to be modified.
-------------------	--

### 6.10.1 Common Coding Profile Configuration Commands

**set coding profile\_id coding\_type coding\_type**

**Syntax description**

**coding\_type** Type of the codcc as defined in the following table.

Parameter	Description
<b>g711_mu</b>	G.711 PCM u-law coding
<b>g723_53</b>	G.723.1 5.3 kbps coding
<b>g723_63</b>	G.723.1 6.3 kbps coding
<b>g729ab</b>	G.729 annex A, annex B 8kbps coding
<b>fax_t38</b>	Fax Relay in T.38 mode

**Note:** Modification will not take effect till save and next reboot.



**set coding profile\_id cp\_tone\_detect {on | off}**

This command is used to specify a secondary level of control of call progress tone detection. If the call progress detection control for a telephony port is set to "As per coding profile" (refer to command "[set port port cp\\_tone\\_det\\_ctrl](#)"), this parameter determines if detection is to be enabled or not.

**Syntax description**

<b>on</b>	Enable call progress tone detection.
<b>off</b>	Disable call progress tone detection.

**set coding profile\_id fax\_tone\_detect {on | off}**

This command is used to specify a secondary level of control of V.21 fax tone detection. If the fax tone detection control for a telephony port is set to "As per coding profile" (refer to command "[set port port fax\\_tone\\_det\\_ctrl](#)"), this parameter determines if detection is to be enabled or not. For a voice coder, fax tone detection has to be enabled, otherwise, telephony port never switches to fax mode while the voice coder is active. For a fax profile it does not matter if the fax tone detection is enabled or disabled.

**Syntax description**

<b>on</b>	Enable V.21 fax tone detection.
<b>off</b>	Disable V.21 fax tone detection.

**set coding profile\_id usage {voice | fax} {on | off}****Syntax description**

<b>Voice</b>	The coding profile is allowed, if the parameter that follows is "on", for being used as voice coder. The coding profile is not allowed, if the parameter that follows is "off", for being used as voice coder.
<b>Fax</b>	The coding profile is allowed, if the parameter that follows is "on", for being used as fax coder. The coding profile is not allowed, if the parameter that follows is "off", for being used as fax coder.

**6.10.2 Voice Coding Profile Configuration Commands****set coding profile\_id adaptive\_playout {on | off}**

VIP has built-in voice packet buffer, which allows VIP to remove packet jitter from the incoming packet stream. VIP also implements an adaptive voice packet playback. This command is used to enable/disable the adaptive playback function for a voice coding profile.

**Syntax description**

<b>on</b>	Enable adaptive playback.
<b>off</b>	Disable adaptive playback.

### **set coding profile\_id dtmf\_relay {on | off}**

VIP supports DTMF Relay, in which DTMF tones are detected during voice processing, encoded into SIP-UserInformation packets and conveyed to the remote VIP via the SIP call control band. This command is used to enable or disable the DTMF Relay feature.

#### **Syntax description**

<b>on</b>	Detect DTMF tones while voice session is on-going, and send detected DTMF digits to remote gateway via the SIP call control band.
<b>off</b>	Do not detect DTMF tones. DTMF tones are compressed and send to remote gateway the same as regular voice frame.

### **set coding profile\_id max\_delay**

Voice packets from network may have traversed variable path and each packets have experienced different propagation delay. To ease this phenomenon, VIP has a built-in voice packet buffer, which stores voice packets received from the network. The effect of non-uniform delay among packets is known as jitter. The voice buffer allows VIP to remove the packet jitter from the incoming packet stream before decompressing and sending the packet to telephony port for playing out. This command is used to set the size of voice buffer.

#### **Syntax description**

<b>delay</b>	Value in milliseconds.
--------------	------------------------

#### **Notes**

1. The maximum delay should be at least 2 packet times greater than the nominal delay. Refer to command "[set coding profile\\_id nom\\_delay](#)" for details about setting nominal delay.
2. The maximum delay for each coder is shown in the following table:

Coding Type	Maximum Delay
G.711 $\mu$ -law	145 ms
G.723	500 ms
G.729AB	500 ms

### **set coding profile\_id min\_delay**

This command is used to set the time each voice packet is stored in the voice packet buffer before VIP playing out the packet. It is only meaningful when the adaptive playback feature is disabled. Refer to "[set coding profile\\_id adaptive\\_playout](#)" for details about adaptive playback feature.

#### **Syntax description**

<b>delay</b>	Value in milliseconds.
--------------	------------------------

**set coding *profile\_id* nom\_delay****Syntax description**

<b>Delay</b>	Value in milliseconds.
--------------	------------------------

**set coding *profile\_id* vad {on | off}**

This command is used to enable/disable the Voice Activity Detector (VAD) for a coding profile.

**Syntax description**

<b>On</b>	Enable VAD.
<b>Off</b>	Disable VAD.

**set coding *profile\_id* vad\_thresh**

This command is used to set threshold level for the VAD for a coding profile.

**Syntax description**

<b>threshold</b>	Value in dBm, ranging from -20 to +10.
------------------	--

**set coding *profile\_id* vif**

This command is used to set the size of the Voice Information Field (VIF), in bits, for a voice coder.

**Syntax description**

Coding type	Sampling time	VIF
G.711 $\mu$ -law	10 ms	640
	20 ms	1,280
	30 ms	1,920
G.723	30 ms	192
	60 ms	384
	G.729AB	10 ms
	20 ms	160
	30 ms	240
	40 ms	320
	50 ms	400
	60 ms	480

**Note:**

Size of the Voice Information Field (VIF), in bits, for a voice coder are related to the coding type and the rate the voice coder samples a voice frame (the packet time), as shown in the table above. **VIF sizes of a coder of values other than those shown in the table are not valid.**

## 6.11 Dial Plan Management Commands

Among the command sets supported by the CLI, the dial plan management commands are the most sophisticated. Some of the dial plan management commands are only allowed when VIP is in the atpm table update state. For ease of explaining, this command set is further categorized into several sub command sets.

Sub command set	Purposes	Commands	atpm table update state required?
Database update control	<ul style="list-style-type: none"> <li>Instruct VIP to start or stop atpm table update state.</li> <li>Store/restore atpm tables to/from non-volatile storage</li> <li>Purge atpm tables</li> <li>Erase dial plan database from non-volatile storage</li> </ul>	atpm req atpm done atpm re-store atpm store atpm purge atpm erase	No No Yes No Yes No
Destination table management	Manage atpm destination table	atpm dadd atpm ddel atpm dfind atpm dlist	Yes Yes No No
Hunt group table management	Manage atpm hunt group table	atpm hadd atom hdel atpm hfind atpm hlist	Yes Yes No No
Address table management	Manage atpm address table	atpm aadd atpm adel atpm afind atpm alist	Yes Yes No No
System	Manage atpm system configuration	atpm slist atpm sys	No Yes

The following sections describe each sub command set and the commands.

## Database Update Control Commands

### atpm done

The **atpm done** command ends the atpm table update session and re-enables the address translation.

#### Syntax description

This command has no arguments or keywords

### atpm erase

The **atpm erase** command erases the dial plan database from the non-volatile memory.

#### Syntax description

This command has no arguments or keywords

### atpm purge {all|addr|dest|hunt}

Use the **atpm purge** command to delete all entries from the atpm tables.

#### Syntax description

<b>all</b>	Delete all entries from atpm address, destination and hunt group tables.
<b>addr</b>	Delete all entries from atpm address table.
<b>dest</b>	Delete all entries from atpm destination table.
<b>hunt</b>	Delete all entries from atpm hunt group table.

### atpm req

The **atpm req** command starts the atpm table update session. Upon starting the atpm table update session, the ATPM address translation is disabled, hence no phone call can be made, until a **atpm done** command is issued.

#### Syntax description

This command has no arguments or keywords

### atpm restore

The **atpm restore** command restores the whole dial plan from non-volatile storage to the atpm address, destination and hunt group tables.

#### Syntax description

This command has no arguments or keywords

### atpm store [erase]

The **atpm store** command store all atpm tables into non-volatile memory.

#### Syntax description

<b>erase</b>	(Optional) Erase the non-volatile before storing the dial plan data-base. This option is not recommended except the very first time you use the <b>atpm store</b> command.
--------------	--

### Hunt Group Table Management Commands

#### atpm hadd *hunt\_group\_id* {1|2} *dest\_id* [*desi\_id2*] ...

Use the **atpm hadd** command to add an entry into the atpm hunt group table.

#### Syntax description

<i>hunt_group_id</i>	Hunt group ID. For each hunt group, you need to assign it a unique identifier between 1 and 65536.
<b>1</b>	Hunt type 1. Hunt type 1 hunts destination within a hunt group starting from the destination member just after the last used member.
<b>2</b>	Hunt type 2. Hunt type 2 hunts destination within a hunt group starting from the first destination member.
<i>dest_id1</i>	ID of the first destination member in the hunt group.
<i>dest_id2</i> <i>dest_id3</i> ...	(Optional)List of ID's of additional destination members in the hunt group.

#### Example

The following example shows how to group destination 1, 2, 3 and 4 into a hunt group, assign it hunt group ID 10, and specify hunt type 2 for this hunt group.

```
ITG>atpm hadd 10 2 1 2 3 4<Enter>
```

#### atpm hdel *hunt\_group\_id*

The **atpm hdel** command deletes an entry from the atpm hunt group table.

#### Syntax description

<i>hunt_group_id</i>	ID of the hunt group to be deleted from the hunt group table.
----------------------	---

#### atpm hfind *hunt\_group\_id*

The **atpm hfind** finds and display an entry in the hunt group table.

**Syntax description**

**hunt\_group\_id** ID of the hunt group to be displayed.

**atpm hlist**

The **atpm hlist** display all entries in the hunt group table.

**Syntax description**

This command has no arguments or keywords

**Example**

```
ITG>atpm hlist
Group id  Type  #Members  Member ids
-----
  1    2    1    1
  2    2    1    2
  3    2    1    3
  4    2    1    4
  5    2    1    5
  6    2    1    6
  7    2    1    7
  8    2    1    8
 11    2    1   11
OK
ITG>
```

**Address Table Management Commands****atpm add tel# min\_digits max\_digits hunt\_group\_id prefix\_strip\_len [prefix#]**

Use the **atpm add** command to add an entry into the atpm address table.

**Syntax description**

<b>tel#</b>	Telephone number to match. This is only part of the total dialed string.
<b>min_digits</b>	Minimum number of digits to be collected before the ATPM starting matching the dialed string with entries in the address table.
<b>max_digits</b>	Maximum number of digits to be collected before the ATPM starting matching the dialed string with entries in the address table.
<b>hunt_group_id</b>	Hung group ID for this telephone number
<b>pre- fix_strip_len</b>	The number of digits to be stripped at the beginning of the collected dial string before forwarding the string to the destination.
<b>prefix#</b>	(Optional) Digit to be added before the beginning of the collected dial string before forwarding it to the destination.

**atpm adel tel#**

The **atpm adel** command deletes an entry from the atpm address table.

**Syntax description**

<b>tel#</b>	Number of a previously added entry to be deleted from the atpm address table.
-------------	---

**atpm afind tel#**

The **atpm afind** finds and display an entry in the address table.

**Syntax description**

<b>tel#</b>	Number of a previously added entry in the atpm table to be displayed.
-------------	---

**atpm alist**

The **atpm alist** displays all entries in the address table.

**Syntax description**

This command has no arguments or keywords

**Example**

```
ITG>atpm alist
Address      Hunt  Min  Max  Prefix Prefix
Entry       Grp_Id Digits Digits strip Address
201         1    1    3    3    None
202         2    1    3    3    None
203         3    1    3    3    None
204         4    1    3    3    None
ITG>atpm done
OK
ITG>
```

**System Commands****atpm slist**

The **atpm slist** displays the atpm system table.

**Syntax description**

This command has no arguments or keywords

**Example**



```
ITG>atpm slist
System Info: Total dial time = 30000ms, First digit wait = 10000ms,
             Interdigit wait = 5000ms, Dial term digit = None
OK
ITG>
```

### **atpm sys dial\_time 1st\_digit\_wait inter\_digit\_wait [dial\_term\_digit]**

Use the **atpm sys** command to set the time constraints for collection of dial digits.

#### **Syntax description**

<b>dial_time</b>	The maximum time, in millisecond, allowed for entry of the entire string of dial digits. At expiration, ATPM starts address lookup.
<b>1st_digit_wait</b>	The maximum time, in millisecond, allowed between off-hook and when the first dial digit is entered. At expiration, ATPM considers address lookup to fail.
<b>inter_digit_wait</b>	The maximum time allowed between entry of each digit after the previous digit. At expiration, ATPM starts address lookup.
<b>dial_term_digitr</b>	(Optional) End of the dial string is declared when the digit is entered.

## **6.12 Tel Commands**

### **tel show pcm\_gain\_level**

The **tel show pcm\_gain\_level** command to display the gain level setting of the PCM codec's receive channel.

#### **Syntax Description**

This command has no arguments or keywords

### **tel show port [port#]**

The **tel show port** command displays the hook state of a telephony port.

#### **Syntax Description**

<b>port#</b>	Number of the port.
--------------	---------------------

#### **Default**

If the port number is not specified, the CLI displays hook state of all telephony ports.

### **tel show ring\_freq**

The **tel show ring\_freq** command to displays the frequency of the ring signal that VIP sends to FXS ports..

**tel set pcm\_gain\_level {1|2|3|4|5}**

The FXO ports might be connected to central office switch or PBX via local loop which may of as long as several miles. For compensating signal distortion in the local loop, VIP's PCM codec is designed in such a way that users might adjust it gain level before transmitting analog signal to the local loop. The **tel set pcm\_gain\_level** command is used to set the gain level for the PCM codec for compensating signal loss in the local loop.

**Syntax Description**

1	Set gain level to -1 dB
2	Set gain level to 0 dB
3	Set gain level to +1 dB
4	Set gain level to +2 dB
5	Set gain level to +3 dB

**Default**

The default setting is -1 dB.

**Note**

The PCM gain level setting is only meaningful to FXO ports. It is not applicable to FXS ports.

**tel set ring\_freq {1|2|3|4}**

Use the **tel set ring\_freq** command to set the frequency of the ringer VIP uses to ring a FXS port.

**Syntax Description**

1	Set ring freq to 17 Hz
2	Set ring freq to 20 Hz
3	Set ring freq to 25 Hz
4	Set ring freq to 50 Hz

## Chapter 7 Upgrading and resetting VIP

VIP-450 is able to have system functionality enhancement via software upgrade. This must be operated in upgrade mode. In firmware upgrade mode, limited commands allow users to read new revision codes from a remote TFTP server and write into the built-in flash non-volatile storage.

To enter download mode, either Telnet or Console (RS-232) connection can take the job, and a TFTP server is required by VIP to complete firmware upgrade process.

### 7.1 Firmware upgrade

To switch from normal operation mode to download mode, use the **download** CLI command.

```
ITG> download <Enter>
```

**Note:** To be able to switch to download mode from Telnet session, TFTP loader on VIP must be version 3.00 or higher. To upgrade to firmware version 3.03 or above, bootloader version 4.01 or above is required.

After **download** command is inserted, VIP will terminate all on-going calls, reset and enter firmware download mode. If you enter download mode from Telnet session. The Telnet session will be terminated too. You need to re-connect to VIP from Telnet client to be able to access the firmware download mode.

Before going any further, please note: **NEVER, NEVER TURN OFF POWER** while firmware upgrade is working in progress!! (**Please ensure power supply is stable before firmware upgrade is executed.**)


TFTP server is required to complete VIP series firmware upgrade process; there are various TFTP server software on the market, please utilize the existing software or find a new one on the net to complete upgrade process. (In this chapter, 3CDeamon TFTP server was installed for demonstration.)

TCP/IP Configuration:

Computer installed with TFTP server: 192.168.0.7


VIP: 192.168.0.1

**Note:** If a Telnet connection is built behind NAT environment, **TCP port 69 MUST** be reserved for data communication.



## TFTP server configuration

1. Execute TFTP server program, assign firmware file location, and save the path if necessary. (In this sample datagram, the file is assigned in c:\) (This part might vary on different kind of TFTP server.)



2. Allocate VIP firmware file in the directory, and apply the modification (if required).

**Note: TCP port 69 is required for TFTP access.**

## VIP configuration:

### Telnet session

- a) Under Telnet firmware download mode, the user name: **eitg**; password: **123** (password may vary because of user's configuration) is used for logging on VIP
- b) Under ITG> prompt, insert command: **download** to enter VIP firmware upgrade mode.
- c) Insert command: **start** and answer questions on screen to proceed firmware upgrade.
- d) When VIP prompts downloading firmware file into EEPROM, insert **y** to continue.
- e) Wait till firmware is fully loaded into VIP, insert **quit** to leave firmware upgrade mode and answer **y** to reboot machine when VIP prompts for restart.

```
ITG>download
===== WARNING =====
* Entering download mode will hang up all telephone connections *
* and all the configuration settings will lose. *
* Be certain all the configuration settings have been saved. *
=====

Do you want to enter download mode now (y/n)? [n] y

Boot loader V4.12
Loading TFTP loader.....
** Internet Telephony Gateway TFTP Loader Ver 4.10 **
EITGLoader>start

IP address of the TFTP server? [192.168.0.254] 192.168.0.7
File name? xyz123.imz

Starting download file: xyz123.imz
.....
Download complete, file size = 833004
Application code downloaded successfully
Do you want to write downloaded image to flash EEPROM (y/n)? [y] y
Press <Enter> to start flash EEPROM programming
Flash EPROM programming on-going, BE CERTAIN NOT TO TURN POWER OFF...
Flash sector no. 4 write done
Flash sector no. 5 write done
Flash sector no. 6 write done
Flash sector no. 7 write done
Flash sector no. 8 write done
Flash sector no. 9 write done
Flash sector no. 10 write done
Flash sector no. 11 write done
Flash sector no. 12 write done
Flash sector no. 13 write done
Flash sector no. 14 write done
Flash sector no. 15 write done
Flash sector no. 16 write done
Flash EEPROM programming completed
All sectors programmed successfully
Download another file (y/n)? [n] n
EITGLoader>quit

Do you want to restart the system now (y/n)? [n] y
```

## Console session

- a) Connect VIP through the 9-pin RS232 female console (No password required)  
Under ITG> prompt, insert command: **download** to enter VIP firmware upgrade mode.
- b) Insert command: "**start**" and answer questions on screen to proceed firmware upgrade.
- c) When VIP prompts downloading firmware file into EEPROM, insert "**y**" to continue.
- d) Wait till firmware is fully loaded into VIP, insert "**quit**" to leave firmware upgrade mode and answer "**y**" to reboot machine when VIP prompts for restart.

```

ITG>download
===== WARNING =====
* Entering download mode will hang up all telephone connections *
* and all the configuration settings will lose. *
* Be certain all the configuration settings have been saved. *
=====

Do you want to enter download mode now (y/n)? [n] y

Boot loader V4.12
Loading TFTP loader.....
** Internet Telephony Gateway TFTP Loader Ver 4.10 **
EITGLoader>start

IP address of the TFTP server? [192.168.0.254] 192.168.0.7
File name? xyz123.imz

Starting download file: xyz123.imz
.....
Download complete, file size = 833004
Application code downloaded successfully
Do you want to write downloaded image to flash EEPROM (y/n)? [y] y
Press <Enter> to start flash EEPROM programming
Flash EPROM programming on-going, BE CERTAIN NOT TO TURN POWER OFF...
Flash sector no. 4 write done
Flash sector no. 5 write done
Flash sector no. 6 write done
Flash sector no. 7 write done
Flash sector no. 8 write done
Flash sector no. 9 write done
Flash sector no. 10 write done
Flash sector no. 11 write done
Flash sector no. 12 write done
Flash sector no. 13 write done
Flash sector no. 14 write done
Flash sector no. 15 write done
Flash sector no. 16 write done
Flash EEPROM programming completed
All sectors programmed successfully
Download another file (y/n)? [n] n
EITGLoader>quit

Do you want to restart the system now (y/n)? [n] y

```

## Trouble Shooting Tips

If following error (**TFTP timeout error**) occurs:

```
** Internet Telephony Gateway TFTP Loader Ver 4.10 **
EITGLoader>start

IP address of the TFTP server? [192.168.0.7]
File name? xyz123.imz

Starting download file: xyz123.imz
TFTP device open failed. - TFTP server timeout while waiting for a response from the client.
Download another file (y/n)? [n]
```

Possibility:

- a) Network connection is not correctly configured
  - check if cable is securely connected.
  - check if TFTP server IP address is correctly configured
  - check if TCP port 69 is available for TFTP connection
  - if firmware upgrade is processed remotely, a fast connection between VIP and TFTP server is required (ping response time <300 ms)

During firmware upgrade, "**protocol error detected**" displays on the screen.

```
** Internet Telephony Gateway TFTP Loader Ver 4.10 **
EITGLoader>start

IP address of the TFTP server? [192.168.0.7]
File name? xyz123.imz

Starting download file: xyz123.imz
TFTP device open failed. - Protocol error detected.
Download another file (y/n)? [n]
```

- a) In most circumstances, this error occurs while requested firmware file cannot be found on TFTP server.

Possibility:

- check if the firmware file is correctly located in assigned folder.
- check if TFTP server supports long file name format.
- check if firmware file name is correctly inserted
- check system log on TFTP server if there is error message for trouble shooting.

## 7.2 CLI Commands in Download Mode

Under download mode, the CLI supports the following commands:

Command	Description
<b>help</b>	Display help screen
<b>quit</b>	Terminate download mode, switch to normal operation mode.
<b>set</b>	Change IP parameter
<b>start</b>	Start downloading code from TFTP server

The following section describes each of the commands.

### help

The **help** command lists the top-level commands.

### quit

The **quit** command is used to terminate the download mode and return to normal operation mode.

#### Syntax Description

This command has no arguments or keywords

#### Note

Switching mode from Telnet session will terminate current active session. You'll need to connect to VIP again to be able to access the CLI.

### set ip ip\_addr

Use the **set ip** command to assign a static IP address to VIP.

#### Syntax description

<b>ip_addr</b>	The IP address of VIP.
----------------	------------------------

#### Note

The new IP address will not take effect until VIP is reset.

### set gateway ip\_addr

Use the **set gateway** command to assign a default gateway (router) for VIP. The default gateway routes packet data outside or your IP subnet.

#### Syntax description

<b>ip_addr</b>	The IP address of the default gateway. Default value: 0.0.0.0
----------------	---

#### Note

The new setting will not take effect until VIP is reset.



### set mask *ip\_mask*

Use the **set mask** command to set the IP subnet mask for VIP.

#### Syntax description

<b><i>ip_mask</i></b>	The subnet mask of your network.
-----------------------	----------------------------------

#### Note

The new setting will not take effect until VIP is reset.

### start

Use the **start** command to start downloading code from TFTP server. VIP will prompt you for the IP address of the TFTP server and the file to download.

## 7.3 Restore default configuration

If there is system re-organization, firmware upgrade or improper parameters are loaded in VIP-450, restoring factory default settings may help you to restore initial state of machine and restart configuration.

Following are steps loading VIP series default parameters:

**Note: restore process in this session only can be applied to firmware version 3.xx)**

#### System configuration default parameters

- Logon VIP via telnet or console connection, and insert command: **config erase**
- After this command, VIP pops up a warning message and prompts for confirmation.
- Press "y" to erase current system configuration parameters,
- Enter **net reset** to reboot and load the default system parameters into machine.
- Log on VIP, and insert command: **config store** to load factory default parameters into VIP.

A sample is attached below for reference.

```
ITG>config erase

The system configuration data will be erased from non-volatile storage permanently.

Are you sure to erase it (y/n)? [n] y
System configuration records erased from flash
ITG>net reset

===== WARNING =====
* Restarting the system will hang up all telephone connections      *
* and all the configuration settings will lose.                      *
* Be certain all the configuration settings have been saved.        *
=====

Do you want to restart the system now (y/n)? [n] y

Boot loader V4.12
Mem 16b 16M
Loading application code.....

***** Internet Telephony Gateway (PLA) Version s1.0 *****

***** Hardware Configuration *****
Flash:  type-MX29L1611 32 sectors 64 KB/sector
RAM:    8 MB 512K x 16
LAN:    auto-negotiation on-going. Link DOWN
TIM slot A: type-FXO2S2 DSP-C5409 codec-PEB2466 Diag-OK
*****

ITG>config store

OK
ITG>
```

**Dialplan configuration default parameters:**

- a) Log on VIP via telnet or console connection.  
 b) At the ITG prompt, insert following commands:

ITG>**atpm erase**

ITG>**net reset** (Answer "y" to reboot machine.)

After rebooting, logon VIP. At the ITG> prompt, insert: **atpm store** to restore Dialplan default value into VIP.

A sample is attached below for reference.

```
ITG>atpm erase

The dial plan will be erased from non-volatile storage permanently.

Are you sure to erase it (y/n)? [n] y
Dial plan erased from flash
OK
ITG>net reset

===== WARNING =====
* Restarting the system will hang up all telephone connections      *
* and all the configuration settings will lose.                      *
* Be certain all the configuration settings have been saved.        *
=====
Do you want to restart the system now (y/n)? [n] y

Boot loader V4.12
Mem 16b 16M
Loading application
code.....

***** Internet Telephony Gateway (PLA) Version s1.0 *****

***** Hardware Configuration *****
Flash:  type-MX29L1611 32 sectors 64 KB/sector
RAM:    8 MB 512K x 16
LAN:    auto-negotiation on-going. Link DOWN
TIM slot A: type-FXO2S2 DSP-C5409 codec-PEB2466 Diag-OK
*****

ITG>No dial plan info can be found in the Flash, the default dial plan is used but NOT saved.
OK

ITG>atpm store

OK
```



## Appendix A Technical Specifications

### A.1 VIP Technical Specifications

<b>Telephony Interface Module support</b>	VIP-450: 2 ports loop start FXO, 2 ports loop start FXS VIP-050: 4 ports loop start FXO, 4 ports loop start FXS (Up to two modules per unit)
<b>Network Interface Ports</b>	1 10/100Base-T, auto sensing, RJ45
<b>Voice codec support</b>	G.711 PCM 64kbps (A-law and $\mu$ -law) G.723.1A ACELP/M-MLQ (5.3, 6.3kbps) G.729AB CS-ACELP (8kbps)
<b>Fax</b>	ITU-T V.21, V.27ter, V.29, V.33 and V.17
<b>Fax over IP protocol</b>	T.38 Proprietary low bandwidth protocol
<b>Echo cancellation</b>	G.168 compliant, 16 ms tail length
<b>Simultaneous connection</b>	VIP-450: 4 channels voice/fax VIP-050: 8 channels voice/fax
<b>Voice processing</b>	Voice activity detection DTMF detection/generation Echo cancellation Comfort noise generation Call progress detection Gain control
<b>Call control</b>	SIP 2.0 (RFC3261)
<b>Management</b>	Built HTTP server allowing management from web browser Command line interface allowing management from VT-100 terminal or Telnet client
<b>Software upgrade</b>	Flash memory and built-in TFTP allowing software upgrade via network
<b>Power</b>	VIP-450: AC-to-DC power supply, 90-260 VAC, 50-60 Hz VIP-050: 90-240 VAC, 20 Watts, 50-60 Hz
<b>Environmental</b>	Operating temperature: 0° to 45° C (32° to 113° F) Storage temperature: -10° to 65° C (-4° to 149° F) Humidity: 10% to 85% (non-condensing)
<b>Dimension (L x W x D)</b>	VIP-450: 150 x 220 x 44 (mm) VIP-000: 445 x 275 x 44 (mm)

<b>Compliances</b>	EMI FCC Part 15 Class A EN55022 Class A (CISPR-22 Class A) VCCI Class A CE Safety UL 1950 CE
<b>Mounting</b>	VIP-450: Desktop VIP-000: Desktop or 19" rack mounting

## A.2 Console Port


The console port uses a DB-9 RS-232 connector. The supplied straight-through RS-232 cable connects the console port of VIP to a console PC or terminal. Pinout for the port is described in the following table.

DB-9 pin	Signal
1	Not connected
2	TxD
3	RxD
4	Not connected
5	Ground
6	Not connected
7	Not connected
8	Not connected
9	Not connected

## A.3 LAN Port

The 10/100 LAN port use standard RJ-45 connector and Ethernet pinouts. The following diagram and table show the pinout on the port connector. When connecting the LAN port to switches or repeaters, you must use a straight-through cable.

RJ45 pin	Signal
1	RxD+
2	RxD-
3	TxD+
4	Not connected
5	Not connected




6	TxD-
7	Not connected
8	Not connected

### A.4 FXO Port Pin Assignments

The FXO Telephony Interface Module has 4 RJ11C/W modular jacks. The following diagram and table show the assignments of the pin for the RJ11 port.


RJ-11 pin	Signal
1	Not connected
2	Tip
3	Ring
4	Not connected



### A.5 FXS Port Pin Assignments

The FXS Telephony Interface Module has 4 RJ11C/W modular jacks. The following diagram and table show the assignments of the pin for the RJ11 port.

RJ-11 pin	Signal
1	Not connected
2	Tip
3	Ring
4	Not connected



## A.6 FXO Card Technical Specifications

Signaling:	Loop Start / DTMF
No. of channels:	4
Interface Connectors:	4 RJ-11 2-pin modular jacks.
Line Impedance :	600 $\Omega$ 900 $\Omega$
Insertion Loss:	2 dB nominal.
Frequency Response:	300Hz ~ 3400Hz +/- 2dB w.r.t. 1004Hz.
Return Loss:	$\geq 18$ dB
Input Level adjustment:	-6 dB to +6 dB
Output Attenuation:	0 dB to 13 dB
Longitudinal Balance:	$\geq 45$ dB

## A.7 FXS Card Technical Specifications

Signaling:	Loop Start / DTMF
No. of channels:	4
Interface Connectors:	4 RJ-11 2-pin modular jacks.
Line Impedance :	600 $\Omega$ 900 $\Omega$
Insertion Loss:	2 dB nominal.
Frequency Response:	300Hz ~ 3400Hz +/- 2dB w.r.t. 1004Hz.
Return Loss:	$\geq 18$ dB
Input Level adjustment:	-6 dB to +6 dB
Output Attenuation:	0 dB to 13 dB
Longitudinal Balance:	$\geq 45$ dB
Loop Current:	25mA nominal
Ring Voltage:	50Vrms Nominal
Ring Tone:	16.67Hz, 20Hz(default), 25Hz or 50Hz



## Appendix B CLI Commands

### B.1 Normal Mode Commands

Command	Description
atpm aadd	Add an entry to the address table
atpm adel	Delete an entry from the address table
atpm afind	Find and display an entry in the address table
atpm alist	Display all entries in the address table
atpm dadd	Add an entry to the destination table
atpm ddel	Delete an entry from the destination table
atpm dfind	Find and display an entry in the destination table
atpm dlist	Display all entries in the destination table
atpm hadd	Add an entry to the hunt group table
atpm hdel	Delete an entry from the hunt group table
atpm hfind	Find and display an entry in the hunt group table
atpm hlist	Display all entries in the hunt group table
atpm done	End the atpm table update session
atpm erase	Erase all atpm tables from NVS
atpm purge	Purge entries from atpm table(s)
atpm req	Start atpm table update session
atpm restore	Restore atpm tables from NVS
atpm store	Store atpm tables into NVS
atpm slist	Display atpm system parameters
atpm sys	Set atpm system parameters
config activate	Move the configuration from temporary area to active area.
config erase	Erase the configuration from NVS
config store	Store the active configuration data into NVS
clrscr	Clear screen
download	Switch to download mode
help	Display help screen

net reset	Reset the system
net set gateway	Set default gateway's IP address
net set http	Turn on/off HTTP server
net set ip	Set IP address
net set ip_preced	Set IP precedence bits
net set mask	Set IP subnet mask
net set speed	Select Ethernet link speed
net set user_pw	Set password
net show	Display IP parameters
net show hwstat	Display hardware status
ping	Send ICMP echo request to another host
show sip	Display SIP parameter settings
show version	Show software versions
set sip	Setup SIP related parameters
tel show pcm_gain_level	Display gain level setting of the PCM codec's receive channel.
tel show port	Display hook state for a telephony port
tel show ring_freq	Show ringer's frequency
tel set pcm_gain_level	Set gain level for the PCM codec's receive channel
tel set ring_freq	Set ringer's frequency

## B.2 Download Mode Commands

Command	Description
help	Display help screen
quit	Switch to normal operation mode
set gateway	Set default gateway 's IP address
set ip	Set IP address
net set mask	Set IP subnet mask
start	Start downloading file

## Appendix C Factory Default Settings

The following table lists the settings of certain parameters before VIP is shipped.

Parameter	Default Setting
<b>Network</b>	
IP address	192.168.0.1
IP subnet mask	255.255.255.0
Default gateway	0.0.0.0
IP precedence	0
Ethernet link speed	10/100 auto-negotiation
User ID for HTTP browser and Telnet client login	administrator
Password for HTTP browser and Telnet access login	123
User name for Telnet session in download mode	eitg
Password for Telnet session in download mode	123
HTTP server	On
Telnet server	On
<b>Serial port (Fixed)</b>	
Baud rate	19,200
Number of data bit	8
Parity check	None
Number of stop bit	1
<b>Voice codec</b>	
Preferred voice codec	G.723 6.3kbps
TxVIF size (default voice codec=g.723)	192
RxVIF size (default voice codec=g.723)	192
VAD	Enabled
Playout nominal delay	120 ms
Playout maximum delay	240 ms
Playout minimum delay	0 ms
Fax tone detect	Enabled
Call Progress Tone detect	Enabled
<b>Telephony</b>	
PCM codec receiver gain for FXO ports	-1 dB
Ringer frequency for FXS ports	17 Hz

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>