

# 2.4GHz Cordless Phone

## with TAD

43-3821


**10 Number Memory Dialing** — stores 10 numbers in memory for easy dialing. See “Memory Dialing” on Page 15.

**Long Battery Life** — the supplied battery pack (when fully charged) provides about 7 hours of talk time or 14 days of standby time. See “Connecting, Charging and Replacing the Battery Pack” on Page 10.

**20 Channels** — automatically selects a clear channel when you make or answer a call. You can also manually change channels during a call. See “Selecting the Channel” on Page 13.

**Headset Jack** — connects an optional headset (available at your local RadioShack store) for hands-free convenience. See “Using a Headset” on Page 14.

**Toll-Saver** — lets you avoid unnecessary charges when you call by long distance to check your messages. See “Using the Toll-Saver” on Page 24.



Thank you for purchasing a RadioShack 2.4 GHz Cordless Telephone. Your telephone uses the 2.4 GHz band for less interference. Its headset jack lets you connect an optional headset for handsfree convenience.

The digital answering system provides clear reliable messaging with call screening, day/time stamp, call counter, remote access and instant skip or replay messaging.

---

### OWNER'S MANUAL



**RadioShack**®

www.radioshack.com™

© 2002 RadioShack Corporation.  
All Rights Reserved.

RadioShack and RadioShack.com are trademarks used by  
RadioShack Corporation.

Download from Www.Somanuals.com. All Manuals Search And Download.

**WARNING:** To reduce the risk of fire or shock hazard, do not expose this product to rain or moisture.



**CAUTION**

RISK OF ELECTRIC SHOCK  
DO NOT OPEN



**CAUTION:** TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER OR BACK. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.



The lightning symbol is intended to alert you to the presence of uninsulated dangerous voltage within this product's enclosure that might be of sufficient magnitude to constitute a risk of electric shock. Do not open the product's case.



The exclamation symbol is intended to inform you that important operating and maintenance instructions are included in the literature accompanying this product.



As an **ENERGYSTAR** Partner, RadioShack Corporation has determined that this product meets the **ENERGYSTAR** guidelines for energy efficiency.



Some cordless telephones operate on frequencies that might cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR.

## THE FCC WANTS YOU TO KNOW

In the unlikely event that your phone causes problems on the phone line, the phone company can temporarily discontinue your service. If this happens, the phone company attempts to notify you in advance. If advance notice is not practical, the phone company notifies you as soon as possible and advises you of your right to file a complaint with the FCC.

Also, the phone company can make changes to its lines, equipment, operations, or procedures that could affect the operation of this telephone. The telephone company notifies you of these changes in advance, so you can take the necessary Steps to prevent interruption of your telephone service.

Your phone might cause TV or radio interference even when it is operating properly. To determine whether your phone is causing the interference, turn off your phone. If the interference goes away, your phone is causing it. Try to eliminate the interference by:

- moving your phone away from the receiver
- connecting your phone to an AC outlet that is on a different electrical circuit from the receiver
- contacting your local RadioShack store for help

If you cannot eliminate the interference, the FCC requires that you stop using your phone. ☞

### LIGHTNING

Your telephone has built-in protection circuits to reduce the risk of damage from surges in telephone line and power line current. These protection circuits meet or exceed the FCC requirements. However, lightning striking the telephone or power lines can damage your telephone.

Lightning damage is not common. Nevertheless, if you live in an area that has severe electrical storms, we suggest that you unplug your phone when storms approach to reduce the possibility of damage.

## IMPORTANT SAFETY INSTRUCTIONS

Careful attention is devoted to quality standards in the manufacture of your telephone equipment, and safety is a major factor in its design. However, safety is also your responsibility.

When using your telephone equipment, always follow basic safety precautions to reduce the risk of fire, electric shock, and injury to persons. **Read all the included safety and operating instructions before using your equipment.** Follow them closely, and retain them for future reference.

**Heed Warnings** — Follow all warnings on the product and in the operating instructions.

**Cleaning** — Unplug this product from the wall outlet before cleaning. Use only a damp cloth for cleaning. Do not use liquid or aerosol cleaners.

**Water and Moisture** — Do not use this product near water (for example, near a bathtub, washbowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool).






**Mounting Accessories** — Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer or sold with the product. Follow the manufacturer's instructions for mounting, and use a recommended mounting accessory.

## CONTENTS

The FCC Wants You to Know .....	2
Lightning .....	2
Important	
Safety Instructions .....	3
Battery	
Safety Instructions .....	6
Read This Before	
Installation .....	6
Installation .....	7
Mounting the Phone .....	7
Connecting, Charging and Replacing the Battery Pack .....	10
Setting the Dialing Mode .....	11
Setting the Handset's Ringer Tone .....	12
Turning the Base's Ringer On/Off .....	12
Telephone Operation .....	13
Making and Receiving Calls .....	13
Selecting the Channel .....	13
Adjusting the Handset Volume .....	13
Using FLASH .....	13
Using Redial .....	14
Using Tone Services on a Pulse Line .....	14
Paging .....	14
Using a Headset .....	14
Memory Dialing .....	15
Answering System	
Operation .....	16
Using the Menu Button .....	16
Setting the Day/Time ..	17
Setting the Number of Rings .....	17
Setting the Record Time .....	18
(Continued)	

## ! IMPORTANT !

If an icon appears at the end of a paragraph, go to the box on that page with the corresponding icon for pertinent information.

-  — Warning
-  — Important
-  — Caution
-  — Hint
-  — Note

## CONTENTS

(Continued)

Setting the	
Message Alert Tone ....	18
Selecting the	
Outgoing Message .....	19
Recording/Deleting an	
Outgoing Message .....	20
Setting the System to	
Answer Calls .....	20
Screening Calls .....	20
Recording	
Incoming Messages ...	21
Recording a Memo .....	21
Recording a	
Conversation .....	21
Playing Messages .....	22
Adjusting the	
Volume .....	23
Deleting Messages .....	23
Remote Operation .....	23
Using	
Remote Commands ...	24
Troubleshooting .....	26
Care .....	27
FCC Statement .....	27

**Ventilation** — Slots and openings in the cabinet provide ventilation, ensure reliable operation, and protect from overheating. Do not block or cover these openings, and do not place the product on a bed, sofa, rug, or other similar surface. Do not place the product in a built-in installation such as a bookcase or rack unless it provides proper ventilation as specified by the manufacturer.

**Heat** — The product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

**Power Sources** — Operate this product using only the power source indicated on its marking label. If you are not sure of your home's power type, consult your product dealer or local power company.

**Polarization** — This product is equipped with a polarized AC line plug (a plug having one blade wider than the other). This plug will fit in the power outlet only one way. This is a safety feature. If you cannot insert the plug fully into the outlet, try reversing the plug. If the plug still doesn't fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug. If you need an extension, use a polarized cord.

**Power-Cord Protection** — Route power-supply cords so they are not likely to be walked on or pinched by items placed on or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

**Overloading** — Do not overload wall outlets, extension cords, or integral convenience receptacles, as this can result in a risk of fire or electric shock.

**Objects and Liquids** — Never push objects of any kind into this product through openings, as they

may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

**Servicing** — Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

**Damage Requiring Service** — Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power-supply cord or plug is damaged.
- If liquid has been spilled or objects have fallen into the product.
- If the product has been exposed to rain or water.
- If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
- If the product has been dropped or damaged in any way.
- When the product exhibits a distinct change in performance.

**Lightning** — Avoid using a telephone (other than a cordless type) during an electrical storm, as there might be a remote risk of electric shock from lightning.

**Gas Leak** — Do not use the telephone to report a gas leak in the vicinity of the leak.

## **! IMPORTANT !**

Cordless phones such as this one require AC power to operate. When the AC power is off, you cannot dial out or receive incoming calls using your phone. To be safe, you should also have a phone that does not need AC power to operate (not a cordless phone) so you can still make and receive calls if there is an AC power failure.

When AC power is lost, the phone loses the security access-protection code connection between the base and the handset. When power is restored, put the handset on the base briefly to restore this connection.

# **BATTERY SAFETY INSTRUCTIONS**

To reduce the risk of fire or injury to persons, read and follow these instructions.

- Use only the required size and type of batteries.
- Do not dispose of batteries in a fire. They can explode. Check with local codes for possible special disposal instructions.
- Do not open or mutilate batteries. Released electrolyte is corrosive, can cause damage to the eyes or skin, and can be toxic if swallowed.
- Be careful when handling batteries in order not to short them with conducting materials such as rings, bracelets, and keys. The battery or conductor can overheat and cause burns.
- Charge the batteries provided with or identified for use with this product only in accordance with the instructions and limitations specified in this manual.
- Observe proper polarity orientation between the batteries and battery charger.
- Do not mix old and new batteries in this product.
- Do not mix batteries of different sizes or from different manufacturers in this product.

## **SAVE THESE INSTRUCTIONS**

### **READ THIS BEFORE INSTALLATION**

We have designed your phone to conform to federal regulations and you can connect it to most phone lines. However, each device that you connect to the telephone line draws power from the line. We refer to this power draw as the phone's ringer

equivalence number, or REN. The REN is on the bottom of your phone.

If you use more than one phone or other device on the line, add up all the RENs. If the total is more than five (three in rural areas), your phones might not ring. If ringer operation is impaired, remove one of the devices from the line.

The digital answering system stores up to 16 minutes of messages on a computer chip and records each message's day and time. This gives you advanced capabilities over tape-based answering machines:

- You can delete individual messages and save the rest.
- There are no tapes to bother with and no tape mechanisms to wear out.

The remote operation feature lets you operate your answering system from a touch-tone phone (or from a rotary phone with a pocket tone dialer).

## **INSTALLATION**

Before using your phone, carefully peel the protective film off the display. The film protects the handset window during shipment and is not necessary for use.

### **MOUNTING THE PHONE**

You can place the phone on a desk or table, mount it on a standard wall plate, or directly on a wall.

Choose a location that is:

- near an AC outlet
- near a modular telephone line jack
- out of the way of normal activities

**CAUTION**

You must use a Class 2 power source that

supplies 9V DC and delivers at least 350 mA. Its center tip must be set to positive and its plug must fit the phone's **DC IN 9V** jack. The supplied adapter meets these specifications. Using an adapter that does not meet these specifications could damage the phone or the adapter.

- Always connect the AC adapter to the phone before you connect it to AC power. When you finish, disconnect the adapter from AC power before you disconnect it from the phone.


- away from electrical machinery, electrical appliances, metal walls or filing cabinets, wireless intercoms, alarms, and room monitors
- away from other cordless phones

You can try different locations to see which provides the best performance.

Your telephone connects directly to a modular telephone line jack. If your telephone wiring does not have a modular jack, you can update the wiring yourself using jacks and adapters (available at your local RadioShack store or online at RadioShack.com), or have the telephone company update the wiring for you. You must use compatible modular jacks that are compliant with Part 68 of *FCC Rules*. The USOC number of the jack to be installed is RJ11C (RJ11W for a wall plate).

**ON A DESK TOP**

1. Plug one end of the supplied long modular cord into the **TEL LINE** jack on the base's back.
2. Plug the modular cord's other end into a modular telephone line jack.
3. Insert the supplied AC adapter's barrel plug into the **DC IN 9V** jack on the back.
4. Route the adapter's cord through the strain relief slot on the base's bottom.
5. Plug the adapter into a standard AC outlet.
6. Lift the base's antenna to a vertical position.






## ON A WALL PLATE OR WALL


To mount the phone directly on a wall, you need two screws (not supplied) with heads that fit into the keyhole slots on the base. Drill two holes  $3^{15}/16$  inches apart. Thread a screw into each hole, letting the heads extend about  $1/8$  inch.

1. Plug one end of the supplied modular cord (short for a wall plate, long for direct wall mounting) into the **TEL LINE** jack on the base's back.
2. Insert the supplied AC adapter's barrel plug into the **DC IN 9V** jack.
3. Route the adapter and modular cords through the base's grooves.

4. *For a wall plate*, plug the modular cord's other end into the wall plate jack, then align the base's keyhole slots with the wall plate studs and slide the base downward to secure it.



*For direct wall mounting*, align the base's keyhole slots with the mounting screws and slide the base downward to secure it.



5. Plug the adapter into a standard AC outlet.

**! IMPORTANT !**

Be sure the battery pack is properly connected before you try to charge it. The CHARGE/IN USE indicator lights when the handset is on the base even if the battery pack is not connected properly.

**NOTE**


- If the phone does not work, recharge the battery pack. (The battery power might be too low for the display to operate.)
- If the battery pack becomes weak during a call, the handset beeps about every 3 seconds and TALK/BATT flashes. When this happens, you cannot make a call on the phone until you recharge the battery pack.
- If the battery pack is completely discharged or the base loses power while the handset is away from it, place the handset on the base to reset the security access-protection code. If it was the handset that lost power, recharge the battery pack.

6. Lift the base's antenna to a vertical position.

**CONNECTING, CHARGING AND REPLACING THE BATTERY PACK**

The phone comes with a rechargeable Ni-Cd (nickel-cadmium) battery pack installed in the handset, but not connected. Before using your phone, you must connect the battery pack, then charge it for about 24 hours.

1. Press down and slide off the battery pack compartment cover.
2. Lift the battery pack out of the compartment.
3. Plug the battery pack's connector into the socket in the compartment. The connector fits only one way.
4. Put the battery pack in the compartment.
5. Replace the cover.



To charge the battery pack, place the handset on the base, face up or down. The base's CHARGE/IN USE indicator lights. !

Recharge the battery pack when the handset beeps and TALK/BATT flashes. ✓

When you first use the phone after charging or recharging the battery pack, the phone might not work and you might hear error beeps. If this happens, return the handset to the base for about 5 seconds to reset the security access-protection code.

Using a pencil eraser, clean the charging contacts on the handset and the base about once a month.

About once a month, fully discharge the battery pack by keeping the handset off the base until TALK/BATT flashes. Otherwise, the battery pack loses its ability to fully recharge.

The supplied battery pack should last about a year. If the battery pack does not hold a charge for more than 2 hours after an overnight charge, replace it with a new 3.6V, 600 mAh battery pack with a connector that fits the socket in the battery compartment. You can order a replacement battery pack through your local RadioShack store (or online at *RadioShack.com*). Install the new battery pack and charge it for about 24 hours. ⚠

If you have trouble replacing the battery pack, take the phone to your local RadioShack for assistance. !

## SETTING THE DIALING MODE

Your phone is set for tone dialing. If you have pulse service, change the dialing mode. If you are not sure which type of service you have, do this test:

1. Lift the handset and press **TALK**, then listen for a dial tone.
2. When you hear the dial tone, press any number other than **0**.

*If the dial tone stops, you have touch-tone service.*

*If the dial tone continues, you have pulse service.*

Once you have determined which type of service you have, set the dialing mode.

1. Hold down **FLASH** until the phone beeps and TALK/BATT flashes.
2. Press **#** to set the phone to pulse mode or **TONE/\*** to set the phone to tone mode.

### ⚠ WARNING ⚠

Dispose of the old battery pack promptly and properly. Do not burn or bury it (see "Battery Safety Instructions" on Page 6 for additional information on proper battery handling).

### ! IMPORTANT !

The EPA certified RBRC®

Battery Recycling



Seal on the nickel-cadmium (Ni-Cd) battery indicates RadioShack is voluntarily participating in an industry program to collect and recycle these batteries at the end of their useful life, when taken out of service in the United States or Canada. The RBRC program provides a convenient alternative to placing used Ni-Cd batteries into the trash or the municipal waste stream, which may be illegal in your area. Please call 1-800-THE-SHACK (1-800-843-7422) for information on Ni-Cd battery recycling and disposal bans/restrictions in your area. RadioShack's involvement in this program is part of the company's commitment to preserving our environment and conserving our natural resources.

If your phone system requires that you dial an access code (9, for example) before you dial an outside number, do not dial the access code.

The phone exits setting mode if a call or page is received, or if you press **END**.

If the battery power is too low, the dialing mode might reset to tone. If you are on a pulse line and cannot make a call, try resetting the dialing mode to pulse.

## SETTING THE HANDSET'S RINGER TONE

You can select either a high or low ringer tone setting while the phone is not in use.

Lift the handset and press **VOL/RING** to hear the current ringer setting. Repeatedly press **VOL/RING** to select the desired ringer setting.

## TURNING THE BASE'S RINGER ON/OFF

You can set the base's ringer to high or low, or turn it off.

1. Press **SET/RING**. The phone's currently set ring sounds, and the current setting appears.
2. Repeatedly press **SET/RING** to change to the desired setting. The system rings at the setting and **Hi**, **Lo**, or **Off** appears. When the ringer is set to **Off**, the phone announces "Off." ✓

Even when you turn off the base's ringer, you can still make or receive calls using this phone. Telephones on the same line and the handset (if its ringer is not turned off) still ring when there is an incoming call.

### NOTE

The phone exits the setting mode if you:

- wait more than 2 seconds between key presses
- receive an incoming call
- press **PLAY/STOP**
- press **TALK** on the handset

If the phone exits the setting mode, start again at Step 1.

# TELEPHONE OPERATION

## MAKING AND RECEIVING CALLS

To make a call, lift the handset and press **TALK**. To answer a call, lift the handset. Or, if the handset is not in place on the base, press **TALK** or any number key, #, or \*. **TALK/BATT** on the handset and **CHARGE/IN USE** on the base light.

To end a call, place the handset on the base or press **END**. **TALK/BATT** and **CHARGE/IN USE** turn off.

## SELECTING THE CHANNEL

The phone scans 20 channels (frequency pairs used between the base and the handset) and automatically selects a clear channel when you make or receive a call.

If you hear other conversations or excessive noise during a call, press **CH** to select a different channel. **TALK/BATT** flashes, followed by a brief pause as your phone searches for a clear channel.

If the handset is too far from the base, the channel might not change. Move closer to the base and try again.

## ADJUSTING THE HANDSET VOLUME

To adjust the volume of the sound you hear through the handset during a call, repeatedly press **VOL/RING**.

## USING FLASH

**FLASH** performs the electronic equivalent of a switchhook operation for special services, such as Call Waiting. For example, if you have Call Waiting, press **FLASH** to answer an incoming call without disconnecting the current call. Press **FLASH** again to return to the first call.

**NOTE****Using Redial**


- The redial memory holds up to 24 digits, so you can redial long-distance as well as local numbers.
- The redial memory also holds pause entries (see "Entering a Pause" on Page 15).

**Using a Headset**

- Connecting a headset disconnects the handset's earpiece and microphone.
- **VOL/RING** on the handset also controls the connected headset's volume.
- If you place the handset on the base to recharge it while the headset is connected, be sure the handset seats properly.
- With a headset connected, you make or answer calls as usual using the keys on the handset.
- You can use an optional handset holder (available from RadioShack) to hang the handset on your belt for greater convenience.

If you do not have any special phone services, pressing **FLASH** might disconnect the current call.

**USING REDIAL**

You can quickly dial the last number you dialed. Lift the handset and press **TALK**, then press **RDL/PAUSE** when you hear a dial tone. 

**USING TONE SERVICES ON A PULSE LINE**

Some special services, such as bank-by-phone, require tone signals. If you have pulse service, you can still use these special tone services. Dial the service's main number. When the service answers, press **TONE/\***. Any additional numbers you dial are sent as tone signals.

When you hang up, the phone automatically resets to pulse dialing.


**PAGING**

To page the person who has the handset or to locate the handset when the phone is not in use, press **PAGE** on the base. The handset beeps for about one minute. To stop it from beeping sooner, press any key on the handset or return the handset to the base. Press **PAGE** again to stop the paging at the base.

**USING A HEADSET**

You can connect an optional headset with a  $\frac{3}{32}$ -inch (2.5-mm) plug. Contact RadioShack for a suitable headset.

To connect the headset, open the rubber cover on the side of the handset, then insert the headset's plug into the jack.

When you finish using the headset, disconnect it from the handset and close the rubber cover to protect the jack. 

## MEMORY DIALING

You can store up to 10 phone numbers in memory, then dial a stored number by entering its memory location number. You can also dial a number stored in memory location number 1 by pressing **SPEED DIAL**. Each number can be up to 16 digits.

### STORING A NUMBER IN MEMORY

1. Lift the handset.
2. Press **MEMORY**. TALK/BATT blinks.
3. Enter the number and any tone or pause entries (see “Using Tone Services on a Pulse Line” on Page 14 and “Entering a Pause”).
4. Press **MEMORY** again, then enter the memory location number (0-9) where you want to store the number. A tone sounds to indicate that the number is stored.

To replace a stored number, simply store a new one in its place. Or, lift the handset and press **MEMORY** twice. Then press the memory location number (0-9) you want to clear. A tone sounds.

### ENTERING A PAUSE

Some telephone systems require you to dial an access code (9, for example) and wait for a second dial tone before you can dial an outside number. You can store the access code with the phone number. However, you should also store a pause after the access code to allow the outside line time to connect.

To enter a 2-second pause, press **RDL/PAUSE**. You can add more pause entries for a longer pause.

### DIALING A MEMORY NUMBER

To dial a number stored in memory, lift the handset and press **TALK**. TALK/BATT lights. When you hear a dial tone, press **MEMORY** and enter the memory location number for the number you want to dial.



#### NOTE

#### *Storing a Number in Memory*

- An error tone sounds and the phone exits the programming mode if you wait more than 30 seconds between keypresses.
- Each tone or pause entry uses one digit of memory.
- If you try to enter more than 16 digits, the phone beeps 5 times and exits the programming mode. Start over at Step 2 and enter no more than 16 digits in Step 3.

#### *Dialing a Memory Number*

If you select an empty memory location, the phone beeps 5 times.

 **NOTE** 

The phone exits menu setting mode if you:

- wait more than 30 seconds between key presses (except when you set the clock, for which time-out is about 2 minutes)
- receive an incoming call
- press **PLAY/STOP**
- press **TALK** on the handset

If the phone exits the setting mode, start again at Step 1.

To dial a number stored in memory location 1, press **SPEED DIAL**. You do not have to press **TALK** when you press **SPEED DIAL**.

## CHAIN-DIALING SERVICE NUMBERS

To quickly recall numbers for special services (such as bank-by-phone), store each group of numbers in its own memory location.


1. Dial the service's main number.
2. When the next number is requested, press **MEMORY** and enter the number for the location where the additional information is stored.

## TESTING STORED EMERGENCY NUMBERS

If you store an emergency service's number (police department, fire department, ambulance) and you choose to test the stored number, make the test call during the late evening or early morning hours to avoid peak demand periods. Also, remain on the line to explain the reason for your call.

# ANSWERING SYSTEM OPERATION

## USING THE MENU BUTTON

Use **MENU** on the base to select the various function settings. Each time you press **MENU**, the system announces the function and its current setting. 

# of Presses	Function
1	Clock set
2	Remote operation Security Code
3	Number of rings before the system answers
4	Recording time for incoming messages
5	Message Alert
6	Exit the menu setting mode.



## SETTING THE DAY/TIME

You must set the day and time so the system can record the correct day and time of each message.



1. Press **MENU** once. The system announces "Time," then the currently set time, day, and the day's number (1 for Sunday, 2 for Monday, and so on) appear.
2. Repeatedly press **▶** on the base to move forward or **◀** to move backward until the correct day appears, then press **SET/RING**. The system announces and displays the hour.
3. Repeatedly press **◀** or **▶** until the correct hour appears, then press **SET/RING**. The system announces and displays the minutes.
4. Repeatedly press **◀** or **▶** until the correct minutes appear, then press **SET/RING**. The system announces "AM" or "PM," and **A** or **P** appears.
5. Press **◀** or **▶** to choose AM or PM, then press **SET/RING**. The system beeps and announces "Time" then announces the currently set day and time.

To check the day and time, press **MENU** once. The system announces the currently set day and time.

## SETTING THE NUMBER OF RINGS

You can select how long the system waits to answer a call — 2, 4, or 6 rings, or toll-saver. If you plan to check messages by long distance, set the ring time to toll-saver (see "Using the Toll-Saver" on Page 24).

1. Press **MENU** three times. The system announces "Ring time" followed by the current setting. The current setting — **2**, **4**, **6**, or **t5** (toll saver) — displays.



### NOTE



- Enter each key press within about 2 minutes. Otherwise, the system exits the time setting process and you must begin again with Step 1.
- If power fails, the clock retains the current time. When the power is restored, it starts counting again from the time the power failed.

2. Repeatedly press **|◀** or **|▶** until the desired number appears.
3. Press **SET/RING** to store the setting.

The system beeps and announces “Ring Time” and the currently set ring time.

## SETTING THE RECORD TIME

You can set the recording time to **1**, **4**, or **R** (Announce Only) to determine how the system records incoming messages.

When set to **1** or **4**, the system plays the outgoing message and lets callers leave a message up to 1 minute (for **1**) or 4 minutes (for **4**) long. When set to **R**, the system plays the outgoing message but does not let callers leave a message.

1. Press **MENU** four times. The system announces “Record time” followed by the current setting. The current setting — **1**, **4**, or **R** — appears.
2. Repeatedly press **|◀** or **|▶** until the desired number appears.
3. Press **SET/RING** to store the setting.

The system beeps and announces “Record Time”, followed by the currently set record time.

## SETTING THE MESSAGE ALERT TONE

The Message Alert feature lets you know you have new messages by sounding a short beeping tone. When a new message is received with the message alert on, the alert tone sounds every 15 seconds.

1. Press **MENU** five times. The system announces “Message Alert” followed by the current setting. The current setting — **OF** (Off) or **On** — appears.
2. Press **|◀** or **|▶** to select **On** or **OF**.

3. Press **SET/RING** to store the setting. A beep sounds, then the system announces "Message Alert" followed by the new setting.

When the first new message is received, a beep sounds.

## **TURNING THE MESSAGE ALERT TONE OFF**

The Message Alert tone automatically stops when you have listened to all the new messages.

To turn off the Message Alert tone sooner, press any key on the base. The Message Alert tone automatically sounds when the next message is received.

## **SELECTING THE OUTGOING MESSAGE**

The system has two prerecorded outgoing messages. One asks the caller to leave a message: "Hello, no one is available to take your call. Please leave a message after the tone." The system uses this message when the recording time is set to **1** or **4** (see "Setting the Record Time" on Page 18).

The other announcement does not allow the caller to leave a message: "Hello, no one is available to take your call. Please call again." The system uses this message when the recording time is set to **Announce Only**.

You can also record your own message (see "Recording/Deleting an Outgoing Message"). When you record your own outgoing message and select it, the system uses it for all recording time settings (**1**, **4**, and **A**).

To switch between your outgoing message and the system's prerecorded message, press **OGM**. The current message plays. While the message is playing, press **OGM** again.



## NOTE

### **Recording/Deleting an Outgoing Message**

Outgoing messages must be between 2 and 30 seconds long.

### **Setting the System to Answer Calls**

When the system's message memory is full, **FL** appears and the system announces "No remaining time" when you try to operate it.

## **RECORDING/DELETING AN OUTGOING MESSAGE**

1. Hold down **OGM**. The system announces "Record greeting," followed by a beep. -- flashes.
2. Speak your message.
3. When you finish your message, press **OGM** or **PLAY/STOP**. The system beeps and plays back your message.

To delete your outgoing message and use the system's prerecorded messages, press **OGM**, then press **DELETE** when your message plays. The system announces "Greeting has been deleted."

## **SETTING THE SYSTEM TO ANSWER CALLS**

Press **ANSWER**.

*If the system is set to record a caller's message (see "Setting the Record Time" on Page 18), it plays the outgoing message and the number of recorded messages appear.*

*If the system is set to **Announcement Only**, it plays the outgoing message, and **A** appears.*

To set the system to not answer calls, press **ANSWER** again. The system announces "Answer off" and the message counter turns off.

## **SCREENING CALLS**

You can let the system answer calls while you listen to the caller's message through the speaker.

Press **TALK** to answer the call if the handset is off the base, or lift the handset if it is on the base. You can also pick up any phone on the same line. The system stops recording and resets to answer the next call.

Press **VOL** ▲ or ▼ to adjust the call screening volume level. If you do not want to listen to calls, repeatedly press **VOL** ▼ until **0** appears. ☑

## RECORDING INCOMING MESSAGES

After the system answers a call, it plays the outgoing message, beeps, then records the caller's message. Each incoming message can be up to 1 or 4 minutes long, depending on how you set the recording time (see "Setting the Record Time" on Page 18). The maximum recording capacity is about 16 minutes (or 59 messages).

The system stops recording and resets to answer the next call when:

- The caller hangs up.
- The maximum message length is reached.
- The system detects a busy signal or more than 7 seconds of silence.
- You pick up the handset or any phone on the same phone line. ☑

## RECORDING A MEMO

A memo is a message you can record for yourself or others. The system stores memos as incoming messages (see "Playing Messages" on Page 22).

Hold down **MEMO** until the system announces "Record memo message" and beeps. Speak your message. -- flashes. The system cannot record a memo less than two seconds long. The maximum length for recording a memo is ten minutes.

When you finish the memo, press **MEMO** or **PLAY/STOP**. ☑

## RECORDING A CONVERSATION

The system lets you record both sides of a telephone conversation when you are talking with the handset. !



**NOTE**

### Screening Calls

Even if you turn the volume to **0** for call screening, you can still hear incoming message playback and announcements.

### Recording Incoming Messages

When the message memory is full, the caller hears "Hello, no one is available to take your call. Please call again." The system cannot record additional messages until you delete some of the old messages (see "Deleting Messages" on Page 23).

### Recording a Memo

When the TAD's message memory is full, **FL** appears and the system announces "No remaining time" when you try to operate it.

### ! IMPORTANT !

Every state has different regulations governing the recording of conversations over the telephone. To determine that your use is in compliance with such laws or guidelines, be sure to check your local, state and federal laws before using this product to record any telephone conversation.

To start recording a phone conversation, press **MEMO** on the base until the answering system beeps and -- appears. As it records the conversation, the system beeps to indicate the conversation is being recorded. To stop recording, press **PLAY/STOP** or **MEMO**. The system stores a recorded conversation as a message (see "Playing Messages").

## PLAYING MESSAGES

After the answering system has recorded a message, its message counter shows the total number of messages stored. If you have new messages, the number of new messages flash. To play your messages, press **PLAY/STOP**. The system announces the number of new and old messages, then plays the new messages. The message number appears as each message plays, and the system announces the day and time of the call at the end of each message.

*To play all messages after playing the new messages, press **PLAY/STOP** again.*

*To skip to the next message, press **▶|** while the message is playing. Hold down **▶|** to quickly advance through a message. The system advances through the message at double speed until the end of the last message. Release **▶|** to resume normal playback.*

*To replay the current message from the beginning, press **|◀**. Hold down **|◀** to review the current message. The system skips back every other second of playback and plays the previous second, until the beginning of the message. Release **|◀** to resume normal playback.*


*To replay the previous message, press **|◀** within about 2 seconds (4 seconds during remote operation) after a message begins playing. If the current message is the first new message, the system plays back from the beginning of the current message (it does not go back into the old message group).*

## ADJUSTING THE VOLUME

To adjust the speaker's volume, repeatedly press **VOL ▲** or **▼** on the base. The volume setting from **0** (lowest) to **9** (highest) appears.


## DELETING MESSAGES

To delete the current message while it is playing, press **DELETE**. The system beeps.

To delete all messages, while messages are not playing, press **DELETE**. The system beeps and announces, "To delete all messages, press **DELETE** again." Within 30 seconds, press **DELETE**. The system beeps, the display clears momentarily, then **0** appears. 

## REMOTE OPERATION

While you are away from your home or office, you can use a touch-tone phone, or a pulse (rotary) phone with a pocket tone dialer (available through RadioShack), to enter your security code and do any of the following:

- Set the system to answer or not answer calls.
- Listen to your messages.
- Record a new outgoing message.
- Record a memo.
- Erase messages. 

## SETTING THE SECURITY CODE

The two-digit remote operation security code prevents unauthorized remote access to your messages. The code is preset to 80. To change the code to any number from 00 to 99:

1. Press **MENU** twice. The system announces "Security code," followed by the currently set code. The code appears.
2. Repeatedly press or hold down **|◀** or **▶|** to change the number, then press **SET/RING** to



### NOTE

#### *Deleting Messages*

You cannot delete new (unplayed) messages. If you try to delete all messages while you still have new messages, the system beeps and announces "Please play back all messages."

#### *Remote Operation*

You cannot remotely operate the system using its handset or another telephone on the same line.

store the setting. The system announces "Security code," followed by the newly set code.

To check your code at any time, press **MENU** twice. The code appears, and the system announces it.

## **USING THE TOLL-SAVER**

If the ring time is set to **t5** (toll-saver) (see "Setting the Number of Rings" on Page 17), the system answers after two rings if you have new messages (ones you have not listened to).

If there are no new messages, the system answers after four rings, so you can hang up before the system answers and avoid unnecessary long-distance charges.

If the message memory is full, the system answers after about ten rings, regardless of the ring time setting.

## **USING REMOTE COMMANDS**

While in remote operation, the system stops all answering functions and displays **Lr**. Answering functions resume when it is no longer being operated remotely, if you have not turned the system off.

Remote operation stops when someone picks up the handset or any phone on the same phone line.

1. Dial your phone number and wait for the system to answer. If the system is not set to answer calls, it will answer after about ten rings and sound a series of beeps.
2. When the outgoing message begins (or the system sounds a series of beeps), press **#**, then enter your security code within 2 seconds.
3. *If the code is correct*, the system announces the number of new and old messages, then "To



play incoming message, press **# 2**. For help, press **# 0**.”

*If the system does not respond, try entering your code again. If you enter an incorrect code three times, the system beeps and disconnects.*

4. While the system is beeping, press **#** and (within 2 seconds) the number for the desired command. (see “Remote Commands”).

## REMOTE COMMANDS

Press # then	To
1	Repeat current message during playback. If you press <b># 1</b> within about 4 seconds after a message begins (unless it is the first new message), the previous message replays.
2	Play messages. The remote playback of incoming messages is limited to 4 minutes. If you have more messages after 4 minutes have passed, you must press <b># 2</b> again to listen to the rest of the messages.
3	Skip current message during playback.
4	Deletes current message during playback. You can only delete the current message during playback. You cannot delete all messages.
5	Stop playback or recording.
6	Set the system to answer calls. Announces the current outgoing message.
7	Record a memo. Announces “Record memo message.” The length of a memo must be between 2 seconds and 4 minutes. Press <b># 7</b> again or <b># 5</b> to stop recording.
8	Record a new outgoing message. Announces “Record greeting.” Press <b># 8</b> again or <b># 5</b> to stop recording.
9	Set the system to not answer calls.
0	Announces the help guidance.

### NOTE

If you wait more than 15 seconds between keypresses, the system sounds a long beep and hangs up.

# TROUBLESHOOTING

Problem	Suggestion
Low volume or unusual sounds.	Someone has picked up another phone on the same line. Hang up the other phone.
Severe noise interference.	<p>Press <b>CH</b> to change the channel.</p> <p>Keep the handset away from computers, remote control toys, wireless microphones, alarm systems, intercoms, room monitors, fluorescent lights, and electrical appliances.</p> <p>Move the handset to another location or turn off the source of interference.</p>
The phone does not work or works poorly.	Be sure the base's phone line cord and AC adapter are correctly and securely connected, and the battery pack is charged.
The phone cannot be operated at a useful distance from the base because the signal becomes weak or noisy.	<p>Lift the base's antenna to a vertical position.</p> <p>The handset's range has decreased. Return the handset to the cradle and recharge the battery pack. Replace the battery pack if necessary.</p>
The handset battery pack does not charge.	<p>If the charging contacts on the handset and base are dirty, clean them with a pencil eraser.</p> <p>Be sure the battery pack is connected correctly.</p> <p>Replace the battery pack.</p>
The handset does not ring or receive a page.	<p>Move the base away from other electrical devices and sources of noise.</p> <p>Move the handset closer to the base.</p> <p>Lift the base's antenna to a vertical position.</p> <p>Be sure the battery pack is charged. (If the battery power is too low, it does not have enough power to light TALK/BATT.)</p>
The handset stops working or works poorly during a call.	<p>Move the handset closer to the base.</p> <p>Lift the base's antenna to a vertical position.</p> <p>Be sure the battery pack is charged. (If the battery power is too low, it does not have enough power to light TALK/BATT.)</p> <p>If the base loses power while the handset is away, the security access-protection code might change. Restore power to the base, then place the handset back on the base. The CHARGE/IN USE indicator lights, indicating that the code is set again.</p> <p>If the charging contacts on the handset and base are dirty, clean them with a pencil eraser.</p>

Problem	Suggestion
The system does not answer calls.	Make sure the system is turned on and the AC adapter is properly connected. Check all phone line connections.
The system does not record the caller's messages	Recording time is set to announce only. Set it to <b>1</b> or <b>4</b> . Delete messages if the memory is full.

If you still have problems, disconnect the phone. If other phones on the same line work properly, the fault is in this phone or its installation. If you cannot find the problem, take your phone to your local RadioShack store for assistance.

## CARE

Keep the phone dry; if it gets wet, wipe it dry immediately. Use and store the phone only in normal temperature environments. Handle the phone carefully; do not drop it. Keep the phone away from dust and dirt, and wipe it with a damp cloth occasionally to keep it looking new.

Modifying or tampering with the phone's internal components can cause a malfunction and might invalidate its warranty and void your FCC authorization to operate it. If your phone is not performing as it should, take it to your local RadioShack store for assistance.

If the trouble is affecting the telephone lines, the phone company can ask you to disconnect your phone until you have resolved the problem.

## FCC STATEMENT

Your telephone complies with Part 68 of the *FCC Rules*. Upon request, you must provide the phone's FCC registration number and REN to your telephone company. These numbers are on the bottom of the base. ☑



### NOTE

You must not connect your telephone to:

- coin-operated systems
- party-line systems
- most electronic key phone systems

## Limited One-Year Warranty

This product is warranted by RadioShack against manufacturing defects in material and workmanship under normal use for one (1) year from the date of purchase from RadioShack company-owned stores and authorized RadioShack franchisees and dealers. EXCEPT AS PROVIDED HEREIN, RadioShack MAKES NO EXPRESS WARRANTIES AND ANY IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE DURATION OF THE WRITTEN LIMITED WARRANTIES CONTAINED HEREIN. EXCEPT AS PROVIDED HEREIN, RadioShack SHALL HAVE NO LIABILITY OR RESPONSIBILITY TO CUSTOMER OR ANY OTHER PERSON OR ENTITY WITH RESPECT TO ANY LIABILITY, LOSS OR DAMAGE CAUSED DIRECTLY OR INDIRECTLY BY USE OR PERFORMANCE OF THE PRODUCT OR ARISING OUT OF ANY BREACH OF THIS WARRANTY, INCLUDING, BUT NOT LIMITED TO, ANY DAMAGES RESULTING FROM INCONVENIENCE, LOSS OF TIME, DATA, PROPERTY, REVENUE, OR PROFIT OR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES, EVEN IF RadioShack HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

In the event of a product defect during the warranty period, take the product and the RadioShack sales receipt as proof of purchase date to any RadioShack store. RadioShack will, at its option, unless otherwise provided by law: (a) correct the defect by product repair without charge for parts and labor; (b) replace the product with one of the same or similar design; or (c) refund the purchase price. All replaced parts and products, and products on which a refund is made, become the property of RadioShack. New or reconditioned parts and products may be used in the performance of warranty service. Repaired or replaced parts and products are warranted for the remainder of the original warranty period. You will be charged for repair or replacement of the product made after the expiration of the warranty period.

This warranty does not cover: (a) damage or failure caused by or attributable to acts of God, abuse, accident, misuse, improper or abnormal usage, failure to follow instructions, improper installation or maintenance, alteration, lightning or other incidence of excess voltage or current; (b) any repairs other than those provided by a RadioShack Authorized Service Facility; (c) consumables such as fuses or batteries; (d) cosmetic damage; (e) transportation, shipping or insurance costs; or (f) costs of product removal, installation, set-up service adjustment or reinstallation.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

RadioShack Customer Relations, 200 Taylor Street, 6th Floor, Fort Worth, TX 76102

12/99

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>