



A new generation of leadership in mobile video.

CV6821

CV6821T Part# 9000566 - Tan

CV6821G Part# 9001181 - Gray

Before operating this unit, please read these operating instructions carefully

Manual # 90001189 Rev. A

ClearVue Series I DVD System Owner's Manual



CORPORATE HEADQUARTERS
1020 Owen Loop South
Eugene, Oregon 97402 800.284.7677

Table of Contents

Quick Reference	3
Powering on the system	
Watching a DVD	
Listening Over Vehicle Speakers	
Using Other Video Sources	
Watching TV	
About the ClearVue 6821 DVD System	4
Operating the System	5
Precautions	5
Switching On	5
Lowering the Screen	5
What You Can Play	6
Front Panel Controls	6
Using the Headphones	7
Using the Car Speakers	8
Using the TV Tuner	9
Remote Control Reference	10
Remote Control Battery Replacement	11
Basic Remote Functions	11
Basic Functions	12
Changing View Settings	15
Advanced Functions	16
Customize Settings	16
DVD Menus	19
Viewing Options	20
Language Support Options	21
Using Auxiliary Sources	22
Important Safety Notices	24

To power on the system:

- 1 Turn ignition switch to *Run* or *ACC*.
- 2 Press the release button as shown.
- 3 Screen will power on automatically.

**To watch a DVD:**

- 1 Power on the system.
- 2 Point the remote at the screen and press the **POWER** button to turn on the DVD player.
- 3 Press the **Eject** button on DVD player or remote to open tray.
- 4 Insert a disc into the DVD and press **Eject** button to close tray. Playback begins.

To listen over the vehicle speakers:

- 1 Turn on the vehicle radio and tune it to 88.7 FM.
- 2 Press **SPEAKER ON/OFF** on the remote until "FM ON" appears on the screen.
- 3 If you hear no audio, try tuning the radio to 89.1 FM.

To use another video source:

- 1 Connect the RCA audio and video outputs of the device to the Audio and Video RCA Inputs on the front of the DVD player.
- 2 Press **MODE** on the remote until the video image appears on the screen.

To watch broadcast television:

- 1 Press **POWER** on the remote.
- 2 Press **MODE** until "TV Mode" appears on the screen.
- 3 Press the up and down arrow buttons on the remote to change channels.

DANGER AN IMPROPERLY LOCATED OR INSTALLED MONITOR CAN CAUSE DEATH OR SERIOUS BODILY INJURY**READ THE FOLLOWING INFORMATION THOROUGHLY BEFORE INSTALLATION**

It is unlawful in most jurisdictions for a person to operate a motor vehicle equipped with a television monitor located where the operator can directly or indirectly view it. In some jurisdictions, television monitors in motor vehicles may be prohibited or may require the television monitor to be located behind the operators seat.

Ensure that you are completely aware of and familiar with all applicable regulations and restrictions related to the use of this equipment in a motor vehicle for your local jurisdiction.

In the event of an accident, passengers can be thrown against objects in the vehicle. **Ensure that the monitor location is in a position where it will not be struck by a passenger in the event of an accident.**

ALWAYS mount the monitor securely using appropriate hardware to a structural component in the vehicle. **Failure to properly secure a monitor could result in the monitor coming loose and endangering the passengers in the event of an accident.**

The **INSTALLER** accepts all responsibility for proper installation of the monitor. **Rosen Products, LLC, is not liable for any damages, incidental or otherwise, which may result from the installation of this product.**

Frequently Asked Questions

Why don't I hear ClearVue sound over my radio?

Try both 89.1 FM and 88.7 FM on your radio dial, and make sure that the FM Modulator is on by pressing and releasing the "SPEAKER ON/OFF" button on the remote until "FM ON" is displayed on the screen.

Why doesn't the TV button on the remote turn on the TV Tuner?

Some buttons on your ClearVue remote are for other Rosen systems and products. Use the **MODE** button to turn the TV Tuner on with your system.

How do I change channels on the TV Tuner?

Press the up and down arrow buttons on the remote.

Why did the headphones stop working?

Check the power switch and the volume control. Check the **MUTE** button on the remote. Then try adding new batteries.

Why did the remote stop working?

Direct remote towards the black oval above the monitor when pressing buttons. Then try adding new batteries.

Why do I have poor ClearVue sound quality sometimes over the speakers?

You may be in an area that has a strong radio signal at the same FM frequency as the FM Modulator. See your Rosen dealer to have the ClearVue FM frequency reset.

Why do I have a poor Video on my screen?

Your DVD players setup may be set to PAL. Check to verify that your "TV Type" in the setup menu is set to NTSC.

About the ClearVue 6821 DVD System

Welcome to the *ClearVue 6821 DVD System Owner's Manual*. The ClearVue 6821 DVD system includes the following components:

- Overhead Monitor
- DVD Player with TV Tuner
- Wireless IR Headphones (2 pair)
- Wireless IR Transmitter Dome
- Remote Control
- FM Modulator (enables the DVD sound to be heard over your vehicle's speakers).
- Vehicle Trim Ring

- Other parts and cables which are installed out of sight in your vehicle.

Note: *The system is intended to be used with your ignition key switch in the Run or Acc position. Extended use of the system without the engine running should be avoided, as it could drain the battery.*

Operating the System

Precautions

- Use this system only after proper installation by a qualified installer.
- If the internal temperature of the vehicle is extremely high, allow a short cooling down period before operating the unit.
- If the unit shows signs of overheating or malfunction, power off the unit and consult your dealer immediately.
- Do not open the unit; there are no serviceable parts inside.

Switching On


Use the system when your vehicle is running or the ignition switch is in the “accessory” position.

To avoid a dead battery, do not use the system for long periods of time without the engine running.

Lowering the Screen

To lower the screen, press the release button on the overhead monitor, as shown. The screen will lower into the viewing position.

To adjust the viewing position, insert two fingers into the adjustment knob and rotate as needed.



Using Auxiliary Sources

The system includes RCA inputs on the front of the DVD player that enable you to attach an external source device such as a video game or camcorder. You can also listen to an external audio source such as an MP3 player, portable CD player, or MiniDisc™.

Note: Before attempting to use any auxiliary source, be sure you have the appropriate cable to connect to the system.

To connect the auxiliary device to the DVD front panel RCA jacks:

- 1 Connect the right channel audio to the red jack.
- 2 Connect the left channel audio to the white jack.
- 3 Connect the video to the yellow jack.

Note: When using a non-battery operated Auxiliary source (video game, or other) in a vehicle, a 12VDC/110VAC power inverter is required.

To play an auxiliary device:

- 1 Power on system.
- 2 Power on the device.
- 3 Press **MODE** on the remote until the auxiliary source device is activated. The system cycles from DVD Mode, to TV Mode, to auxiliary source mode, and back to DVD Mode.

Language Support Options

Some DVDs offer a variety of language options for DVD audio, DVD menu text, and DVD subtitles. Features vary depending on the DVD you are viewing.

If DVDs and VCDs contain multiple audio tracks, the same video can be viewed with different audio.

To change the audio on a DVD:

- 1 During DVD playback, press the **AUDIO** button on the remote control.

“AUDIO x/y” appears in the monitor, where x represents the current audio stream and y represents the total available audio streams.

- 2 Press the **AUDIO** button to cycle through all available audio streams until the preferred audio is selected.

To change the audio on a VCD:

- During VCD playback, press the **AUDIO** button until the desired audio is selected.


What You Can Play

This unit is designed for use with DVD, VCD, CD, CD-R, and CD-RW with MP3 or MPEG-1 file recordings. Functions will vary depending on the features available on the disc you are playing.

Note: *LDs are not compatible.*


Front Panel Controls

Backlighting on the front panel controls indicates when power is on.




- 1 Arrow buttons—Highlight selections.
- 2 Next track—Selects next chapter, title, or CD track.
- 3 Previous track—Selects previous chapter, title, or track.
- 4 DVD tray.
- 5 Power—Powers the system on and off.
- 6 Eject—Ejects a disc.
- 7 Aux input—Right channel audio input, red.
- 8 Aux input—Left channel audio input, white.
- 9 Aux input—Video input, yellow.
- 10 Menu—Accesses main menu (DVDs only).
- 11 Enter—Confirms a selection.
- 12 Play—Begins or resumes playback.
- 13 Stop—Stops playback.
- 14 Infrared sensor—For use with DVD remote control only. Does not operate with the ClearVue system remote.

Using the Headphones



Using the headphones with your system allows rear-seat passengers to listen to their DVD or video game without disturbing front-seat passengers. When using the headphones the IR transmitter dome must have a direct line of sight to the headphones to work properly.

The system comes with two wireless IR headphones that receive a signal from the IR transmitter dome near the overhead console.



To turn the headphones on and off, push the Power ON/OFF button on the right ear piece. The Power LED on the left ear piece indicates when headphone power is on. Power turns off automatically after 3 minutes of no audio to preserve battery life.

To adjust the headphone volume, rotate the thumb wheel switch on the headphones.

The wireless IR headphones require two AAA batteries. To replace

- “Chapter remain”—Chapter remaining time.

To display status information for audio CDs:

Press the **DISP** button repeatedly to cycle through the following information:

- “Single elapsed”—Track time.
- “Single remain”—Track remaining time.
- “Total elapsed”—Disc time.
- “Total remain”—Disc remaining time.
- Display off.

Viewing Options

Camera Angle

Some DVD discs contain scenes with more than one viewing angle. For these discs, the same scene can be viewed from a different angle by using the **ANGLE** button on the remote control.

To view a scene from another angle:

- 1 During DVD playback, press the **ANGLE** button. “ANGLE x/y” appears in the monitor, where x represents the current camera angle and y represents the total available camera angles.
- 2 Press the **ANGLE** button again to cycle through all available camera angles until the preferred angle is selected.

Note: *This function is only available on DVDs that contain multiple viewing angles.*

DVD Menus

Most DVD discs have unique menu structures. DVD menu contents and operation may differ from disc to disc.

To use DVD menus:

- 1 During DVD playback, press the **MENU** button. The DVD menu available on the disc appears on the screen.
- 2 Use the up, down, left and right arrows to select the preferred menu option.
- 3 Press **PLAY/PAUSE** when the desired option is selected.

Title Menu

Some DVD discs also include more than one title.

To change titles:

- 1 During DVD playback, press the **TITLE** button. A list of the titles available on the DVD appears on the screen.
- 2 Use the up, down, left and right arrows to select a title.
- 3 Press the **ENTER** button when the desired option is selected.

Display Menu


The DISPLAY function enables you to view the status, current title number, track number and the total playing time of the disc on the monitor.

To display status information for VCDs and DVDs:

Press the **DISP** button repeatedly to cycle through the following information on the monitor:

- “Title x/y and Chapter x/y”—Title elapsed time, where x is the current chapter or title and y is the total number of chapters or titles.
- “Title remain”—Title remaining time.
- “Chapter elapsed”—Chapter elapsed time.

the batteries, remove the battery compartment cap on the right earpiece and insert batteries, as shown.



Using the Car Speakers

To listen to system audio through your car speakers:

- 1 Insert a disc.
- 2 Turn on the car radio.
- 3 Tune the car radio to the FM frequency 88.7; this is the default system frequency.

If audio from the system does not play over the car speakers:

- 1 Press **SPEAKER ON/OFF** on the remote control until “FM ON” appears on the screen.

and/or

- 2 Tune the radio to 89.1 FM. This is an alternate system frequency.

To turn off audio over the car speakers, press **SPEAKER ON/OFF** on the remote. Audio from the system is then available over the headphones only.

Note: Leaving the system to **SPEAKER ON** mode will reduce the performance of normal radio reception. To receive the best reception, always turn the system to **SPEAKER OFF** when not in use.

Using the TV Tuner

To view television on the system:

- 1 Press **MODE** on the remote control until “TV Mode” appears on the screen.
- 2 Press the up and down arrow buttons on the remote to change channels.
- 3 Press **MODE** on the remote twice to return to DVD Mode.

Note: *Broadcast television reception varies with location, terrain, distance from the broadcast tower, and other factors. Signal quality is likely to vary in a moving vehicle.*

To access the parental control rating system:

- 1 Press the **SETUP** button. The Setup menu appears.
- 2 Use the up and down arrows to highlight “Parental Control” and press **PLAY/PAUSE** twice to confirm your selection.
- 3 Use the up and down arrows to highlight “Parental”.
- 4 To set a parental control level, press the right arrow and then use the up and down arrows to highlight the desired level of control.
- 5 Press **PLAY/PAUSE** twice to confirm your selection. “Input pwd” appears, prompting you to enter a password.
- 6 Enter a four-digit password and press **PLAY/PAUSE** twice to confirm your selection. The factory default password is 0000.
- 7 Press **SETUP** to exit the Setup menu and begin playback.

To change the password:

- 1 Press the **SETUP** button. The Setup menu appears.
- 2 Use the up and down arrows to highlight “Parental Control” and press **PLAY/PAUSE** twice to confirm your selection.
- 3 Use the up and down arrows to highlight “Password”.
- 4 Press the right arrow to highlight “Change” and press **PLAY/PAUSE**.
- 4 Enter the existing four digit password using the number buttons on the remote. The factory default password is 0000.
- 5 Enter a new four digit password.
- 6 Enter the new password again to confirm it.
- 7 Press **SETUP** to exit the Setup menu and begin playback.

- “Pic mode”—
“Auto”: Automatically adjusts screen.
“Hi-resolution”: Enhances screen image.
“N-flicker”: Prevents screen trembling.
- “Angle mark”—When playing DVDs that can be viewed from different angles, a camera icon appears on the upper part of the screen.
- “Captions”—Turns on or off subtitles.
- “Scr saver”—Activates screen saver after 10 minutes of inactivity. After 1 hour the DVD Tuner enters standby mode.

Audio Setup

- “Digital out”—Adjusts the output for the digital audio terminal.
- “Dynamic range”—Dolby Digital sound. Use when it is difficult to hear dialogues through the stereo or TV. This feature is only supported by DVD titles with DRC properties.
- “Downmix”—Controls stereo and two channel audio.
“LT/RT”: Select when the amplifier has Dolby Pro Logic support.
“Stereo”: Select when listening to general stereo sound.
“VSS (Virtual Surround System)”: Select when listening through VSS.


Parental Control

- “Parental”—If the current disc has a parental code, it is possible to skip or substitute various scenes not suitable for young children.
- “Password”—Create and change password necessary for parental control feature.
- “Default”—Returns DVD player to default settings. The user must know the current password to do so.

The Parental Control feature interacts with the DVD rating, if available on the DVD, to enable parents to limit DVD playback.


Remote Control Reference

The ClearVue system remote control includes the following features. Only the buttons labeled below are active.



Remote Control Battery Replacement

The ClearVue system remote requires two AAA batteries. Replace the batteries as shown below.



Using the Remote Control

When using the remote control, always aim at the infrared sensor on the overhead monitor.

This unit is designed for use with DVD, VCD, CD, CD-R, and CD-RW, and with MP3 or MPEG-1 file recordings. Functions on the remote control will vary depending on the features available on the disc you are playing. If a function is unavailable on the inserted CD, VCD, or DVD, the following symbol appears on the on-screen display:



If a disc is incompatible with the unit or if the disc is loaded incorrectly, you may see one of the following on the on-screen display:

- “No disc” — Check to see that the disc is loaded with the **label side up**.
- “Smart navigation” screen — The DVD player may be trying to read an incompatible disc. Check disc compatibility.
- Another error message indicating the disc is either incompatible or loaded incorrectly.

Advanced Functions

Customize Settings

Use the Setup menu to personalize operation of your DVD player. Setup includes options for various Language, Display, Audio, and Parental Control features. The features are described below.

- 1 Press the **SETUP** button. The Setup menu appears.
- 2 Use the arrow keys to highlight your selection and press **PLAY/PAUSE** to confirm your selection.
- 3 Press **SETUP** again to begin playback.

Language Setup

- “OSD Language”—Selects language used in Setup menu.
- “Audio”—Selects the language of DVD audio.
- “Subtitle”—Selects the caption language.
- “Disc menu”—Selects the DVD menu language.

Note: *Audio, Subtitle, and Disc menu can only be adjusted when playback is stopped.*

Display Setup

- “TV display”—
 - “Normal/PS”: When viewing a 16:9 image on a 4:3 screen the sides are cropped.
 - “Normal/LB”: When viewing a 16:9 image on a 4:3 screen, a black bar appears on the top and bottom of the screen and the complete image is shown.
 - “Wide”: Use when connecting to a wide-screen TV.
- “TV type”—
 - “Multi”: Outputs the original PAL or NTSC signal recorded into the title.
 - “NTSC”: Changes image signal to NTSC.
 - “PAL”: Changes image signal to PAL. **Do not use this setting.**

Changing View Settings

To adjust settings for color, contrast, brightness, or tint:

- 1 Press **VIDEO MENU** on the remote. The following menu appears in the screen.

MENU	
COLOR	(32)
CONTRAST	(32)
BRIGHT	(32)
TINT	(32)

- 2 Press the up and down arrow keys on the remote to highlight a menu option. Each menu option has a range of values from 0 to 63, with 32 as the default.
- 3 Press the left arrow key on the remote to reduce a setting.
- 4 Press the right arrow key on the remote to increase a setting.
- 5 Press **EXIT** on the remote to close the menu. The menu also closes automatically after a few seconds.

Basic Functions

Inserting or Ejecting Discs

Press the **EJECT** button to insert or eject a disc.

Playback

To play a disc:

- 1 Press the **EJECT** button to open the DVD player.
- 2 Load the disc with the **label side up**.
- 3 Press **EJECT** again. "Disc loading" appears on the screen. The disc commences playback automatically.

DVD playback varies from disc to disc. Options include:

- DVD playback begins automatically when you insert the disc.
- DVD playback begins automatically, but proceeds only until a menu of options appears. To continue playback, highlight an option using the arrow buttons then press **PLAY/PAUSE** on the remote control.
- The screen displays a menu of options before proceeding. To continue, highlight an option using the arrow buttons then press **PLAY/PAUSE** on the remote control.

Stop

- 1 Press the **STOP** button to stop playback. The DVD player saves in internal memory the exact position where it stopped and will playback again from that position.
- 2 Press **PLAY/PAUSE** to resume normal playback.

Note: For some VCDs, the Stop function can be enabled by pressing the **NEXT** button.

Pause

- 1 Press the **PLAY/PAUSE** button to pause playback of the disc.
- 2 Press **PLAY/PAUSE** to resume playback.

Mute

- 1 Press the **MUTE** button once to mute the sound.
“Mute” appears on the monitor.
- 2 Press **MUTE** again to restore sound.

Fast Forward and Reverse Searching

- 1 Press the **FAST** button during playback to fast forward.
“FF 2x” appears on the monitor.
- 3 Press **PLAY/PAUSE** to resume regular play.

Slow Forward and Reverse Searching

- 1 Press the **SLOW** button during playback to slow forward.
“SF 2x” appears on the monitor.
- 3 Press **PLAY/PAUSE** to resume regular play.

Note: *Slow forward is not an option when playing audio CDs.*

Searching One Scene or Track at a Time

- 1 Press the **PLAY/PAUSE** button to pause playback of the disc.
- 2 Set the direction of the scene-by-scene search by using the right or left arrow button.
- 3 Press **PLAY/PAUSE** to resume regular play.

Searching by Next or Previous Chapter or Track

- Press the **NEXT TRK** button during playback to skip forward to the next track or to the next title/chapter.

For VCDs and DVDS—“Chapter x/y” appears on the monitor, where x is the current chapter and y is the total number of chapters.

For audio CDs—“Next” appears on the monitor.

Note: *For MP3 discs, if the disc is stopped, press the up and down arrows instead of the **NEXT TRK** or **PREVIOUS TRK** buttons to select a song.*

- Press the **PREVIOUS TRK** button during playback to skip backward to the previous track or to the previous title/chapter.

For VCDs and DVDS—“Chapter x/y” appears on the monitor, where x is the current chapter and y is the total number of chapters.

For audio CDs—“Previous” appears on the monitor.

Repeating a Track or Chapter

The DVD player will repeat a track or chapter, or an audio disc.

Press the **REP** button on the remote control to cycle through the following on-screen display options.

For DVDs:

- “Chapter repeat on”—The current chapter will be repeated.
- “Title repeat on”—The current title will be repeated.
- “Repeat off”—Repeat mode is off.

For audio/video CDs:

- “Rep one”—The current track will be repeated.
- “Rep all”—The current disc will be repeated.
- “Repeat off”—Repeat mode is off.

Note: *For MP3 CDs, press the **REP** button to change the play mode.*

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>