




myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for SONY CYBER-SHOT DSC-H10. You'll find the answers to all your questions on the SONY CYBER-SHOT DSC-H10 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SONY CYBER-SHOT DSC-H10
User guide SONY CYBER-SHOT DSC-H10
Operating instructions SONY CYBER-SHOT DSC-H10
Instructions for use SONY CYBER-SHOT DSC-H10
Instruction manual SONY CYBER-SHOT DSC-H10



[Your user manual](#)
[SONY CYBER-SHOT DSC-H10](#)

Manual abstract:

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. The supplied interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules. [Attention The electromagnetic fields at the specific frequencies may influence the picture and sound of this unit. [Notice If static electricity or electromagnetism causes data transfer to discontinue midway (fail), restart the application or disconnect and connect the communication cable (USB, etc.) again.

[Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems) For the State of California, USA only Perchlorate Material - special handling may apply, See www.dtsc.ca.gov/hazardouswaste/perchlorate Perchlorate Material:

Lithium battery contains perchlorate. This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product. 5 Notice for customers in the United Kingdom A moulded plug complying with BS 1363 is fitted to this equipment for your safety and convenience.

Should the fuse in the plug supplied need to be replaced, a fuse of the same rating as the supplied one and approved by ASTA or BSI to BS 1362, (i.e., marked with an or mark) must be used. If the plug supplied with this equipment has a detachable fuse cover, be sure to attach the fuse cover after you change the fuse. Never use the plug without the fuse cover. If you should lose the fuse cover, please contact your nearest Sony service station. 6 Table of contents IMPORTANT SAFEGUARDS . 2 Read this first 4 Notes on using your camera 8 Getting started . 9 Checking the accessories supplied . 9 1 Preparing the battery pack 10 2 Inserting the battery pack/a "Memory Stick Duo" (not supplied) 11 3 Turning the camera on/setting the clock .

13 Shooting images easily . 14 Mode dial/Zoom/Flash/Macro/Self-timer/Display . 15 Viewing/deleting images . 16 Learning the various functions HOME/Menu . 18 Using the HOME screen . 18 HOME items . 19 Using menu items . 20 Menu items . 21 Enjoying your computer . 22 Supported Operating Systems for USB connection and application software (supplied) .

22 Viewing "Cyber-shot Handbook" and "Cyber-shot Step-up Guide" . 23 Indicators on the screen . 24 Battery life and memory capacity 26 Battery life and number of images that can be recorded/viewed 26 Number of still images and recording time of movies 27 Troubleshooting . 28 Battery pack and power ..



[Your user manual](#)

[SONY CYBER-SHOT DSC-H10](#)

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>