

AUTOMATIC BATTERY CHARGER

OWNER'S MANUAL & WARRANTY INFORMATION
12 VOLT 2/6/12 AMPERE CHARGE RATES WITH
ALTERNATOR VOLTAGE CHECK AND BATTERY RECONDITION FUNCTIONS

• IMPORTANT SAFETY INSTRUCTIONS •

WARNING – RISK OF EXPLOSIVE GASES

- 1. WORKING IN VICINITY OF A LEAD-ACID BATTERY IS DANGEROUS. BATTERIES GENERATE EXPLOSIVE GASES DURING NORMAL BATTERY OPERATION. FOR THIS REASON, IT IS OF UTMOST IMPORTANCE THAT EACH TIME BEFORE USING YOUR CHARGER, YOU READ THIS MANUAL AND FOLLOW THE INSTRUCTIONS EXACTLY.**
2. To reduce risk of battery explosion, follow these instructions and those published by the battery manufacturer and manufacturer of any equipment you intend to use in vicinity of battery. Review cautionary markings on these products and on engine.

GENERAL BATTERY SAFETY

1. Use this charger for charging a 12 V LEAD-ACID battery only. It is not intended to supply power to a low voltage electrical system other than in automotive applications. Do not use this battery charger for other types of batteries, these may burst and cause injury to persons and damage to property.
2. Use of an attachment not recommended or sold by the battery charger manufacturer may result in a risk of fire, electric shock, or injury to persons.
3. To reduce risk of damage to electric plug and cord, pull by plug rather than cord when disconnecting charger.
4. An extension cord should not be used unless absolutely necessary. Use of an improper extension cord could result in a risk of fire and electric shock. If extension cord must be used, make sure:
 - a. That pins on plug of extension cord are the same number, size, and shape as those of plug on charger.
 - b. That extension cord is properly wired and in good electrical condition; and
 - c. That wire size is AWG#14 (14 gauge) to 100 feet and AWG#12 for distances over 100 feet.
5. Do not operate charger with damaged cord or plug - replace the cord or plug immediately.
6. Do not operate charger if it has received a sharp blow, been dropped, or otherwise damaged in any way; take it to a qualified service technician.
7. Do not disassemble charger; take it to a qualified service technician when service or repair is required. Incorrect reassembly may result in a risk of electric shock or fire.
8. To reduce risk of electric shock, unplug charger from outlet before attempting any maintenance or cleaning. Turning off controls will not reduce this risk.
9. Do not expose charger to rain or snow or use when wet .
10. Never charge a frozen battery.

SAVE THESE INSTRUCTIONS:

This manual contains important safety and operating instructions for battery charger Model VEC088
4140 SW 28TH WAY, FT. LAUDERDALE, FL 33312 • TEL: 954-584-4446 • FAX: 954-584-5556 • TOLL-FREE 866-584-5504

PERSONAL PRECAUTIONS AND SAFETY

1. Someone should be within range of your voice or close enough to come to your aid when you work near a lead-acid battery.
2. Have plenty of fresh water and soap nearby in case battery acid contacts skin, clothing, or eyes.
3. Wear complete eye protection and clothing protection. Avoid touching eyes while working with a battery. Acid, acid particles or corrosion may get into your eyes. Immediately flood eye with running cold water for at least 10 minutes and get medical attention immediately.
4. If battery acid contacts skin or clothing, wash immediately with soap and water.
5. NEVER smoke or allow a spark or flame in vicinity of battery or engine.
6. Be extra cautious to reduce risk of dropping a metal tool onto battery. It might spark or short-circuit battery or other electrical part that may cause explosion.
7. Remove any metal items on your person such as rings, bracelets, necklaces, and watches when working with a lead-acid battery. A lead-acid battery can produce a short-circuit current high enough to weld a ring, or the like to metal causing a severe burn.

GROUND AND AC POWER CORD CONNECTION

Charger should be grounded to reduce risk of electric shock. Charger is equipped with an electric cord having an equipment grounding conductor and a grounding lug. The plug must be plugged into an outlet that is properly installed and grounded in accordance with all local codes and ordinances. (See Figure 1.)

DANGER! NEVER alter AC cord or plug provided - if it will not fit outlet, have proper outlet installed by a qualified electrician. Improper connection can result in the risk of an electric shock.


This battery charger is for use on a nominal 120 volt circuit, has a grounding plug that looks like the plug illustrated in Figure 1 A. A temporary adapter, which looks like the adapter illustrated in Figure 1 B, may be used to connect this plug to a two-pole receptacle as shown in Figure 1 B, if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet can be installed by a qualified electrician.

DANGER! Before using adapter as illustrated, be certain that center screw of outlet plate is grounded. The green-colored rigid ear or tab extending from adapter must be connected to a properly grounded outlet - make certain it is grounded. If necessary, replace original outlet cover plate screw with a longer screw that will secure adapter ear or tab to outlet cover plate and make ground connection to grounded outlet.

FIGURE 1A

GROUNDING PIN (A)


SCREW




GROUNDING
MEANS

FIGURE 1B

ADAPTER (B)



METAL



USE OF AN ADAPTER IS NOT ALLOWED IN CANADA. IF A GROUNDING TYPE RECEPTACLE IS NOT AVAILABLE, DO NOT USE THIS APPLIANCE UNTIL THE PROPER OUTLET IS INSTALLED BY A QUALIFIED ELECTRICIAN.

VEC088

PREPARING TO CHARGE

1. Determine voltage of battery by referring to car owner's manual.
2. If it is necessary to remove battery from vehicle to charge, or to clean terminals, always remove grounded terminal from battery first. Make sure all accessories in the vehicle are off, so as not to cause an arc.
3. Clean battery terminals. Be careful to keep corrosion from coming in contact with eyes.
4. Add distilled water in each cell until battery acid reaches level specified by battery manufacturer. This helps purge excessive gas from cells. Do not overfill. For a battery without cell caps, carefully follow manufacturer's recharging instructions.
5. Study all battery manufacturers' specific precautions such as removing or not removing cell caps while charging and recommended rates of charge.
6. Be sure area around battery is well ventilated while battery is being charged. Gas can be forcefully blown away by using a piece of cardboard or other nonmetallic material such as a fan.
7. Make sure the initial charging rate is not over battery manufacturer's suggestion.

CHARGER LOCATION

1. Locate charger as far away from battery as cables permit.
2. Never place the charger directly above battery being charged; gases from battery will corrode and damage charger.
3. Never allow the battery acid to drip on charger when reading gravity or filling battery.
4. Do not operate charger in a closed-in area or restrict ventilation in any way.
5. Marine batteries must be removed and charged on shore.
6. Do not set a battery on top of charger.

DC CONNECTION PRECAUTIONS

1. Connect and disconnect DC output clips only after removing AC cord from electric outlet.
2. Never allow clips to touch each other.
3. Attach clips to battery posts and twist or rock back and forth several times to make a good connection. This tends to keep clips from slipping off terminals and helps to reduce risk of sparking.

FOLLOW THESE STEPS WHEN BATTERY IS INSTALLED IN VEHICLE. A SPARK NEAR BATTERY MAY CAUSE BATTERY EXPLOSION. TO REDUCE RISK OF A SPARK NEAR BATTERY:


- a. Position AC and DC cords to reduce risk of damage by hood, door, or moving engine part.
- b. Stay clear of fan blades, belts, pulleys, and other parts that can cause injury to persons.
- c. Check polarity of battery posts. POSITIVE (POS, P, +) battery post usually has larger diameter than NEGATIVE (NEG, N, -) post.
- d. Determine which post of battery is grounded (connected) to the chassis. If negative post is grounded to chassis (as in most vehicles), see (e). If positive post is grounded to the chassis, see (f).
For negative-grounded vehicle, connect POSITIVE (RED) clip from battery charger to POSITIVE (POS, P, +) ungrounded post of battery. Connect NEGATIVE (BLACK) clip to vehicle chassis or engine block away from battery. Do not connect clip to carburetor, fuel lines, or sheet-metal body parts. Connect to heavy gauge metal part of the frame or engine block.
- f. For positive-grounded vehicle, connect NEGATIVE (BLACK) clip from battery charger to NEGATIVE (NEG, N, -) ungrounded post of battery. Connect POSITIVE (RED) clip to vehicle chassis or engine block away from battery. Do not connect clip to carburetor, fuel lines, or sheet-metal body parts. Connect to a heavy gauge metal part of the frame or engine block.
- g. When disconnecting charger, disconnect AC cord, remove clip from vehicle chassis, and then remove clip from battery terminal.
- h. See operating instructions for length of charge information.
- i. Do not charge the battery while the engine is operating.

INTRODUCTION AND FEATURES

Thank you for selecting the Vector Model VEC088 2/6/12 Amp 12 volt Smart Battery Charger, with Alternator Voltage Check and Battery Recondition modes. With proper care and use, it will give you years of dependable service. This model battery charger has a high charge rate of up to 35 amps, and low charge rate of up to 2 amps. It is intended for charging only 12 volt lead-acid batteries maintenance free, conventional automotive, marine deep cycle and gel that are usually used in cars, trucks, farm equipment, boats, RVs and SUVs, lawn mowers and garden tractors, motorcycles, personal watercraft, snowmobiles, ATVs, trucks and various commercial applications.

Vector Smart Chargers are microprocessor-based and have a charge curve that has three stages. (See Figure 2). Stage One is essentially a constant current charge. This continues until the connected battery is about 85 percent charged. When Stage One ends, the charger briefly sounds a tone (beep) to indicate a change to Stage Two, the Absorption Phase. This stage is essentially a constant voltage phase and supplies approximately 10 percent of the charge. At the end of Stage Two, the charger changes output to Stage Three. Stage Three continues and turns OFF when the battery reaches full charge. This charger has a CHARGING COMPLETE LED and the digital display shows FUL when the battery is fully charged.

FIGURE 2. CHARGE CURVE



FEATURES


- The unit has three charge rate setting, with a 2/6/12A pushbutton charge rate switch:
 - a) 2 amps: smaller batteries as in lawn mowers, snowmobiles, motorcycles, etc.
 - b) 6 amps: middle sized batteries such as in small cars
 - c) 12 amps: automobile and small truck batteries.
- Microprocessor controlled for proper operation and for fault detection.
- Large Lighted Digital Display, shows charging current, and codes that indicate faults, and modes of operation and timeout of functions.
- High Frequency operation for pure DC output.
- Rapid charging three stage output.
- Heavy-duty cables and clamps are corrosion-resistant for better connections.
- Connect to side, or top-mount battery terminals.
- Rugged case with baked on finish, plus sturdy carry handle.
- Self storage of cables and clamps.
- Ideal for charging during winter season when the starting performance of vehicle batteries is lowered by cold or extreme weather conditions.
- Single beep tone indicates a button is pressed or a mode change occurs.
- Battery Recondition mode provides desulfation of battery plates to improve battery performance.
- Alternator Voltage Check can confirm proper operation of the alternator and indicate less than full output.

VEC088

FIGURE 3A (FRONT VIEW)



FIGURE 3B (REAR VIEW)



WARNINGS:

THERE ARE NO USER-SERVICEABLE PARTS IN THIS CHARGER. IN THE EVENT OF ANY OPERATING PROBLEM THAT THE CHARGER'S BUILT-IN CIRCUIT PROTECTION CANNOT HANDLE, DO NOT OPEN THE UNIT. IT MUST BE RETURNED TO VECTOR FOR PROFESSIONAL TESTING AND REPAIR. OPENING THE UNIT WILL VOID THE MANUFACTURER'S WARRANTY. Contact the Vector Technical Support Department at (954) 584-4446 or toll free at (866) 584-5504 for further information.

CONTROLS AND INDICATORS

There are four LED indicators and four switches that make up the controls and indicators for this charger. Every time a pushbutton is pressed or the charger changes mode or charging stage, the charger sounds a single beep tone. Refer to Figure 4 for locations of items on the Controls and Indicators panel.

FIGURE 4A




FIGURE 4B
Circulating pattern

From left to right the pushbuttons are:

ON/OFF - this prepares the charger to be placed in any of the operating modes. Pressing the ON/OFF pushbutton immediately stops any operating mode and the display shows the circulating pattern (Figure 4B).

Alternator Voltage Check enables a five second check that measures the battery voltage. This check is repeated at various electrical load levels and the tests allow the user to determine if the alternator can keep up with the loads. It can indicate alternator service may be required.




Battery Recondition is an automatic mode that once started continues for 24 hours and then stops. A series of electrical pulses breaks the crystalline form of lead sulfate to return these chemicals into useful service as part of the battery chemistry. More than 24 hours may be needed to restore. If 5 cycles does not improve battery performance, discontinue and recycle the battery.

2/6/12A allows the user to select the charger rate based on battery size. This selection and the actual battery charge rate are monitored by the microprocessor and the charger will stop charging if the rate is too fast or too slow for the battery size or condition.

INDICATORS

The large 3-character Digital Display in the upper left hand corner of the panel indicates many conditions. It indicates when AC power is applied to the charger, actual charge rate in ampere, when the battery is fully charged, detected faults, operating modes and when the charger is ready for the next mode selection. What is displayed are called "status codes". They are described below (Figure 5) and on the rear of the charger, for handy reference.

FIGURE 5

| | |
|-------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | AC POWER INDICATOR - When connected to an AC outlet, digital display shows circulating pattern to indicate power is on. Disconnect charger after use. |
| FAULT CODES | |
| F01 | INTERNAL SHORTED CELL BATTERY - Cannot be charged, bad battery. Replace Battery. |
| F02 | BAD BATTERY CONNECTION - Check battery connection or BATTERY VOLTAGE TOO LOW TO ACCEPT CHARGE - Bad battery. Replace Battery. |
| F03 | INTERNAL OPEN CELL - Bad battery. Battery needs to be replaced or SULFATED CONDITION - Battery needs to be reconditioned for 24 to 48 hours. |
| F04 | OVERTIME CONDITION - Battery will not accept a charge after 18 hours of continuous charging. Battery has internal damage and needs to be replaced or BATTERY CHARGE RATE IS SET TOO LOW - Set charger to higher charge rate. |
| F05 | OVERHEATED CONDITION - Disconnect charger and allow to cool for 30 minutes, check for ample ventilation. |
| OPERATION CODES | |
|  | BATTERY RECONDITIONING - (The letters <i>des</i> will display for the first 5 seconds) |
|  | ALTERNATOR VOLTAGE CHECK |
| 000 | CHARGER STANDBY |
| FUL | BATTERY FULLY CHARGED |

Below the Digital Display are series of four LEDs that light on the following conditions:

FAULT - lights when any of several faults are detected - see F01 through F05 Codes as described above (If the Fault LED lights, refer to **TROUBLESHOOTING** for details).

REV POLARITY - Lights when the clamps are connected to incorrect polarity.

CHARGING COMPLETE - Indicates Battery is charged. Charging Complete lights at same time the digital display shows "FUL".

ALTERNATOR GOOD - lights when this particular load check shows the alternator is keeping up with the electrical load.

CHARGE RATE SELECTION

After the clamps are connected, plug in the charger to an AC outlet and the charger will show a circulating pattern on the Digital Display. This pattern indicates power is applied. Press the ON/OFF button to prepare the charger to change to an operating mode. Press the 2/6/12A button and the charger will begin charging at 2 Amps. Pressing the 2/6/12A switch again will advance the charge rate to 6A, then 12A. Pressing the switch again will turn OFF the charger output and the display will show the circulating pattern.

Note that each time the charger rate is changed, the charger sounds a beep tone. The only time the selected charge rate does not display at the full selected rate is when the battery is nearly full and charging at either steps two or three. The display will be showing a slowing charge rate. To return to 2A, press the 2/6/12A button. When the battery is fully charged, the charging Complete LED is lit and "FUL" is displayed on the Digital Display.

CONNECTING IF BATTERY IS INSTALLED IN VEHICLE

- a) Check polarity of battery posts. For top-mounted battery connectors, the Positive post (marked POS, P, +) usually has a larger diameter than the Negative battery post (marked NEG, N, -). For side-mounted battery connectors, the terminals are marked Positive -red and Negative -black.
- b) Attach charger clamps to battery connections, as follows, ensuring a good connection (if there is a mistake, the Reverse Polarity Indicator will light): **NEGATIVE-GROUNDED VEHICLE:** Connect the **POSITIVE (RED)** charger clamp to the **POSITIVE (POS, P, +)** ungrounded battery terminal. Then, connect the **NEGATIVE (BLACK)** charger clamp to the vehicle chassis, or the engine block (away from the battery). Do not connect the clamp to the carburetor, fuel lines, or sheet-metal body parts: connect only to a heavy gauge metal part of the frame or engine block. **NOTE:** **NEGATIVE-GROUNDED** type systems are the most common in today's vehicles.
- c) Set charger's charge rate to appropriate setting 2/6/12A according to battery size.

POSITIVE-GROUNDED VEHICLE: Connect the **NEGATIVE (BLACK)** charger clamp to the **NEGATIVE (NEG, N, -)** ungrounded battery post. Then, connect the **POSITIVE (RED)** battery clamp to the vehicle chassis or engine part (away from the battery). Do not connect the clamp to the carburetor, fuel lines, or sheet-metal body parts:

connect only to a heavy gauge, stable metal part of the frame or engine block.

NOTE: If there is any problem connecting the charger clamps to the battery terminals, contact the Vector Technical Support Department toll-free at (866) 584-5504 for assistance.

- d) Plug battery charger power cord into grounded AC power outlet and refer to Appendix A at the end of this document for approximate charging times.
- e) When charging is completed, disconnect cables and clamps in reverse order from which they were connected.

NOTE: Use of Extension Cords

If it is necessary to use an extension cord, as is often the case, observe the following important safety information:

- Before using any extension cord, ensure that the wire size is at least 12 AWG for up to 100 feet and 10 AWG for longer than 100 feet.
- Use only a good quality, good condition, UL-listed extension cord, and ALWAYS connect charger to the extension cord before plugging the extension cord into a 110/120 volt AC power outlet. The use of a poor quality extension cord or one that is not in good repair could cause fire and/or electric shock.
- Use a three-wire extension cord with a 3-prong plug and 3-conductor socket.

CONNECTING IF BATTERY IS OUTSIDE OF VEHICLE

- a) Check polarity of battery posts- For top-mounted battery connectors, the positive post (marked POS, P, +) usually has a larger diameter than the Negative battery post (marked NEG, N, -). For side-mounted battery connections the Positive terminal is red, the Negative terminal is black.
- b) Attach a 24-inch (minimum length) 6 AWG insulated battery cable to the Negative battery post (marked NEG, N, -)
- c) Connect the Positive (RED) battery clamp to the Positive battery connector (marked POS, P, + or red).
- d) Stand as far back from battery as possible, and do not face battery when making final connection.
- e) Carefully connect the Negative (BLACK) charger clamp to the free end of the battery cable connected to the negative terminal. Connect the charger's power cord to a grounded 110/120 volt AC power outlet, and refer to Appendix A for approximate charging times.
- f) Set charger's charge rate to appropriate setting according to battery size.
- g) When charging is complete, disconnect cables and clamps in reverse order from which they were connected.

CHARGING TIMES

The VEC088 is a fully automatic battery charger. It automatically adjusts the charge rate as the battery becomes charged and stops charging when the battery is fully charged. If you require some estimate of the time it takes to charge a battery refer to Appendix A for these details.

BATTERY RECONDITION MODE

NOTE: BATTERY RECONDITION mode does not charge any battery. Charging is a separate operation. The battery to be treated does not have to be installed in a vehicle. Follow the instructions for Connecting if Battery is Outside of Vehicle.

BATTERY RECONDITION MODE should only be used with 10 Amp Hour or larger capacity lead-acid batteries. Charge the battery to be treated for 20 minutes, before using RECONDITION Mode. Observe the Digital Display for any codes. This initial charge will check the battery for shorted cells (F01), open cells or battery too low (or overcharged) to accept a charge (F02), and to ensure the battery can take a charge. If code F03 is displayed, change modes to the BATTERY RECONDITION MODE.

Whenever a lead acid battery begins to discharge, lead sulfate, an insulator, begins to build up on the plates in the battery. This reduces the ability of the battery to hold a full charge. When that battery has an immediate charge, most of the lead sulfate is dissolved and the plates are free of this insulation. If a battery remains in a discharged condition, the lead sulfate changes to a hard crystalline form, making a full charge difficult. BATTERY RECONDITION mode sends a sequence of electronic pulses into the battery, shaking loose and dissolving the crystals. This slowly (over 24 hours) removes the insulating buildup from the plates so the battery can hold a full charge. Most automotive batteries (50 to 70AH) can be treated once to reduce the lead sulfate buildup. Smaller 12 volt batteries, such as found in jump starters can be treated for 12 hours. However depending on the severity of lead sulfate buildup and a larger size of the battery, up to five 24 hour treatments may be necessary. Battery Restore mode automatically operates and then times out after 24 hours. When a smaller battery is treated, Battery Restore mode can be manually stopped after 12 hours of treatment.

To start the BATTERY RECONDITION MODE, press Battery Recondition, the first 5 seconds the display will show dES then change to moving bars for the remainder of the timing period. After 24 hours the timer will stop the operation. The digital display will show the circulating pattern. If the battery is not fully charged, charge the battery until FUL is displayed on the digital display.

NOTE: Battery Recondition Mode can treat a severely sulfated battery up to five times. If performance of the battery does not improve, recycle the battery.

VEC088

ALTERNATOR VOLTAGE CHECK

NOTE: This check may not be accurate for every make, manufacturer and model of vehicle. There is wide variation in user-controlled electrical loads, alternator output, and wiring. Other factors include battery condition, temperature, and engine idle speed. It is recommended to check your alternator when it is known to be operating properly to verify that this check is valid for your particular vehicle. **Check** only 12V systems. Checking 24 or 36V systems will damage the charger.

The ALTERNATOR VOLTAGE CHECK measures a defined range of voltage that is available from the fully charged battery. The user must allow the engine to warm to normal operating temperature and achieve a normal idle speed. As many appliances as possible are turned off for the first part of the check to allow the battery to reach its highest voltage level.

The ALTERNATOR VOLTAGE CHECK is only activated after 10 to 30 minutes of engine idle. If the ALTERNATOR GOOD LED lights, then the ON/OFF button is pressed to stop the check. Alternator Check is then repeated after many appliances are turned on to check the alternator output under a greater load, if the first (unloaded) and second (loaded) checks indicate the alternator is good, then the entire procedure should be repeated again, if after all appliances are turned on (except for air conditioning and defroster), and the check shows Alternator Good LED lights, it is likely that the alternator is good.

NOTE: Do not turn on air conditioning, or the defroster system to load the alternator. These appliances may start operating in the middle of a measurement cycle and give an invalid results.

If the first check indicates the alternator is good, and the second or third repeat of the check indicates the alternator is bad, there probably is some problem in the system. Problems can range from loose fan belts to a diode going bad in the alternator. To begin the check press Alternator and to stop the check press ON/OFF. Note that the FAULT light will light when the Alternator is bad; a good Alternator will light the Alternator Good LED.

NOTE: Do not charge the battery while waiting for the engine to warm. This will invalidate any alternator check. The Digital Display should show the circulating pattern while the engine is warming.

CARE AND MAINTENANCE

With only minimal maintenance, this Vector 2/6/12A Smart Battery Charger will deliver years of dependable service. Follow these simple steps to maintain the charger in optimum condition:

- After each use, clean the battery charger clamps. Be sure to remove any battery fluid that will cause corrosion of the copper clamps.
- Clean the outside case of the charger with a soft cloth and, if necessary, mild soap solution.
- Do not allow liquid to enter the charger. Do not operate when charger is wet.
- Keep the charger cords loosely coiled during storage to prevent damage to the cords. Do not use the charger if cords or clamps have been damaged in any way. Call Vector Technical Support Department toll-free at (866) 584-5504 for details on replacing cords and clamps.

TROUBLESHOOTING FAULT LED LIT

NOTE: Batteries below 4.0 Volts will not allow the charger to operate. If a 12 Volt battery is below 4.0 Volts it is probably either shorted, open or sulfated. Replace the battery.

The following conditions may light the FAULT LED:

- Poor connection to battery (or frame)
- Charging too fast - Decrease Charge Rate - Press 2/6/12A button to select lower rate.
- Charging too slowly - Battery is large and did not complete charging in 18 hours. Press 2/6/12A to charge at a faster rate
- Shorted battery cell. Replace battery (F01)
- Open battery Cell. Replace battery (F03)
- Battery sulfated. Have battery serviced or replace battery (F03)
- Reverse Polarity LED Lit - disconnect AC then reverse clamp locations on battery and frame.
- Internal over-heat in charger-make sure fan is not blocked. (F05)

Try charging another battery, if the FAULT LED does not light, then one of the above problems exists. Charger will not charge and the fan will not operate if there is a fault. Call Vector Technical Support at (866) 584.5504

SULFATED BATTERY(F03)

When batteries are left in a discharged state for a long period of time, they become "sulfated". Sulfated batteries cannot accept a high rate of charge since the internal plates are coated with lead sulfate. To see if a battery in this condition can be "saved", follow the instructions in battery recondition.

INTERNAL SHORT CELL BATTERY(F01)

- If the battery being charged has internal short cell, the FAULT LED will light.
- Using a voltmeter, determine the voltage of the battery and if it is under 12 volts, the battery is probably beyond repair or recharging, and will need to be replaced.
- If the voltage is over 12 volts, make sure there is no loading on the battery, resume the process again.

BATTERY NOT ACCEPTING A CHARGE

- Make sure that the charger is plugged into a "live" 110/120 volt AC outlet.
- Unplug charger and check battery connections. Ensure that there is a good connection with the battery terminal and/or vehicle chassis.
- Check to be sure that the battery is not sulfated.
- Check that the correct charge rate has been selected for the battery being charged.
- Ensure that enough charging time has been allowed for-check table in Appendix A for approximate charging times.

VERY COLD BATTERY

If the battery to be charged is extremely cold (in temperatures less than freezing -0° C/32° F) it cannot accept a high rate of charge, so the initial charge rate will be slow. The rate of charge will increase as the battery warms.

WARNING: DO NOT attempt to charge a frozen battery.

APPENDIX A CHARGING TIMES

To calculate the approximate charging time required to fully charge a battery, it is necessary to determine the specific gravity (or, percent of battery charge) using a hydrometer. Use this technique if battery vent caps can be removed. Check each cell. If there is one cell with a very low specific gravity compared to the other cells, there is probably a shorted cell in the battery. Replace the battery.

The following chart converts hydrometer readings into percent of charge values.

| SPECIFIC GRAVITY (HYDROMETER READING) | PERCENT OF CHARGE IN BATTERY | PERCENT OF CHARGE NEEDED BY BATTERY |
|--------------------------------------------------|-----------------------------------------|------------------------------------------------|
| 1.265 | 100% | 0% |
| 1.225 | 75% | 25% |
| 1.190 | 50% | 50% |
| 1.155 | 25% | 75% |
| 1.120 | 0% | 100% |

Refer to the chart below for approximate charging times.

| PERCENT OF CHARGE | 75% | 50% | 25% | 0% |
|--------------------------|------------|------------|------------|-----------|
| 2 AMPS | 7 HRS | 13 HRS | N.R* | N.R* |
| 6 AMPS | 2.5 HRS | 5 HRS | 7 HRS | 9 HRS |
| 12 AMPS | 1.2 HRS | 2.5 HRS | 3.2 HRS | 4.6 HRS |

* Not Recommended because over 18 hrs charging time.

The times shown in the chart above are approximate and refer to an average automotive battery. For smaller batteries, the charge time should be adjusted using the formula shown below and adding 1 hour to the time calculated.

To estimate charging time for a discharged battery, divide the AH rating of the battery by the charge rate selected. This is the number of hours required to recharge the battery. For example, a 50 AH (12 volt) battery is discharged (10 volts). How long should it be charged at the 12 Amp rate. Divide the 50 AH by 12. The answer is approximately 4.2 hours. Always round up the charge time by 10% to ensure full charge. In most cases, battery recharge times will vary depending on the age and condition of the battery. Smaller batteries should be charged at a lower rate (2 Amps) and add an extra hour to charge time.

VECTOR 5 YEAR LIMITED WARRANTY PROGRAM

This limited warranty program is the only one that applies to this product, and it sets forth all the responsibilities of Vector Manufacturing, Ltd. regarding this product. There is no other warranty, other than described herein.

This Vector Manufacturing, Ltd. product is warranted, to the original purchaser only, to be free of defects in materials and workmanship for five years from the date of purchase without additional charge. The warranty does not extend to subsequent purchasers or users. Vector Manufacturing, Ltd. will not be responsible for any amount of damage in excess of the retail purchase price of the product under any circumstances. Incidental and consequential damages are specifically excluded from coverage under this warranty.

This product is not intended for commercial use. This warranty does not apply to accessories or damage to units from misuse or incorrect installation. Misuse includes wiring or connecting to improper polarity power sources.

RETURN/REPAIR POLICY: Defective products, other than accessories, may be returned postage prepaid to Vector Manufacturing. Any defective product, other than accessories, that is returned to Vector Manufacturing within 30 days of the date of purchase will be replaced free of charge. If such a product is returned more than 30 days but less than five years from the purchase date, Vector Manufacturing will repair the unit or, at its option, replace it free of charge.

If the unit is repaired, new or reconditioned replacement parts may be used, at Vector Manufacturing's option. A unit may be replaced with a new or reconditioned unit of the same or comparable design. The repaired or replaced unit will then be warranted under the terms of the remainder of the warranty period. The customer is responsible for the shipping charges on all returned items after 30 days. During the warranty period, Vector Manufacturing, Ltd. will be responsible for the return shipping charges.

LIMITATIONS: This warranty does not cover accessories, bulbs, fuses and batteries, defects resulting from normal wear and tear (including chips, scratches, abrasions, discoloration or fading due to usage or exposure to sunlight), accidents, damage during shipping to our service facility, alterations, unauthorized use or repair, neglect, misuse, abuse, failure to follow instructions for care and maintenance, fire, flood and Acts of God.

If your problem is not covered by this warranty, call our Technical Support Department at (954) 584-4446 or toll free at (866)584-5504 for general repair information and charges if applicable. You may also contact us through our website at www.vectormfg.com.

STATE LAW RIGHTS: This warranty gives you specific legal rights. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the exclusions or limitations stated herein may not apply. This warranty gives the purchaser specific legal rights; other rights, which vary from state to state, may apply.

TO REQUEST WARRANTY SERVICE FOR THIS PRODUCT: Contact Vector Manufacturing Technical Support by telephone, fax or mail. We suggest that you keep the original packaging in case you need to ship the unit. When returning a product, include your name, address, phone number, dated sales receipt (or copy) and a description of the reason for return and product serial number. After repairing or replacing the unit, we will make every effort to return it to you within four weeks.

WARRANTY ACTIVATION: Please complete Warranty Activation Card and mail to Vector Manufacturing. Enter "VEC088" as Model and 12V Automatic Battery Charger 2/6/12 Amp as "Product Type". All Vector Manufacturing, Ltd. products must be registered within 10 days of purchase to activate this warranty. Mail the completed registration form, along with a copy of the original sales receipt to:

ATTN.: CUSTOMER SERVICE / VECTOR MANUFACTURING, Ltd.

4140 SW 28th Way, Ft. Lauderdale, FL 33312

PH: 954-584-4446 • TOLL FREE: 866-584-5504 • Fax: 954-584-5556.

You may also contact us at our web site www.vectormfg.com.

WARRANTY IS NON-TRANSFERABLE AND NON-REFUNDABLE.

VEC088

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>