



**MOTOROLA**  
**TALKABOUT®**

User's Guide



**KEM-PK8359-03**

**Models T7100, T7150**

# Contents

<b>Safety and General Information</b> .....	2	<b>Changing your Radio's Setting</b> .....	18
<b>FCC Licensing Information</b> .....	10	Setting the Channel .....	18
<b>Getting Started</b> .....	11	Setting the Interference Eliminator Code .....	18
Turning On/Off Your Radio .....	11	Setting the Call Tone.....	19
Installing Batteries .....	11	Hands-free Use/VOX .....	19
NiMH Battery Installation .....	12	Scanning .....	20
AA Alkaline Battery Installation .....	12	Battery Meter.....	22
Battery Drop-In Charging Tray .....	13	Battery Life.....	22
<b>Control Buttons</b> .....	14	Menu Functions.....	23
<b>Operating</b> .....	15	<b>Using Accessories</b> .....	24
Talk Range .....	15	Ear-piece with Push-To-Talk Microphone .....	24
Accessing the Backlight .....	16	Ear-piece with Boom Microphone.....	24
Lock .....	16	<b>Use and care</b> .....	25
Monitor .....	16	<b>Frequency and Code Charts</b> .....	26
"Roger" Beeps/Talk Confirmation Tone .....	17	Interference Eliminator Codes .....	28
Button Beeps .....	17	<b>Troubleshooting</b> .....	29
		<b>Copyright Information</b> .....	31
		<b>Warranty</b> .....	32

## Safety and General Information

### Important Information on Safe and Efficient Operation Read This Information Before Using Your Radio.

The information provided in this document supersedes the general safety information in user guides published prior to December 1, 2002.

#### Transmit and Receive Procedure

Your two-way radio contains a transmitter and a receiver. To control your exposure and ensure compliance with the general population/uncontrolled environment exposure limits, always adhere to the following procedure:

- Transmit no more than 50% of the time.
- To transmit (talk), press the Push to Talk (PTT) button.
- To receive calls, release the PTT button.

Transmitting 50% of the time, or less, is important because the radio generates measurable RF energy exposure only when transmitting (in terms of measuring standards compliance).

#### Exposure To Radio Frequency Energy

Your Motorola two-way radio complies with the following RF energy exposure standards and guidelines:

- United States Federal Communications Commission, Code of Federal Regulations; 47CFR part 2 sub-part J

- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992
- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998
- Ministry of Health (Canada) Safety Code 6. Limits of Human Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999
- Australian Communications Authority Radiocommunications (Electromagnetic Radiation --- Human Exposure) Standard, 2003
- ANATEL ANNEX to Resolution No. 303 of July 2, 2002 "Regulation of limitation of exposure to electrical, magnetic and electromagnetic fields in the radio frequency range between 9 KHz and 300 GHz" and "Attachment to resolution # 303 from July 2, 2002"

To assure optimal radio performance and make sure human exposure to radio frequency electromagnetic energy is within the guidelines set forth in the above standards, always adhere to the following procedures.

### **Portable Radio Operation and EME Exposure**

#### ***Antenna Care***

**Use only the supplied or an approved replacement antenna.** Unauthorized antennas, modifications, or attachments could damage the radio and may violate FCC regulations.

**DO NOT hold the antenna when the radio is "IN USE."** Holding the antenna affects the effective range.



### ***Two-way Radio Operation***

When using your radio as a traditional two-way radio, **hold the radio in a vertical position with the microphone 1 to 2 inches (2.5 to 5 cm) away from the lips.**

### ***Body-Worn Operation***

To maintain compliance with FCC/Health Canada RF exposure guidelines, if you wear a radio on your body when transmitting, always place the radio in a Motorola-supplied or approved clip, holder, holster, case, or body harness for this product. Use of non-Motorola-approved accessories may exceed FCC/Health Canada RF exposure guidelines.

If you do not use one of the Motorola-supplied or approved body-worn accessories, and are not using the radio held in the normal use position, **ensure the radio and its antenna are at least 1 inch (2.5 cm) from your body when transmitting.**

### ***Data Operation***

If applicable, when using any data feature of the radio with or without an accessory cable, **position the radio and its antenna at least 1 inch (2.5 cm) from the body.**

### ***Approved Accessories***

For a list of approved Motorola accessories, visit our website at [www.Motorola.com](http://www.Motorola.com).

### ***Electromagnetic Interference/Compatibility***

**Note:** Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed, or otherwise configured for electromagnetic compatibility.

### ***Facilities***

To avoid electromagnetic interference and/or compatibility conflicts, turn off your radio in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy.

### ***Aircraft***

When instructed to do so, turn off your radio when on board an aircraft. Any use of a radio must be in accordance with applicable regulations per airline crew instructions.

### ***Medical Devices - Pacemakers***

The Advanced Medical Technology Association recommends that a minimum separation of 6 inches (15 cm) be maintained between a handheld wireless radio and a pacemaker. These recommendations are consistent with the independent research by, and recommendations of the U.S. Food and Drug Administration.

Persons with pacemakers should:

- ALWAYS keep the radio more than 6 inches (15 cm) from their pacemaker when the radio is turned ON.
- Not carry the radio in the breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for interference.
- Turn the radio OFF immediately if you have any reason to suspect that interference is taking place.

### ***Medical Devices - Hearing Aids***

Some digital wireless radios may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

### ***Other Medical Devices***

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

### **Safety and General Use While Driving**

Check the laws and regulations on the use of radios in the area where you drive. Always obey them. When using your radio while driving, please:

- Give full attention to driving and to the road.
- Use hands-free operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

### **Operational Warnings**

#### ***For Vehicles with an Air Bag***

Do not place a portable radio in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a portable radio is placed in the air bag deployment area and the air bag inflates, the radio may be propelled with great force and cause serious injury to occupants of the vehicle.

### ***Potentially Explosive Atmospheres***

Turn off your radio prior to entering any area with a potentially explosive atmosphere, unless it is a radio type especially qualified for use in such areas as “Intrinsically Safe.”

Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

**Note:** The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders, and any other area where you would normally be advised to turn off your vehicle engine. Areas with potentially explosive atmospheres are often but not always posted.

### ***Blasting Caps and Areas***

To avoid possible interference with blasting operations, turn off your radio when you are near electrical blasting caps, in a blasting area, or in areas posted: “Turn off two-way radio.” Obey all signs and instructions.

### **Operational Cautions**

#### ***Antennas***

**Do not use any portable radio that has a damaged antenna.** If a damaged antenna comes into contact with your skin, a minor burn can result.



***Batteries***

All batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touch exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects.

**Battery Charger Safety Instructions****Save these Instructions**

1. Do not expose the charger to rain or snow.
2. Do not operate or disassemble the charger if it has received a sharp blow, or has been dropped or damaged in any way.
3. Never alter the AC cord or plug provided with the unit. If the plug will not fit the outlet, have the proper outlet installed by a qualified electrician. An improper condition can result in a risk of electric shock.
4. To reduce the risk of damage to the cord or plug, pull the plug rather than the cord when disconnecting the charger from the AC receptacle.
5. To reduce the risk of electric shock, unplug the charger from the outlet before attempting any maintenance or cleaning.
6. Use of an attachment not recommended or sold by Motorola may result in a risk of fire, electric shock, or personal injury.

7. Make sure the cord is located so it will not be stepped on, tripped over, or subjected to damage or stress.
8. An extension cord should not be used unless absolutely necessary. Use of an improper extension cord could result in a risk of fire and/or electric shock. If an extension cord must be used, make sure that:
  - The pins on the plug of the extension cord are the same number, size and shape as those on the plug of the charger.
  - The extension cord is properly wired and in good electrical condition.
  - The cord size is 18 AWG for lengths up to 100 feet, and 16 AWG for lengths up to 150 feet.
9. The supply cord of this charger cannot be replaced. If the cord is damaged, call Motorola Product Services at 1-800-353-2729 in USA or 1-888-390-6456 TTY (Text Telephone).

## FCC Licensing Information

Your Motorola radio operates on General Mobile Radio Service (GMRS) frequencies and is subject to the Rules and Regulations of the Federal Communications Commission (FCC). The FCC requires that all operators using GMRS frequencies obtain a radio license before operating their equipment. To obtain the FCC forms, please request Form **605** and **159**, which includes all forms and instructions. If you wish to have the document faxed or mailed, or have questions, please use the following contact information.

<b>Faxed</b> <b>Contact the Fax-On-Demand system at:</b>	<b>Mailed</b> <b>Call the FCC forms hotline at:</b>	<b>Questions</b> <b>Regarding FCC license</b> <b>Contact the FCC at:</b>
<b>1-202-418-0177</b>	<b>1-800-418-FORM</b> <b>1-800-418-3676</b>	<b>1-888-CALL-FCC</b> <b>1-888-225-5322</b> <b>Or: <a href="http://www.fcc.gov">http://www.fcc.gov</a></b>

Changes or modifications not expressly approved by Motorola may void the user's authority granted by the FCC to operate this radio and should not be made. To comply with FCC requirements, transmitter adjustments should be made only by or under the supervision of a person certified as technically qualified to perform transmitter maintenance and repairs in the private land mobile and fixed services as certified by an organization representative of the user of those services. Replacement of any transmitter component (crystal, semiconductor, etc.) not authorized by the FCC equipment authorization for this radio could violate FCC rules.

**Note:** Use of this radio outside the country where it was intended to be distributed is subject to government regulations and may be prohibited.


# Getting Started

## Turning On/Off Your Radio

Turn  
Knob


Display

Normal Menu Mode



### T7100 Display icon when the switch is powered ON

Turn Knob on the top of the radio clockwise to use. Turn the Knob counterclockwise to turn the radio OFF. The radio chirps and displays all feature icons that your radio has available for approximately one second.






### Installing Batteries

Some radio packages include a rechargeable Nickel-Metal Hydride (NiMH) battery, or you may use 4 AA Alkaline batteries. If you would like to obtain the battery, the charger or the Rechargeable Upgrade Kit, please contact place of purchase.

## NiMH Battery Installation

Your radio uses one rechargeable Nickel-Metal Hydride Battery pack. These cells provide 13 hours of radio use; based upon 5/5/90 duty cycle (5% Transmit, 5% Receive, 90% Standby).

- To begin, slide the Ribbed Latch on the bottom of the radio away from the back cover, or toward the contacts.
- Slide and lift the back cover off.
- Position the battery with the Motorola Logo side up, and the charge contacts are facing the bottom of the radio. Insert the top of the battery into the radio and push the battery up and into the battery compartment to fit tightly into place.
- Slide and snap the cover back into place.



## AA Alkaline Batteries Installation

Your radio also uses 4 AA alkaline batteries. These cells provide 22 hours of radio use. Based upon 5/5/90 duty cycle.

- Push the Ribbed Latch on the bottom of the radio away from the battery door.
- Slide and lift the battery door off.
- Place AA batteries so that the + markings match the markings in the compartment.
- Slide and snap the battery cover into place.

## Battery Drop-In Charging Tray


The Drop-In Charging Tray can be placed on any flat surface and provides drop-in charging convenience.

- Connect Plug-in Charger and Drop-In Charging Tray by inserting the pin into the rear of Drop-In charging tray, insert pin as far as possible, then stop.
- To charge the battery, place the radio into Drop-In Charging Tray with the front of the radio facing toward you.


**Note:** The battery can be charged while inside the radio or separately. The battery's silver contacts must face down and the Motorola Logo must face the front of Charger.

The light on the Plug-in Charger will glow continuously when radio/battery is inserted.

**Note:** Allow up to 10 hours for the battery to reach full charge.



## Control Button



## Operating Your T7100

**Note:** The microphone is located on the front of your radio, please refer to the diagram on page 18.



- Press and hold **PTT** .
- Talk two-to-three inches away from the microphone.
- When you're finished talking, release **PTT** .

While transmitting, the red indicator light located above the display, glows.

### Talk Range



#### Optimal Range

Flat, open areas

- **Outdoor**



#### Medium Range

Buildings or trees

- **Outdoor**

Also near residential buildings



#### Minimal Range

Dense foliage or mountains



- **Outdoor**

Also inside some buildings










- **Indoor**





## Accessing the Backlight

Your radio has a Backlight that turns On automatically any time you press a front button (except  and ). The Backlight turns Off automatically five seconds after you last pressed a front button.



## Lock


- To avoid accidentally changing radio operation, press  for three seconds. Now you will see .
- The Lock Feature locks ,  and , and Scan functions. When the keypad is locked you can still adjust the volume, transmit , send a Call Tone , and monitor  (Long Press).
- To unlock, press .

## Monitor



 allows you to listen to all activity on a Channel to tell whether the Channel is currently in use.  can also help you determine when a radio is moving out of range.

## “Roger” Beeps/Talk Confirmation Tone

When you turn this feature On, your two-way radio transmits a unique tone when you finish transmitting. It’s like saying “Roger” or “Over” and lets others know you have finished talking. If the person you are talking to does not hear the talk confirmation tone, you can enable it by pressing and holding  as you turn On your radio. Now, whenever you release , you let your friends know you have finished talking by transmitting a “Roger” Beep tone. “Roger” Beeps will be disabled as the Default Setting.

**Note:** To toggle the Talk Confirmation Tone feature, turn your radio Off and then back On while pressing and holding  .





## Button Beeps

Every time you press a button on the front of your radio, it beeps unless you turn Button Beeps Off. To turn Button Beeps Off, turn your radio On while you press and hold . To turn Button Beeps back On, turn the radio Off and then back On again while you press and hold . On is the Default setting.

**Note:** Your radio will only communicate with radios set to the same Channel and Interference Eliminator Code.

## Changing your Radio's Settings

### Setting the Channel





- Turn radio On.
- To set, press  once the Channel display begins to flash.
- Then press  or  to choose the Channel.
- Press  to exit this menu.




**Note:** The red indicator light above the display flashes every second when the Channel is in use.

### Setting the Interference Eliminator Code



The Interference Eliminator Code helps minimize interference by providing you with a choice of code combinations.

- Turn radio On.
- To set, press  twice the Code display begins to flash.
- Then press  or  to choose the Code.
- Press  to exit this menu.









**Note:** To hear everyone on your Channel, or to communicate with a radio that does not have Interference Eliminator Codes, select Interference Eliminator Code .

## Setting the Call Tone

Your radio can transmit different individual call tones to other radios in your group so you can alert the group that you want to talk to them. There are ten distinct individual call tones to choose from and you can also turn Call Tones Off by selecting Call Tone . Once selected, press  to transmit the Call Tone to others.



To set your Call Tone:

- Turn radio On.
- Press  3 times as needed to display: .
- You can press and hold  or  to scroll through the available call tones. The radio plays a sample of each individual Call tone as you scroll through them.
- The default is set on , or you may choose .



## Hands-Free Use/VOX

*With Compatible VOX Accessories*

- Turn radio Off.
- Open Accessory Cover.
- Insert plug of audio accessory firmly into Accessory Jack.
- Turn radio On. Radio will display: .
- Lower radio volume BEFORE placing accessory on head or in ear.
- To transmit, speak into Accessory Microphone and to receive, stop talking.
- VOX operation can be disabled by pressing  or removing audio accessory.







**Note:** There is a short delay between when you start talking and the radio transmits.

To order accessories, please contact the point of purchase.

### **Setting Sensitivity Level**


Adjusting your radio's Sensitivity Level helps minimize the possibility of unintended noises triggering a transmission, or enhances the ability to pick up quiet voices.


- Press  4 times as needed to display . The radio will also display the sensitivity type you are setting:
- Select Sensitivity Level of 1, 2, or 3 by using  or :
  - 3 = **High Sensitivity**, for quiet environments
  - 2 = **Medium Sensitivity**, for most environments
  - 1 = **Low Sensitivity**, for noisy environments






**Note:** There is a short delay between when you start talking and the radio transmits.


### **Scanning**

By using , you can monitor Channels and Codes for transmissions and lock in on the one that interests you. More importantly, you can find someone in your group who has accidentally changed Channels and is talking during your scan. You don't have to set a new Channel or Code, the radio just resets itself temporarily to that Channel and Code and you can start talking.

- To start scanning, briefly press .


Your Channel/Code screen displays  and begins to scroll through Channels. When the radio detects channel activity, it stops on that channel and displays its Channel and Code. You can talk to the person(s) transmitting without having to switch Channels by pressing .

- To stop scanning, briefly press .





If you press  while the radio is scanning, the radio will transmit on the Channel which was selected before you activated Scan.

If no transmission occurs within five seconds, scanning will resume.

### Scan Manual Advance

If Scan stops on a Channel that you don't want, briefly press  to resume scanning for the next active Channel in the Scan List.





### Scan Nuisance Delete



If Scan continuously stops on an undesired Channel, hold press  or  key for 2 seconds. This will temporarily remove the undesired Channel from being scanned. To restore the deleted Channel, turn Scan Off by pressing , then turn Scan back On by pressing  again.

**Note:** Your Home Channel is the Channel your radio was set to when you activated Scan. You cannot Nuisance Delete your Home Channel.

## Battery Meter

The battery meter located in the upper left corner of the display indicates how much battery power you have.

				
NiMH/Alkaline %	100-85	85-25	25-10	Final 10

The radio will power off when the voltage drops below a pre-determined level in order to protect the rechargeable battery. When the battery meter flashes; , the radio chirps after releasing  and every 5 minutes.

## Battery Life






The following chart lists the appropriate battery life during Two-way Use\* for Alkaline and NiMH batteries.

Battery Type	Two-way Use*
AA Alkaline (High Capacity)	22 Hours
Motorola NiMH Battery-pack	13 Hours

\*Two-way Use is defined as 90% standby time, 5% talk time, and 5% receive time.

**Note:** Use of Scan, VOX, Weather and other features may reduce Battery Life.

## Menu Functions

Radio Model	Press	To
T7100	 one time	Change the Channel. <i>Please refer to page 18.</i>
	 two times	Change the Interference Eliminator Code. <i>Please refer to page 18.</i>
	 three times	Change the Call Tone (10 to choose from). Choose  if you want to turn Call Tone Off. <i>Please refer to page 19.</i>
	 four times	Sensitivity Level selection. <i>Please refer to Setting Sensitivity Level on page 20.</i>



## Using Accessories

Make sure the radio is turned Off before plugging audio accessories into the accessory port. Before you place an accessory on your head or in your ear, turn the volume down. To order accessories, please contact the point of purchase.

### **Ear-piece with Push-To-Talk Microphone**

Discreet, lightweight ear-piece with hand-operated lapel or collar-mounted microphone. It allows clear communication without disturbance or interference.

### **Ear-piece with Boom Microphone**

Discreet, lightweight ear-piece which fits comfortably around the ear while boom microphone allows for remote radio placement and is VOX/Hands-free compatible.

## Use and Care



Use a soft damp cloth to clean the exterior.



Do not immerse in water.



Do not use alcohol or cleaning solutions.

### If the radio gets wet...



Turn it off and remove batteries.



Dry with soft cloth.



Do not use until completely dry.

## Frequency and Code Charts

The charts on these pages provide frequency and code compatibility information. These charts are useful when using Motorola Talkabout two-way radios with other GMRS and FRS radios.


T7100 Channel	Code Display	Transmit Frequency (MHz)	Transmit Power (Watts)	Receive Frequency (MHz)	Description
1	0-38	462.5625	2	462.5625	FRS 1/GMRS Interstitial 1
2	0-38	462.5875	2	462.5875	FRS 2/GMRS Interstitial 2
3	0-38	462.6125	2	462.6125	FRS 3/GMRS Interstitial 3
4	0-38	462.6375	2	462.3675	FRS 4/GMRS Interstitial 4
5	0-38	462.6625	2	462.6625	FRS 5/GMRS Interstitial 5
6	0-38	462.6875	2	462.6875	FRS 6/GMRS Interstitial 6
7	0-38	462.7125	2	462.7125	FRS 7/GMRS Interstitial 7
8	0-38	467.5625	0.5	467.5625	FRS 8
9	0-38	467.5875	0.5	467.5875	FRS 9
10	0-38	467.6125	0.5	467.6125	FRS 10
11	0-38	467.6375	0.5	467.6375	FRS 11
12	0-38	467.6625	0.5	467.6625	FRS 12
13	0-38	467.6875	0.5	467.6875	FRS 13
14	0-38	467.7125	0.5	467.7125	FRS 14
15	0-38	462.5500	2	462.5500	GMRS Primary 1
16	0-38	462.5750	2	462.5750	GMRS Primary 2
17	0-38	462.6000	2	462.6000	GMRS Primary 3
18	0-38	462.6250	2	462.6250	GMRS Primary 4



<b>T7100 Channel</b>	<b>Code Display</b>	<b>Transmit Frequency (MHz)</b>	<b>Transmit Power (Watts)</b>	<b>Receive Frequency (MHz)</b>	<b>Description</b>
19	0-38	462.6500	2	462.6750	GMRS Primary 5
20	0-38	462.6750	2	462.6750	GMRS Primary 6
21	0-38	462.7000	2	462.7000	GMRS Primary 7
22	0-38	462.7250	2	462.7250	GMRS Primary 8

Carrier squelch (0) disables Interference Eliminator Codes. This allows you to monitor all activity on the Channel you are using. Interference Eliminator Codes help minimize interference by providing you with a choice of code combinations.

<b>Interference Eliminator Codes</b>					
<b>Code</b>	<b>Hz Freq</b>	<b>Code</b>	<b>Hz Freq</b>	<b>Code</b>	<b>Hz Freq</b>
<b>1</b>	67.0	<b>14</b>	107.2	<b>27</b>	167.9
<b>2</b>	71.9	<b>15</b>	110.9	<b>28</b>	173.8
<b>3</b>	74.4	<b>16</b>	114.8	<b>29</b>	179.9
<b>4</b>	77.0	<b>17</b>	118.8	<b>30</b>	186.2
<b>5</b>	79.7	<b>18</b>	123.0	<b>31</b>	192.8
<b>6</b>	82.5	<b>19</b>	127.3	<b>32</b>	203.5
<b>7</b>	85.4	<b>20</b>	131.8	<b>33</b>	210.7
<b>8</b>	88.5	<b>21</b>	136.5	<b>34</b>	218.1
<b>9</b>	91.5	<b>22</b>	141.3	<b>35</b>	225.7
<b>10</b>	94.8	<b>23</b>	146.2	<b>36</b>	233.6
<b>11</b>	97.4	<b>24</b>	151.4	<b>37</b>	241.8
<b>12</b>	100.0	<b>25</b>	156.7	<b>38</b>	250.3
<b>13</b>	103.5	<b>26</b>	162.2		

## Troubleshooting

Symptom	Try This:
No power	Reposition or replace Alkaline batteries. Recharge or replace NiMH battery.
Message not transmitted	Make sure  is completely pressed as you transmit. Reposition, replace or recharge batteries.
Hearing other noises or conversation on a Channel	Confirm Interference Eliminator Code is set. Shared Channel or Interference Eliminator Code may be in use, try another.
Limited talk range	Steel and/or concrete structures, heavy foliage, use in buildings or vehicles decrease range. Check for clear line of sight to improve transmission. Wearing radio close to body such as in a pocket or on a belt decreases range. Change location of radio.

Symptom	Try This:
Message not Received	Confirm radios have the same Channel and Interference Eliminator Code settings. Make  sure is <b>NOT</b> being pressed while trying to listen. Reposition, replace, or recharge batteries. Obstructions and operating indoors, or in vehicles, may interfere -- change location.
Heavy static or interference	Radios are too close, they must be at least five feet apart. Radios are too far apart or obstacles interfering with transmission.
Keypad locked	Make sure keypad is unlocked. Unlock by pressing  for three seconds.
Low batteries	Recharge or replace NiMH battery. Replace AA batteries. Extreme operating temperatures affect battery life.
Cannot activate VOX	Feature not set and On. You can also increase the Sensitivity Level. Please refer to Setting Sensitivity Level on page 20.

## Copyright Information

Manufactured, distributed or sold by Giant International Ltd., official licensee for this product. Motorola, the Motorola logo trademarks and the Motorola trade dress are owned by Motorola, Inc. and are used under license from Motorola, Inc. Please contact Giant International Ltd. at 800-638-5119 for questions/comments, warranty, support, or service related to this product. MOTOROLA and the Stylized M Logo are registered in the U.S. Patent & Trademark Office. All other product or service names are the property of their respective owners. © Motorola, Inc. 2004.



## Motorola Limited Warranty for Personal Communication Products, Accessories and Software Purchased in the United States or Canada

**What Does this Warranty Cover?** Subject to the exclusions contained below, Motorola, Inc. or its licensees warrants its consumer two-way radios that operate via Family Radio Service or General Mobile Radio Service ("Products"), Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software contained on CD-Roms or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products Covered	Length of Coverage	Exclusions
<b>A. <u>Products</u></b> as defined above, unless otherwise provided for below.	<b>A. One (1) year</b> from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.	<b><u>Normal Wear and Tear.</u></b> Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage. <b><u>Batteries.</u></b> Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Products Covered	Length of Coverage	Exclusions
<p><b>1. <u>Decorative Accessories and Cases.</u></b> Decorative covers, bezels, PhoneWrap™ covers and cases.</p> <p><b>2. <u>Monaural Headsets.</u></b> Ear buds and boom headsets that transmit mono sound through a wired connection.</p> <p><b>3. <u>Consumer Two-Way Radio Accessories.</u></b></p> <p><b>4. <u>Products and Accessories that are Repaired or Replaced.</u></b></p>	<p><b>1. Limited lifetime warranty</b> for the lifetime of ownership by the first consumer purchaser of the product.</p> <p><b>2. Limited lifetime warranty</b> for the lifetime of ownership by the first consumer purchaser of the product.</p> <p><b>3. Ninety (90) days</b> from the date of purchase by the first consumer purchaser of the product.</p> <p><b>4. The balance of the original warranty or for ninety (90) days</b> from the date returned to the consumer, whichever is longer.</p>	<p><b><u>Abuse &amp; Misuse.</u></b> Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola or (Giant International Ltd.), are excluded from coverage.</p> <p><b><u>Use of Non-Motorola branded Products and Accessories.</u></b> Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.</p>

Products Covered	Length of Coverage	Exclusions
		<p><b><u>Unauthorized Service or Modification.</u></b> Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, (Giant International Ltd.) or its authorized service centers, are excluded from coverage.</p> <p><b><u>Altered Products.</u></b> Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola branded housings, or parts, are excluded from coverage.</p> <p><b><u>Communication Services.</u></b> Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.</p>

Products Covered	Length of Coverage	Exclusions
<p><b>B. Software.</b> Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).</p>	<p><b>B. Ninety (90) days</b> from the date of purchase.</p>	<p><b><u>Software Embodied in Physical Media.</u></b> No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.</p> <p><b><u>Software NOT Embodied in Physical Media.</u></b> Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided “as is” and without warranty. embodied in physical media (e.g. software that is downloaded from the internet), is provided “as is” and without warranty.</p>

**Who is covered?** This warranty extends only to the first consumer purchaser, and is not transferable.

**What will Giant International Ltd. Do?** Giant International Ltd., at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

### **How to Obtain Warranty Service or Other Information?**

To obtain service or information, please call:

<b>USA</b> <b>Two-Way Radios 1-800-638-5119</b>	<b>Canada</b> <b>Two-Way radio 1-800-638-5119</b>
--	--

For **Accessories** and **Software**, please call the telephone number designated above for the product with which they are used.

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Giant International Ltd. Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

**What Other Limitations Are There?** ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND

FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA OR GIANT INTERNATIONAL LTD. BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

**Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.**

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

- **22 Channels**
- **38 Interference Eliminator Codes**  
Interference eliminator codes help minimize interference by providing you with a choice of code combinations
- **Handsfree Use (VOX)**  
Voice activation lets you talk handsfree with optional accessories.
- **Talk Confirmation Tone**  
It's like saying 'roger' or 'over', and lets others know you have finished talking.
- **Scan**  
Easily finds your group's channel and code by searching all possible combinations while your home channel is scanned most frequently.
- **10 Call Tones**  
Multiple distinct ringing options so your group can identify who's calling.
- **Companding**  
Voice compression for improved range and clear sound.
- **Low Battery Alert**  
Audible tone and visual display tell you when the battery is running down.
- **Backlit Display**  
Easy to read your settings in dark places.
- **Motorola Quality**  
Shock, drop, and temperature tested to meet Motorola's high quality standards.
- **1 Year Limited Warranty**  
For a copy of this warranty prior to purchase, please ask your retailer.
- **User's Guide Included**
- **Batteries (not included)**  
Required 4 AA alkaline batteries or one NiMH rechargeable battery.

**FRS/GMRS use approved in the US only;  
GMRS License Required.**



**WARNING CHOKING HAZARD  
SMALL PARTS**

Not for children under 3 years.  
This product is not intended to be used as a toy or plaything.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>