

**Uniden** | A World Without Wires®

UNIDEN  
CORDLESS  
PHONES



**CXA15698**

**OWNER'S MANUAL**

# Contents

<b>Welcome/Accessibility</b> .....	<b>3</b>	<b>Using the Speed Dial Memory</b> .....	<b>21</b>
<b>Terminology/Manual Conventions</b> .....	<b>4</b>	Storing a Name and Number in Memory .....	21
<b>Product Overview</b> .....	<b>5</b>	Storing Caller ID in Speed Dial Memory .....	24
<b>Controls and Functions</b> .....	<b>6</b>	<b>Using Your Phone</b> .....	<b>25</b>
<b>Using the Interface</b> .....	<b>8</b>	During a Power Failure .....	25
Using the Base Menus .....	8	Making and Receiving Calls .....	26
Using the Handset Menus .....	8	Redialing the Last Dialed Number .....	29
<b>Installing the Phone</b> .....	<b>9</b>	Adjusting the Ringer, and Earpiece and Speaker Volume .....	29
Choosing the Best Location .....	9	Do Not Disturb (DND) (All calls) .....	31
Connecting the Base and Corded Handset .....	10	Muting the Ringer (One Call Only) .....	31
Testing the Connection .....	11	Mute Base Microphone .....	31
Changing the Dial Mode .....	11	Using Call Waiting .....	32
Mounting the Base Unit on a Wall .....	12	Selecting a Different Channel .....	32
Installing the Rechargeable Battery Pack for Cordless Handset .....	14	Find Handset .....	33
Connecting the Cordless Handset and Charger .....	15	Placing a Call on Hold from the Base .....	33
Installing the Belt Clip .....	16	Conferencing .....	34
Headset Installation .....	16	Intercom .....	35
<b>Base Setup</b> .....	<b>17</b>	Transferring a Call .....	36
Setting the Day and Time .....	17	Tone Dialing Switch-over .....	37
Selecting a Language for your Answering Machine and Base Display .....	17	<b>Caller ID and CIDCW (Caller ID on Call Waiting) .....</b>	<b>38</b>
Setting Caller ID on Call Waiting (CIDCW) .....	18	Caller ID on Call Waiting (CIDCW) .....	39
Setting the Area Code .....	18	Viewing the Caller ID Message List .....	39
Adjusting the Base Display (LCD Contrast) .....	19	Deleting Information from the Caller ID List .....	40
<b>Handset Setup</b> .....	<b>19</b>	<b>The Integrated Answering Machine</b> .....	<b>41</b>
Setting AutoTalk .....	19	Features .....	41
Selecting a Language for the Handset Display .....	20	<b>Setting Up Your Answering Machine</b> .....	<b>42</b>
Checking the Area Code Setting from the Handset .....	20	Selecting a Language .....	42
		Setting the Record Time (or Announce Only) .....	42
		Activating Call Screening .....	43

Setting the Number of Rings.....	43
Activating the Message Alert .....	44
Setting a Security Code or Personal Identification Number (PIN).....	44
Setting Your Outgoing Message (Greeting).....	45
<b>Using Your Answering Machine .....</b>	<b>47</b>
Turning the Answering Machine On/Off .....	47
Reviewing Messages .....	47
Screening a call .....	49
Recording a Conversation .....	49
Voice Memo (Base Only) .....	50
Remote Operation .....	51
Turn on the Answering Machine Remotely .....	52
<b>Maintenance.....</b>	<b>53</b>
Specifications.....	53
Power Failure.....	54
Talk and Standby Times.....	54
Low battery alert .....	55
Battery replacement and handling .....	55
Cleaning the battery charging contacts .....	56
<b>Troubleshooting .....</b>	<b>56</b>
Traveling Out-of-Range .....	56
Common Issues.....	56
Liquid Damage.....	59
<b>Precautions .....</b>	<b>60</b>
The FCC Wants You To Know .....	61
I.C. Notice.....	63
<b>One Year Limited Warranty.....</b>	<b>64</b>
<b>Index .....</b>	<b>65</b>

## Welcome

Congratulations on purchasing your new Uniden Corded/Cordless Telephone! Your new phone system comes with a corded base unit and a cordless handset. The corded base allows you the convenience, safety, security and making and receiving calls during a power failure. In addition to the corded base, your new phone has a full featured cordless handset and charger that can be placed anywhere in your home where you have AC power and it does not require you to plug the handset in to a telephone line.

**Note: Illustrations in this manual are used for explanation purposes. Some illustrations in this manual may differ from the actual unit. The color of your cordless telephone may vary.**

Uniden® is a registered trademark of Uniden America Corporation.

AutoTalk, AutoStandby and UltraClear Plus are trademarks of Uniden America Corporation.

## Accessibility

Uniden provides a customer service hotline for accessibility questions. If you have a disability and need customer service assistance or if you have any questions about how Uniden's products can accommodate persons with disabilities, please call the accessibility voice/TTY line:

1-800-874-9314.

Our customer care hours as well as accessibility information can be found on our website, [www.uniden.com](http://www.uniden.com), under the "Accessibility" link. If your call is received outside of our business hours, you can leave us a message and we will call you back.

## Terminology

<b>Base</b>	The main part of the phone that connects to your phone line and lets you make and receive calls.
<b>Charger</b>	A cradle that charges the handset battery. It connects to power but does not connect to a phone line.
<b>CID</b>	Caller ID is available from your telephone provider. With this service, you can see the name and number of incoming callers.
<b>CIDCW</b>	Caller ID on Call Waiting is available from your telephone provider. With this service, you can see incoming caller information while on another call.

<b>Corded Handset on the Base</b>	A handset connected to the base. It can make and receive calls during a power failure.
<b>Handset</b>	A cordless handset that can be placed anywhere in your home or office where AC power is available.
<b>Standby</b>	The cordless handset or the base is NOT in use. <b>[talk/flash]</b> on the cordless handset and <b>[🔊]</b> (speaker) have not been pressed. No dial tone is present.
<b>Station</b>	The Cordless handset or base phone.
<b>Talk</b>	When a dial tone has been enabled allowing the user to dial and carry on a conversation with an outside party.

## Manual Conventions

This manual uses several different type styles to help you distinguish between different parts of the phone:

- **lower case bold** text with “[ ]” indicates a key or button on the phone
- ALL CAPITALS indicates text on the display, such as menu options, prompts, and confirmation messages
- **lower case bold** text indicates a status light on the phone base

# Product Overview

## Main Phone Features


- 5.8GHz Extended Range Technology
- Corded/Cordless Telephone System
- Make and Receive Calls During a Power Failure
- Dual Keypad and Backlit Screens
- Caller ID and Caller ID on Call Waiting
- 50 Number Caller ID List in the Base and Handset
- 10 Speed Dial Numbers in the Base and Handset
- Base Speakerphone
- Trilingual Display Options (English, French and Spanish)
- Intercom Between Cordless Handset and Base
- Do Not Disturb (DND) Feature
- Clock Display in the Base
- Hold Feature
- Last Number Redial
- Tone/Pulse Dialing
- Page/Find Handset Key
- Earpiece/Ringer Volume Controls
- Mute or Turn Ringer Off
- Hearing Aid Compatible
- 20-Channel Auto Scan
- Desk or Wall Mountable

## Answering Machine Features


- Digital Tapeless Recording
- Access Messages with Handset Remote Key
- Up to 13 minutes of Recording Time
- Call Screening
- Personal or Pre-recorded Outgoing Messages
- Trilingual Display and Voice Prompts (English, Spanish, or French)
- Time and Day Announcement
- Remote Message Retrieval
- Toll Saver
- Conversation Recording
- Voice Memo
- Message Alert On/Off

# Controls and Functions



## Main Base Unit




1. Corded base handset
2. **in use** LED
3. **message** LED
4. **[answer on/off]** key and LED
5. **[greet]** key
6. Base speaker
7. **[dnd]** (do not disturb) key and LED
8. **[hold]** key and LED
9. **[redial/pause]** key
10. Curl cord
11. **[memo/call rec]** (memo/call record) key
12. **[clock /menu]** key
13. LCD display
14. **[⏮ (repeat/rewind)]** key
15. **[▶/■ (play/stop)]** key
16. **[∅ (delete)]** key
17. **[▶▶ (skip/fast forward)]** key
18. **[set]** key
19. **[mem]** (memory) key
20. **[cid select/∧]** (up) and **[cid select/∨]** (down) keys
21. **[cid]** key
22. **[mute]** key and LED
23. **[flash]** key
24. **[🔊 (speaker)]** key and LED
25. **[find hs/intercom]** (find handset/intercom) key
26. **[\*/tone/<]** (left cursor) key
27. Mic (microphone)
28. **[#/>]** (right cursor) key
29. Base antenna
30. Base **DC IN 9V** jack
31. **TEL LINE** jack
32. Wall mound adapter



## Handset



## Charger




- |  |  |
|--|--|
| 1. Handset antenna                                     | 13. <b>[select/int'com]</b><br>(select/intercom) key |
| 2. Belt clip hole                                      | 14. <b>[talk/flash]</b> key                          |
| 3. Jack for optional headset                           | 15. <b>[end]</b> key                                 |
| 4. Handset ringer speaker                              | 16. <b>[#/→]</b> (right cursor) key                  |
| 5. Handset battery compartment                         | 17. <b>[mem/menu]</b> (memory/<br>menu) key          |
| 6. Handset earpiece                                    | 18. <b>[delete/channel]</b> key                      |
| 7. LCD display   | 19. Handset microphone                               |
| 8. <b>[▲/cid]</b> (up/cid) key                         | 20. Handset charging contacts                        |
| 9. <b>[▼/M]</b> (down/memory quick access) key         | 21. Charger charging contacts                        |
| 10. <b>[ans sys/rec]</b> (answering system/record) key | 22. ⚡ (charge) LED                                   |
| 11. <b>[*/tone/←]</b> (left cursor) key                | 23. Charger <b>DC IN 9V</b> jack                     |
| 12. <b>[redial/pause]</b> key                          |  |



## Using the Interface



### Using the Base Menu

- Press [**clock/menu**] on the base to access the base main menu.
- Use [**cid select/∧**] or [**cid select/∨**] to scroll through options.
- Press [**set**] on the base to make a selection.
- For your convenience, voice prompts will guide you through the base main menu (except LCD Contrast and Dial Mode settings).
- To cancel your selection and return to standby, press [**▶/■**] (**play/stop**) on the base.
- If you do not press a key within thirty seconds, the phone will time out and exit the menu. When setting Day and Time, the time-out period is extended to two minutes.



### Using the Handset Menus

- Press and hold [**mem/menu**] on the cordless handset to access the main menu.
- Use [**∧/cid**] or [**∨/∅**] to scroll through the options.
- Press [**select/int'com**] on the cordless handset to make a selection.
- To return to standby, press [**end**] on the cordless handset, or return the cordless handset to the charger.



```

Ringler :A High
Auto Talk :Off
Language :Eng
  
```

# Installing the Phone

## Choosing the Best Location

Before choosing a location for your new phone, here are some important guidelines you should consider:

Avoid heat sources, such as radiators, air ducts, and sunlight

Avoid television sets and other electronic equipment

Choose a central location


Avoid noise sources such as a window by a street with heavy traffic

Avoid microwave ovens

Avoid excessive moisture, extremely low temperatures, dust, mechanical vibration, or shock

Avoid personal computers

Avoid other cordless telephones



- The location should be close to both a phone jack and a continuous power outlet (one which is not connected to a switch).
- The base and handset should be kept away from sources of electrical noise such as motors, microwave ovens, and fluorescent lighting.
- The base can be placed on a desk, tabletop, or mounted on a standard wall plate. For better reception, place the base as high as possible.
- The base should be placed in an open area for optimum range and reception.
- If your home has specially wired alarm equipment connected to the telephone line, be sure that installing the system does not disable your alarm equipment. If you have questions about what will disable your alarm equipment, contact your telephone company or a qualified installer.


## Connecting the Base and Corded Handset

- 1) Connect the corded handset curl cord to the left side of the phone and to the corded handset.
- 2) Route the curl cord inside the molded wiring channel as shown.
- 3) Connect the AC adapter to the **DC IN 9V** jack and to a standard 120V AC wall outlet.

**CAUTION: To avoid risk of fire and shock, only use the Uniden AD-314 AC adapter.**

- 4) Route the AC adapter cord inside the molded wiring channel as shown.
- 5) Connect the AC adapter to a continuous power supply (i.e., an outlet that is not controlled by a switch).
- 6) Place the base unit close to the AC outlet to avoid long extension cords.
- 7) Connect the telephone line cord to the **TEL LINE** jack and to a telephone outlet.
- 8) Set the base on a desk or tabletop. Place the corded base handset in the base cradle.

**Tip: If your telephone outlet isn't modular, contact your telephone company for assistance.**



## Testing the Connection


There's an easy way to test your connection: try making a call from your base. If your call connects, your phone's settings are fine. If your call does not connect:

- 1) Check the AC adapter cord. Make sure it is securely connected to the **DC IN 9V** connector and to a standard AC power outlet.
- 2) Change Dial Mode (Instructions below).

## Changing the Dial Mode

Your phone can communicate with the telephone network in two different ways: tone dialing or pulse dialing. These days, most phone networks use a method called tone dialing, so your phone comes programmed for tone dialing. If your phone company uses pulse dialing, you will need to change your phone's dial mode. If you cannot connect to the telephone network, please follow the steps below to modify your phone's settings:

- 1) Press **[clock/menu]** on the base.
- 2) Press **[cid select/~]** to move the pointer to select DIAL MODE, and then press **[set]**.
- 3) Press **[cid select/^]** or **[cid select/~]** to select TONE or PULSE (the initial setting is TONE).
- 4) Press **[set]**. You will hear a confirmation tone.



## Mounting the Base Unit on a Wall


### Standard wall plate mounting

This phone can be mounted on any standard wall plate.

- 1) Remove the wall mount adapter from the base and snap it into the notches on the bottom of the base.
- 2) Plug the AC adapter to the **DC IN 9V** jack.

**CAUTION: To avoid risk of fire and shock, only use the Uniden AD-314 AC adapter.**


- 3) Route the AC adapter cord inside the molded wiring channel as shown.
- 4) Plug the AC adapter into a standard 120V AC wall outlet.
- 5) Plug the telephone line cord into the **phone** jack.
- 6) Route the telephone line cord inside the molded wiring channel as shown.
- 7) Plug the telephone line cord into the telephone outlet.
- 8) Align the mounting slots on the base with the mounting posts on the wall. Then push in and down until the phone is firmly seated.
- 9) On the base unit, pull the corded handset retainer out of the slot. Rotate it clockwise 180 degrees.
- 10) Flip the retainer from front to back. Slide it back into the slot so that the lip of the retainer is up and the oval is down. The retainer holds the corded handset in place.



## Direct wall mounting

If you don't have a standard wall plate, you can mount your phone directly to the wall. Before doing this, consider the following:

- Avoid electrical cables, pipes, or other items behind the mounting location that could cause a hazard when inserting screws into the wall.
  - Try to mount your phone within five feet of a working phone jack to avoid excessive cord lengths.
  - Make sure the wall material is capable of supporting the weight of the base and handset.
  - Use #10 screws (minimum length of 1-3/8 inches) with anchoring devices suitable for the wall material where the base unit will be placed.
- 1) Insert two mounting screws into the wall (with their appropriate anchoring device), 3-15/16 inches apart. Allow about 1/8 of an inch between the wall and screw heads for mounting the phone.
  - 2) Refer to steps 1 through 10 on page 12 to mount the telephone.




## Installing the Rechargeable Battery Pack for Cordless Handset

The handset is powered by a rechargeable battery pack. Once installed, the battery charges automatically when the cordless handset is placed in the charger.

To install the rechargeable battery pack:

- 1) Press down on the cordless handset battery case cover (use the finger indentation for a better grip) and slide the cover downward to remove.
- 2) Plug the battery pack connector (red & black wires) into the small jack inside the battery compartment. (The connector notches fit into the grooves of the jack only one-way.) Match the wire colors to the polarity label in the battery compartment, connect the battery, and listen for a click to insure connection.
- 3) Make sure you have a good connection by slightly pulling on the battery wires. If the connection is secure, the battery jack will remain in place.
- 4) Place the battery case cover back on the cordless handset and slide it upwards until it clicks into place.

**Note: Use only the Uniden (BT-905) rechargeable battery pack supplied with your phone.**




## Connecting the Cordless Handset and Charger

The cordless handset is powered by a rechargeable battery pack. The battery recharges automatically when the handset is placed in the charger.

- 1) Connect the AC adapter to the **DC IN 9V** jack and to a standard 120V AC wall outlet.

**CAUTION: Use only the Uniden AD-310 or AD-1010 AC adapter.**

- 2) Set the charger on a desk or tabletop, and place the handset in the charger with the keypad facing forward.
- 3) Make sure that the **charge** light illuminates. If the **charge** light does not illuminate, check to see that the AC adapter is plugged in and the handset makes good contact with the charging contacts.
- 4) Charge the handset battery pack for at least 15-20 hours before using your new cordless handset for the first time.
- 5) To test your connection, try making a call from the cordless handset. If your call does not connect, check to make sure the battery is fully charged. If you see **LOW BATTERY** on the cordless handset display, check to make sure the battery is properly connected. To check the battery, slide the battery compartment door open and check the battery cables to ensure a tight and proper connection. If your handset still does not work, please contact Uniden's Customer Service department. Please see back cover for contact information.






## Installing the Belt Clip

### To attach the belt clip

Insert the belt clip into the holes on each side of the handset. Press down until it clicks.


### To remove the belt clip

Pull both sides of the belt clip to release the tabs from the holes.



## Headset Installation

Your phone may be used with an optional headset. To use this feature, insert the headset plug into the headset jack. Your phone is ready for hands-free conversations. (Headsets may be purchased by visiting our website at [www.uniden.com](http://www.uniden.com) or by calling our Parts Department. See back cover page.)




## Base Setup

### Setting the Day and Time

To set the day and time on your phone, do the following:

- 1) When the phone is in standby, press **[clock/menu]** on the base.
- 2) Press **[set]** to select TIME. The system announces "Time", the current time and the voice guidance for setting the time.
- 3) Press **[cid select/^]** or **[cid select/~]** to select the day of the week, and then press **[set]**.
- 4) Enter a two-digit number (**01-12**) to set hour, and then press **[set]**.
- 5) Enter a two-digit number (**00-59**) to set minute, and then press **[set]**.
- 6) Press **[cid select/^]** or **[cid select/~]** to choose AM or PM, and then press **[set]**. You will hear a confirmation tone.




**Note:** If you make a mistake while entering the hour or minute, use **[Ø]** (delete) to erase the wrong number and then enter the correct number.

### Selecting a Language for your Answering Machine and Base Display

You can set the language of your base menu display and answering machine announcements to English, French, or Spanish.


- 1) When the phone is in standby, press **[clock/menu]** on the base.
- 2) Press **[cid select/~]** to move the pointer to select LANGUAGE, and then press **[set]**.
- 3) Press **[cid select/^]** or **[cid select/~]** to choose ENGLISH, FRANÇAIS (French), or ESPAÑOL (Spanish).
- 4) Press **[set]**. You will hear a confirmation tone.



## Setting Caller ID on Call Waiting (CIDCW)

Caller ID on Call Waiting (CIDCW) displays the name and number of an incoming call while you are on the line.


- 1) When the phone is in standby, press **[clock/menu]** on the base.
- 2) Press **[cid select/~/]** to move the pointer to select CIDCW, and then press **[set]**.
- 3) Press **[cid select/^/]** or **[cid select/~/]** to select ON or OFF, and then press **[set]**. You will hear a confirmation tone.



## Setting the Area Code

If in your local calling area you can make a local call by dialing only seven digits (instead of ten), you can program your local area code in your phone. Calls that come from within your area code will show only the seven-digit phone number; calls from outside your area code will show all ten digits. To enter an area code, follow the steps below:

- 1) When the phone is in standby, press **[clock/menu]** on the base.
- 2) Press **[cid select/~/]** to move the pointer to select AREA CODE, and then press **[set]**.
- 3) Press the number keypad **[0-9]** to enter a three-digit area code.
- 4) If you press **[set]**, the stored number will be transferred to the cordless handset. If the transfer is successful, you will hear a confirmation tone from the base and cordless handset. Otherwise, AREA CODE SETTING FAILED! appears on the display and an error tone sounds. You will have to start over with the procedure you are performing.




**Note: If the area code has already been stored in memory, the stored area code will be displayed. To change it, use [Ø] (delete) and the number keys to enter the new area code.**

## Adjusting the Base Display (LCD Contrast)

You can adjust the contrast or brightness of the text that appears on your base display. Choose one of ten levels for optimum viewing.

- 1) When the phone is in standby, press **[clock/menu]** on the base.
- 2) Press **[cid select/~/]** to move the pointer to select LCD CONTRAST and then press **[set]**.
- 3) Press **[cid select/^]** or **[cid select/~/]** to adjust the contrast of the base display.
- 4) Press **[set]**. You will hear a confirmation tone.



## Handset Setup Setting AutoTalk

AutoTalk allows you to answer the phone simply by removing the cordless handset from the charger. You do not have to press any keys to answer the call.

- 1) When the phone is in standby, press and hold **[mem/menu]** on the cordless handset.
- 2) Press **[▼/☐]** to move the pointer to select AUTO TALK.
- 3) Press **[select/int'com]** to turn AutoTalk on.
- 4) Press **[end]** or return the handset to the charger to complete the setting. The handset returns to standby.



## Selecting a Language for the Handset Display

You can change the language the cordless handset will display. Choose from ENGLISH, FRENCH, or SPANISH.

- 1) When the phone is in standby, press and hold **[mem/menu]** on the cordless handset.
- 2) Press **[▼/☒]** to move the pointer to select LANGUAGE.
- 3) Press **[select/int'com]** to toggle between ENG (English), FR. (French) and ESP (Spanish).
- 4) Press **[end]** or return the handset to the charger to complete the setting. The handset returns to standby.

Ringer	:A High
Auto Talk	:Off
▶Language	:Eng

## Checking the Area Code Setting from the Handset

If you have set a default area code in your base phone, your cordless handset will default to the same area code setting. You can only check the Area Code number you have set. If you want to enter or edit the number, you will have to use the base to modify. Please refer to “Setting the Area Code” on page 18.

- 1) When the phone is in standby, press and hold **[mem/menu]** on the cordless handset.
- 2) Press **[▼/☒]** to move the pointer to select AREA CODE.
- 3) You can check the number entered in Area Code.
- 4) Press **[end]** or return the handset to the charger to complete the setting. The handset returns to standby.

Auto Talk	:Off
Language	:Eng
▶Area Code	:345


## Using the Speed Dial Memory

Your cordless handset allows you to store up to ten names and numbers in the cordless handset and base. You can dial these numbers with just a few key presses. The speed dial memory is not limited to just phone numbers. You can store any number (up to twenty digits) that you need to enter once your call connects. This is referred to as Chain Dialing. You can store any number (up to twenty digits) that you need to enter once your call connects. This is referred to as Chain Dialing. An example is a frequently refilled prescription number. Store your pharmacy phone number in one speed dial and your most frequently refilled prescription number as another speed dial. To use, once you ring your pharmacy's automated prescription line, simply press **[mem/menu]** (**[mem]** on the base) and the speed dial number where you stored your prescription number and press **[select/int'com]** (**[set]** on the base).


**Note: When editing the speed dial memory, you must press a key within thirty seconds or the phone will return to standby. If you return the cordless handset to the charger, the phone will return to standby also.**

## Storing a Name and Number in Memory

- 1) While the phone is in standby, press **[▼/☒]** or **[mem/menu]** (**[mem]** on the base).
- 2) Enter **[0]** - **[9]** or use **[▲]** and **[▼]** to select the speed dial location where you would like to store this entry, and then press **[select/int'com]** (**[set]** on the base) twice.
- 3) STORE NAME appears and a cursor flashes indicating that the phone is ready for the name to be entered.



```
Select Memory
1
2 JOHN DOE
```



```
Store Name
█
```



```
Edit Memory 1
Delete Memory 1
Go Back
```

**Note: If the selected speed dial number is already assigned, the Edit screen appears. You can select EDIT MEMORY to edit this entry, select DELETE MEMORY to erase this entry, or select GO BACK to choose another speed dial number.**

- 4) Enter a name according to the instructions below, then press **[select/int'com]** (**[set]** on the base). If no name is required, go to step 5.
- The name can be up to fourteen characters.
  - Use **[\*/tone/←]** and **[#/→]** to move the cursor to the desired location.
  - Press **[delete/channel]** (**[∅]** (**delete**) on the base) to delete characters as needed or press and hold to delete all characters.

Refer to the letters on the number keys to select the desired characters.

With each press of a number key, the displayed character appears in the following order: upper case letters first, lower case letters next and finally the number corresponding to the key.

**Note: If the next character uses the same number key, you must press [#/→] to move the cursor over. Otherwise the next time you press the number key, it changes the character that was previously set.**

For example, to enter **Movies**.

- 1) Press **[6]** once. Then press **[#/→]** to move the cursor to the right.
- 2) Press **[6]** six times.
- 3) Press **[8]** six times.
- 4) Press **[4]** six times.
- 5) Press **[3]** five times.
- 6) Press **[7]** eight times.

	Number of times key is pressed								
keys	1	2	3	4	5	6	7	8	9
<b>1</b>	1								
<b>2abc</b>	A	B	C	a	b	c	2		
<b>3def</b>	D	E	F	d	e	f	3		
<b>4ghi</b>	G	H	I	g	h	i	4		
<b>5jkl</b>	J	K	L	j	k	l	5		
<b>6mno</b>	M	N	O	m	n	o	6		
<b>7pqrs</b>	P	Q	R	p	q	r	s	7	
<b>8tuv</b>	T	U	V	t	u	v	8		
<b>9wxyz</b>	W	X	Y	Z	w	x	y	z	9
<b>0oper</b>	*	#	-	&	(	)	(blank)	∅	

### If you make a mistake while entering a name

Use [**\*/tone/←**] or [**#/→**] to move the cursor to the incorrect character.

Press [**delete/channel**] ([**∅**] (**delete**)) on the base) to erase the wrong character. Then enter the correct character. To delete all characters, press and hold [**delete/channel**] ([**∅**] (**delete**)) on the base).

- 5) STORE NUMBER is displayed. The cursor flashes indicating that the phone is ready for the number to be entered.

```
Store Number
|
```

- 6) Use the keypad to enter the phone number; each number can be up to twenty digits. If you need the phone to pause during the dialing sequence, press [**redial/pause**] to insert a two-second pause between the numbers. You can enter multiple pauses to increase the delay. Each pause counts as a digit. The display shows a P for every pause.

```
Store Number
8007303456P
```

- 7) Press [**select/int'com**] ([**set**] on the base). You will hear a confirmation tone, and the following screen appears. Memory storage is complete.

```
Memory 1 Stored
```

- 8) After about two seconds, the following screen displays all the speed dial memory entries.

```
1 Movies
2 JOHN DOE
3 MOM AND DAD
```

- 9) Press [**end**] ([**▶/■**] (**play/stop**)) on the base) to exit memory setup mode. The phone returns to standby.

**Note: When storing numbers into memory, if the base or cordless handset is idle (i.e., no key is pressed) for more than thirty seconds, it will beep rapidly, and the phone will return to standby.**



## Storing Caller ID in Speed Dial Memory

Caller ID names and numbers shown in the Caller ID list can be stored in speed dial memory.

To store a caller id name/number to memory:

- 1) When the phone is in standby, press [**▲/cid**] (**[cid]** on the base). Select the phone number to be stored from the Caller ID list by pressing [**▲**] or [**▼**].

```
5/17 12:30PM  
Jane Smith  
214 555 1234
```

- 2) Press [**mem/menu**] (**[mem]** on the base).

```
Select Memory  
1  
2 JOHN DOE
```

- 3) Enter a number ( **[0]** - **[9]** ) or press [**▲**] or [**▼**] to select the memory location to be stored.

```
5/17 12:30PM  
Jane Smith  
214 555 1234
```

- 4) Press [**select/int'com**] (**[set]** on the base). You hear a confirmation tone, and the number is stored in memory. The display returns to the Caller ID list.

```
Replace Memory?  
Yes  
No
```

### Note:

- If a number has already been stored in the selected memory number location, a confirmation screen is displayed. To overwrite, press [**▲**] to YES and press [**select/int'com**] (**[set]** on the base). The display returns to the Caller ID list.
- You cannot store a Caller ID message if no phone number appears in the message.

## Using Your Phone During a Power Failure

Because the phone is a corded/cordless combination phone, it can still perform several of its functions during a power failure. The following features will function with base corded handset even during a power failure:

- Making and receiving calls with the base corded handset
- Corded handset volume control
- Call Waiting (Base corded handset only)
- Redialing the last number dialed (Base corded handset only)
- Entering pauses when dialing from the base corded handset
- A special ring tone will sound during a power failure and you will not be able to control the volume setting of this ring.

All other features are disabled during a power failure.

## Making and Receiving Calls

	From the cordless handset	From the base speakerphone	From the base corded handset
<b>Making a call</b>	1) Pick up the handset from the charger. 2) Press <b>[talk/flash]</b> . 3) Listen for the dial tone. 4) Dial the number. OR 1) Pick up the handset from the charger. 2) Dial the number. Then press <b>[talk/flash]</b> .	1) Press <b>[☎]</b> (speaker). 2) Listen for the dial tone. 3) Dial the number. OR Dial the number. Then press <b>[☎]</b> (speaker).	1) Pick up the corded handset. 2) Listen for the dial tone. 3) Dial the number. OR Dial the number. Then pick up the corded handset.
<b>Receiving a call</b>	1) Pick up the handset from the charger. (If AutoTalk is on, the phone answers automatically when you pick up the handset from the charger.) 2) Press <b>[talk/flash]</b> . OR If the handset is off the charger, press <b>[talk/flash]</b> (or <b>[*/tone/&lt;]</b> , <b>[#/&gt;]</b> or any number key if AutoTalk is on).	Press <b>[☎]</b> (speaker).	Pick up the corded handset.
<b>Hanging up</b>	Press <b>[end]</b> or return the handset to the charger.	Press <b>[☎]</b> (speaker).	Return the corded handset to the base.

**Note: To turn on the AutoTalk feature, see "Activating AutoTalk" on page 19.**


## Switching between the Base Speakerphone and Corded Handset During a Call

To switch a call from the corded handset on the base to the base speakerphone, press **[<sup>☎</sup>]** (speaker) on the base. To switch from a base speakerphone call to the base corded handset, pick up the corded handset.


## Making a Call from Speed Dial Memory

To make a call from speed dial memory:

- 1) When the phone is in standby, press **[mem/menu]** (**[mem]** on the base). The cordless handset or base displays your programmed speed dial number.
- 2) Enter the number ( **[0]** - **[9]** ), or press **[▲]** or **[▼]** to select the speed dial number you would like to dial.
- 3) Press **[talk/flash]** (**[<sup>☎</sup>]**) (speaker) on the base) or pick up the corded handset from the base. Then the displayed number is dialed.



Select Memory  
1 Movies  
2 JOHN DOE



Talk  
8007303456

**Note: You can also press [talk/flash] (<sup>☎</sup>) (speaker) on the base) or pick up the corded handset from the base before you access the speed dial memory. When you come to the phone number you want to dial, press [select/int'com] ([set] on the base).**

## Easy dialing

If you want to directly access the speed dial location, press and hold the number (**[0]** - **[9]**) when the phone is in standby, and when the stored number appears, press **[talk/flash]** (**[<sup>☎</sup>]**) (speaker) on the base) or pick up the corded handset from the base.

## To cancel speed dialing

If accessing the list when the phone is in standby, press **[end]** (**[▶/■]**) (play/stop) on the base).

If accessing the list during an active call, press **[mem/menu]** (**[mem]**) on the base) to exit the list immediately.

If no key is pressed for thirty seconds, the cordless handset or base will exit the speed dial list automatically.

**Note: Pressing [end] on the handset or [▶/■] (speaker) on the base to exit the speed dial list during a call will disconnect the call immediately.**

## Making a Call from the Caller ID List

You can place a call directly from the Caller ID list.



- 1) When the phone is in standby, press **[▲/cid]** (**[cid]**) on the base) in standby. Use **[▲]** or **[▼]** to select the phone number that you want to dial.
- 2) To have the phone dial a "1" before the displayed Caller ID number, press **[1]**. To have the phone dial the stored area code before the displayed Caller ID number, press **[3]**.
- 3) Press **[talk/flash]** (**[▶/■]**) (speaker) on the base) or pick up the corded handset from the base. The displayed phone number dials automatically.

5/17 12:30PM Jane Smith 214 555 1234
--

### Note:

- From the base, you can also press **[▶/■]** (speaker) or pick up the corded handset from the base before you access the Caller ID list. When you come to the phone number you want to dial, press **[set]**.
- You cannot make a call from the Caller ID list if your phone is connected to a private branch exchange (PBX).

## Redialing the Last Dialed Number

From the cordless handset	From the base speakerphone	From the base corded handset
1) Pick up the handset from the charger. 2) Press <b>[talk/flash]</b> . 3) Listen for the dial tone. 4) Press <b>[redial/pause]</b> . OR 1) Pick up the handset from the charger. 2) Press <b>[redial/pause]</b> . 3) Press <b>[talk/flash]</b> .	1) Press <b>[</b> (speaker). 2) Listen for the dial tone. 3) Press <b>[redial/pause]</b> . OR 1) Press <b>[redial/pause]</b> . 2) Press <b>[</b> (speaker).	1) Pick up the corded handset. 2) Listen for the dial tone. 3) Press <b>[redial/pause]</b> . OR 1) Press <b>[redial/pause]</b> . 2) Pick up the corded handset.

## Adjusting the Ringer, and Earpiece and Speaker Volume

### Selecting the Cordless Handset Ring Tone and Volume

Your phone has five different ringer tone/volume combinations you can choose from.

To select the ringer:

- When the phone is in standby, press and hold **[mem/menu]** on the cordless handset.
- Press **[select/int'com]** to toggle between A HIGH, A LOW, B HIGH, B LOW and OFF. The phone will sound the different ring tones at different volumes. To turn the ringer off, select OFF.
- When the phone sounds the ring tone and volume you wish to use, press **[end]** or return the handset to the charger to complete the setting. The handset returns to standby.

▶ Ringer	:A High
Auto Talk	:Off
Language	:Eng

## Setting the Base Ringer Volume

The base has three settings for ringer volume: High, Low, and Off.



- 1) When the phone is in standby, press **[cid select/^]** or **[cid select/~]**.
- 2) The base will sound the ringer volume at the selected setting and display the new ringer volume.
- 3) When the phone sounds the ringer volume you wish to use, press **[▶/■]** (play/stop).

## Adjusting the Earpiece and Speaker Volume

**Cordless Handset:** You can select the earpiece volume from among four volume levels. To adjust the earpiece volume of cordless handset while on a call, press **[▲]** (to make it louder) or **[▼]** (to make it softer). This setting will remain in effect after the telephone call has ended.

**Base Speakerphone:** You can select eight different volume levels for the base speaker. To adjust the base speaker volume while on a call, press **[cid select/^]** (to make it louder) or **[cid select/~]** (to make it softer). This setting will remain in effect after the telephone call has ended.

**Base Corded Handset:** You can select the earpiece volume from among four volume levels. To adjust the earpiece volume of corded handset while on a call, press **[cid select/^]** (to make it louder) or **[cid select/~]** (to make it softer). This setting will remain in effect after the telephone call has ended.



## Do Not Disturb (DND) (All calls)

The do not disturb feature (DND) allows you to mute the ringer on the base and cordless handset at the same time. The phone must be in standby mode. Press and hold **[dnd]** the base. You will hear a confirmation tone, and the **do not disturb** LED illuminates on the base. DO NOT DISTURB flashes on the cordless handset display. To cancel the DND feature, press **[dnd]** again. You can also mute the ringer tone while the phone is ringing by pressing **[dnd]** on the base.

### Note:

- If you activate DND while the answering machine is off, the answering machine will be automatically turned on.
- If you deactivate the answering machine while DND is on, DND will be automatically turned off.

## Muting the Ringer (One Call Only)

To mute the ringer tone temporarily for the cordless handset or the base, when the phone is ringing, press **[end]** on the cordless handset when the cordless handset is off the charger, or press **[▶/■] (play/stop)** or **[mute]** on the base. The mute will last for the current incoming call only. The ringer tone will return to the previous setting starting with the next incoming call.

## Mute Base Microphone

During a call or an intercom call, press **[mute]** on the base to mute the microphone. MUTE ON appears on the display.

To cancel muting, press **[mute]** again.




## Using Call Waiting

If you subscribe to Call Waiting through your local telephone company, you can receive calls while on the line.

To answer a call waiting call:

- 1) While on the phone, you will hear a call waiting tone. (If you have CIDCW service activated, you will see the name and number of the incoming caller. See page 38 for more information)
- 2) Press **[talk/flash]** (**[flash]** on the base) to accept the waiting call. After a short pause, you will hear the new caller.
- 3) To return to the original caller, press **[talk/flash]** (**[flash]** on the base) again.




## Selecting a Different Channel

Your phone incorporates **UltraClear Plus™** true compander circuitry which virtually eliminates background noise. This innovative technology, together with twenty different channels, provides you with the best possible reception during all your conversations. If you happen to encounter interference while using your phone, you can manually change the phone's channel for clear operation. To change the channel during a call, press **[delete/channel]**. SCANNING appears on the display, indicating the phone is changing to another channel. For more information on interference, refer to "Radio Interference" on page 62.

## Find Handset

If you misplace the cordless handset, press **[find hs/intercom]** on the base. The cordless handset will beep for sixty seconds. To cancel the page, press **[find hs/intercom]** on the base. The cordless handset will also stop beeping automatically when an incoming call is received.



## Placing a Call on Hold from the Base

- 1) During a call from the base, press **[hold]**. The call will be put on hold.
- 2) To return to the call, press **[hold]** again, pick up the corded handset or press **[speaker]** (speaker) on the base. To talk to the caller from the cordless handset, press **[talk/flash]** on the cordless handset.

### Note:


- You can place a call on hold for ten minutes. When ten minutes has passed, the call is disconnected, and the phone automatically returns to standby.
- You can return the corded handset to the base while a call is on hold, and the call will remain on hold.

## Conferencing

With this phone system, up to three people can participate in a conference call while using an outside line, the cordless handset, and the base.

### Joining a Conference Call

You can easily join a call already in progress.





	From the cordless handset	From the base speakerphone	From the base corded handset
<b>Joining the conference call</b>	During a call from the base, press <b>[talk/flash]</b> on the handset.	During a call from the cordless handset, press <b>[speaker]</b> (speaker) on the base.	During a call from the cordless handset, pick up the corded base handset.
<b>Exiting the conference call</b>	Press <b>[end]</b> on the handset or return the handset to the charger. The base will still be connected to the call.	Press <b>[speaker]</b> (speaker) on the base. The cordless handset will still be connected to the call.	Return the corded handset to the base cradle. The cordless handset will still be connected to the call.

## Intercom

The intercom feature lets you communicate between the cordless handset and base without using the phone line. You can make an intercom call while an outside caller is on hold; making an intercom call will not terminate the call on hold. If the party does not answer within one minute, the operation is canceled.

### Making an Intercom Page

	From the cordless handset	From the base speakerphone	From the base corded handset
<b>Making an Intercom Page (in standby)</b>	<ol style="list-style-type: none"><li>1) Press <b>[select/int'com]</b>.</li><li>2) The base will be paged. An intercom tone sounds.</li></ol> <p><b>To cancel the Page:</b> Press <b>[select/int'com]</b> or <b>[end]</b>, or return the handset to the charger.</p>	<ol style="list-style-type: none"><li>1) Press <b>[find hs/intercom]</b>.</li><li>2) The cordless handset will be paged. An intercom tone sounds.</li></ol> <p><b>To cancel the Page:</b> Press <b>[find hs/intercom]</b> or <b>[]</b> (speaker).</p>	<ol style="list-style-type: none"><li>1) Press <b>[find hs/intercom]</b>.</li><li>2) The cordless handset will be paged. An intercom tone sounds.</li><li>3) Pick up the corded handset.</li></ol> <p><b>To cancel the Page:</b> Press <b>[find hs/intercom]</b> or return the corded handset to the base.</p>
<b>Making an Intercom Page (During a call)</b>	<ol style="list-style-type: none"><li>1) Press <b>[select/int'com]</b>.</li><li>2) The call will automatically be placed on hold, and the paging tone sounds.</li></ol> <p><b>To cancel the Page:</b> Press <b>[select/int'com]</b> or <b>[talk/flash]</b>.</p>	<ol style="list-style-type: none"><li>1) Press <b>[find hs/intercom]</b>.</li><li>2) The call will automatically be placed on hold, and the paging tone sounds.</li></ol> <p><b>To cancel the Page:</b> Press <b>[find hs/intercom]</b> or <b>[]</b> (speaker).</p>	<ol style="list-style-type: none"><li>1) Press <b>[find hs/intercom]</b>.</li><li>2) The call will automatically be placed on hold, and the paging tone sounds.</li></ol> <p><b>To cancel the Page:</b> Press <b>[find hs/intercom]</b>.</p>

## Answering and Hanging up an Intercom Page

	On the cordless handset	With the base speakerphone	With the base corded handset
<b>Answering an Intercom Page</b>	<p>1) Pick up the handset from the charger. (If AutoTalk is on, the phone answers automatically when you pick up the handset from the charger.)</p> <p>2) Press <b>[select/int'com]</b> or <b>[talk/flash]</b>. OR If the handset is off the charger, press <b>[select/int'com]</b> or <b>[talk/flash]</b>. (If AutoTalk is on, you can press any key in the twelve number keypad.)</p>	Press <b>[find hs/intercom]</b> or <b>[☎]</b> (speaker).	Pick up the corded handset.
<b>Hanging up an Intercom Page</b>	Press <b>[select/int'com]</b> or <b>[end]</b> , or return the handset to the charger.	Press <b>[☎]</b> (speaker).	Return the corded handset to the base.

## Transferring a Call


You can transfer a call from one station to another.

During a call, make an intercom call to the other station; press **[select/int'com]** on the cordless handset or press **[find hs/intercom]** on the base. The call will be automatically be placed on hold. Then answer the intercom page at the other station. After the intercom conversation, the station transferring the call may now hang up; the other station returns to the call and then the call is transferred.

## Tone Dialing Switch-over

If your telephone company requires pulse dialing, you can temporarily switch over to tone dialing after the call connects. This feature is useful when you need tone dialing to use automated such as telephone bank tellers, telephone prescription refills, customer support menus, etc.

If your phone is set to pulse dialing mode, make your call normally. Once your call connects, press **[\*/tone/←]** on the handset or **[\*/tone/<]** on the base. Any digits you enter from then on will be sent as tone dialing. When this particular call ends, the phone automatically returns to pulse dialing mode.



## Caller ID and CIDCW (Caller ID on Call Waiting)

You must subscribe to Caller ID services through your local telephone provider to use these features. When the telephone rings, the Caller ID feature allows you to view the caller's name, phone number, date and time of call. The incoming call information is stored in the Caller ID record. If the Caller ID service includes the caller's name, the caller's name appears on the display (up to fifteen letters).

The date and time received	5/11 12:30PM
Caller's name	Jane Smith
Caller's phone number	214-555-1234

You may receive any one of the following messages:

When invalid data is received	INCOMPLETE DATA
When a private name is received	PRIVATE NAME
When a private number is received	PRIVATE NUMBER
When an unknown name is received	UNKNOWN NAME
When an unknown number is received	UNKNOWN NUMBER

### Note:

- Data errors appear as " ■ ".
- If you answer a call before the Caller ID message is received (for example, before the second ring), the Caller ID message will not appear.
- When the call is received via a telephone company that does not offer Caller ID service, the caller's phone number and name do not appear. (This includes international calls.)
- When the call is received via a private branch exchange (PBX), the caller's phone number and name may not appear.

## Caller ID on Call Waiting (CIDCW)

If you subscribe to CIDCW offered by your telephone company, you will hear a Call Waiting tone while you are on a call, and the Caller ID data will be displayed at the cordless handset or base. To accept the waiting call, press **[talk/flash]** on the cordless handset or **[flash]** on the base (see page 32).

## Viewing the Caller ID Message List

The Caller ID list stores information for up to fifty incoming calls - even unanswered calls.

- 1) When the phone is in standby, press **[▲/cid]** (**[cid]** on the base). The summary screen displays the number of new messages and total messages.
- 2) Use **[▼]** to scroll through the messages from the latest to the earliest, or use **[▲]** to scroll through the messages from the earliest to the latest.
- 3) Press **[end]** (**[▶/■]** (**play/stop**) on the base) to return to standby.

```
Caller ID
New :01
Total:02
```

```
5/17 12:30PM
Jane Smith
214 555 1234
```

### Note:

- From the base, you can also view the Caller ID list during a call. To return to the call, press **[cid]**.
- In Caller ID operation, if no key is pressed for more than thirty seconds, an error tone sounds and the handset or base returns to standby.
- Each message can be up to fifteen characters for the name and fifteen digits for the phone number.
- The number of calls from the same Caller ID appears next to the received time. Once you view the new message, the number will be cleared and disappear.



## Deleting Information from the Caller ID List

If the phone receives more Caller ID messages than it can store, the oldest one in the list is automatically deleted. Caller ID data can also be deleted manually.

### Deleting a Caller ID message

- 1) When the phone is in standby, press [**▲/cid**] (**[cid]** on the base). Find the message to be deleted from the Caller ID list by pressing [**▲**] or [**▼**].
- 2) Press [**delete/channel**] (**[Ø] (delete)** on the base).
- 3) Press [**▲**] or [**▼**] to select YES, and then press [**select/int'com**] (**[set]** on the base).

```
5/17 12:30PM
Jane Smith
214 555 1234
```

```
Delete Message?
▶Yes
No
```

### Deleting all Caller ID names/numbers

- 1) When the phone is in standby, press [**▲/cid**] (**[cid]** on the base).
- 2) Press [**delete/channel**] (**[Ø] (delete)** on the base).
- 3) Press [**▲**] or [**▼**] to select YES, and then press [**select/int'com**] (**[set]** on the base). You hear a confirmation tone and all stored Caller ID messages are deleted.

```
Caller ID
New :01
Total:02
```

```
Delete All?
▶Yes
No
```

#### Note:

- While using the **DELETE ALL?** or **DELETE MESSAGE?** screen, if no key is pressed for more than thirty seconds, an error tone sounds, and the handset or base returns to standby.
- If you get an incoming call or page, the deleting operation is canceled and you can answer the call or page.

# The Integrated Answering Machine

The phone has a built-in answering machine that answers and records incoming calls. You can also use your answering machine to record a conversation, leave a voice memo message, or to announce a special outgoing message to callers when you're away from your phone.

## Features

- Digital Tapeless Recording
- Access Messages with Handset Remote Key
- Up to 13 Minutes of Recording Time
- Call Screening
- Personal or Pre-recorded Outgoing Message
- Trilingual Display Options and Voice Prompts (English, French or Spanish)
- Time and Day Announcement
- Remote Message Retrieval
- Toll Saver
- Conversation Recording
- Voice Memo
- Message Alert On/Off
- Records Up to 59 Messages

## Setting Up Your Answering Machine

- For your convenience, voice prompts will guide you through the menus.
- Press **[▶/■]** (**play/stop**) on the base to return to standby.
- If you do not press a key within thirty seconds, the phone will time out and exit the menu.


## Selecting a Language

You can set the language of your base menu display and answering machine announcements to English, French, or Spanish. To select your language choice, please refer to "Selecting a Language for your Answering Machine and Base Display" on page 17 under "Base Setup".

## Setting the Record Time (or Announce Only)

You can select how long a caller has to record a message. You have three record time options. The options 1 MINUTE or 4 MINUTES set the duration for recording the incoming messages. ANNOUNCE ONLY answers the call and plays either your personal greeting or the pre-recorded system greeting, but prevents the caller from leaving a message.


- 1) Press **[clock/menu]** on the base.
- 2) Press **[cid select/∨]** to move the pointer to select RECORD TIME, and then press **[set]**.
- 3) Press **[cid select/∧]** or **[cid select/∨]** to select Record Time 1 MINUTE, 4 MINUTES, or ANNOUNCE ONLY.
- 4) Press **[set]**. You will hear a confirmation tone.



## Activating Call Screening

Your phone allows you to listen to callers leaving you a message. This feature can be turned on or off with the following steps:


- 1) Press **[clock/menu]** on the base.
- 2) Press **[cid select/~]** to move the pointer to select CALL SCREENING, and then press **[set]**.
- 3) Press **[cid select/^]** or **[cid select/~]** to select ON or OFF.
- 4) Press **[set]**. You will hear a confirmation tone.



## Setting the Number of Rings

The ring time setting allows you to set the number of rings the caller hears before your answering machine plays the outgoing message. You can set the ring time to answer after two, four, or six rings. If you enable the Toll Saver, the answering machine picks up after two rings if you have new messages and after four rings if there are none.


- 1) Press **[clock/menu]** on the base.
- 2) Press **[cid select/~]** to move the pointer to select RING TIME, and then press **[set]**.
- 3) Press **[cid select/^]** or **[cid select/~]** to select a Ring Time (TOLL SAVER, 2 TIMES, 4 TIMES, or 6 TIMES).
- 4) Press **[set]**. You will hear a confirmation tone.



## Activating the Message Alert

The Message Alert feature sounds a short alert tone every fifteen seconds whenever you have a new message. Once all new messages have been played, the alert tone automatically stops beeping until you receive another new unplayed message.

- 1) Press **[clock/menu]** on the base.
- 2) Press **[cid select/~]** to move the pointer to select MESSAGE ALERT, and then press **[set]**.
- 3) Press **[cid select/^]** or **[cid select/~]** to select ON or OFF.
- 4) Press **[set]**. You will hear a confirmation tone.




To quickly turn off the Message Alert tone, press any key on the base unit; the tone will automatically quiet until you receive another new message.

## Setting a Security Code or Personal Identification Number (PIN)

To play your messages from a remote location outside of your home, you will need to enter a two-digit Security code or Personal Identification Number (PIN).

- 1) Press **[clock/menu]** on the base.
- 2) Press **[cid select/~]** to move the pointer to select SECURITY CODE, and then press **[set]**.
- 3) Enter a two-digit Security or PIN code (**01-99**) using the number keypad. To change the number, use **[0]** (delete) to backspace.
- 4) Press **[set]**. You will hear a confirmation tone.



## Setting Your Outgoing Message (Greeting)

When you receive a call, the answering machine automatically plays either a preset message or your own greeting. Your answering machine comes with the following preset message:

"Hello, no one is available to take your call. Please leave a message after the tone."

If the answering machine is set to announce only, the preset greeting automatically changes to:


"Hello. No one is available to take your call. Please call again."

See "Setting the Record Time (or Announce Only)" on page 42 on how to set the announce only feature.

Or you can record your own personal outgoing greeting. Your recorded greeting must be between two seconds and thirty seconds long. Once you have recorded a personal greeting, you can switch back and forth between the preset greeting and your own personal greeting.

### To Record a personal outgoing message (Greeting)

- 1) With the phone in standby, press **[greet]**. While the preset message is playing, press and hold **[greet]** again. You will hear the announcement "Record greeting" and a confirmation tone.



If you already have a greeting recorded, you can delete the current one and then record a new greeting. While the current greeting is playing, press **[Ø] (delete)**. And then start over with the first.

- 2) Start recording your message. You will have thirty seconds, and the message counter will count down.

- 3) When you are finished recording your greeting, press **[greet]**, **[▶/■]** (play/stop) or **[set]**. You hear a confirmation tone, and then your greeting plays back for you.

**Note:**

- **Position yourself as close to the base as possible and speak clearly when recording your greeting.**
- **If you make an outside call or a call is received during the new greeting recording, the operation is canceled.**
- **The greeting must be more than two seconds long, or it will not be recorded.**

### **Choosing between the two outgoing messages**

With the phone in standby, press **[greet]** to play the current outgoing message. While the outgoing message is playing, press **[greet]** again to switch between the prerecorded greeting and the personal greeting. After the message finishes playing, a confirmation tone is heard.

**Note: To delete the personal greeting, press [∅] (delete) during the announcement and the system announces "Greeting has been deleted."**

# Using Your Answering Machine

## Turning the Answering Machine On/Off

	From the base	From the cordless handset
<b>Turning On</b>	<ol style="list-style-type: none"> <li>1) With the phone in standby, press <b>[answer on/off]</b>.</li> <li>2) The phone announces "Answering system is on." and plays the current greeting. The <b>answer on/off</b> LED will be illuminated.</li> </ol>	<ol style="list-style-type: none"> <li>1) With the phone in standby, press <b>[ans sys/rec]</b>. REMOTE ANSWERING MACHINE OPERATION appears on the display, and the answering system announces the number of messages stored in the memory.</li> <li>2) Press <b>[6]</b> at any time during the announcement.</li> <li>3) The system announces "Answering System is on" and plays the current greeting message.</li> </ol>
<b>Turning Off</b>	<ol style="list-style-type: none"> <li>1) With the phone in standby, press <b>[answer on/off]</b> again.</li> <li>2) The phone announces "Answering system is off." The <b>answer on/off</b> LED will no longer be illuminated.</li> </ol>	<ol style="list-style-type: none"> <li>1) With the phone in standby, press <b>[ans sys/rec]</b>. REMOTE ANSWERING MACHINE OPERATION appears on the display, and the answering system announces the number of messages stored in the memory.</li> <li>2) Press <b>[9]</b> at any time during the announcement. The system announces "Answering System is off".</li> </ol>

**Note:** When the answering machine is full, [ FL ] is displayed on the base, and the system announces "No remaining time." You should delete some messages so that the system can record new messages.

## Reviewing Messages

The message counter displays the number of messages stored in memory. If the display flashes, new messages waiting for you. The flashing number represents the number of new messages, not total messages. The phone plays your new messages first; after all the new messages are played, you can play the old messages.



To review your message:

	From the base	From the cordless handset
<b>Playing messages</b>	With the phone in standby, press <b>[▶/■]</b> . The system announces the number of new and old messages. It announces the message number, plays the message, then announces the time and day it was received.	Press <b>[ans sys/rec]</b> . The system announces the number of messages stored in the memory. Press <b>[▶/2]</b> to play your messages. After playing the message, the system announces the time and day that message was received.
<b>Repeating a message</b>	Press <b>[◀◀]</b> once to go to the beginning of the current message. Press <b>[◀◀]</b> repeatedly to go back to a previous message. Press and hold <b>[◀◀]</b> to rewind through the current message.	Press <b>[◀◀/1]</b> once to go to the beginning of the current message. Press <b>[◀◀/1]</b> repeatedly to go back to a previous message.
<b>Skipping a message</b>	Press <b>[▶▶]</b> to go to the beginning of the next message. Press and hold <b>[▶▶]</b> to fast forward through the current message.	Press <b>[▶▶/3]</b> to go to the beginning of the next message.
<b>Deleting a message</b>	While a message is playing, press <b>[Ø]</b> . The message is permanently deleted.	While a message is playing, press <b>[Ø/4]</b> . The message is permanently deleted.
<b>Deleting all messages</b>	While the phone is in standby, press <b>[Ø]</b> . When the system asks you to confirm, press <b>[Ø]</b> again. All messages are permanently deleted.	Not available.
<b>Ending the message review</b>	Press <b>[▶/■]</b> to stop the message playback and return to standby.	Press <b>[■/5]</b> to stop the message playback. Press <b>[end]</b> to exit the system and return to standby.

**Note: You cannot delete all messages at once when you have unheard messages. If you try to delete all messages before listening to unheard messages, the answering machine will beep and say "Please playback all messages."**

## **Screening a call**

If you activate the call screening feature, you can listen to callers leaving a message without answering the phone (see Activating Call Screening on page 43). You can always hear callers from the base speaker.

- To mute the Call Screen, press **[mute]** or **[▶/■] (play/stop)**.
- To cancel muting, press **[cid select/^]** or **[cid select/√]**.

To screen an incoming call from the cordless handset:

- Press **[ans sys/rec]** when the system is answering.
- To answer the call, press **[talk/flash]**.
- To stop screening the call, press **[end]** or return the cordless handset to the charger.

## **Recording a Conversation**

You can record a conversation from the base or cordless handset up to ten minutes of conversation while you are using your phone. Any conversation that lasts less than two seconds will not be recorded.

- 1) During a conversation, press and hold **[memo/call rec]** on the base or press **[ans sys/rec]** on the handset.
- 2) The unit begins recording with a confirmation tone and RECORDING A CALL appears on the display.

**A beep that can be heard by both parties sounds during recording.**

- 3) To stop recording, press [▶/■] (play/stop) or [memo/call rec] on the base or [ans sys/rec] on the handset. You hear a confirmation tone.

**Note:**

- If you receive a call waiting tone while recording a conversation, press [flash] on the base or [talk/flash] on the handset to accept the waiting call. The recording feature continues recording the new call. The original call is put on hold.
- A recorded conversation is treated as a typical message and will be added to the stored messages.
- Every state has different regulations governing the recording of conversations over the telephone. Make sure to check your local, state and federal laws before using this product to record any telephone conversation in order to determine that your use is in compliance with such laws or guidelines.

## Voice Memo (Base Only)

The voice memo function allows you to record messages as short as two seconds and as long as four minutes.

- 1) With the phone in standby, press and hold [memo/call rec] on the base. You hear an announcement "Record memo message" and a confirmation tone.
- 2) Start your recording.
- 3) When you have finished, press [▶/■] (play/stop), [mem/call rec] or [set] to stop recording. You hear a confirmation tone and the system returns to standby.

**Note:** When the answering machine is full, [ FL ] appears on the base display and recording is terminated.

## Remote Operation

When you are away from home, you can operate your answering machine with any touch-tone telephone. Use this function to check for recorded messages, to play or delete messages, even record a new greeting message.

- 1) Call your telephone number.
- 2) During the greeting message, press **[0]** and enter your PIN code (See page 44).
- 3) The answering machine announces the current time and the number of messages stored in memory. Then you hear "To play incoming message, press zero two. For help, press one zero."
- 4) You may continue to listen to the voice prompts, or you may select a command from the following chart:

Command	Function	Command	Function
<b>[0]</b> then <b>[1]</b>	Repeat a Message	<b>[0]</b> then <b>[6]</b>	Answering Machine On
<b>[0]</b> then <b>[2]</b>	Play Incoming Messages	<b>[0]</b> then <b>[7]</b>	Memo Record/Stop*
<b>[0]</b> then <b>[3]</b>	Skip a Message	<b>[0]</b> then <b>[8]</b>	Greeting Message Record/Stop*
<b>[0]</b> then <b>[4]</b>	Delete a Message	<b>[0]</b> then <b>[9]</b>	Answering Machine Off
<b>[0]</b> then <b>[5]</b>	Stop Operation	<b>[1]</b> then <b>[0]</b>	Voice Prompts

\* For Memo Record and Greeting Message Record functions, the first time you enter the corresponding command, it starts the Recording function. If you want to stop the recording, enter the command again.

**Note: Once you enter the remote access menu, you must enter a command within fifteen seconds, or the answering machine automatically hangs up and returns to standby.**

- 5) After all of the voice prompts have been played, you hear intermittent beeps indicating that the system is in the command waiting mode. You may enter another command at this time from the chart.
- 6) When you are finished, hang up to exit the system. The answering machine automatically returns to standby.

**Note: For your convenience remote operation cards are provided for you to use while away from home (located back of this manual).**

## **Turn on the Answering Machine Remotely**

If you have forgotten to turn on your answering machine, you can turn it on remotely from any touch-tone telephone.

- 1) Call your telephone number.
- 2) Wait ten rings until the system answers. You hear intermittent beeps.
- 3) Press **[0]** and then enter your PIN code. The answering machine announces the number of messages stored in memory. You hear "To play incoming message, press zero two. For help, press one zero."
- 4) Press **[0]** then **[6]** to turn the answering machine On. You hear the outgoing message and a confirmation tone.
- 5) Hang up the phone; subsequent calls will be answered by the system.

## Maintenance Specifications

The phone complies with FCC Parts 15 and 68.

<b>Operating temperature</b>	-10°C to +50°C (+14°F to +122°F)		
<b>AC Adapter</b>		<b>For the base</b>	<b>For the charger</b>
	<b>Part number</b>	AD-314	AD-310 or AD-1010
	<b>Input Voltage</b>	120V AC 60Hz	120V AC 60Hz
	<b>Output Voltage</b>	9V DC 350mA	9V DC 210mA
<b>Battery</b>	<b>Part number</b>	BT-905	
	<b>Capacity</b>	600mAh, 3.6V	
<b>Frequency</b>	921.103102-923.787761 MHz 5856.533347-5863.692437 MHz		

**Note: To avoid damage to the phone use only Uniden AD-314, AD-310 or AD-1010 and BT-905 with your phone.**

Specifications, features, and availability of optional accessories are all subject to change without prior notice.

## **Power Failure**

During a power failure, you can make and receive calls with the base corded handset; however, you will not be able to use the base speakerphone or the cordless handset. The following features are available with the base corded handset during a power failure:


- Corded Handset Volume Control
- Call Waiting
- Redialing the Last Number Dialed
- Entering Pauses when Dialing
- A special ring tone will sound during a power failure and you will not be able to control the volume setting of this ring.

## **Talk and Standby Times**

With average use, your cordless handset battery provides approximately six hours of talk time and approximately ten days of standby time. When your cordless handset is not being used and is left off of the charger, the battery will gradually discharge. You can achieve optimum battery life and performance by returning the cordless handset to the charger after each use. If the cordless handset is left off of the charger, the actual talk time duration will be reduced respective to the amount of time the cordless handset is off of the charger.

## Low battery alert

When the battery pack is very low and needs to be charged, the phone is programmed to eliminate functions in order to save power. If the phone is not in use, LOW BATTERY appears on the LCD and none of the keys will operate. During a call, LOW BATTERY flashes and the cordless handset beeps. Complete your conversation as quickly as possible and return the cordless handset to the charger for charging.



**Note: Information stored in the phone's memory will be retained for thirty minutes after the battery pack is removed. This includes earpiece volume, ringer tone and volume, and last number dialed.**

Even when the battery pack is not being used, it will gradually discharge over a long period of time. For optimum performance, be sure to return the cordless handset to the charger after a telephone call.

## Battery replacement and handling

Recharge your phone on a regular basis by returning the cordless handset to the charger after each phone call. When the operating time becomes short even after a battery is recharged, please replace the battery. With normal usage, your battery should last about one year. To order replacement batteries, please contact Uniden's Parts Department. The contact information is listed on the back cover page.

### Warning:

**To avoid the risk of personal injury or property damage from fire or electrical shock, only use the Uniden battery model and Uniden adapter model specifically designated for this product.**

### Caution:

- **Use only the specified Uniden battery pack (BT-905).**
- **Do not remove the battery from the cordless handset to charge it.**
- **Never throw the battery into a fire, disassemble it, or heat it.**
- **Do not remove or damage the battery casing.**




## Cleaning the battery charging contacts

To maintain a good charge, clean the charging contacts on the cordless handset once a month. Dampen a cloth with plain water. Gently rub the damp cloth over the charging contacts until all visible dirt is removed. Dry the contacts thoroughly before returning the cordless handset to the charger.

### Caution:

**Do not use paint thinner, alcohol, or other chemical products. Doing so may discolor the surface of the telephone and damage the finish.**



## Troubleshooting

### Traveling Out-of-Range

During a call, as you begin to move your cordless handset too far from your base unit, noise increases. If you pass the range limits of the base, your call will terminate within one minute.

## Common Issues

If your phone is not performing to your expectations, please try these simple steps first. If these steps do not solve your problem, please call our Customer Hotline. See back cover page for contact information.

Symptom	Suggestion
The <b>charge</b> LED won't illuminate when the cordless handset is placed in the charger.	<ul style="list-style-type: none"><li>• Make sure the AC adapter is plugged into the charger and wall outlet.</li><li>• Make sure the cordless handset is properly seated in the charger.</li><li>• Make sure the charging contacts on the cordless handset are clean.</li></ul>

<b>Symptom</b>	<b>Suggestion</b>
The audio sounds weak and/or scratchy.	<ul style="list-style-type: none"> <li>• Move the cordless handset and/or base away from metal objects or appliances and try again.</li> <li>• Press <b>[delete/channel]</b> during a call to help eliminate background noise.</li> <li>• Make sure that the cordless handset is not too far from the base.</li> </ul>
Can't make or receive calls.	<ul style="list-style-type: none"> <li>• Check both ends of telephone line cord.</li> <li>• Make sure the AC adapter is plugged into the base and wall outlet.</li> <li>• Disconnect the AC adapter for a few minutes, then reconnect it.</li> <li>• Make sure that the cordless handset is not too far from the base.</li> <li>• Check the dialing mode used by your telephone company.</li> </ul>
During power failure, can't make or receive a call.	<ul style="list-style-type: none"> <li>• Make sure to use corded handset to make or receive a call.</li> <li>• Make sure that TEL line cord is connected firmly.</li> </ul>
The cordless handset doesn't ring or receive a page.	<ul style="list-style-type: none"> <li>• The battery pack may be weak. Charge the battery for 15-20 hours.</li> <li>• Make sure that the cordless handset is not too far from the base.</li> <li>• Place the base unit away from appliances or metal objects.</li> <li>• Check the battery pack to ensure there is a secure connection.</li> <li>• Make sure ringer volume isn't set to "off."</li> </ul>
Severe noise interference.	<ul style="list-style-type: none"> <li>• Keep the cordless handset away from microwave ovens, computers, remote control toys, wireless microphones, alarm systems, intercoms, room monitors, fluorescent lights, and electrical appliances.</li> <li>• Move the base to another location or turn off the source of interference.</li> </ul>

<b>Symptom</b>	<b>Suggestion</b>
The Caller ID does not display.	<ul style="list-style-type: none"> <li>• The call was answered before the second ring.</li> <li>• The call was placed through a switchboard.</li> <li>• Charge the cordless handset.</li> <li>• Your Caller ID service may not be active; contact your local telephone service provider.</li> </ul>
The answering machine does not work.	<ul style="list-style-type: none"> <li>• Make sure the AC adapter is plugged into wall outlet.</li> <li>• Make sure the answering machine is turned on.</li> </ul>
The answering machine does not record any messages.	<ul style="list-style-type: none"> <li>• Set the record time to either the one minute or four minute option.</li> <li>• The memory may be full. Delete some or all of the saved messages.</li> </ul>
Messages are incomplete.	<ul style="list-style-type: none"> <li>• The incoming messages may be too long. Remind callers to leave a brief message.</li> <li>• The memory may be full. Delete some or all of the saved messages.</li> </ul>
After a power failure, the outgoing message is deleted.	<ul style="list-style-type: none"> <li>• Record your personal outgoing message again. The default message should remain.</li> </ul>
No sound on the base speaker during call monitoring or message playback.	<ul style="list-style-type: none"> <li>• Adjust the speaker volume on the base unit.</li> <li>• Make sure the call screen feature is set to on.</li> </ul>
Cannot access remote call-in features from another touch-tone phone.	<ul style="list-style-type: none"> <li>• Make sure you're using the correct PIN code.</li> <li>• Make sure that the touch-tone phone you're using can transmit the tone for at least two seconds. If it cannot, you may have to use another phone to access your messages.</li> </ul>

## Liquid Damage

Moisture and liquid can damage your cordless phone.

- If the phone or base is exposed to moisture or liquid, but only the exterior plastic housing is affected, wipe off the liquid, and use as normal.
- If moisture or liquid has entered the plastic housing (i.e. liquid can be heard in the phone or liquid has entered the handset battery compartment or vent openings on the base), follow the steps below:

<b>Cordless Handset</b>	<b>Base</b>
<ol style="list-style-type: none"><li>1) Remove the battery cover and leave it off for ventilation.</li><li>2) Disconnect the battery pack. Leave the battery cover off and the battery pack disconnected for at least three days.</li><li>3) Once the handset is completely dry, reconnect the battery pack and the battery cover.</li><li>4) Recharge the handset's battery pack for 15 to 20 hours before using.</li></ol>	<ol style="list-style-type: none"><li>1) Disconnect the AC adapter from the base, cutting off electrical power.</li><li>2) Disconnect the telephone cord from the base.</li><li>3) Let dry for at least three days.</li></ol>

### **IMPORTANT:**

You must unplug the telephone line while recharging the battery pack to avoid charge interruption.

### **CAUTION:**

DO NOT use a microwave oven to speed up the drying process. This will cause permanent damage to the cordless handset, base and the microwave oven. After following these steps, if your cordless telephone does not work, please call our Customer Service Hotline. See back cover page for contact information.

## Precautions!

Before you read anything else, please note the following:

### Warning!

Uniden America Corporation DOES NOT represent this unit to be waterproof. To reduce the risk of fire, electrical shock, or damage to the unit, DO NOT expose this unit to rain or moisture.

### Rechargeable Nickel-Cadmium Battery Warning

- This equipment contains a rechargeable nickel-cadmium battery.
- Cadmium is a chemical known to the State of California to cause cancer.
- The rechargeable nickel-cadmium battery contained in this equipment may explode if disposed of in a fire.
- Do not short-circuit the battery.
- Do not charge the rechargeable nickel-cadmium battery used in this equipment in any charger other than the one designed to charge this battery as specified in the owner's manual. Using another charger may damage the battery or cause the battery to explode.

## Rechargeable Nickel-Cadmium Batteries Must Be Recycled or Disposed of Properly

- Uniden voluntarily participates in an RBRC® industry program to collect and recycle nickel-cadmium batteries at the end of their useful life, when taken out of service within the United States.
- The RBRC® program provides a convenient alternative to placing used nickel-cadmium batteries into the trash or municipal waste stream, which is illegal in some areas.
- Through the RBRC® program, Uniden makes it easy for you to drop off the used battery at local retailers of replacement nickel-cadmium batteries. You may also contact your local recycling center for information on where to return the used battery.  
Please call 1-800-8-BATTERY for information on Ni-Cd battery recycling in your area. Uniden's involvement in this program is part of its commitment to protecting our environment and conserving natural resources.
- RBRC® is a registered trademark of the Rechargeable Battery Recycling Corporation.  
Uniden works to reduce lead content in our PVC coated cords in our products and accessories.

### Warning!

The cords on this product and/or accessories contain lead, a chemical known to the State of California to cause birth defects or other reproductive harm. Wash hands after handling.



## Important Safety Instructions

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

1. Do not use this product near water, for example, near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electric shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local authorities for possible battery disposal instructions.
5. Do not disassemble any component of this product.

## SAVE THESE INSTRUCTIONS

### CAUTION!

Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions. Do not open or mutilate the battery, and disconnect the battery before shipping this product.

## The FCC Wants You To Know

This equipment complies with Part 68 of the FCC rules and the requirements adopted by the ACTA.

On the bottom of this equipment is a label that contains, among other information, a product identifier in the format US:AAAEQ##TXXXX. If requested, this number must be provided to the telephone company.

An applicable Universal Service Order Codes (USOC) certification for the jacks used in this equipment is provided (i.e., RJ11C) in the packaging with each piece of approved terminal equipment. A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA.

A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

The REN is used to determine the number of devices that may be connected to a telephone line. Excessive RENs on a telephone line may result in the devices not ringing in response to an incoming call. In most but not all areas, the sum of RENs should not exceed five (5.0). To be certain of the number of devices that may be connected to a line, as determined by the total RENs, contact the telephone provider. For products approved after July 23, 2001, the REN for this product is part of the product identifier that has the format US:AAAEQ##TXXXX. The digits represented by ## are the REN without a decimal point (e.g., 03 is a REN of 0.3). For earlier products, the REN is separately shown on the label.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary. The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice in order for you to make necessary modifications to maintain uninterrupted service. Please follow instructions for repairing, if any (e.g. battery replacement section); otherwise do not substitute or repair any parts of the device except as specified in this manual. Connection to party line service is subject to state tariffs. Contact the state public utility commission, public service commission or corporation commission for information. This equipment is hearing aid compatible. Should you experience trouble with this equipment, please contact Uniden customer service at 800-297-1023. If the equipment is causing harm to the telephone network, the telephone company may request that you disconnect the equipment until the problem is resolved.

**NOTICE:** According to telephone company reports, AC electrical surges, typically resulting from lightning strikes, are very destructive to telephone equipment connected to AC power sources. To minimize damage from these types of surges, a surge arrestor is recommended.

Changes or modifications to this product not expressly approved by Uniden, or operation of this product in any way other than as detailed by the owner's manual, could void your

authority to operate this product.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Privacy of communications may not be ensured when using this phone.

To insure the safety of users, the FCC has established criteria for the amount of radio frequency energy various products may produce depending on their intended usage. This product has been tested and found to comply with the FCC's exposure criteria. For body worn operation, the FCC RF exposure guidelines were also met when used with the Uniden accessories supplied or designed for this product. Use of other accessories may not ensure compliance with FCC RF exposure guidelines and should be avoided.

## **Radio Interference**

Radio interference may occasionally cause buzzing and humming in your cordless handset, or caused by external sources such as TV, refrigerator, vacuum cleaner, fluorescent lighting, or electrical storm. Your unit is NOT DEFECTIVE. If these noises continue and are too distracting, please check around your home to see what appliances may be causing the problem. In addition, we recommend that the base not be plugged into a circuit that also powers a major appliance because of the potential for interference. Be certain that the antenna on the unit is fully extended when needed. In

the unlikely event that you consistently hear other voices or distracting transmissions on your phone, you may be receiving radio signals from another cordless telephone or other source of interference. If you cannot eliminate this type of interference, you need to change to a different channel. Finally, it should be noted that some cordless telephones operate at frequencies that may cause interference to nearby TVs and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference.

### **Cordless Telephone Privacy**

Cordless telephones are radio devices. Communications between the handset and base of your cordless telephone are accomplished by means of radio waves which are broadcast over the open airways. Because of the inherent physical properties of radio waves, your communications can be received by radio receiving devices other than your own cordless telephone unit. Consequently, any communications using your cordless telephone may not be private.

## **I.C. Notice Terminal Equipment**

**NOTICE:** This equipment meets the applicable Industry Canada Terminal Equipment Technical Specifications. This is confirmed by the registration number. The abbreviation, IC, before the registration number signifies that registration was performed based on a Declaration of Conformity indicating that Industry Canada technical specifications were met. It does not imply that Industry Canada approved the equipment

**NOTICE:** The Ringer Equivalence Number (REN) for this terminal equipment is marked on the equipment itself. The REN assigned to each terminal equipment provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed five.

### **Radio Equipment**

The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device. "Privacy of communications may not be ensured when using this telephone".



## One Year Limited Warranty

Important: Evidence of original purchase is required for warranty service. **WARRANTOR:** UNIDEN AMERICA CORPORATION ("Uniden") **ELEMENTS OF WARRANTY:** Uniden warrants, for one year, to the original retail owner, this Uniden Product to be free from defects in materials and craftsmanship with only the limitations or exclusions set out below.

**WARRANTY DURATION:** This warranty to the original user shall terminate and be of no further effect 12 months after the date of original retail sale. The warranty is invalid if the Product is (A) damaged or not maintained as reasonable or necessary, (B) modified, altered, or used as part of any conversion kits, subassemblies, or any configurations not sold by Uniden, (C) improperly installed, (D) serviced or repaired by someone other than an authorized Uniden service center for a defect or malfunction covered by this warranty, (E) used in any conjunction with equipment or parts or as part of any system not manufactured by Uniden, or (F) installed or programmed by anyone other than as detailed by the owner's manual for this product.

**STATEMENT OF REMEDY:** In the event that the product does not conform to this warranty at any time while this warranty is in effect, warrantor will either, at its option, repair or replace the defective unit and return it to you without charge for parts, service, or any other cost (except shipping and handling) incurred by warrantor or its representatives in connection with the performance of this warranty. Warrantor, at its option, may replace the unit with a new or refurbished unit. **THE LIMITED WARRANTY SET FORTH ABOVE IS THE SOLE AND ENTIRE WARRANTY PERTAINING TO THE PRODUCT AND IS IN**

**LIEU OF AND EXCLUDES ALL OTHER WARRANTIES OF ANY NATURE WHATSOEVER, WHETHER EXPRESS, IMPLIED OR ARISING BY OPERATION OF LAW, INCLUDING, BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THIS WARRANTY DOES NOT COVER OR PROVIDE FOR THE REIMBURSEMENT OR PAYMENT OF INCIDENTAL OR CONSEQUENTIAL DAMAGES.** Some states do not allow this exclusion or limitation of incidental or consequential damages so the above limitation or exclusion may not apply to you.

**LEGAL REMEDIES:** This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. This warranty is void outside the United States of America and Canada. **PROCEDURE FOR OBTAINING PERFORMANCE OF WARRANTY:** If, after following the instructions in the owner's manual you are certain that the Product is defective, pack the Product carefully (preferably in its original packaging). Disconnect the battery from the Product and separately secure the battery in its own separate packaging within the shipping carton. The Product should include all parts and accessories originally packaged with the Product. Include evidence of original purchase and a note describing the defect that has caused you to return it. The Product should be shipped freight prepaid, by traceable means, to warrantor at:

Uniden America Service  
4700 Amon Carter Blvd.  
Fort Worth, TX 76155

# Index

- A**  
AC adapter information..... 53  
Answering machine  
    Remote operation..... 51  
    Reviewing messages..... 47  
    Setup..... 42  
    Turning on/off..... 47
- B**  
Battery pack  
    Information..... 53  
    Installing..... 14  
    Preparing and charging..... 14, 15  
    Replacement and handling..... 55  
Belt clip installation..... 16
- C**  
Caller ID service..... 38  
    Caller ID on call waiting..... 39  
    Deleting..... 40  
    Making a call..... 28  
    Viewing..... 39  
Call waiting..... 32  
Channel..... 32  
Charging the battery pack..... 15  
Cleaning contacts..... 56  
Clock..... 17
- Conferencing..... 34  
Connect the base..... 10  
Connect the charger..... 15  
Controls and functions..... 6, 7
- D**  
Dial mode..... 11  
Do not disturb..... 31
- E, F, G, H**  
Earpiece volume..... 29  
Find handset..... 33  
Greeting..... 45  
Headset installation..... 16  
Hold..... 33
- I, J, K, L**  
Installing the phone..... 9  
Intercom..... 35  
Interference..... 62  
Liquid damage..... 59
- M, N, O**  
Maintenance..... 53  
Making a call..... 26  
Message alert..... 44  
Outgoing message..... 45
- P**  
Personal security code  
    (PIN code)..... 44  
Power failure..... 25, 54  
Precautions..... 60
- R**  
Receiving a call..... 26  
Record time..... 42  
Redial..... 29  
Remote operation..... 51  
Reviewing messages..... 47  
Ringer tone and volume..... 29, 30  
Ring time..... 43
- S**  
Screening calls..... 43, 49  
Setup  
    Answering machine..... 42  
    Base..... 17  
    Handset..... 19  
Speaker volume..... 29  
Speed dial memory  
    Making calls from speed dial  
        memory..... 27  
    Storing names and numbers in  
        speed dial memory..... 21

## **T, U**

Talk and standby times .....	54
Tone dialing switch-over .....	37
Transferring a call .....	36
Traveling out-of-range .....	56
Troubleshooting .....	56

## **V, W, X, Y, Z**

Voice memo .....	50
Wall mounting .....	12
Warranty .....	64

# Memo

# Remote Operation Card

C U T

## REMOTE OPERATION CARD

Uniden

### Remote access away from home Turn on the answering system remotely

1. Call your phone number from a touch-tone phone.
  2. During the outgoing message, press **[0]** and enter your PIN code. The answering system announces the number of messages stored in memory and the voice prompts. The phone stands by for you to enter a command.
  3. To quit, hang up the phone.
1. Call your phone and let it ring 10 times until it answers.
  2. Press **[0]** and enter your PIN code.
  3. Press **[0]** then **[5]** to stop the announcement.
  4. Press **[0]** then **[6]** to turn the answering system on.

C U T

## REMOTE OPERATION CARD

Uniden

### Remote access away from home Turn on the answering system remotely

1. Call your phone number from a touch-tone phone.
  2. During the outgoing message, press **[0]** and enter your PIN code. The answering system announces the number of messages stored in memory and the voice prompts. The phone stands by for you to enter a command.
  3. To quit, hang up the phone.
1. Call your phone and let it ring 10 times until it answers.
  2. Press **[0]** and enter your PIN code.
  3. Press **[0]** then **[5]** to stop the announcement.
  4. Press **[0]** then **[6]** to turn the answering system on.

C U T

## MEMORY LOCATION MEMO

Memory Location	Name	Phone Number
1		
2		
3		
4		
5		

C U T

## MEMORY LOCATION MEMO

Memory Location	Name	Phone Number
1		
2		
3		
4		
5		

# Remote Operation Card

C U T

## MEMORY LOCATION MEMO

Memory Location	Name	Phone Number
6		
7		
8		
9		
10		

C U T

## MEMORY LOCATION MEMO

Memory Location	Name	Phone Number
6		
7		
8		
9		
10		

C U T

Task	Key
Repeat a Message	0 1
Play Incoming Messages	0 2
Skip a Message	0 3
Delete a Message	0 4
Stop Operation	0 5
Answering System On	0 6
Memo Record/Stop	0 7
Greeting Message Record/Stop	0 8
Answering System Off	0 9
Voice Prompts	1 0

C U T

Task	Key
Repeat a Message	0 1
Play Incoming Messages	0 2
Skip a Message	0 3
Delete a Message	0 4
Stop Operation	0 5
Answering System On	0 6
Memo Record/Stop	0 7
Greeting Message Record/Stop	0 8
Answering System Off	0 9
Voice Prompts	1 0

## At Uniden, we'll take care of you!

Thank you for purchasing a Uniden product. If you have any questions or problems, **please do not return this product to the place of purchase.**

<b>Having Trouble?</b>	Our customer care specialists are here to help you! Visit our website at <b>www.uniden.com</b> or call our Customer Hotline at <b>1-800-297-1023</b> during regular business hours. *
<b>Need a Part?</b>	To order headsets, additional handsets, replacement batteries or other accessories, visit our website at <b>www.uniden.com</b> or call <b>1-800-554-3988</b> during regular business hours. *
<b>Help for our Special Needs Customers</b>	If you need special assistance due to a disability or have questions on the accessibility features of this product, please call <b>1-800-874-9314 (voice or TTY)</b> .

\* Central Standard Time. Detailed customer service hours are available at [www.uniden.com](http://www.uniden.com).

May be covered under one or more of the following U.S. patents:

4,797,916 5,426,690 5,434,905 5,491,745 5,493,605 5,533,010  
5,574,727 5,581,598 5,650,790 5,660,269 5,661,780 5,663,981  
5,671,248 5,696,471 5,717,312 5,732,355 5,754,407 5,758,289  
5,768,345 5,787,356 5,794,152 5,801,466 5,825,161 5,864,619  
5,893,034 5,912,968 5,915,227 5,929,598 5,930,720 5,960,358  
5,987,330 6,044,281 6,070,082 6,125,277 6,253,088 6,314,278  
6,418,209 6,618,015 6,671,315 6,714,630 6,782,098 6,788,920  
6,788,953 6,839,550 6,889,184 6,901,271 6,907,094 6,914,940  
6,953,118 7,023,176

Other patents pending.

**VISIT  
WWW.UNIDEN.COM  
TO REGISTER YOUR  
PRODUCT**

© 2007 Uniden America Corporation, Fort Worth, Texas. Contains additional foreign articles. Printed in China.



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>