


LVS-400

VIDEO MIX/LIVE SWITCHER

Owner's Manual

Thank you, and congratulations on your choice of the EDIROL VIDEO MIX/LIVE SWITCHER LVS-400.

Before using this unit, carefully read the sections entitled: "USING THE UNIT SAFELY" and "IMPORTANT NOTES" (p. 2-3; p. 4). These sections provide important information concerning the proper operation of the unit. Additionally, in order to feel assured that you have gained a good grasp of every feature provided by your new unit, Owner's Manual should be read in its entirety. The manual should be saved and kept on hand as a convenient reference.



USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠ WARNING and ⚠ CAUTION Notices

⚠ WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
⚠ CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

	The ⚠ symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The ⓧ symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The ● symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

⚠ WARNING

- Before using this unit, make sure to read the instructions below, and the Owner's Manual.
- Do not open (or modify in any way) the unit or its AC adaptor.
- Do not attempt to repair the unit, or replace parts within it (except when this manual provides specific instructions directing you to do so). Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page.
- Never use or store the unit in places that are:
 - Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are
 - Damp (e.g., baths, washrooms, on wet floors); or are
 - Humid; or are
 - Exposed to rain; or are
 - Dusty; or are
 - Subject to high levels of vibration.
- Make sure you always have the unit placed so it is level and sure to remain stable. Never place it on stands that could wobble, or on inclined surfaces.
- Be sure to use only the AC adaptor supplied with the unit. Also, make sure the line voltage at the installation matches the input voltage specified on the AC adaptor's body. Other AC adaptors may use a different polarity, or be designed for a different voltage, so their use could result in damage, malfunction, or electric shock.

⚠ WARNING

- Use only the attached power-supply cord. Also, the supplied power cord must not be used with any other device.
- Do not excessively twist or bend the power cord, nor place heavy objects on it. Doing so can damage the cord, producing severed elements and short circuits. Damaged cords are fire and shock hazards!
- Do not allow any objects (e.g., flammable material, coins, pins); or liquids of any kind (water, soft drinks, etc.) to penetrate the unit.
- In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the unit.
- Protect the unit from strong impact. (Do not drop it!)
- Do not force the unit's power-supply cord to share an outlet with an unreasonable number of other devices. Be especially careful when using extension cords—the total power used by all devices you have connected to the extension cord's outlet must never exceed the power rating (watts/amperes) for the extension cord. Excessive loads can cause the insulation on the cord to heat up and eventually melt through.
- Before using the unit in a foreign country, consult with your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page.

CAUTION

- The unit and the AC adaptor should be located so their location or position does not interfere with their proper ventilation.

- Always grasp only the plug on the AC adaptor cord when plugging into, or unplugging from, an outlet or this unit.

- At regular intervals, you should unplug the AC adaptor and clean it by using a dry cloth to wipe all dust and other accumulations away from its prongs. Also, disconnect the power plug from the power outlet whenever the unit is to remain unused for an extended period of time. Any accumulation of dust between the power plug and the power outlet can result in poor insulation and lead to fire.

- Try to prevent cords and cables from becoming entangled. Also, all cords and cables should be placed so they are out of the reach of children.

- Never climb on top of, nor place heavy objects on the unit.

- Never handle the AC adaptor or its plugs with wet hands when plugging into, or unplugging from, an outlet or this unit.

- Before moving the unit, disconnect the AC adaptor and all cords coming from external devices.

- Before cleaning the unit, turn off the power and unplug the AC adaptor from the outlet (p. 8).

- Whenever you suspect the possibility of lightning in your area, disconnect the AC adaptor from the outlet.

- Should you remove the BNC-RCA adaptors, make sure to put them in a safe place out of children's reach, so there is no chance of them being swallowed accidentally.

IMPORTANT NOTES

In addition to the items listed under “USING THE UNIT SAFELY” on page 2–3, please read and observe the following:

Power Supply

- Do not connect this unit to same electrical outlet that is being used by an electrical appliance that is controlled by an inverter (such as a refrigerator, washing machine, microwave oven, or air conditioner), or that contains a motor. Depending on the way in which the electrical appliance is used, power supply noise may cause this unit to malfunction or may produce audible noise. If it is not practical to use a separate electrical outlet, connect a power supply noise filter between this unit and the electrical outlet.
- The AC adaptor will begin to generate heat after long hours of consecutive use. This is normal, and is not a cause for concern.
- Before connecting this unit to other devices, turn off the power to all units. This will help prevent malfunctions and/or damage to speakers or other devices.

Placement

- This device may interfere with radio and television reception. Do not use this device in the vicinity of such receivers.
- Noise may be produced if wireless communications devices, such as cell phones, are operated in the vicinity of this unit. Such noise could occur when receiving or initiating a call, or while conversing. Should you experience such problems, you should relocate such wireless devices so they are at a greater distance from this unit, or switch them off.
- When moved from one location to another where the temperature and/or humidity is very different, water droplets (condensation) may form inside the unit. Damage or malfunction may result if you attempt to use the unit in this condition. Therefore, before using the unit, you must allow it to stand for several hours, until the condensation has completely evaporated.

Maintenance

- For everyday cleaning wipe the unit with a soft, dry cloth or one that has been slightly dampened with water. To remove stubborn dirt, use a cloth impregnated with a mild, non-abrasive detergent. Afterwards, be sure to wipe the unit thoroughly with a soft, dry cloth.
- Never use benzine, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

Additional Precautions

- This product is compatible with regular NTSC or PAL video signal. In case irregular signal is input, it may obstruct stable operation of this product.
- Use a reasonable amount of care when using the unit's buttons, sliders, or other controls; and when using its jacks and connectors. Rough handling can lead to malfunctions.
- When connecting / disconnecting all cables, grasp the connector itself—never pull on the cable. This way you will avoid causing shorts, or damage to the cable's internal elements.
- When you need to transport the unit, package it in the box (including padding) that it came in, if possible. Otherwise, you will need to use equivalent packaging materials.

Copyright



- Unauthorized recording, distribution, sale, lending, public performance, broadcasting, or the like, in whole or in part, of a work (musical composition, video, broadcast, public performance, or the like) whose copyright is held by a third party is prohibited by law.
- Do not use this unit for purposes that could infringe on a copyright held by a third party. We assume no responsibility whatsoever with regard to any infringements of third-party copyrights arising through your use of this unit.
- Even when intended for the user's private enjoyment (use), any duplication of third-party copyrighted works that circumvents technology to protect such works without the permission of the copyright holder is an infringement of copyright, and is prohibited by law.
- Duplication of works not protected by such technology are allowed for private individual use.

Contents

USING THE UNIT SAFELY	2
IMPORTANT NOTES	4
Before You Begin	6
Check the Included Items.....	6
Connecting Peripheral Devices	7
Turning the Power On	8
Turning the Power Off	8
Switching Between NTSC and PAL.....	8
Names of Things and What They Do.....	9
Front Panel.....	9
Rear Panel.....	9
Basic Operation	10
Switching Images with the Switcher	10
Controlling the Output.....	11
Using the Monitor Output to Check the Images.....	11
Advanced Operation	12
Inserting Images with the Video Fader	12
About Insert Effects	12
Key Composite Effects.....	13
Control the LVS-400 from an External Device.....	14
Correspondence Between Commands and MIDI Messages.....	14
Using V-LINK to Control the LVS-400.....	15
Using V-LINK.....	15
MIDI Implementation Chart	16
Troubleshooting.....	17
Specifications.....	18

Before You Begin

Check the Included Items



About Ground Terminal

In some cases, depending on the environment in which the unit is installed, the surface of the panel may sometimes feel rough and grainy. This is due to an infinitesimal electrical charge, which is absolutely harmless. However, if you are concerned about this, connect ground terminal (see figure) with an external ground. When the unit is grounded, a slight noise may result, depending on the particulars of your installation. If you are unsure of the connection method, contact nearest Edirol Service Center, or authorized Edirol/Roland distributor, as listed on the "Information" page.

Unsuitable places for connection

- Water pipes (may result in shock or electrocution)
- Gas pipes (may result in fire or explosion)
- Telephone-line ground or lightning rod (may be dangerous in the event of lightning)

Connecting Peripheral Devices


1

You can connect up to four video playback devices (sources). Here's how to connect sources such as a video camcorder, VCR, DVD player, and play them back to create an impressive video performance. To prevent malfunction and/or damage to other devices, always turn down the volume, and turn off the power on all devices before making any connections.

2

Connect the AC adaptor included with the LVS-400 to the DC IN jack, then plug the adaptor into a power outlet.

Connect the LVS-400 to peripheral equipment as shown in the figure.



* To prevent the inadvertent disruption of power to your unit (should the plug be pulled out accidentally), and to avoid applying undue stress to the AC adaptor jack, anchor the power cord using the cord hook, as shown in the illustration.

- The LVS-400 does not have audio inputs so will not mix audio. Audio outputs can be connected directly to speakers or via an audio mixer if mixing of audio from multiple devices is necessary.
- No video cables come with this product. Please use appropriate video cables for connection with source devices or TV monitor/Projector.
- It is recommended to use composite cable rather than S-video cable where you need to connect devices long distances (unless using S-video amplifiers). If devices are installed closer to the LVS-400, it is recommended to use S-video cables so that you can obtain better image quality.
- If both video (composite) and S-video signals are input simultaneously to the same channel, the S-video signal will take priority.
- The same image is output simultaneously from the OUTPUT 1, OUTPUT 2, and S-VIDEO outputs.
- The LVS-400 inputs and outputs composite video via BNC connectors. Using the BNC connectors securely locks the connection. If connecting with RCA phono connectors, use the BNC-RCA phono adaptor included with the LVS-400 or another commercially available BNC-RCA adaptor to connect to the LVS-400's BNC connector.

Before You Begin

Turning the Power On

1

Check the power cable.

Make sure that the cable from the power source is connected to the power jack on the rear panel of the monitor.

2

Press the POWER button.

Press the POWER button on the front panel of the monitor. The monitor will take about 400 to 450 milliseconds to initialize.

POWER



...ed before ... will operate

Turn

All of the ... panel LEDs will go dark.

PA

... or PAL ... signals.

...ect "OUTPUT" button and "OUTPUT ON/OFF" button, and press the


... press the ... button to start up in PAL mode.

...ce again ... down monitor select "OUTPUT" button and "OUTPUT ON/OFF"

... indication ... whether it is starting up in NTSC mode or PAL mode will appear for several ...reen.

Names of Things and What They Do

Front Panel



Rear Panel

Basic Operation

Switching Images with the Switcher

You can easily get a transition effect when switching images, just by using the MAIN [1]–[4] buttons.

1. Play back the images with the video equipment.

Input the images from the video device connected to the LVS-400 (such as a video camera or DVD player).

2. Check the output.


Turn on the video monitor or projector connected to the LVS-400's output jacks/connector and check to see whether or not the images are being output correctly.

3. Switch the input channel.

Switch the LVS-400's input channel. Turn the TRANSITION TIME control knob so that it points straight up (2 seconds), then press one of the buttons from [1] through [4] to switch the input.

Check the image on the video monitor or from the projector to confirm that the images are switched correctly.

Changing the TRANSITION TIME control knob setting allows you to adjust the amount of time required to completely switch from one image to another.



4. Switch the transition effect.

Press the TRANSITION TYPE select buttons and switch the input.

The following effects are available when switching images.

- MIX:** The two images are mixed (overlapped) as they are switched.



- WIPE 1:** The images are switched by wiping left to right.



- WIPE 2:** The images are switched with a rectangular wipe starting from the center of the image.




Advanced Operation

Inserting Images with the Video Fader

You can use the video fader to insert video images manually.

When using this feature, you can use the "PinP" (Picture in Picture) or key composite effects.



- 1** Pull the video fader all the way toward **MAIN**.
- 2** Select the input to insert (1–4).
- 3** Move the video fader to the **INSERT** side.
The video images are inserted as you move the fader.
- 4** Return the fader to the **MAIN** side to return to the original image.

NOTE

If you do not start out with the video fader completely tilted to the MAIN side, then the Insert function will not work, even when you then move the video fader. First bring the fader all the way to MAIN to start the function.

MEMO


The insert method varies with the insert effect.

NOTE

Switch the insert input before inserting. Although it is possible to switch the insert input while the insert is in progress, note that this disrupts synchronization.


About Insert Effects

MODE: OFF



When this is set to "OFF," composite effects are not applied. The video is inserted in the entire screen according to the transition selected with the TRANSITION TYPE selection buttons (p. 10).

MODE: PinP



When PinP is selected, the Picture in Picture function goes into effect. A small picture is mixed (faded in), regardless of the TRANSITION TYPE button setting.

The position of the smaller picture changes according to the MODE setting (upper right, upper left, lower right, or lower left).

MAIN Image




INSERT Image



OUTPUT Image



Key Composite Effects



The key composite functions are enabled when WHT/BLK/CHR is selected. The video is inserted according to the transition selected with the TRANSITION TYPE selection buttons.


Adjust the composite effects with the KEY LEVEL adjustment knob.

WHT: Light portions of the inserted image are replaced with the main image.
(White Luminance Key)

BLK: Dark portions of the inserted image are replaced with the main image.
(Black Luminance Key)

CHR: Blue portions of the inserted image are replaced with the main image.
(Blue Chroma Key)

Key Composite Example: MODE: CHR



- 1** Tilt the video fader to the MAIN side.
- 2** Input the video to be used as the background in the final composite output to MAIN.
- 3** Record the video you want to insert against a blue background, then input to INSERT.
- 4** Return the fader to the INSERT side.
The composite output video appears as shown in the figure above.
You can adjust with the KEY LEVEL knob.
- 5** Return the fader to the MAIN side to return to the original image.



If you reselect the MAIN input while the Insert function is still in use, the insert is automatically cleared, and the video image switches via the transition effect from the current MAIN image to the newly selected image. If you want to use the Insert function again, first bring the fader all the way to the MAIN side, then move it to INSERT again.

Control the LVS-400 from an External Device

You can connect the LVS-400 with a MIDI device, and control the LVS-400 remotely.

What is MIDI?


MIDI stands for “Musical Instrument Digital Interface” a worldwide standard that allows performance data and other information to be exchanged among musical instruments. MIDI compatible devices can be connected together easily using MIDI cables. Once connected, performance data can readily be communicated between the two devices; or one can make settings for, as well as control the operation of the other device.

Correspondence Between Commands and MIDI Messages

Normally, after power up (with V-LINK off), the LVS-400 outputs the corresponding MIDI messages from its MIDI OUT when its buttons and knobs are operated.

Conversely, when any of the supported MIDI messages arrive at its MIDI IN, the LVS-400 performs the same functions that it would if its buttons or knobs were operated.

* MIDI message values are in hexadecimal notation.



Using V-LINK to Control the LVS-400

The LVS-400 can be placed under the control of V-LINK capable instruments and operated in sync with musical performances (when V-LINK is on).

What is V-LINK?

V-LINK is a function that allows images to be synchronized to music. V-LINK makes it easy to manipulate images in a variety of ways, while linking them to the expressive elements of a performance.

Using V-LINK

For details on how to turn V-LINK on/off, refer to the owner's manual of the V-LINK compatible device that you intend to connect to the LVS-400.

Use 10H as the LVS-400's Device ID in V-LINK messages.

The factory setting of V-LINK (receipt of V-LINK ON message only) is as follows.

Rx Channel	1
Tx Channel	1
Input Select	A ch: 1
	B ch: 2
Transition Time (CC#5)	0.0 sec
Transition Select	1
Output Fade	Off
Video Fader (CC#11)	Main

MIDI Implementation Chart

Function...	Transmitted	Recognized	Remarks
Basic Channel Default Changed	1-16 1-16	1-16 1-16	
Mode Default Messages Altered	Mode 3 X *****	Mode 3 X	
Note Number : True Voice	X X	O 36, 38, 40, 41, 43, 45, 47, 48	Operational only when Note Mode in ON
Velocity Note On Note Off	X X	O X	
After Touch Key's Channel's	X O	X O	Control Various Values
Pitch Bend	O	O	Control Various Values
Control Change	0, 32 1-5 7-31 64-95 O O O O	O O O O	Bank Select Control Various Values Control Various Values Control Various Values
Program Change : True Number	O 0-3, 0-7	O 0-3, 0-7	Input Select : 1-4 Effects Mode : 1-8
System Exclusive	X	O	Control Various Values, V-LINK
System Common : Song Position : Song Select : Tune Request	X X X	X X X	
System Real Time : Clock : Commands	X X	O O	Start, Continue
Aux Messages : All Sound Off : Reset All Controllers : Local On/Off : All Notes Off : Active Sensing : System Reset	X X X X O X	X X X X O X	
Notes			

Mode 1 : OMNI ON, POLY
Mode 3 : OMNI OFF, POLY

Mode 2 : OMNI ON, MONO
Mode 4 : OMNI OFF, MONO

O : Yes
X : No

Troubleshooting

If you think there may be a problem with the device, first check the following points. If after checking these points the problem persists, consult your dealer or local Roland Service.

Image not switching when fader is moved

If the same input is selected for both MAIN and INSERT while the EFFECTS MODE is set to OFF, moving the video fader to switch the images will not change the image that is output.

In addition, switching the main input while the insert effects are in use automatically cancels the insert effects, so to start using the insert effects again, first tilt the video fader completely to the MAIN side. Begin the insertion with the fader tilted all the way to MAIN.

Image not switching when main input is switched

Are you looking at a display connected to MONITOR OUT? Select OUTPUT in the Monitor Select buttons. Alternatively, you can connect the display to OUTPUT (the video output connector).

Images not switching as intended when the input is switched

You cannot use the same input simultaneously with both the composite and S-VIDEO connectors. The S-VIDEO takes priority in this case.

No picture, even though source device is producing a signal

Is the Output Control button switched off (flashing)? If it is switched off, the screen will be black. Press the flashing Output Control button to switch it to ON (lit), and the images are then output.

Transition effects not working

When the TIME setting knob is set near "0," no transition effect is attained when the main image is switched. You can obtain the effect by using a longer time setting.

In addition, if the unit is not operating as you expect, first connect a display to the output of the device connected to the LVS-400's input connector and confirm that the images are being output correctly.

Specifications

LVS-400: VIDEO MIX / LIVE SWITCHER

Video Format

NTSC or PAL (ITU601)

Video Sampling Rate

13.5 MHz, 4:2:2 (Y: B-Y: R-Y), 8 bits

Frame Synchronizer

2

Video Input

S-Video: 4-pin mini DIN type x 4

Video (Composite): BNC type x 4

* If S-Video is simultaneously, S-Video takes priority

Video Output

S-Video: 4-pin mini DIN type x 1

Video (Composite): BNC type x 2

Monitor Output

Video (Composite): BNC type x 1

Input/Output Level and Impedance

S-Video Luminance signal: 1 Vp-p, 75 ohms

Chrominance signal: 0.286 mVp-p, 75 ohms (NTSC),
0.3 mVp-p, 75 ohms (PAL)

Video (Composite): 1 Vp-p, 75 ohms

Control Connectors

MIDI IN: 5-pin DIN type

MIDI OUT: 5-pin DIN type

Transition Effects

Mix (Dissolve)

Wipe 1

Wipe 2

Composite Effects

Picture-in-Picture (4 types)

Luminance Key (2 types)

Chroma Key

Power Supply

DC 9 V (AC Adaptor)

Current Draw

1500 mA

Dimensions

365 (W) x 259 (D) x 87 (H) mm

14-3/8 (W) x 10-1/4 (D) x 3-7/16 (H) inches

* Maximum height (top of T-bar): 118 mm / 4-11/16 inches

Weight (excluding the AC adaptor)

2.95 kg

6 lbs 9 oz

Accessories

Owner's Manual

AC Adaptor (PSB-1U)

BNC-RCA Adapter x 4

* In the interest of product improvement, the specifications and/or appearance of this unit are subject to change without prior notice.

For the U.K.

IMPORTANT: THE WIRES IN THIS MAINS LEAD ARE COLOURED IN ACCORDANCE WITH THE FOLLOWING CODE.

BLUE: NEUTRAL
BROWN: LIVE

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N or coloured BLACK.
The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L or coloured RED.
Under no circumstances must either of the above wires be connected to the earth terminal of a three pin plug.

For EU Countries



This product complies with the requirements of European Directive 89/336/EEC.

For the USA

FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Unauthorized changes or modification to this system can void the users authority to operate this equipment.
This equipment requires shielded interface cables in order to meet FCC class B Limit.

For Canada

NOTICE

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

AVIS

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

Information

When you need repair service, call your nearest EDIROL/Roland Service Center or authorized EDIROL/Roland distributor in your country as shown below.

R I N

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>