

Model 25952 Series 5.8 GHz Cordless Handset Speakerphone Answering System User's Guide



Your new GE telephone system is **EXPANDABLE** up to a total of 4 handsets (by purchase of optional Model 25902 handset with charge cradle)

Equipment Approval Information

Your telephone equipment is approved for connection to the Public Switched Telephone Network and is in compliance with parts 15 and 68, FCC Rules and Regulations and the Technical Requirements for Telephone Terminal Equipment published by ACTA.

1 Notification to the Local Telephone Company

On the bottom of this equipment is a label indicating, among other information, the US number and Ringer Equivalence Number (REN) for the equipment. You must, upon request, provide this information to your telephone company.

The REN is useful in determining the number of devices you may connect to your telephone line and still have all of these devices ring when your telephone number is called. In most (but not all) areas, the sum of the RENs of all devices connected to one line should not exceed 5. To be certain of the number of devices you may connect to your line as determined by the REN, you should contact your local telephone company.

A plug and jack used to connect this equipment to the premises wiring and telephone network must comply with the applicable FCC Part 68 rules and requirements adopted by the ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. See installation instructions for details.

- Notes**
- This equipment may not be used on coin service provided by the telephone company.
 - Party lines are subject to state tariffs, and therefore, you may not be able to use your own telephone equipment if you are on a party line. Check with your local telephone company.
 - Notice must be given to the telephone company upon permanent disconnection of your telephone from your line.
 - If your home has specially wired alarm equipment connected to the telephone line, ensure the installation of this product does not disable your alarm equipment. If you have questions about what will disable alarm equipment, consult your telephone company or a qualified installer.

Visit the GE website at: www.GE.com/phones



Thomson Inc.
101 West 103rd Street
Indianapolis, IN 46290-1102
© 2007 Thomson Inc.
Trademarks © Registered
Marca(s) Registrada(s)
Model 25952
00017254 (Rev. 1 Dom E/S)
07-39
Printed in China

US Number is located on the cabinet bottom.
REN Number is located on the cabinet bottom.

2 Rights of the Telephone Company

Should your equipment cause trouble on your line which may harm the telephone network, the telephone company shall, where practicable, notify you that temporary discontinuance of service may be required. Where prior notice is not practicable and the circumstances warrant such action, the telephone company may temporarily discontinue service immediately. In case of such temporary discontinuance, the telephone company must: (1) promptly notify you of such temporary discontinuance; (2) afford you the opportunity to correct the situation; and (3) inform you of your right to bring a complaint to the Commission pursuant to procedures set forth in Subpart E of Part 68, FCC Rules and Regulations. The telephone company may make changes in its communications facilities, equipment, operations or procedures where such action is required in the operation of its business and not inconsistent with FCC Rules and Regulations. If these changes are expected to affect the use or performance of your telephone equipment, the telephone company must give you adequate notice, in writing, to allow you to maintain uninterrupted service.

Interference Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

Privacy of Communications may not be ensured when using this product. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna (that is, the antenna for radio or television that is "receiving" the interference).
- Reorient or relocate and increase the separation between the telecommunications equipment and receiving antenna.
- Connect the telecommunications equipment into an outlet on a circuit different from that to which the receiving antenna is connected.

If these measures do not eliminate the interference, please consult your dealer or an experienced radio/television technician for additional suggestions. Also, the Federal Communications Commission has prepared a helpful booklet, "How To Identify and Resolve Radio/TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. Please specify stock number 004-000-00345-4 when ordering copies.

Notice: The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Hearing Aid Compatibility (HAC)

This telephone system meets FCC standards for Hearing Aid Compatibility.

Licensing

Licensed under US Patent 6,427,009.

FCC RF Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

For body worn operation, this phone has been tested and meets the FCC RF exposure guidelines when used with the belt clip supplied with this product. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

<p>WARNING: TO PREVENT FIRE OR ELECTRICAL SHOCK HAZARD, DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.</p>	<p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER OR SERVICEABLE PARTS INSIDE. REFER TO THE QUALIFIED SERVICE PERSONNEL.</p>	<p>THE EXCLAMATION POINT WITHIN THE TRIANGLE IS AN ALERTING YOU OF INSTRUCTIONS ACCOMPANYING THE PRODUCT.</p>
--	--	--

Introduction


CAUTION: When using telephone equipment, there are basic safety instructions that should always be followed. Refer to the IMPORTANT SAFETY INSTRUCTIONS provided with this product and save them for future reference.

IMPORTANT: Because cordless phones operate on electricity, you should have at least one phone in your home that isn't cordless, in case the power in your home goes out.

Before You Begin

Parts Checklist (for 25952xx1 model)

Make sure your package includes the items shown here.



For Model 25952xx2 there will be **ONE** additional handset, charge cradle, belt clip, battery pack and cover than shown above.

For Model 25952xx3 there will be **TWO** additional handsets, charge cradles, belt clips, battery packs and covers than shown above.

For Model 25952xx4 there will be **THREE** additional handsets, charge cradles, belt clips, battery packs and covers than shown above.

Telephone Jack Requirements

To use this phone, you need an RJ11C type modular telephone jack, which might look like the one pictured here, installed in your home. If you don't have a modular jack, call your local phone company to find out how to get one installed.

Installation

Digital Security System

Your cordless phone uses a digital security system to protect against false ringing, unauthorized access, and charges to your phone line.


INSTALLATION NOTE: Some cordless telephones operate at frequencies that may cause or receive interference with nearby TVs, microwave ovens, and VCRs. To minimize or prevent such interference, the base of the cordless telephone should not be placed near or on top of a TV, microwave ovens, or VCR. If such interference continues, move the cordless telephone farther away from these appliances.

Certain other communications devices may also use the 5.8 GHz / 900 MHz frequency for communication, and, if not properly set, these devices may interfere with each other and/or your new telephone. If you are concerned with interference, please refer to the owner's manual for these devices on how to properly set channels to avoid interference. Typical devices that may use the 5.8 GHz frequency for communication include wireless audio/video senders, wireless computer networks, multi-handset cordless telephone systems, and some long-range cordless telephone systems.


Important Installation Guidelines

- Avoid sources of noise and heat, such as motors, fluorescent lighting, microwave ovens, heating appliances and direct sunlight.
- Avoid areas of excessive dust, moisture and low temperature.
- Avoid other cordless telephones or personal computers.
- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch non-insulated telephone wires or terminals, unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

Handset Layout



Base Layout



Installing the Phone


Installing the Handset Battery

NOTE: You must connect the handset battery before use.

CAUTION: To reduce the risk of fire or personal injury, use only the Thomson Inc. approved Nickel-Cadmium (Ni-Cd) battery model 5-2729 or Nickel-Metal Hydride (Ni-MH) battery model 5-2522, which is compatible with this unit.

1. Locate battery and battery door which are packaged together inside a plastic bag and are separate from the handset.
2. Locate the battery compartment on the back of the handset.
3. Plug the battery pack cord into the jack inside the compartment. **PLEASE REGISTER** shows in the display.

NOTE: To ensure proper battery installation, the connector is keyed and can be inserted only one way.



4. Insert the battery pack.
5. Close the battery compartment by pushing the door up until it snaps into place.

Base Station

1. Choose an area near an electrical outlet and a telephone wall jack (RJ11C), and place your cordless telephone on a level surface, such as a desktop or tabletop, or you may mount it on the wall.
2. Plug one end of the telephone line cord into the TEL LINE jack at the back of the base and the other end into a modular jack.
3. Plug the AC power converter into the electrical outlet and the DC connector into the jack at the back of the base.



4. Place the handset in the base cradle. The charge/in use indicator turns on, verifying the battery is charging. The unit will take 20 seconds to register and verify its security code. **READY** shows in the display.

NOTE: In case of a power failure, the handsets may display UNAVAILABLE when the TALK/CALL BACK button is pressed. You must then place all handsets on the main base cradle for 20 seconds to re-register.

5. Allow the phone to charge for 16 hours prior to first use. If you don't properly charge the phone, battery performance is compromised.

CAUTION: To reduce risk of personal injury, fire, or damage use only the 5-2732 power adaptor listed in the user's guide. This power adaptor is intended to be correctly orientated in a vertical or floor mount position.

Wall Mounting

1. Turn the base over.
2. Attach the wall mounting pedestal by first inserting the tabs on the open edge of the pedestal into the slots on the lower portion of the bottom of the base. Then push down and snap the pedestal into place.
3. Slip the mounting holes (on the back of the base) over the wall plate posts, and slide the unit down into place. (Wall plate not included.)

NOTE: If desired, gather the extra telephone line and power adaptor cord and store inside the wall mounting pedestal.

Answering System Setup

This section shows you how to set up your answering system to receive incoming calls. Before you begin the set up process, you must turn on the answering system.

- Press the ans on/off button to turn the answering system **ON** and **OFF**. The MESSAGES indicator lights when the answering system is **ON**. The indicator blinks when you have new messages.

NOTE: The answering system displays "- -" when it is OFF.

Setting the Voice Prompt Language

The default voice prompt language is *English*. To change the answering system's voice prompt language, press and hold the skip button for two seconds. The unit announces **"SELECCIONADO ESPANOL"** (Spanish selected).

NOTE: To change to English, press and hold the skip button again for 2 seconds. The unit announces "ENGLISH IS SELECTED".

NOTE: In remote access mode, the system follows the selected language. The voice prompt language cannot be switched remotely.

Voice Time/Day Stamp

1. Make sure the answering system is **ON**.
2. Press and hold the day/check button on the base to set the day of the week.
3. Press and hold the hour button on the base to set the hour (a.m. or p.m.). Example: **12AM, 1AM, or 12PM, 1PM.**

4. Press and hold the min button on the base to set the minute. The time advances in 5-minute intervals, or tap and release to advance in 1 minute intervals.

Speaker Volume

Use the speaker volume (- / +) buttons to adjust speaker volume on the base to a comfortable level. L1 is the minimum speaker volume and L8 is the maximum.

Recording the Outgoing Announcement

For best results when recording, you should be about nine inches from the microphone, and eliminate as much background noise as possible.

1. Make sure the answering system is **ON**.
2. Press and hold the announce button on the base.
3. Begin speaking after you hear the beep.
4. Release the button when you finish your announcement.

NOTE: If you choose not to record an outgoing announcement, a default announcement plays instead. To return to the default announcement after you have recorded your own outgoing announcement, press the announce button and release it when you hear the beep.

Sample Outgoing Announcement

"HI, THIS IS (USE YOUR NAME HERE), I CAN'T ANSWER THE PHONE RIGHT NOW, SO PLEASE LEAVE YOUR NAME, NUMBER AND A BRIEF MESSAGE AFTER THE TONE, AND I'LL GET BACK TO YOU. THANKS."

Reviewing the Announcement

Press and release the announce button to review your outgoing announcement.

Rings to Answer

While talking on the phone, it may be necessary for you to manually change the channel to improve reception and reduce noise or static on the line. Press and release the chan/delete button to move to the next clear channel.

1. Press the mute/menu button until **▶ 1 TONE 2 PULSE** shows in the display. **1 TONE** is the default.
2. Use the CALLER ID-VOLUME (▲ or ▼) button or the touch-tone pad on the handset to scroll to **1 TONE** or **2 PULSE**.
3. Press mute/menu to save.

NOTE: If you select Toll Saver (TS) the unit answers after the 3rd ring if there ARE new messages, OR the unit answers after the 5th ring if there ARE NO new messages.

Handset Setup

There are nine programmable menus available: Language, Handset Name, Area Code, Ringer ON/OFF, Ringer Tone, VIP Ring Tone, Tone/Pulse, Transfer and Default Setting.

During programming, you may press the mute/menu button at any time to go to the next option. Pressing mute/menu button takes you through the menu choices. When changes have been made to selected menu item, pressing the mute/menu button saves the changes and Confirmation Tone sounds. To exit the menu and keep the previous setting and return to the standby mode, press the *EXIT/tone button.

Display Language

1. Press the mute/menu button until **▶ 1ENG 2FRA 3ESP** shows in the display. **1ENG** is the default. (**ENG** stands for English, **FRA** stands for French, **ESP** stands for Spanish.)
2. Use the CALLER ID-VOLUME (▲ or ▼) button or the touch-tone pad on the handset to enter your selection.
3. Press mute/menu again to save.

Handset Name

1. Press the mute/menu button until **ENTER NAME** shows in the display.
2. Use the touch-tone pad to enter the name (up to 15 characters). More than one letter is stored in each of the number keys. For example, to enter the name Bill Smith, press the 2 key twice for the letter B. Press the 4 key 3 times for the letter I. Press the 5 key 3 times for the letter L. Wait for one second. Press the 5 key 3 times for the second letter L. Press the 4 key 1 time to insert a space between the L and the S. Press the 7 key 4 times for the letter S; press the 6 key once for the letter M; press the 4 key 3 times for the letter I; press the 8 key for the letter T; press the 4 key twice for the letter H.

NOTE: If you make a mistake, use the chan/delete button to backspace and delete one character at a time.

3. Press mute/menu again to save.

NOTE: If no name is entered, READY shows in the display.

Local Area Code

This program setup allow you to setup how the incoming caller ID show on the display.

1. Press the mute/menu button until **AREA CODE - - -** shows in the display. **- - -** is the default.
2. Use the touch-tone pad on the handset to enter your three digit area code.
3. Press mute/menu again to save.

NOTE: If you make a mistake, press the chan/delete button to erase a wrong number.

Ringer ON/OFF

1. Press the mute/menu button until **RINGER ▶ 1 ON** shows in the display. **1 ON** is the default.
2. Use the CALLER ID-VOLUME (▲ or ▼) button or the touch-tone pad on the handset to scroll to **1 ON** or **2 OFF**.
3. Press mute/menu to save.

NOTE: If you turn the ringer off, RINGER OFF shows on the display.

Ringer Tone

You can choose from 10 ringtones.

1. Press the mute/menu button until **RINGER TONE ▶ 01** shows in the display. **01** is the default.
2. Use the CALLER ID-VOLUME (▲ or ▼) button or the touch-tone pad on the handset to select from **01** to **10**.
3. Press mute/menu to save.

VIP Ring Tone

This feature allows you to assign a specific ring tone to a number stored in Memory. It is recommended that you store a Caller ID record into Memory for this purpose.

1. Press the mute/menu button until **VIP RING TONE** shows in the display.
2. Press the desired memory location (0 through 9). If there is a number stored in the selected memory location, **VIP RT ▶ DEFAULT** shows in the display.
3. Press CALLER ID-VOLUME (▲ or ▼) on the handset to select from **01** to **10** or **DEFAULT** to use ring tone set in the Ringer Tone Menu or **SILENT** to silence ringer.
4. Press mute/menu to save.

NOTE: Delete the memory record will also delete the VIP ring tone.

Tone/Pulse

1. Press the mute/menu button until **▶ 1 TONE 2 PULSE** shows in the display. **1 TONE** is the default.
2. Use the CALLER ID-VOLUME (▲ or ▼) button or the touch-tone pad on the handset to scroll to **1 TONE** or **2 PULSE**.
3. Press mute/menu to save.

Transfer ON/OFF

In order to use the Call Transfer feature (applicable ONLY with additional handsets), you must have the Transfer ON/OFF set to ON through the menu of the transferring handset.

1. Press the mute/menu button until **TRANSFER ▶ 1OFF** shows in the display.
2. Use the CALLER ID-VOLUME (▲ or ▼) button or the touch tone pad on the handset and select **2ON**.
3. Press mute/menu again to save.

Default Setting

You may return handset settings to the factory default setup using this menu.

1. Press the mute/menu button until **DEFAULT ▶ NO** shows in the display. **NO** is the default.
2. Use the CALLER ID-VOLUME (▲ or ▼) button on the handset to scroll to **YES** or **NO**.
3. Press mute/menu to save.

Cordless Phone Basics

Charge/In Use Indicator

The phone is **ON** when the charge/in use indicator on the base is lit. The handset visual ringer and base indicator flash when you receive a call.

Answering a Call

1. When the phone rings, pick up the handset and press the TALK/CALL BACK or SPEAKER button.
2. When finished, press the TALK/CALL BACK or SPEAKER button again or place the handset on the base cradle to hang up.

Making a Call

1. Pick up the handset and press the TALK/CALL BACK or SPEAKER button. Wait for the dial tone. The call timer starts counting minutes and seconds in the display.
2. Dial a telephone number.
3. When finished, press the TALK/CALL BACK or SPEAKER button again or place the handset on the base cradle to hang up.

NOTE: In case of power failure, the handset may display UNAVAILABLE when the TALK/CALL BACK or SPEAKER button is pressed. You must then place the handset on the main base for 20 seconds to reset the unit.

Pre-dialing

1. Make sure the phone is **OFF** (not in TALK mode).
2. Dial a telephone number (the number you dial shows in the display).
3. Press the TALK/CALL BACK or SPEAKER button on that handset. The number automatically dials and the call timer starts counting the minutes and seconds in the display.
4. When finished, press the TALK/CALL BACK or SPEAKER button again to hang up.

NOTE: You may enter up to 32 pre-dial digits.

Redial

While the phone is **ON** (in TALK or SPEAKERPHONE mode), press the redial button to redial the last number you dialed (up to 32 digits).

- OR -
While the phone is **OFF** (in standby mode), press the redial button and then the TALK/CALL BACK or SPEAKER button to redial the last number.

Flash

Use the flash/answerer/call waiting button to activate custom calling services such as call waiting, which are available through your local phone company.

TIP: Do not use the TALK/CALL BACK button to activate custom calling services such as call waiting or you'll hang up the phone.

Channel Button

While talking on the phone, it may be necessary for you to manually change the channel to improve reception and reduce noise or static on the line. Press and release the chan/delete button to move to the next clear channel.

Exit

Press the *EXIT/tone button to cancel any command you initiated.

Page

This feature assists in locating a misplaced handset.

Press the page button on the base. The handset beeps continuously for about 2 minutes until you press the TALK/CALL BACK or SPEAKER button on the handset or the page button on the base.

NOTE: You may still page the handset when the ringer is off.

Storing CID Records in Internal Memory

You may also store CID information in the phone's internal memory.

NOTE: It is important that you format CID records correctly BEFORE storing in internal memory as you cannot reformat CID records stored in memory.

- Make sure the phone is **OFF** (not in talk mode).
- Use the CALLER ID-VOLUME (▲ or ▼) button to scroll to the desired CID record.
- Press the mem button.

- Use the touch-tone pad to enter a memory location (0-9) to store the number in that memory location. You will hear a confirmation tone.

NOTE: If the memory location is occupied, *REPLACE MEMO?* is displayed, and you must confirm replacement by pressing the mem button.

NOTE: Press the *EXIT/tone button once to keep the previous setting (making no changes) and return to Standby mode.

NOTE: If the selected CID record contains any information that is non-numeric, the unit will not allow this record to transfer to the internal user memory. The handset will display *UNABLE TO STORE*.

To Replace a Stored CID Record

- Repeat steps 1 through 3 in Storing CID Records in Internal Memory. After you enter the memory location, ***REPLACE MEMO?*** shows in the display.
- Press the mem button again, and the new CID record replaces the old memory in that location. You will hear a confirmation tone.

Deleting a CID Record

- Make sure the phone is **OFF** (not in TALK mode).
- Use the CALLER ID-VOLUME (▲ or ▼) button to display the CID record you want to delete.
- Press chan/delete. The display shows ***DELETE ALL ID?***
- Press chan/delete again to erase the record and ***DELETED*** shows in the display. You will hear a confirmation tone.

NOTE: Press the *EXIT/tone button to return to the standby mode.

Deleting All CID Records

- Make sure the phone is **OFF** (not in TALK mode).
- Use the CALLER ID-VOLUME (▲ or ▼) button to display any Caller ID record.
- Press and hold the chan/delete button until ***DELETE ALL?*** shows in the display.
- Press chan/delete again to erase all records. You will hear a confirmation tone. The display shows ***NO CALLS***.

NOTE: Press the *EXIT/tone key to return to the standby mode.

Memory

Each handset can store up to ten 24-digit numbers with up to 15-character names in memory for quick dialing. This memory feature is in addition to the CID memory log, which stores up to 40 CID records in each handset.

Storing a Name and Number in Memory

- Make sure the phone is **OFF** (not in TALK mode).
- Press the mem button.
- Press the desired memory location (0 through 9) or use CALLER ID-VOLUME (▲ or ▼) to scroll to the desired memory location.

NOTE: If the memory location is occupied, the memory location number and stored name and telephone number shows in the display. If the memory location is empty, *EMPTY* shows in the display.

- Press the mem button again. The display shows ***ENTER NAME***.

NOTE: If you don't want to enter the name, skip step 5.

- Use the touch-tone pad on the handset to enter the name (up to 15 characters) and press the memory button to save. More than one letter is stored in each of the number keys. For example, to enter the name Bill Smith, press the 2 key twice for the letter B, press the 4 key 3 times for the letter L, press the 5 key 3 times for the second letter L, press the 1 key to insert a space between the L and the S, press the 7 key 4 times for the letter S, press the 6 key once for the letter M, press the 4 key 3 times for the letter I, press the 8 key for the letter T, press the 4 key twice for the letter H.

NOTE: If you make a mistake press the chan/delete button to backspace and erase the wrong character(s) or number(s).

- Press the mem button to save the name. The display shows ***ENTER TEL NUMBR***.

- Use the touch-tone pad to enter the telephone number you want to store (up to 24 digits).

NOTE: The system treats PAUSES as delays or spaces in the dialing sequence.

- Press mem again to store the number. You will hear a confirmation tone.

Storing the Last Number Dialed

- Repeat steps 1 through 6 in Storing a Name and Number in Memory.

- Press the redial button.
- Press the mem button to store the number. You will hear a confirmation tone.

To replace an old number with a new redial number:

- Repeat steps 1 through 6 in Storing a Name and Number in Memory.
- Press the redial button.

- Press the mem button, and ***REPLACE MEMO?*** shows in the display.

- Press the mem button again to replace the old number with the new number. You will hear a confirmation tone.

Inserting a Pause in the Dialing Sequence of a Stored Number

If a pause is needed to wait for a dial or access tone, press the #PAUSE/ringer button to insert a delay in dialing sequence of a stored number (for example, after you dial 9 for an outside line, or to wait for a computer access tone). Pause shows in the display as a P, and each pause counts as one digit in the dialing sequence.

Changing a Stored Number

- Repeat steps 1 through 7 in Storing a Name and Number in Memory.
- Press the mem button, and ***REPLACE MEMO?*** shows in the display.
- Press the mem button to store the number. You will hear a confirmation tone.

Reviewing and Deleting Stored Numbers

- To review stored numbers, press the mem button, and use the CALLER ID-VOLUME (▲ or ▼) button to scroll to the memory location, or press the corresponding number key for a desired memory location (0-9).

- When the number that you want to delete shows in the display, press the chan/delete button. The display shows ***DELETE?***

- Press chan/delete again to delete the data. The display shows ***DELETED***.

Dialing a Stored Number

- Make sure the phone is **ON** by pressing the TALK/CALL BACK button.
- Press the mem button.
- Press the memory location (0-9). The number dials automatically.

- OR -

- Make sure the phone is **OFF** (not in TALK mode).
- Press the mem button.
- Use the touch-tone pad or the CALLER ID-VOLUME (▲ or ▼) button to scroll to the number you want to dial.
- Press the TALK/CALL BACK or SPEAKER button. The number dials automatically.

Chain Dialing from Memory

Use this feature to make calls which require a sequence of numbers, such as the calling card calls to a frequently called long distance number. Each part of the sequence is dialed from memory. The following example shows you how to use chain dialing to make a call through a long distance service:

<i>The Number For</i>	<i>Memory Location</i>
Long distance access number	7
Authorization code	8
Frequently called long distance number	9

- Make sure the phone is **ON** (in TALK or SPEAKERPHONE mode).
- Press the mem button and then press 7.
- When you hear the access tone, press the mem button and then press 8.
- At the next access tone, press the mem button and then 9.

TIP: Wait for the access tones before pressing the next mem button, or your call may not go through.

Answering System Operation

This section discusses the buttons and features on the answering system.

Messages Indicator

The messages indicator shows you how many messages you have received, and blinks when there are new messages. The ans/on/off button must be **ON** in order for the messages indicator to work.

NOTE: The answering system displays "--" when it is turned off.

Screening Calls from the Base

- Wait for the caller to begin leaving a message (to determine who is calling).

- To speak to the caller, pick up the handset, and press the TALK/CALL BACK button.

The answering system automatically stops recording when you activate the handset or pick up an extension phone.

TIP: Make sure the volume on the base is set loud enough to hear your incoming calls.

Message Playback

The messages indicator on the base lets you know when you have messages. To play messages, press PLAY/STOP.

While a message is playing, you may do the following:

- Press PLAY/STOP to stop the message playback.
- Press and release ◀ repeat to restart the current message; continue pressing and releasing ◀ repeat to review previous messages.
- Press and release ▶ skip to go to the next message.

Memory Full

When the answering system memory is full, the system answers after 10 rings. You should erase some messages so the answering system may record new messages.

Erasing Messages

You may erase messages three ways: one message at a time from the base; all messages from the base; or one message at a time from the handset or a phone in another location.

To erase one message at a time from the base:

- Press PLAY/STOP. The message plays.
- Press and release the erase button.

To erase all reviewed messages from the base:

- Press and hold the erase button until the unit beeps.

To erase a message from the handset:

- Press flash/answerer/call waiting button to enter into the handset remote access operation.
- Press PLAY/STOP on the handset (the 2 button). The message plays.
- Press erase (the 0 button) to erase the message during message playback.

NOTE: Erased messages cannot be restored.

Leaving a Memo

Use the memo feature to leave a message.

- Press and hold the memo button on the base. **You must hold the button until you finish recording the memo.**
- Begin speaking after you hear the beep.
- Release the memo button when finished.

Remote Access

You may access the answering system with the cordless handset or from any tone-dial compatible telephone.

Cordless Handset

- Press the flash/answerer/call waiting button to access the answering system.
- Use the corresponding handset keys just like you would use the base buttons (see Answering System Setup). The button functions are located on the handset above each number key. For example, to play messages:
 - Press the flash/answerer/call waiting button. The display shows ***ANSWERER REMOTE***.
 - Press 2 (PLAY/STOP).
 - When you are finished listening to your messages, press the flash/answerer/call waiting button again.

Screening Calls from the Handset

Use the handset to screen calls even when you can't hear the answering system.

When the answering system picks up:

- Press the flash/answerer/call waiting button to access the answering system.
- Listen as the caller leaves a message.
- Press the TALK/CALL BACK button to speak to the person or press the flash/answerer/call waiting button to stop screening the call.

Memory Full

When answering system memory is full, the system answers after 10 rings, beeps and waits for you to enter the 3-digit security code. If you don't enter the security code within 10 seconds, the phone hangs up.

You should erase some messages so the answering system can record new ones.

NOTE: The unit also answers after the 10th ring if it is turned off. To access the answering system, enter your 3-digit security code after you hear the beep.

Accessing the Answering System from Another Location

You can access your answering system from any touch-tone phone by entering your 3-digit security code after you hear the outgoing announcement.

- Dial the telephone number to which the answering system is connected to.
- Enter the security code after you hear the tone.
- Follow the voice menu to use the answering system's remote functions.

The remote feature lets you perform the following functions:

To	Press this Button
Review message	1
Play back messages	2
Stop message playback	2
Erase message	0 (during message playback)
Skip message	3
Turn off/on answerer	4
Review voice menu options	7

TIP: You can bypass the outgoing announcement by pressing any numbered key on the touch-tone pad while the announcement is playing. Then, you can enter your security code to access the answering system.

Changing the Security Code

The default security code for accessing the answering system from another location is 1 2 3. You must use the handset to change the security code. With the phone **OFF** (not in TALK mode), follow these steps:

- Press the flash/answerer/call waiting button to display ***ANSWERER REMOTE***.
- Press the *EXIT/tone button.
- Enter the new 3-digit security code.
- Press the *EXIT/tone button again. The unit announces the new code, pauses, beeps, and then announces the menu options again.

Headset and Belt Clip Operation

Connecting an Optional Headset to the Handset

For hands free operation:

- Remove the rubber cap covering the headset jack.
- Connect the headset to the headset jack on the handset. The handset receiver is disabled when the headset is connected.
- Adjust the headset to rest comfortably on top of your head and over your ear. Move the microphone to approximately two to three inches from your mouth.
- Press the TALK/CALL BACK button on the handset to answer a call or make calls with the headset.
- To return to normal operation, unplug the headset from the jack.

Attaching the Belt Clip

To attach the belt clip, insert the sides of the belt clip into the slots on each side of the handset. Snap the ends of the belt clip into place.

Changing the Battery

CAUTION: To reduce the risk of fire or personal injury, use only the Thomson Inc. approved Nickel-Cadmium (Ni-Cd) battery model 5-2729 or Nickel-Metal Hydride (Ni-MH) battery model 5-2522, which is compatible with this unit.

- Make sure the telephone is **OFF** (not in TALK mode) before you replace battery.
- Remove the battery compartment door.
- Disconnect the cord attached to the battery pack and remove the battery pack from the handset.
- Insert the new battery pack and connect the cord to the jack inside the battery compartment.
- Replace battery compartment door.
- Place handset in the base to charge. **Allow the handset battery to properly charge (for 16 hours) prior to first use or when you install a new battery pack. If you do not properly charge the phone, battery performance will be compromised.**

Battery Safety Precautions

- Do not burn, disassemble, mutilate, or puncture. Like other batteries of this type, toxic materials could be released which can cause injury.
- To reduce the risk of fire or personal injury, use only the **Nickel-Metal Hydride (Ni-MH)** battery listed in this User's Guide.
- Keep batteries out of the reach of children.
- Remove batteries if storing over 30 days.

NOTE: The RBRc seal on the battery used in your Thomson Inc. product indicates that we are participating in a program to collect and recycle the rechargeable battery (or batteries). For more information go to the RBRc web site at www.rbrc.org or call 1-800-8-BATTERY or contact a local recycling center.

Display Messages

The following messages show the status of the phone or help you set up and use your phone.

ANSWERER REMOTE Indicates the handset is accessing the answering system.

BLOCKED CALL Caller information is blocked from transmission.

BLOCKED NAME/NUMBER Caller name and number is blocked from transmission.

DELETE ALL?

Prompt asking if you want to erase all Caller ID records.

DELETE CALL ID?

Prompt asking if you want to erase the current Caller ID record that is shown on the display.

DELETE?

Prompt asking if you want to erase one of the 10 numbers stored in the phone's outgoing memory.

DELETED

Prompt confirming a CID record is erased.

DO NOT DISTURB

Indicates DO NOT DISTURB function is turned on. Ringer and call screening is silenced.

EMPTY Indicates a memory location is vacant.

END OF LIST

Indicates there is no additional information in the Caller ID memory log.

ENTER NAME

Prompt telling you to name the handset or enter a name for one of the 10 memory locations.

INCOMPLETE DATA

Caller information is interrupted during transmission or the phone line is excessively noisy.

LOW BATTERY

Indicates the handset battery is low and needs charging.

NEW

NO DATA

NO CALLS

PAGING FRM BASE

PLEASE REGISTER

PRESS TALK KEY

READY

Indicates the handset is registered and available for use.

REPT

Repeat call message. Indicates that a new call from the same number was received more than once.

TRANSFERRING

Indicates the call is being transferred from one handset to another.

UNABLE TO DIAL

Indicates the CID or memory contents cannot be dialed.

UNABLE TO STORE

Indicates the CID or memory contents cannot be stored.

UNAVAILABLE

Indicates the handset is out of range. Or an additional handset is in use. Or there has been a base power failure, in which case you must place all handsets on the main base cradle for 20 seconds to re-register.

UNKNOWN NAME/CALLER/NUMBER

The incoming call is from an area not serviced by Caller ID or caller information is not sent.

Answering System Display Messages

The following messages show the status of the answering system or help you set up and use the system.

0-59 Indicates the total number of messages.

CL (blinking) The voice time/day stamp needs to be set.

--

An (blinking) The system is answering a call and recording an incoming call.

F (blinking) Answering system memory is full.

Six bars (blinking) The system is recording a memo or an announcement.

LA (Line Access) Answering system is being accessed remotely from another location.

Handset Sound Signals

<i>Signal</i>	<i>Meaning</i>
A long warbling tone (with ringer on)	Signals an incoming call
Three short beeps (several times)	Page signal
One long tone	Confirmation tone
One beep every 7 seconds	Low battery warning

Troubleshooting Tips

Caller ID Solutions

No display

- Fully charge (for 16 hrs) or replace the battery.
- If you are using AC (electrical) power, make sure that the unit is connected to a non-switched electrical outlet. Unplug the AC power converter from the unit and plug it back in.
- To see Caller ID information in your display, you must be subscribed to Caller ID service through your local telephone company.

Caller ID incomplete

- The unit displays this message if it detects anything other than valid Caller ID information during the silent period after the first ring. This message indicates the presence of noise on the line.

Telephone Solutions

Handset can not link.

- If any handsets become inoperable, place it on the main base cradle for 20 seconds to re-register.

No dial tone

- Check or repeat installation steps
- Make sure the base power cord is connected to a working electrical outlet.
- Make sure the telephone line cord is connected to the base unit and the modular phone jack?
- Disconnect the base from the wall phone jack and connect another phone to the same jack. If there is no dial tone on the second phone, the problem might be your wiring or local service.
- The handset might be out of range of the base. Move closer to the base.

- Make sure the battery is properly charged (for 16 hours).
- Ensure the battery pack is installed correctly.
- Did the handset beep when you pressed the TALK/CALL BACK button? Did the in use indicator come on? The battery may need to be charged.

Handset does not ring

- Make sure the ringer is set to ON, this can be done through the handset setup menu Ringer Volume.
- You may have too many extension phones on your line. Try unplugging some phones.
- See solutions for "No dial tone."

You experience static, noise, or fading in and out

- Change channels
- The handset may be out of range. Move closer to the base.
- Relocate the base.
- Charge the battery.
- Make sure base is not plugged into an electrical outlet with another household appliance.

Unit beeps

- Place handset in base cradle for 20 seconds to reset the security code. If that doesn't work, charge the battery for 16 hours.
- See solutions for "No dial tone."
- Replace the battery.

Memory dialing

- Make sure you correctly program the memory location keys.
- Make sure you follow the proper dialing sequence.
- You may need to reprogram numbers into memory after a power outage or battery replacement.

Out of range

- Move closer to the base.
- Reset the battery. Unplug the battery and plug it in again after five seconds.
- Reset the power supply. Unplug the supply and plug it in again after five seconds.

Phone with tone service dials out in pulse mode

- Make sure phone is in tone dialing mode.

Phone won't dial out with pulse service

- Make sure phone is in pulse dialing mode.

Handset displays ***UNAVAILABLE***

- Place the handset on the main base for reset.
- An additional handset is in use.
- Move closer to the base.

Answering System Solutions

Can't hear messages, beep, etc.

- Adjust speaker volume.

Time/Day setting is incorrect.

- Set the time clock.

Answers on 10th ring

- Make sure answering system is turned on.
- Answering system memory may be full. Erase some messages.

Incoming messages are incomplete

- An extension phone may have been lifted as a message is received.
- Answering system memory is full. Erase some messages.
- You may have accidentally pressed the PLAY/STOP button during playback and stopped the message.

Won't respond to remote commands

- You must use a tone-dial

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>