



RS/6000 SP



SP Switch2 Service Guide

RS/6000 SP



SP Switch2 Service Guide

Note!

Before using this information and the product it supports, read the information in "Safety and environmental notices" on page ix and "Notices" on page A-1.

Fourth edition (April 2002)

IBM welcomes your comments. A form for readers' comments may be provided at the back of this publication or you may address your comments to the following address:

International Business Machines Corporation
Department 55JA, Mail Station P384
2455 South Road
Poughkeepsie, NY 12601-5400
United States of America

FAX (United States & Canada): 1+845+432-9405
FAX (Other Countries):
Your International Access Code+1+845+432-9405

IBMLink (United States customers only): IBMUSM10(MHVRCFS)
Internet e-mail: mhvrdfs@us.ibm.com

If you would like a reply, be sure to include your name, address, telephone number, or FAX number.

Make sure to include the following in your comment or note:

- Title and order number of this book
- Page number or topic related to your comment

When you send information to IBM, you grant IBM a nonexclusive right to use or distribute the information in any way it believes appropriate without incurring any obligation to you.

© **Copyright International Business Machines Corporation 2000, 2002. All rights reserved.**

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Figures	v
Tables	vii
Safety and environmental notices	ix
Safety notices (in English)	ix
Danger notices	ix
Caution notices	xi
Laser safety information	xiii
Environmental notices	xiii
Product recycling and disposal	xiii
About this book	xv
Who should use this book	xv
Related information	xv
User's responsibilities	xvi
How to use this book	xvi
How to send your comments	xvi
Chapter 1. Maintenance Analysis Procedures (MAPs)	1-1
Switch MAPs	1-1
Switch description and problem determination (MAP 0590)	1-1
Switch supervisor communications (MAP 0595)	1-6
Switch environment (MAP 0600).	1-9
Switch power (MAP 0610)	1-13
Switch function (MAP 0620)	1-17
Chapter 2. Locations	2-1
Naming standard for RS/6000 SP components	2-1
Format structure	2-1
Location diagrams of the RS/6000 SP components.	2-2
Front and rear views of RS/6000 SP frame.	2-3
Frame locations	2-5
Switch assembly locations	2-7
Connector details	2-7
Cable routing.	2-8
Cable routing in a multi-switch frame (F/C 2032)	2-10
Switch data cables	2-11
Chapter 3. Service procedures	3-1
Personal ESD requirements	3-1
Tools and files overview	3-1
Using the css.snap script	3-3
css.snap file structure	3-4
css.snap file package names	3-6
Disk space handling	3-6
SP Switch2 supervisor self-test	3-6
Self-test Conditions	3-7
Switch supervisor status verification using Perspectives	3-7
Opening a switch pane	3-7
Checking switch status	3-7
Base code verification	3-8
Updating the SP Switch2 supervisor code	3-8

Removing and restoring switch resources	3-9
Removing an SP Switch2 from the active configuration	3-9
Restoring an SP Switch2 to the active configuration	3-9
Using Perspectives to fence and unfence nodes attached to the switch	3-10
Service position procedures	3-10
Placing an SP Switch2 into service position	3-10
Replacing an SP Switch2 from service position	3-11
Resetting the clock and bootlist after servicing a node	3-11
Running diagnostics on a switch port	3-12
Chapter 4. FRU removals and replacements	4-1
Handling static-sensitive devices	4-1
SP Switch2 service procedures	4-2
Removing a fan assembly	4-2
Replacing a fan assembly	4-2
Removing a power supply	4-3
Replacing a power supply	4-3
Removing the LED bracket assembly	4-4
Replacing the LED bracket assembly	4-4
Removing the switch supervisor card	4-5
Replacing the switch supervisor card	4-6
Removing an interposer card	4-6
Replacing an interposer card	4-7
Removing the switch planar	4-7
Replacing the switch planar	4-8
Removing the 48 V dc circuit breaker assembly	4-8
Replacing the 48 V dc circuit breaker assembly	4-9
Removing the LED power extension cable	4-9
Replacing the LED power extension cable	4-10
Chapter 5. Parts catalog	5-1
SP Switch2 assembly (view 1)	5-2
SP Switch2 assembly (view 2)	5-4
Switch cables	5-6
SP Switch2 Frame (F/C 2032)	5-8
F/C 2032 frame extender	5-10
SP Switch2 Frame Model 556 and F/C 2034.	5-12
Model 556 and F/C 2034 frame extender	5-14
Notices	A-1
Trademarks	A-1
Electronic emissions notices	A-2
Federal Communications Commission (FCC) statement	A-2
European Union (EU) statement.	A-2
United Kingdom telecommunications safety requirements	A-2
Industry Canada compliance statement	A-2
For installations in Japan:	A-3
Electromagnetic interference (EMI) statement - Taiwan	A-3
Radio protection for Germany	A-3
Index	X-1

Figures

1-1.	SP Switch2 Assembly High-Level Diagram	1-3
1-2.	SP Switch2 Wrap Plugs	1-5
1-3.	SP Switch2 Chassis Assembly	1-11
2-1.	Front view of frame locations	2-3
2-2.	Front view of multi-switch frame locations	2-4
2-3.	Rear view of frame locations	2-5
2-4.	SP Switch2 high level planar view	2-7
2-5.	RS/6000 SP connector details (as seen at receiving ends, not at cable ends)	2-8
2-6.	Frame cabling routing path in rear of RS/6000 SP frame — 1.93 m frame	2-9
2-7.	Frame cabling routing path in rear of RS/6000 SP frame — 2.01 m frame	2-9
2-8.	Frame cable routing paths in rear of RS/6000 SP multi-switch frame (F/C 2032) — 1.93 m frame	2-11
4-1.	Handling an anti-static device.	4-2
4-2.	Removing SP Switch2 fan assemblies and power supplies	4-3
4-3.	Removing SP Switch2 power and environmental LED assembly	4-4
4-4.	Removing and replacing SP Switch2 supervisor and interposer cards	4-5
4-5.	Installing an SP Switch2 supervisor and interposer cards	4-6
4-6.	Removing SP Switch2 circuit breaker assembly	4-9

Tables

1-1.	Switch Problem Diagnostics	1-5
1-2.	SP Switch2 supervisor LED indications	1-6
1-3.	Perspectives SP Switch2 status indicators	1-9
1-4.	Fan Failure Diagnostics	1-10
1-5.	Power supply failure diagnostics	1-12
1-6.	SP Switch2 error conditions	1-19
1-7.	Problem from the out.top file	1-22
1-8.	Service Request Numbers (SRNs) for SP Switch2 adapters	1-24
1-9.	Switch Problem Priority Listing	1-25
2-1.	External cable routing	2-9
2-2.	SP Switch2 data cable chart	2-11
3-1.	Service procedure tools	3-2
3-2.	Setup output files	3-2
3-3.	Tuning output files	3-3
3-4.	SP Switch2 log files	3-4
5-1.	SP Switch2 assembly (view 1)	5-3
5-2.	SP Switch2 assembly (view 2)	5-5
5-3.	Switch cables	5-7
5-4.	SP Switch2 Frame (F/C 2032)	5-9
5-5.	F/C 2032 frame extender	5-11
5-6.	SP Switch2 Frame Model 556 and F/C 2034.	5-13
5-7.	Model 556 and F/C 2034 frame extender	5-15

Safety and environmental notices

Safety notices (in English)

For general information concerning safety, refer to *Electrical Safety for IBM Customer Engineers* (S229-8124). For a copy of this publication, contact your IBM marketing representative or the IBM branch office serving your locality.

The following is a list of all safety notices (in English only) pertaining to SP hardware maintenance tasks from this and other RS/6000 SP hardware publications. Translations of each of the safety notices into other languages are included in *RS/6000 SP: Safety Information*.

DANGER notices warn you of conditions or procedures that can result in death or severe personal injury.

CAUTION notices warn you of conditions or procedures that can cause personal injury that is neither lethal nor extremely hazardous.

Each notice contains a reference number (*SPSFXXXX*) which you can use to help find a specific notice in other languages.

Danger notices

DANGER

Do not attempt to open the covers of the power supply. Power supplies are not serviceable and are to be replaced as a unit. (SPSFD001)

DANGER

An electrical outlet that is not correctly wired could place hazardous voltage on metal parts of the system or the devices that attach to the system. It is the responsibility of the customer to ensure that the outlet is correctly wired and grounded to prevent an electrical shock.

Before installing or removing signal cables, ensure that the power cables for the system unit and all attached devices are unplugged.

When adding or removing any additional devices to or from the system, ensure that the power cables for those devices are unplugged before the signal cables are connected. If possible, disconnect all power cables from the existing system before you add a device.

Use one hand, when possible, to connect or disconnect signal cables to prevent a possible shock from touching two surfaces with different electrical potentials.

During an electrical storm, do not connect cables for display stations, printers, telephones, or station protectors for communications lines. (SPSFD002)

DANGER

In the U.S., Canada, and Japan, this product has a 4-wire power cable with a 4-prong plug. Use this power cable with a correctly grounded power receptacle to prevent possible electric shock. (SPSFD003)

DANGER

Before you connect the power cable of this product to ac power, verify that the power receptacle is correctly grounded and has the correct voltage. (SPSFD004)

DANGER

During an electrical storm, do not connect or disconnect any cable that has a conductive outer surface or a conductive connector. (SPSFD005)

DANGER

Switch off power and unplug the machine power cable from the power receptacle, before removing or installing any part that is connected to primary power. (SPSFD006)

DANGER

To prevent possible electrical shock during machine installation, relocation, or reconfiguration, connect the primary power cable only after connecting all electrical signal cables. (SPSFD007)

DANGER

High voltage present. Perform "Lockout safety procedures" to remove primary power to the frame. (SPSFD008)

DANGER

High voltage present. Perform "Lockout safety procedures" to remove primary power to the frame (and high-voltage transformer if present). (SPSFD009)

DANGER

High voltage present at test points. Use high voltage test probes. (SPSFD010)

DANGER

High energy present. Do not short 48V to frame or 48VRtn. Shorting will result in system outage and possible physical injury. (SPSFD011)

DANGER

If a unique power module fails, all LEDs will be off. The high voltage LED will be off even though the high voltage is still present. (SPSFD012)

DANGER

The remaining steps of the procedure contain measurements that are taken with power on. Remember that hazardous voltages are present. (SPSFD013)

DANGER

The frame main circuit breaker and the controller must not be switched on again now.

Before disconnecting the power cables from the power receptacles, ensure that the customer's branch distribution circuit breakers (customer power source circuit breakers) are Off and tagged with DO NOT OPERATE tags, S229-0237. Refer to "Lockout safety procedures" in *RS/6000 SP: System Service Guide*, before proceeding. (SPSFD014)

DANGER

Before connecting ac power cables to electrical outlets, ensure that:

- The customer's branch distribution circuit breakers (customer power source circuit breakers) are off and tagged with DO NOT OPERATE tags, S229-0237 (or national language equivalent).
- The activities in "Performing the Customer 50/60 Hz Power Receptacle Safety Check" have been performed on all customer power source outlets and cable connectors. (SPSFD015)

DANGER

Ensure that the customer's branch distribution circuit breakers (customer power source circuit breakers) to the ac power outlets are off and tagged with DO NOT OPERATE tags, S229-0237 (or national language equivalent). (SPSFD016)

DANGER

Both the SEPBU power chassis and the PDU 48 V dc power chassis are field replaceable units (FRUs) which contain NO serviceable parts; they are labeled as such. Do not attempt to isolate or repair these components, since doing so may result in severe injury or even death. (SPSFD017)

Caution notices

CAUTION:

The weight of the PDU assembly, 48 V dc power chassis, and the SEPBU power chassis is greater than 18 Kg (40 lbs). Be careful when removing or installing. Remove all 48 V dc power supplies from the power chassis before removing or installing the power chassis. (SPSFC001)

CAUTION:

The unit weight exceeds 18 Kg (40 lbs) and requires two service personnel to lift. (SPSFC002)

CAUTION:

The covers are to be closed at all times except for service by trained service personnel. (SPSFC003)

CAUTION:

When the unit is being serviced, the covers should not be left off or opened while the machine is running unattended. (SPSFC004)

CAUTION:

Due to weight of each thin node (under 18 Kg [40 lbs]), use care when removing and replacing thin nodes above shoulder height. (SPSFC005)

CAUTION:

The wide node weight may exceed 32 Kg (70.5 lbs). (SPSFC006)

CAUTION:

Do not open more than one wide node or switch assembly drawer at a time. (SPSFC007)

CAUTION:

Make sure the stability foot and wheel chocks are installed on the frame. These are required to maintain frame balance and position during service operations. (SPSFC008)

CAUTION:

Outer edges of chassis may be sharp. Care must be taken when removing and installing chassis. (SPSFC009)

CAUTION:

The ground strip may have sharp edges. (SPSFC010)

CAUTION:

Do not remove wide nodes or switch assemblies from the mounting slides. Caution must be observed when working with mounting slides to prevent pinched fingers or accidental release of the unit. (SPSFC011)

CAUTION:

Do not remove the drawer case mounting screws at the bottom of both sides. (SPSFC012)

CAUTION:

Once the latch is released, push the drawer closed. Do not pull, as the drawer may disengage from the rails, creating a safety hazard. (SPSFC013)

CAUTION:

Due to the weight of each wide node, use care when sliding and closing wide processor nodes above shoulder height. (SPSFC014)

CAUTION:

- When moving frames into position, team members should work together. Using one person on each corner of the frame can prevent strain.
- In raised floor installations, mechanically safe moldings should be installed around floor cutouts. Extreme caution should be used when moving frames during installation or removal because of the proximity of floor cutouts to casters. (SPSFC015)

CAUTION:

When using step ladder or step stool, be sure that the work surface is level and the step ladder or step stool is in good working order. (SPSFC016)

CAUTION:

Portable ladders present a serious safety hazard if not used properly. Follow these general guidelines:

- Make sure the ladder is firm and steady, and has no defective rungs or braces.
- Work only on a level surface.
- Never use a metal ladder near electrical power lines.
- Never overreach. Instead, move the ladder.

Be as careful on a short ladder as on a 30-foot extension ladder. False security can lead to carelessness and falls which can cause painful injuries. (SPSFC017)

CAUTION:

All IBM laser modules are designed so that there is never any human access to laser radiation above a class 1 level during normal operation, user maintenance, or prescribed service conditions. Data processing environments can contain equipment transmitting on system links with laser modules that operate at greater than class 1 power levels. For this reason, never look into the end of an optical fiber cable or open receptacle. Only trained service personnel should perform the inspection or repair of optical fiber cable assemblies and receptacles. (SPSFC018)

Laser safety information

The RS/6000 SP might contain certain communication adaptors, such as ESCON or FDDI, which are fiber optic based and use lasers.

Laser Compliance

All lasers are certified in the U.S. to conform to the requirements of DHHS 21 CFR Subchapter J for class 1 laser products. Outside the U.S., they are certified to be in compliance with the IEC 825 (first edition 1984) as a class 1 laser product. Consult the label on each part for laser certification numbers and approval information.

Environmental notices

Product recycling and disposal

This product contains materials such as circuit boards, cables, electromagnetic compatibility gaskets, and connectors which might contain lead and copper/beryllium alloys that require special handling and disposal at end of life. Before this unit is disposed of, these materials must be removed and recycled or discarded according to applicable regulations. IBM offers product return programs in several countries. You can find country-specific instructions at www.ibm.com/ibm/environment/products/prp.phtml.

This product might contain nickel-cadmium or lithium batteries in communication adapters. The batteries must be recycled or disposed of properly. Recycling facilities might not be available in your area. In the United States, IBM has established a collection process for reuse, recycling, or proper disposal of used sealed lead-acid, nickel-cadmium and nickel metal hydride batteries and battery packs from IBM equipment. For information on proper disposal of batteries in this product, please contact IBM at 1-800-426-4333. For information on disposal of batteries outside the United States, contact your local waste disposal or recycling facility.

About this book

This book covers the SP Switch2 only. Refer to *RS/6000 SP: SP Switch Service Guide*, GA22-7443 for information related to the SP Switch.

This book is to help you, as a customer engineer diagnose and repair an RS/6000® SP™ SP Switch2 by performing the following tasks:

- Identify field replaceable unit (FRU) locations
- Isolate RS/6000 SP failures using Maintenance Analysis Procedures (MAPs)
- Perform diagnostic service procedures
- Perform removal and replacement procedures
- Identify FRUs and their corresponding part numbers

Who should use this book

This book is intended for RS/6000 SP product-trained service personnel.

Related information

The following books make up the complete RS/6000 SP hardware service library:

- *RS/6000 SP: Safety Information*, GA22-7467. Safety notices, in English and translated into other national languages, which are compiled from all the books in the library.
- *RS/6000 SP: Installation and Relocation*, GA22-7441. Installation and relocation procedures, maintenance agreement and qualification procedures, SP system verification.
- *RS/6000 SP: System Service Guide*, GA22-7442. General SP system service procedures, the system Start MAP, and MAPs and parts catalog for the frames and power subsystems. Use this book to begin a diagnostic procedure to isolate a problem to a specific major component of the SP system.
- *RS/6000 SP: SP Switch Service Guide*, GA22-7443. Service procedures, MAPs, and parts catalog information specific to the SP Switch.
- *RS/6000 SP: SP Switch2 Service Guide*, GA22-7444. Service procedures, MAPs, and parts catalog information specific to the SP Switch2 (this book).
- *RS/6000 SP: Uniprocessor Thin and Wide Node Service Guide*, GA22-7445. Service procedures, MAPs, and parts catalog information specific to all uniprocessor-type nodes.
- *RS/6000 SP: 604 and 604e SMP High Node Service Guide*, GA22-7446. Service procedures, MAPs, and parts catalog information specific to these nodes.
- *RS/6000 SP: SMP Thin and Wide Node Service Guide*, GA22-7447. Service procedures, MAPs, and parts catalog information specific to these nodes.
- *RS/6000 SP: POWER3 SMP High Node Service Guide*, GA22-7448. Service procedures, MAPs, and parts catalog information specific to this node.

This book and other RS/6000 SP hardware and software documentation are available both online and, for some books, in printed form from the following sources:

- The Web site at http://www.ibm.com/servers/eserver/pseries/library/sp_books/index.html
- The Resource Center on the PSSP product media
- Printed and CD-ROM versions (which can be ordered from IBM)

For more information on these sources and an extensive listing of RS/6000 SP related publications, see the bibliography in *RS/6000 SP: Installation and Relocation*.

User's responsibilities

Before calling IBM® for service, the system administrator should use the problem determination section of the *Parallel System Support Programs for AIX®: Diagnosis Guide* (GA22-7350), for initial problem determination. If there is nothing wrong with the customer operating procedures, customer-supplied cables, or the power source, the customer should then call IBM for service.

How to use this book

This book is intended for RS/6000 SP product-trained service personnel.

When performing RS/6000 SP maintenance, the service provider must follow **all** "Maintenance Analysis Procedures" beginning with the Start MAPs in the *RS/6000 SP: System Service Guide*.

Beginning with the Start MAPs, isolate the problem to one or more of these RS/6000 SP components:

- Supervisor Subsystem
- Processor Node
- Power Subsystem
- High Voltage Transformer (World Trade)
- Ethernet Local Area Networks (LANs)
- PCI Adapter.

Note: If the diagnostic procedures indicate that the problem is isolated to a SP Switch2, the information in *RS/6000 SP: System Service Guide* will direct you to return to this book.

If you cannot determine the failure's cause, you should request the assistance of the RS/6000 SP Field Support Center.

How to send your comments

Your feedback is important in helping to provide the most accurate and highest quality information. If you have any comments about this book or any other RS/6000 SP documentation:

- Send your comments by e-mail to **mhvrcfs@us.ibm.com**. Be sure to include the name of the book, the order number of the book, and, if applicable, the specific location of the text you are commenting on (for example, a page number or table number).
- Fill out one of the forms at the back of this book and return it by mail, by fax, or by giving it to an IBM representative.

Chapter 1. Maintenance Analysis Procedures (MAPs)

This chapter provides information for identifying problems and guides you to the most likely failed Field Replaceable Unit (FRU). The MAPs then refer you to the FRU Removal/Replacement procedures for the corrective action.

Switch MAPs

- “Switch description and problem determination (MAP 0590)”
- “Switch supervisor communications (MAP 0595)” on page 1-6
- “Switch environment (MAP 0600)” on page 1-9
- “Switch power (MAP 0610)” on page 1-13
- “Switch function (MAP 0620)” on page 1-17

Attention: Components in the frame are susceptible to damage from static discharge. Always use an ESD wristband when working inside frame covers. (See “Personal ESD requirements” on page 3-1 for more details.) Do not touch the pins or circuitry on these components.

Switch description and problem determination (MAP 0590)

Purpose of this MAP

This MAP describes the components of the SP Switch2 fabric and provides a table (Table 1-1 on page 1-5) containing diagnostic information.

Each SP Switch2 has the following components:

- Switch interposer cards
 - One per occupied switch port
 - Connects the SP Switch2 to a switch adapter mounted in processor node
- SP Switch2 adapter
 - Installed in processor nodes
 - Connects processor node to SP Switch2

Note: Systems equipped with the SP Switch2 require SP Switch2 adapters. This switch cannot connect to the SP Switch MX2 adapter.

- Switch supervisor
- Switch power cable
- Switch wrap plugs:
 - To test systems using SP Switch2 interposer cards and adapters, use male and female wrap plugs
 - Refer to Figure 1-2 on page 1-5
- Interposer wrap card:
 - Used to test the SP Switch2 interposer interface
 - Refer to “SP Switch2 assembly (view 2)” on page 5-4 for the interposer wrap card part number
- Switch data cables (two types):
 - Internal to the frame
 - External data cables (multi-frame only)

Attention: Switch data plug and jack connector pins are easily bent. Check for bent pins on male plugs or bent pin guides on female jacks if a cable is difficult to plug. Problems with bent pins or pin guides can propagate to new plugs and jacks if not corrected first.

Refer to Figure 1-1 on page 1-3 for a high-level view of the RS/6000 SP SP Switch2 assembly.

Switch Description and Problem Determination (MAP 0590)

Switch Connection Types

Standard Node

Processor nodes in 9076 SP frames are attached to the switches with switch cables.

Switch-to-Switch

Connections between switches.

Switch Assembly Description

SP Switch2

Each switch chip has its own clock and all clocks communicate through the switch data cables. Each switch provides a maximum of 16 switch-to-node ports and 16 switch-to-switch ports.

FRUs include: Fans, circuit breaker assembly, LED bracket assembly, LED power extension cable, switch supervisor card, switch power supplies, switch interposer cards, and the complete planar replacement assembly.

Note: An 8-port variation of the SP Switch2 is not available.

Switch Description and Problem Determination (MAP 0590)




Figure 1-1. SP Switch2 Assembly High-Level Diagram

There are two LEDs on the front of each switch assembly. For quick reference, their definitions are as follows:

Switch Description and Problem Determination (MAP 0590)

Yellow (Environment) LED

- Off** No environmental problems detected by switch supervisor card.
- On** Warning of environmental condition out of nominal range. Preventative Maintenance should be scheduled for this switch.
- Flashing**
Serious environmental condition detected; power shut off.

Green (Power) LED

- Off** No 48 V dc power available at switch assembly.
- Flashing**
Power available at switch assembly, but switch logic is Off.
- On** Power available at switch assembly, and logic is On.

Note: Refer to "Service position procedures" on page 3-10 for placing or removing the switch assembly into or from service position.

Step 0590-001

Read the following warning and then follow steps to ensure continuity of customer's jobs in the queue.

Attention: Servicing a processor node or switch assembly will interrupt customer usage of the processor node and the remainder of the switch network. If the switch feature must be replaced in a multi-frame system, refer to "Removing and restoring switch resources" on page 3-9, for information on isolating the switch assembly.

Attention: It is possible that the SP Switch2 cabling has been modified from recommended or documented configurations. Any connector jack numbers will be correct as reported by system programs, so tracing cables from the jack may be necessary.

It may be necessary for the customer to complete all active parallel jobs or jobs using switch interface (for example, tape B/U ADSM), then remove the switch feature from the active configuration. Refer to "Removing and restoring switch resources" on page 3-9, for these procedures.

Step 0590-002

Determine the condition of the switch by viewing its LEDs and the information displayed in Perspectives. Then refer to Table 1-1 on page 1-5 for a prioritized list of conditions. Find the first condition that describes your problem, then perform the associated action.

Step 0590-003

Check for errors indicating environmental problems with the switch feature. These can be viewed by issuing the appropriate command from the control workstation:

- **errpt -a -N sphwlog | pg**
- **errpt -a -N css0**
- **errpt -a -N Worm**
- Refer to the "Starting a service call (MAP 0100)" in *RS/6000 SP: System Service Guide* for more information on the **pg** command

Switch Description and Problem Determination (MAP 0590)

Note: In a frame with processor nodes, entries for the switch will refer to “node17” or “slot17”. In a multi-switch frame, switches will be listed as even slot addresses.




Figure 1-2. SP Switch2 Wrap Plugs

Notes:

1. SP Switch2 advanced diagnostics use the 8.75 meter data cable provided by the SPS feature bill of material.
2. Advanced cable wrap tests will not run successfully for 10-, 15-, and 20-meter SPS data cables. If these data cables are used, change the suspected cable.
3. Refer to “SP Switch2 assembly (view 1)” on page 5-2 in Chapter 5, “Parts catalog” for the wrap plug part numbers.

Table 1-1. Switch Problem Diagnostics

Priority	Message or condition	Action
1 (1 of 4)	Supervisor communication problem <ul style="list-style-type: none"> • Yellow switch supervisor LED on, green LED off • Perspectives switch pane indicates problem with 48 volts but other voltages are OK • Perspectives switch pane shows several gray icons with question marks • Fans are running but green LEDs on all interposer cards and all power supplies are off <p>Note: Power supply LEDs are viewable through the fan assemblies.</p> <p>Note: For information on opening a Perspectives switch pane see: “Opening a switch pane” on page 3-7.</p>	Go to “Switch supervisor communications (MAP 0595)” on page 1-6.

Switch Description and Problem Determination (MAP 0590)

Table 1-1. Switch Problem Diagnostics (continued)

Priority	Message or condition	Action
2 (2 of 4)	Environmental problems <ul style="list-style-type: none"> Control workstation errpt file reports a switch failure, shutdown, or warning message associated with a fan, power supply, or temperature indicator Perspectives switch environmental indicator is yellow and a fan or power supply indicator is red Perspectives switch environmental indicator is either yellow or red and the temperature indicator is either yellow or red Yellow switch supervisor LED is on or flashing 	Go to "Switch environment (MAP 0600)" on page 1-9.
3 (3 of 4)	Power problem <ul style="list-style-type: none"> Green switch supervisor LED is off or flashing Perspectives switch power indicator is red Switch has no power All voltages at zero 	Go to "Switch power (MAP 0610)" on page 1-13.
4 (4 of 4)	Switch function problem <ul style="list-style-type: none"> Error in <code>/var/adm/SPlogs/css0/p0/out.top</code> (see note) Problem with <code>switch_responds</code> Problem returned from <code>errpt -a -N Worm</code> or <code>errpt -a -N css0</code> (issued on the primary node) Problem detected by CE/customer. 	Go to "Switch function (MAP 0620)" on page 1-17.

Notes:

- `out.top` is located on the primary node. To find the primary node, issue:

```
Eprimary
```
- Verify that the file has a valid (recent) time stamp using:

```
ls -l
```

Switch supervisor communications (MAP 0595)

Notes:

- Refer to "Service position procedures" on page 3-10 for procedures used to place the switch into the service position or for removing it from the service position.
- Refer to Table 1-2 for descriptions of the SP Switch2 supervisor LED indications.

Table 1-2. SP Switch2 supervisor LED indications

Green LED	Yellow LED	Indication
On	Off	Normal switch operation
Flashing	Off	Logically powered off (48 V available)
Off	Off	Physically powered off (48 V circuit breaker off)
On	On	Non-critical power or environmental problem
On, Off, or Flashing	Flashing	Critical power or environmental problem Note: For this indication, the green and yellow LEDs are flashing together .
Off	On	Supervisor communications or base code problem

Switch supervisor communications (MAP 0595)

Table 1-2. SP Switch2 supervisor LED indications (continued)

Green LED	Yellow LED	Indication
Flashing	Flashing	Defective supervisor card (replace card) Note: For this indication, the green and yellow LEDs are flashing alternately .

Step 0595-001

Perspectives indicates that a power problem exists and the yellow LED on the SP Switch2 supervisor is On and it **is not** flashing.

1. Perform the "SP Switch2 supervisor self-test" on page 3-6.
 - While the test is running, compare the LED conditions on the supervisor with those listed in "Self-test Conditions" on page 3-7.
2. Did the supervisor pass the self-test?
 - If yes, go to "Step 0595-002".
 - If no, go to "Step 0595-003".

Step 0595-002

The supervisor passed the self-test. This indicates that the self-test may have reset the supervisor processor and you need to determine if the problem has been cleared.

1. Refresh Perspectives.
2. Power on the switch.
3. Does Perspectives indicate that the original problem is still present or that a new problem is occurring?
 - If yes, return to the Start MAP (0100) in the *RS/6000 SP: System Service Guide*.
 - If no, go to the End of call procedures (MAP 0650) in the *RS/6000 SP: System Service Guide*.

Step 0595-003

The SP Switch2 supervisor failed the self-test therefore, you need to analyze the LED conditions you observed during the self-test.

1. Did the green and yellow supervisor LEDs light?
 - If yes, go to "Step 0595-005".
 - If no, go to "Step 0595-004".

Step 0595-004

Both green and yellow supervisor LEDs **did not** light during the self-test.

1. Check the supervisor LEDs on the nodes connected to the same supervisor cable as the switch.
2. Are any other supervisor LEDs lit?
 - If yes:
 - a. Replace the switch supervisor.
 - b. Go to "Step 0595-008" on page 1-8.
 - If no, go to the Start MAP (0100) in the *RS/6000 SP: System Service Guide* and troubleshoot the supervisory bus system.

Step 0595-005

The switch supervisor failed the self-test. However, during the self-test the green and yellow LEDs on the supervisor **did** light.

1. Did the yellow LED flash the wrong address or was it on steady after the self-test completed?
 - If the yellow LED flashed the wrong address, go to "Step 0595-006" on page 1-8.
 - If the yellow LED was on steady after the self-test, go to "Step 0595-007" on page 1-8.

Switch supervisor communications (MAP 0595)

Step 0595-006

The supervisor self-test failed because the yellow LED flashed the wrong address.

1. Make certain that the correct supervisor harness connector is plugged into the supervisor.
2. Is the correct harness plugged in?
 - If yes, go to the Start MAP (0100) in the *RS/6000 SP: System Service Guide* and troubleshoot the supervisory bus system.
 - If no:
 - a. Plug in the correct supervisor connector.
 - b. Return to "Step 0590-002" on page 1-4 and confirm the original conditions.

Step 0595-007

The supervisor self-test failed because the yellow LED was on steady. This indicates that the supervisor is operating with base code only and needs to have the correct application code loaded.

Note: If the replacement supervisor card is new or it has the wrong application code, the self-test will fail at the last step and the yellow LED will remain on.

1. Perform the SP Switch2 Base code verification procedure on 3-8.
2. Based on the information returned from the Base code verification, perform the procedure for "Updating the SP Switch2 supervisor code" on page 3-8.
3. After updating the supervisor code, perform the "SP Switch2 supervisor self-test" on page 3-6.
4. Does the supervisor pass the self-test?
 - If yes, go to "Step 0595-010".
 - If no, go to the Start MAP (0100) in the *RS/6000 SP: System Service Guide* and troubleshoot the supervisory bus system.

Step 0595-008

You replaced an SP Switch2 supervisor card.

1. Reconnect the supervisor harness to the connector at the back of the SP Switch2.
 - Reconnecting the harness initiates the supervisor self-test.
2. Do the green and yellow LEDs light?
 - If yes, go to "Step 0595-009".
 - If no, go to the Start MAP (0100) in the *RS/6000 SP: System Service Guide* and troubleshoot the supervisory bus system.

Step 0595-009

You replaced a supervisor card and the green and yellow LEDs lit during the self-test.

1. Rerun the "SP Switch2 supervisor self-test" on page 3-6.
 - While the test is running, compare the LED conditions on the supervisor with those listed in the "Self-test Conditions" table.
2. Did the supervisor pass the self-test?
 - If yes, go to "Step 0595-002" on page 1-7.
 - If no, go to "Step 0595-003" on page 1-7.

Step 0595-010

1. Refresh Perspectives
2. Power on the switch.
3. Does Perspectives indicate that the problem is still present?
 - If yes, return to the Start MAP (0100) in the *RS/6000 SP: System Service Guide*.
 - If no, go to the End of call procedures (MAP 0650) in the *RS/6000 SP: System Service Guide*.

Switch environment (MAP 0600)

Purpose of this MAP

This MAP provides diagnostic information for switch problems that are related to the operating environment.

Note: Refer to “Service position procedures” on page 3-10 for placing a switch into the service position or for removing the switch from the service position.

Step 0600-001

A switch environmental problem has been detected.

1. You have observed either:
 - The yellow switch supervisor LED is on or flashing
 - Perspectives switch environmental indicator is yellow or red
 - Errpt message stating, “Warning”, “Shutdown”, or “Failure”
2. **If:**
 - The yellow switch supervisor LED is on, **or** the Perspectives environmental indicator is yellow, **or** the Errpt message states “Warning”, go to “Step 0600-002”.
 - The yellow switch supervisor LED is flashing, **or** the Perspectives environmental indicator is red, **or** the Errpt message states “Shutdown” or “Failure”, go to “Step 0600-003”.

Step 0600-002

You received a switch environment “Warning”.

1. Does this same message occur on other switches or on any processor nodes mounted in the same frame as this switch?
 - If yes, call the next level of support.
 - If no, verify that the customer is not experiencing problems with this switch.
 - If no problems are being experienced, or this is an N+1 fan or power supply failure, then no immediate service is required, and service can be deferred until a later date.
 - If problems are being experienced, and the customer will allow power on service, service can be performed now by treating the problem as an Errpt message of “Shutdown” or “Failure” and going to “Step 0600-003”.

Step 0600-003

A critical power or environmental problem has been detected and the switch has logically powered off.

1. If service action has just been completed on this switch, check for loose cables or shorted conditions.
2. Record the locations of **all** failing FRUs (multiple FRUs may be reported).

Note: Fans are N+1 devices; two fans off will power off the SP Switch2. Power Supplies are N+2; three power supplies off will power off the SP Switch2. Therefore, fix **all** fan problems **before** troubleshooting power supply problems.

3. Power off the switch using the rear 48 V circuit breaker. Remember to turn on the circuit breaker when the repair has been completed.
4. Based on the text of the message, use the information in Table 1-3 to continue service.

Table 1-3. Perspectives SP Switch2 status indicators

Condition	Action
“...P48OK...”	Go to “Switch power (MAP 0610)” on page 1-13.
Fan 1, 2, 3, or 4 indicator is red	Go to “Step 0600-004” on page 1-10.
Temperature indicator is red	Go to “Step 0600-006” on page 1-11.
Power Supply 1, 2, 3, or 4 indicator is red	Go to “Step 0600-010” on page 1-12.

Switch environment (MAP 0600)

Step 0600-004

Perspective display shows "Fan X: Failure" on a red background.

1. Use Table 1-4 to service components
2. Refer to Chapter 4, "FRU removals and replacements" on page 4-1 for instructions about the component being serviced.

Table 1-4. Fan Failure Diagnostics

Priority	Component	Action
1 (1 of 6)	Fan 1, 2, 3, or 4	<ol style="list-style-type: none">a. Check specified fans for blockages or loose connections.b. Fix any obvious problems and continue at "Step 0600-005" on page 1-11.c. If you do not find any problems, continue at Priority 2.
2 (2 of 6)	Fan 1, 2, 3, or 4	<ol style="list-style-type: none">a. Replace fans as described in Chapter 4, "FRU removals and replacements" on page 4-1.b. Continue at "Step 0600-005" on page 1-11.
3 (3 of 6)	Switch supervisor card	<ol style="list-style-type: none">a. Replace the card.b. Continue at "Step 0600-005" on page 1-11.
4 (4 of 6)	Power supply 1, 2, 3, or 4	<ol style="list-style-type: none">a. Replace the power supply associated with the fan.<ul style="list-style-type: none">• Refer to Figure 1-3 on page 1-11.b. Continue at "Step 0600-005" on page 1-11.
5 (5 of 6)	Switch planar	<ol style="list-style-type: none">a. Replace planar/chassisb. Continue at "Step 0600-005" on page 1-11.
6 (6 of 6)	All replaced	Call next level of support.

Switch environment (MAP 0600)




Figure 1-3. SP Switch2 Chassis Assembly

Step 0600-005

You performed the recommended action in Table 1-4 on page 1-10.

1. Component replaced or reseated.
2. Check the yellow switch supervisor LED for an On or flashing condition.
3. Is the yellow switch supervisor LED On or flashing?
 - If yes, return to “Step 0600-004” on page 1-10 and continue service with the next highest priority.
 - If no, go to “Step 0620-021” on page 1-27.

Step 0600-006

Perspectives indicated a shutdown temperature condition and Table 1-3 on page 1-9 directed you to this step.

Temperature is out of specified range; however, no serious electrical current or fan speed problems have been detected.

1. Check for airflow blockage at air intakes and exhaust of the switch assembly and system frame. Also, check air temperatures around the frame, looking for sources of abnormally high temperatures (above 40 C or 104 F).
2. Is there an obvious airflow blockage or abnormally high temperature source near air intakes?
 - If yes, go to “Step 0600-009” on page 1-12.
 - If no, go to “Step 0600-007” on page 1-12.

Switch environment (MAP 0600)

Step 0600-007

You are here for one of the following reasons:

- An over temperature condition exists
- You fixed an obvious airflow blockage or removed a high temperature source near the air intakes
- A problem with the switch supervisor card sensors may exist

For any of the reasons listed above:

1. Perform "SP Switch2 supervisor self-test" on page 3-6.
2. Does the card pass self-test?
 - If yes, go to "Step 0600-008".
 - If no, replace the switch supervisor card. If the problem persists, call the next level of support.

Step 0600-008

The switch supervisor card passed the self-test.

1. Check the yellow switch supervisor LED for ON or FLASHING condition.
2. Is the yellow switch supervisor LED ON or FLASHING?
 - If the switch supervisor LED **is** ON or FLASHING, return to "Step 0600-003" on page 1-9 to determine if any other conditions exist. If no obvious problems are found, call next level of support.
 - If the switch supervisor LED **is not** ON or FLASHING:
 - a. You have resolved the problem.
 - b. Go to "Step 0620-021" on page 1-27 to verify fix.

Step 0600-009

You found an obvious airflow blockage or abnormally high temperature source near air intakes.

1. Remove blockage or high temperature source.
2. Return to "Step 0600-007" to verify fix.

Step 0600-010

Perspective display shows "PS X: Failure" on a red background.

1. Use Table 1-5 to service components
2. Refer to Chapter 4, "FRU removals and replacements" on page 4-1 for instructions about the component being serviced.

Table 1-5. Power supply failure diagnostics

Priority	Component	Action
1 (1 of 4)	Power Supply 1, 2, 3, or 4	a. Replace the power supplies. b. Continue at "Step 0600-011".
2 (2 of 4)	Switch supervisor card	a. Replace the card. b. Continue at "Step 0600-011".
3 (3 of 4)	Switch planar	a. Replace planar/chassis b. Continue at "Step 0600-011".
4 (4 of 4)	All replaced	Call next level of support.

Step 0600-011

You performed the recommended action in Table 1-5.

1. Component replaced or reseated.
2. Check the yellow switch supervisor LED for an On or flashing condition.

3. Is the yellow switch supervisor LED On or flashing?
 - If yes, return to “Step 0600-010” on page 1-12 and continue service with the next highest priority.
 - If no, go to “Step 0620-021” on page 1-27.

Switch power (MAP 0610)

Purpose of this MAP

This MAP provides diagnostic steps for resolving problems related to SP Switch2 power.

Note: Refer to “Service position procedures” on page 3-10 for placing the switch into the service position or removing it from the service position.

Step 0610-001

A power problem with the switch was detected.

1. On the switch, check the status condition of the green switch supervisor LED.
2. Status condition for the green switch supervisor LED is as follows:

Green (power) LED

Off	No 48 V dc power available at switch.
Flashing	Power available at switch, but switch logic is Off.
On	Power available at switch, and logic is On.

3. Is the green switch supervisor LED **Off**?
 - If yes, go to “Step 0610-004” on page 1-14.
 - If no:
 - The green switch supervisor LED is **On** or **flashing**.
 - Go to “Step 0610-002”.

Step 0610-002

1. Is the green switch supervisor LED flashing?
 - If the green LED is flashing, go to “Step 0610-003”.
 - If the green LED is lit but not flashing:
 - a. This indicates that you **do not** have a power supply problem.
 - b. Verify that you have the proper switch, then restart “Switch description and problem determination (MAP 0590)” on page 1-1.
 - c. If this is the proper switch, call the next level of support.

Step 0610-003

The green switch supervisor LED is **flashing**.

1. Attempt to power up the switch using Perspectives from the control workstation.
 - Note the status of the green switch supervisor LED.
2. Does green LED light and stay lit?
 - If yes, go to Switch function (MAP 0620) and refer to “Step 0620-021” on page 1-27 and return the switch to the active configuration.
 - If the green LED continues **flashing**, go to “Frame supervisor not responding (MAP 0110)” in *RS/6000 SP: System Service Guide*.

Switch power (MAP 0610)

Step 0610-004

The green switch supervisor LED is **Off**.

1. Make certain that the switch power cable is properly connected to jack J1 on the switch and on the SEPBU.
2. Place the inline switch on the switch power cable into the On ('1') position if it is not already in that position.
3. Place the switch circuit breaker into the On ('1') position if it is not already in that position.
4. Does the switch circuit breaker trip to the Off ('0') position?
 - If yes, go to "Step 0610-005".
 - If no, go to "Step 0610-006".

Step 0610-005

The switch circuit breaker went (tripped) to the Off ('0') position.

1. One at a time, remove each fan/power supply pair.
 - Refer to "Removing a fan assembly" on page 4-2 and "Removing a power supply" on page 4-3.
2. After each fan/power supply pair is removed, check to see if the circuit breaker trips.
3. Does the circuit breaker still trip?
 - If yes, go to "Step 0610-012" on page 1-15.
 - If no, go to "Step 0610-009" on page 1-15.

Step 0610-006

The switch circuit breaker stayed in the On ('1') position.

1. Check the status of the green switch supervisor LED.
2. Is the green LED lit?
 - If the green LED is **off**, go to "Step 0610-007".
 - If the green LED is **on**:
 - a. You have resolved the switch assembly problem.
 - b. Go to Switch function (MAP 0620) and refer to "Step 0620-021" on page 1-27 to return the switch to the active configuration.

Step 0610-007

The switch circuit breaker is in the On ('1') position and the green switch supervisor LED is **off**.

1. Perform the "SP Switch2 supervisor self-test" on page 3-6.
2. Did the green switch supervisor LED light during the supervisor self-test?
 - If yes, go to "Step 0610-008".
 - If the green LED remained **off**, go to "Step 0610-019" on page 1-16.

Step 0610-008

The green switch supervisor LED lights during the supervisor self-test, but not when the switch circuit breaker is in the On ('1') position.

1. Place the inline switch on the switch power cable in the Off ('0') position.
2. Remove the power cable from jack J1 at the rear of the switch.
3. Return the inline switch on the switch power cable to the On ('1') position.
4. Check for 48 volts (dc) across the two power pins on the disconnected power cable.
5. Were you able to measure 48 V on the power cable?
 - If yes, go to "Step 0610-019" on page 1-16.
 - If no, you have a problem with 48 V dc power distribution.
 - Go to "Open in 48 V dc distribution (MAP 0560)" in *RS/6000 SP: System Service Guide*.

Step 0610-009

The switch circuit breaker no longer trips to the Off ('0') position when a fan/power supply pair is removed.

1. Reinstall the power supply into the switch.
2. Check circuit breaker.
3. Does the circuit breaker still trip?
 - If yes, go to "Step 0610-010".
 - If no, go to "Step 0610-011".

Step 0610-010

A power supply caused the circuit breaker to trip.

1. Replace the power supply.
2. Return to "Step 0610-004" on page 1-14 to verify the replacement.

Step 0610-011

The circuit breaker **does not** trip with the fan removed.

1. Replace the fan.
2. Return to "Step 0610-004" on page 1-14 to verify the replacement fan.

Step 0610-012

You removed a fan/power supply pair and the circuit breaker still trips.

1. Reinstall the fan/power supply pair.
 - If you have tested all fan/power supply pairs, go to "Step 0610-013".
2. Remove the next fan/power supply pair.
3. Return to "Step 0610-005" on page 1-14 and test the next fan/power supply pair.

Step 0610-013

You tested (by removal and replacement) **all** fan/power supply pairs and the circuit breaker still trips.

1. Remove the switch supervisor card.
2. Check the circuit breaker.
3. Does the circuit breaker still trip?
 - If yes, reinstall the switch supervisor card and go to "Step 0610-014".
 - If no, replace the switch supervisor card and return to "Step 0610-004" on page 1-14 to verify fix.

Step 0610-014

You removed the switch supervisor card but the circuit breaker still trips.

1. Remove all interposer cards to isolate.
2. Check the circuit breaker.
3. Does the circuit breaker trip?
 - If yes, go to "Step 0610-017" on page 1-16.
 - If no, go to "Step 0610-015".

Step 0610-015

1. Reinstall the interposer cards one at a time.
2. Does the circuit breaker trip?
 - If yes, **replace** the interposer and return to beginning of this step to test the replacement interposer.
 - If no, go to "Step 0610-016".

Step 0610-016

1. **Reinstall** the next interposer card.
2. Return to "Step 0610-015" and check that the circuit breaker does not trip.

Switch power (MAP 0610)

3. If **all** interposers have been tested, go to “Step 0610-004” on page 1-14.

Step 0610-017

You tested **all** interposers and the circuit breaker still trips.

1. Replace the circuit breaker assembly.
2. Check the circuit breaker.
3. Does the circuit breaker still trip?
 - If yes, go to “Step 0610-018”.
 - If no, return to “Step 0610-004” on page 1-14 to verify fix.

Step 0610-018

You replaced the circuit breaker assembly but the circuit breaker still trips.

1. Replace the switch planar.
2. Return to “Step 0610-004” on page 1-14 to verify fix.

Note: If replacing the switch planar does not correct this problem (verify fix fails), call the next level of support.

Step 0610-019

The switch circuit breaker is in the On position, the input power cable connections appear good, and the green switch supervisor LED is Off.

1. Replace the switch supervisor card.
2. Are both the green switch supervisor and front panel power LEDs On?
 - If yes, go to Switch function (MAP 0620), “Step 0620-021” on page 1-27 and return the switch to the active configuration.
 - If no:
 - If both the green switch supervisor **and** front panel power LEDs are Off, go to “Step 0610-023” on page 1-17.
 - If the front panel power LED is Off **but** the green switch supervisor LED is On, go to “Step 0610-020”.

Step 0610-020

The front panel power LED is Off, **but** the green switch supervisor LED is On.

1. Replace the switch's LED bracket assembly.
2. Is the front panel power LED On?
 - If yes, go to Switch function (MAP 0620), “Step 0620-021” on page 1-27 and return the switch to the active configuration.
 - If no:
 - a. Call the next level of support.
 - You may be advised to replace the LED power extension cable and, if needed, the switch planar.
 - b. If advised to proceed, go to “Step 0610-021”.

Step 0610-021

The switch's front panel power LED remained Off after you replaced the LED bracket assembly **and** you were advised to continue troubleshooting.

1. Replace the LED power extension cable.
2. Is the front panel power LED On?
 - If yes, go to Switch function (MAP 0620), “Step 0620-021” on page 1-27 and return the switch to the active configuration.
 - If no, go to “Step 0610-022” on page 1-17.

Step 0610-022

The switch's front panel power LED remained Off after replacing the LED power extension cable.

1. Replace the switch planar.
 - Refer to "Removing the switch planar" on page 4-7 and "Replacing the switch planar" on page 4-8
2. Is the front panel power LED On?
 - If yes, go to Switch function (MAP 0620), "Step 0620-021" on page 1-27 and return the switch to the active configuration.
 - If no, call the next level of support.

Step 0610-023

The switch supervisor card was replaced and both the switch front panel and green switch supervisor LEDs remain Off.

1. Replace the switch's circuit breaker assembly.
2. Are both power LEDs On?
 - If yes, go to Switch function (MAP 0620), "Step 0620-021" on page 1-27 and return the switch to the active configuration.
 - If no, go to "Step 0610-024".

Step 0610-024

The switch's circuit breaker assembly was replaced and both the switch front panel and green switch supervisor LEDs remain Off.

1. Replace the switch planar.
2. Are both power LEDs On?
 - If yes, go to Switch function (MAP 0620), "Step 0620-021" on page 1-27 and return the switch to the active configuration.
 - If no, call the next level of support.

Switch function (MAP 0620)

Purpose of this MAP

This MAP provides diagnostic information for problems related to the SP Switch2 function.

Notes:

1. Refer to "Appendix A" in *RS/6000 SP: Installation and Relocation* for frame-to-frame or switch-to-switch cables. Logical frame to physical frame translation information can also be found in this appendix.
2. Refer to "Service position procedures" on page 3-10 for placing or removing the switch into or from service position.

Step 0620-001

A message in Perspectives indicated that you have a switch function problem and Table 1-1 on page 1-5 directed you to this MAP.

1. To complete the following procedures, you will need to have primary node root access. (Customer may enter root password when required.)
2. If either of the following two conditions is true:
 - **Estart** has not been run by the customer
 - The CE has already replaced components that might affect the switch.

Then from the control workstation, enter:

Estart

Switch Function (MAP 0620)

You should receive a message indicating successful initialization. If you receive any other message, consult the "Diagnosing SP Switch2 Problems" section of *Parallel System Support Programs for AIX: Diagnosis Guide* (GA22-7350).

- Determine the primary node number. From an AIX window on the control workstation, enter:
Eprimary
- Determine the host name for this node by checking "reliable_hostname" for the node number with the command:
splstdata -n | pg
- Log into primary node as root using the **telnet** command:
telnet PrimaryNodename
- Check both **errpt -a -N Worm | pg** and **errpt -a -N css0 | pg** for any switch related problems. If any errors are listed, use the error information, with this MAP, to help isolate the problem.
- Check the functional state of the switch in the **out.top** file by issuing the following command on the primary node:
pg /var/adm/SPIlogs/css0/p0/out.top

Notes:

- Verify that the timestamp on the **out.top** file is current (using **ls -l /var/adm/SPIlogs/css0/p0/out.top**).
 - Refer to "Starting a service call (MAP 0100)" in *RS/6000 SP: System Service Guide* for information on using the **pg** command.
- Problems are indicated at the end of a text line by the following sequence:
 `-# ErrorMessage`

–OR–

`# ErrorMessage`

Error message example:

```
s 13 2 s 23 2 E01-S17-BH-J4 to E02-S17-BH-J4    2 L: initialized (link is not operational - link failed to time)
```

For a detailed interpretation of these error messages, refer to the out.top information in *Parallel System Support Programs for AIX: Diagnosis Guide* (GA22-7350).

- Does **/var/adm/SPIlogs/css0/p0/out.top** file report any problems?
 - If yes, use the SPS2 Error Conditions table (Table 1-6 on page 1-19) to continue service.
 - If no, go to "Step 0620-002".

Step 0620-002

No functional problems found.

- Have you replaced any components or fixed problems?
 - If yes:
 - You have resolved the switch problem.
 - Go to "End of call (MAP 0650)" in *RS/6000 SP: System Service Guide*.
 - If no, go to "Step 0620-003".

Step 0620-003

You did not find any functional problems and you did not fix or replace anything.

- Did **Estart** command start okay?
 - If yes, call the next level of support.
 - If no:
 - Consult the "Diagnosing Switch Problems" section of *Parallel System Support Programs for AIX: Diagnosis Guide* (GA22-7350).

b. Return to "Step 0620-001" on page 1-17.

Table 1-6. SP Switch2 error conditions

Error #	Device Message	Link Message	Description and Action
2	Initialized	N/A	<p>Description: Initialization detected a wrapped port where a processor node was expected (this may result from isolation procedures), or else a disconnected cable.</p> <p>Action:</p> <ol style="list-style-type: none"> 1. If this is an unexpected condition, check cabling against the configuration file var/adm/SPIogs/cssX/p0/out.top (where X=0 or 1) and review the appropriate miswire file, var/adm/SPIogs/cssX/p0/cable_miswire (where X=0 or 1). 2. If the processor node can be reconnected, remove the wrap plug and connect the data cable between the switch assembly and the processor node. 3. If the processor node is to be permanently removed, have the customer update the switch topology. 4. If problem is on board connection, as indicated by out.top or Estart_sw: "0028-331 Note: 1 switch to switch links did not initialize. Switch performance may be affected." Run the switch wrap-test described in "Running diagnostics on a switch port" on page 3-12. 5. Repeat "Step 0620-001" on page 1-17 for next problem or go to "Step 0620-021" on page 1-27 to verify fix.

Switch Function (MAP 0620)

Table 1-6. SP Switch2 error conditions (continued)

Error #	Device Message	Link Message	Description and Action
0	Uninitialized	Uninitialized	<p>Description: Switch adapter has not been initialized. Processor node may not recognize adapter due to hardware failure or bad software configuration.</p> <p>Action:</p> <ol style="list-style-type: none"> If there are any other errors in the /var/adm/SPIogs/css0/p0/out.top file on the primary node, address those errors first. <p>Note: If the problem is on all nodes in the frame, check for any hardware problems with the switch assembly. Also check for switch-to-switch problems on all jacks of the switch assembly.</p> If all the nodes are uninitialized except for the primary node, verify that the primary node is connected to the correct port. Have customer verify that the correct switch software is installed and running on the problem node. rc.switch starts the fault_service_Worm_RTG_CS daemon. <p>Note:</p> <ul style="list-style-type: none"> If the daemon starts, go to 6 If the daemon does not start, go to 4 When working with a two-plane SP Switch2 system, add the adapter name to the command, as follows: rc.switch -a <adapter_name> If you: <ul style="list-style-type: none"> Are not certain that the problem is hardware related, go to the <i>Parallel System Support Programs for AIX: Diagnosis Guide (GA22-7350)</i> Are certain that you have a hardware problem, go to 5 If you get no result, try swapping in another switch adapter. Repeat step 3. If you get a result, the problem is probably resolved; repeat "Step 0620-001" on page 1-17 for next problem or go to "Step 0620-021" on page 1-27 to verify fix. The problem is probably the switch assembly. Go to "Step 0620-004" on page 1-22.
-1	N/A	Link is not operational Link is retiming	<p>Description: Possible hardware problem.</p> <p>Action: Go to "Step 0620-004" on page 1-22.</p>
-2	N/A	Wrap plug is installed	<p>Description: Initialization detected a wrap plug or cable rather than the expected cabling.</p> <p>Action: Repeat "Step 0620-001" on page 1-17 for next problem or go to "Step 0620-021" on page 1-27 to verify fix.</p>
-3	Device has been removed from network because of a bad signature	Link is not operational Link failed to time	<p>Description: Possible hardware problem.</p> <p>Action: Go to "Step 0620-004" on page 1-22.</p>

Table 1-6. SP Switch2 error conditions (continued)

Error #	Device Message	Link Message	Description and Action
-4	Device has been removed from network, faulty	Link has been removed from network or miswire, faulty	<p>Description: Switch network not wired as specified in switch topology or problem with connection between switch and device.</p> <p>Note: You may get this error number for a jack which could connect to a node, but instead has a wrap plug. In this case, this message is a warning only and can be ignored.</p> <p>Action:</p> <ol style="list-style-type: none"> 1. Check the cable_miswire file in var/adm/SPIlogs/cssX/p0 (where X=0 or 1) and rewire the cable as needed. 2. If the cabling does not match, correct the cabling problem, then go to step 5 below. 3. If this occurs on all nodes of a frame, check for a logical-to-physical frame number mismatch. 4. If there is a mismatch, have the customer update the configuration, or you can correct the cabling, as appropriate. 5. Go to "Step 0620-004" on page 1-22.
-5	Device has been removed from network by system administrator	Link has been removed from network by system administrator	<p>Description: Node was fenced from the network.</p> <p>Action: run Eunfence for the node.</p>
-6	Device has been removed from network, no AUTOJOIN	Link has been removed from network, no AUTOJOIN	<p>Description: AUTOJOIN was not selected for node during removal.</p> <p>Action:</p> <ol style="list-style-type: none"> 1. If there is an obvious problem, like node powered off or disconnected, fix that problem first. Then issue Eunfence for this processor node. 2. If problem was resolved, repeat "Step 0620-001" on page 1-17 for next problem or go to "Step 0620-021" on page 1-27 to verify fix. 3. If problem was not resolved, go to "Step 0620-004" on page 1-22.
-7	Device has been removed from network for not responding	Link has been removed from network, fenced	<p>Description: Possible hardware problem.</p> <p>Action: Go to "Step 0620-004" on page 1-22.</p>
-8	Device has been removed from network because of a miswire	Link has been removed from network, probable miswire	<p>Description: Initialization of this link detected a different switch node number than the one expected.</p> <p>Action:</p> <ol style="list-style-type: none"> 1. Check the cable_miswire file in var/adm/SPIlogs/cssX/p0 (where X=0 or 1) and rewire the cable as needed. 2. If the cabling does not match, correct the cabling problem, then go to step 5. 3. If this occurs on all nodes of a frame, check for a logical-to-physical frame number mismatch. 4. Have the customer update the configuration, or you can correct the cabling, as appropriate. 5. Repeat "Step 0620-001" on page 1-17 for next problem or go to "Step 0620-021" on page 1-27 to verify fix.

Switch Function (MAP 0620)

Table 1-6. SP Switch2 error conditions (continued)

Error #	Device Message	Link Message	Description and Action
-9	Destination not reachable	Link has been removed from network, not connected	Description: Possible hardware problem. Action: Go to "Step 0620-004".

Step 0620-004

You were directed here by an Error Condition listed in Table 1-6 on page 1-19 which lists functional problems reported in `/var/adm/SPIlogs/css0/p0/out.top` file. This file lists all switch data connections with comment lines indicating the various types.

1. Check the entire `/var/adm/SPIlogs/css0/p0/out.top` file for errors before proceeding to the prioritized table.
2. Use the following prioritized table to service problems reported in the `/var/adm/SPIlogs/css0/p0/out.top` file. The messages are from comment lines preceding the error.

Notes:

- a. Be aware that wrap plugs or terminators used in the following steps can potentially fail; therefore, exercise caution before performing major replacements to make sure that a diagnostic wrap plug or terminator is not faulty.
- b. Where applicable, frame and switch assembly jack numbers are indicated on each line of the `out.top` file. (Refer to "Format structure" on page 2-1 for more information on the nomenclature.)

For example:

E02-S17-BH-J18

Identifies the switch in frame 2, slot 17 using bulkhead jack 18

E02-N05

Identifies node in frame 2, slot 5

E06-S02-BH-J3

Identifies multi-switch frame 6, slot 2, BH-J3

Refer to notes at beginning of "Switch function (MAP 0620)" on page 1-17 for more information on cable connections and logical-to-physical frame translations.

Table 1-7. Problem from the `out.top` file

Priority	Condition	Action
1 (1 of 5)	<ul style="list-style-type: none"> • Primary node connection • Node connections on same switch as primary node 	Go to "Step 0620-005" on page 1-23 to check "primary" or "secondary" processor node connection
2 (2 of 5)	On board connections	Go to "Step 0620-020" on page 1-27 to replace the switch assembly
3 (3 of 5)	Node connections not on same switch as primary node	Go to "Step 0620-005" on page 1-23 to check "secondary" processor node connection
4 (4 of 5)	<ul style="list-style-type: none"> • Frame # to frame # • Switch # to switch # • Switch connections 	Go to "Step 0620-017" on page 1-26 to check the external switch connection
5 (5 of 5)	All problems in <code>/var/adm/SPIlogs/css0/p0/out.top</code> file have been addressed	Go to "Step 0620-021" on page 1-27

Step 0620-005

The `/var/adm/SPIogs/css0/p0/out.top` file indicates a problem with a “Primary node” or “Secondary node” connection.

1. Open frame rear cover and check the cable connection from the indicated switch assembly jack to the processor node.
2. Is there a cable connected to the indicated jack on the switch assembly?
 - If yes, go to “Step 0620-008”.
 - If no, go to “Step 0620-006”.

Step 0620-006

No cable connected at the indicated interposer on the switch assembly (refer to the tables in “Switch data cables” on page 2-11).

1. Should there be a cable connecting the indicated interposer to a processor node?
 - If yes:
 - a. Connect a switch data cable from this interposer to the proper processor node.
 - b. Go to “Step 0620-021” on page 1-27.
 - If no, go to “Step 0620-007”.

Step 0620-007

A switch cable is not required on the indicated interposer.

1. Have customer check the switch configuration file to see if an interposer is required in that slot:
 - Use the **Etopology** command.
2. Did you just correct the switch configuration?
 - If yes, go to “Step 0620-021” on page 1-27.
 - If no, go to “Step 0620-020” on page 1-27 to service or replace the switch assembly.

Step 0620-008

You have a switch cable connected to the indicated interposer on the switch assembly.

1. Check cable connection at switch assembly and processor node.
2. Does the cable appear to be fully connected at the switch assembly and the processor node?
 - If yes, go to “Step 0620-009”.
 - If no:
 - a. Fix the cable connection problem.
 - b. Go to “Step 0620-021” on page 1-27.

Step 0620-009

The cable appears to be fully connected at both the switch assembly and at the processor node.

1. From the front of the RS/6000 SP frame or from the control workstation, check the Power (green) LED on the processor node to make sure it is lit.
2. Is the Power (green) LED lit, indicating the processor node is powered on?
 - If yes, go to “Step 0620-011” on page 1-24.
 - If no, go to “Step 0620-010”.

Step 0620-010

The processor must be powered on for the switch to recognize the port.

1. Power on this processor node, and check the Power (green) LED.
2. Does the Power (green) LED stay lit, indicating the processor node is powered on?
 - If yes, go to “Step 0620-021” on page 1-27.
 - If no:
 - a. The processor node has a power problem.

Switch Function (MAP 0620)

- b. Go to "Processor node diagnostics and descriptions (MAP 0130)" in *RS/6000 SP: System Service Guide* to fix problem.

Step 0620-011

The Power (green) LED is lit, indicating the processor node is powered on.

1. Run advanced diagnostics in service mode on device "cssX" (where X=0 or 1) on this processor node and its associated switch port. Refer to:

- "Running diagnostics on a switch port" on page 3-12.
- "Running diagnostics in a processor node" in *RS/6000 SP: System Service Guide*

Notes:

- a. Advanced cable wrap tests will not run successfully for 10-, 15-, and 20-meter SP Switch2 data cables. If these data cables are used, swap or change the suspected cable.
 - b. Advanced "cssX" (where X=0 or 1) diagnostics will require a male and a female wrap plug to perform the card wrap and cable wrap tests. When testing the SP Switch2 adapter, the cable associated with the male and female wrap plugs included in the ship group must be used to perform card diagnostics (refer to *RS/6000 SP: System Service Guide*).
 - c. If unable to run diagnostics, make certain the adapter is configured correctly.
 - d. If the adapter is configured correctly and diagnostics fail, replace the card.
2. Do you get a Service Request Number (SRN) from "cssX" (where X=0 or 1) diagnostics?
 - If yes:
 - a. An SRN was obtained from diagnostics.
 - b. Use the following SRN table (Table 1-8) to continue service.
 - c. After using Table 1-8, go to "Step 0620-012" on page 1-25.
 - If no:
 - a. The diagnostics did not detect a problem, therefore the problem is in switch assembly.
 - b. Go to "Step 0620-020" on page 1-27.

Table 1-8. Service Request Numbers (SRNs) for SP Switch2 adapters

Service Request Number	SRN Source	Failing Component	Description	Notes
765-x1xx	D	SP Switch2 adapter software	Software problem, probably due to bad installation. Note: Reinstall the software. If SRN does not clear, contact next level of support.	If the fifth digit (y) = 1, troubleshoot the adapter software first.
765-1yx6	D	Switch cable	Wrap test failed. Problem caused by bad switch cable.	1
765-2yx1	D	SP Switch2 adapter	RDRAM test failed	1
765-2yx2	D	SP Switch2 adapter	RDRAM Controller test failed	1
765-2yx3	D	SP Switch2 adapter	SRAM test failed	1
765-2yx4	D	SP Switch2 adapter	SRAM Controller test failed	1
765-2yx5	D	SP Switch2 adapter	DMA test failed	1
765-2yx6	D	SP Switch2 adapter	WRAP test failed.	1
765-2yx7	D	SP Switch2 adapter	Registers test failed.	1
765-2yx8	D	SP Switch2 adapter	740 access test failed.	1
765-2yx9	D	SP Switch2 adapter	Reassembly test failed.	1
765-2yxA	D	SP Switch2 adapter	Segmentation test failed.	1
765-2yxB	D	SP Switch2 adapter	Interrupts adapter.	1

Table 1-8. Service Request Numbers (SRNs) for SP Switch2 adapters (continued)

Service Request Number	SRN Source	Failing Component	Description	Notes
<p>Notes:</p> <ol style="list-style-type: none"> If y = 1 in these SRNs, you must troubleshoot the SP Switch2 adapter software (SRN 765-x1xx) before you follow procedures related to a hardware item. x may be any digit. 				

Step 0620-012

An SRN was obtained and Table 1-8 on page 1-24 was used to determine the list of possible failing components.

- From the list of possible failing components, use the following prioritized table (Table 1-9) to perform service.

Table 1-9. Switch Problem Priority Listing

Priority	Failing Component	Action
1 (1 of 6)	Software	<ol style="list-style-type: none"> Have customer verify that the software is configured and operating correctly for this processor node/system. If no problem is found, continue with next highest priority item in the list for this SRN. Otherwise, power off this processor node and continue service at "Step 0620-013".
2 (2 of 6)	Data cable	<ol style="list-style-type: none"> Check to see if a switch cable is connected at switch adapter of this processor node. Reseat switch data cable at switch adapter of this processor node. Run advanced diagnostics on the device "cssX" (where X=0 or 1) and its associated switch port. If diagnostics fail with the previous SRN, replace switch data cable. Continue service at "Step 0620-014" on page 1-26.
3 (3 of 6)	SP Switch2 adapter	<ol style="list-style-type: none"> Replace the switch adapter card on this processor node. Reconnect all cables to the processor node. Continue service at "Step 0620-014" on page 1-26.
4 (4 of 6)	System or I/O planar	<ol style="list-style-type: none"> Run advanced diagnostics on the "Base System" or I/O planar. If a problem is detected, use SRN to service. Replace the system or I/O planar on this processor node. Make sure to reinstall all parts and cables. Reconnect all cables to the processor node. Continue service at "Step 0620-014" on page 1-26.
5 (5 of 6)	Wrap plug or Terminator	Check the wrap plug or terminator again to make sure that it is not at fault.
6 (6 of 6)	All components replaced.	Call next level of support.

Step 0620-013

An SRN listed in Table 1-8 on page 1-24 indicated that you have a software problem and Priority 1 in Table 1-9 directed you to this step.

Switch Function (MAP 0620)

1. From the node front panel on the control workstation, put the node in the SERVICE mode.
2. Power-on this processor node.
3. Go to "Step 0620-014".

Step 0620-014

At this point, you must run the advanced diagnostics in service mode on the device "cssX" (where X=0 or 1) and its associated switch port.

1. Did you get an SRN from the diagnostics?
 - If yes, go to "Step 0620-016".
 - If no, go to "Step 0620-015".

Step 0620-015

Since the diagnostics did not return an SRN, no problem was detected.

1. Have you just reseated, repaired, or replaced a component?
 - If yes, go to "Step 0620-021" on page 1-27 to verify fix.
 - If no:
 - a. Problem is in the switch assembly.
 - b. Go to "Step 0620-020" on page 1-27 to service or replace switch assembly.

Step 0620-016

The advanced diagnostics returned an SRN indicating that the diagnostics detected a problem.

1. Is this SRN the same as the previous SRN?
 - If yes, go to "Step 0620-011" on page 1-24 to perform service on the next highest priority component in the list for this SRN.
 - If no, go to "Step 0620-012" on page 1-25 to service the new SRN.

Step 0620-017

An error message in the `/var/adm/SPIlogs/css0/p0/out.top` file indicated that you either have an external switch connection problem. Priority 3 in Table 1-7 on page 1-22 directed you to this step.

1. Check the specified jacks at rear of switch assemblies for an obvious problem such as a loose connection.
2. Pay special attention to cables that may have been moved recently.
3. Do connections appear to be okay?
 - If yes, go to "Step 0620-018".
 - If no:
 - a. Fix the obvious connection problem.
 - b. Go to "Step 0620-021" on page 1-27 to verify fix.

Step 0620-018

The `/var/adm/SPIlogs/css0/p0/out.top` file indicated a switch problem and all connection appeared to be okay.

Note: Be aware that in large systems, connections for switch assemblies not in the multi-switch frame are usually scattered throughout the `out.top` file.

1. If this is a **multi-frame system**, check the indicated interposers against the wiring charts for multi-frame switch systems.
2. Is this a multi-frame system with problems reported on all switch data cables from one or more switches?
 - If yes:
 - a. Determine if a power or environmental problem exists on that switch.
 - b. Go to "Step 0590-003" on page 1-4.

- If no, go to “Step 0620-019”.

Step 0620-019

Some but not all switch data cables appear to be having problems.

1. Depending on whether the problem is a **wrapped port** or a **switch-to-switch** connection, perform one of the following steps:
 - **Wrapped port** (wrap plug installed): Remove the existing wrap plug. Install a different wrap plug on the interposers indicated.
 - **Switch-to-switch** connection: Disconnect the switch data cable from both ports indicated. Install wrap plugs on the interposers indicated.

Note: When unplugging the two ends of the suspect cable, check `/var/adm/SPIlogs/css0/p0/out.top` to verify only two (2) ports were lost. If four (4) ports were lost, then two cables were swapped across that switch to switch connection. Connect the cables correctly and check `/var/adm/SPIlogs/css0/p0/out.top` for any other errors.

2. Make sure processor nodes that were put in “Service” mode are returned to “Normal” mode. Make sure all processor nodes are IPLed completely.
3. Have customer verify that the switch code is running on all processor nodes.
4. From the control workstation, type **Estart** followed by **ENTER**.
5. Check `/var/adm/SPIlogs/css0/p0/out.top` file for problems regarding the interposers indicated.
6. Does **out.top** file show a problem on any interposers indicated?
 - If yes:
 - a. Problem is in the switch assembly which is still reporting a problem.
 - b. Go to “Step 0620-020” to service or replace the switch assembly.
 - If no:
 - a. If this is a **switch-to-switch** connection, remove both wrap plugs from the switch assemblies.
 - b. Replace the frame-to-frame switch data cable that was disconnected before.
 - c. Go to “Step 0620-021” to verify fix.

Step 0620-020

You have determined that there is a problem in the switch assembly and that you need to replace the switch assembly.

Note: Before taking this action, contact the next level of support. They will be able to advise you about system availability options that may allow the customer to continue operating.

1. Replace the switch planar.
 - Refer to “Removing the switch planar” on page 4-7 and “Replacing the switch planar” on page 4-8
2. Go to “Step 0620-021”.

Step 0620-021

You have replaced switch components and need to verify that the problem has been fixed.

1. Make sure any processor nodes that were put in **SERVICE** mode are returned to **NORMAL** mode. Make sure all processor nodes are IPLed completely in **NORMAL** mode.
2. If any processor nodes lost connection to the switch due to unplugging node data cable, you will need to include them in the following command. From the control workstation, enter:

```
dsh -w nodelist /usr/lpp/ssp/css/rc.switch
```

where *nodelist* is a list of node names separated by commas.

Note: When working with a two-plane SP Switch2 system, add the adapter name to the command, as follows: `dsh -w nodelist /usr/lpp/ssp/css/rc.switch -a <adapter_name>`
OR, if all processor nodes have lost switch connection, enter:

Switch Function (MAP 0620)

```
dsh -a /usr/lpp/ssp/css/rc.switch
```

Note: When working with a two-plane SP Switch2 system, add the adapter name to the command, as follows: **dsh -a /usr/lpp/ssp/css/rc.switch -a <adapter_name>**

Example:

```
dsh -w fr2n03,fr2n04,fr3n01 /usr/lpp/ssp/css/rc.switch
```

Attention: Issuing this command on processor nodes that did *not* lose a connection may cause unpredictable results.

3. Have customer start the switch code from the control workstation by entering:
Estart
4. Check **/var/adm/SPlogs/css0/p0/out.top** file on the primary node.
5. Go to "Step 0620-001" on page 1-17 to verify that there are no other switch problems.

Chapter 2. Locations

Naming standard for RS/6000 SP components	2-1
Format structure	2-1
Example of format structure	2-1
Frame (WWW)	2-1
Major assembly (XXX)	2-2
Sub-assembly (YY)	2-2
Connection location (ZZZZ)	2-2
Examples for using complete levels of nomenclature	2-2
Location diagrams of the RS/6000 SP components.	2-2
Front and rear views of RS/6000 SP frame.	2-3
Frame locations.	2-5
Frame (FRA)	2-5
Switch assembly locations	2-7
Connector details	2-7
Cable routing.	2-8
Cable routing in a multi-switch frame (F/C 2032)	2-10
Switch data cables	2-11
SP Switch2 data cables	2-11

Naming standard for RS/6000 SP components

The purpose of this section is to define a naming standard for all components in the RS/6000 SP system. This standard provides a consistent, logical naming convention system necessary for documentation including details, assembly drawings, schematics, manufacturing documents, service documents, and customer publications.

Format structure

The RS/6000 SP system is structured in a modular fashion with different levels of assembly which can be independently described. These levels are:

1. System level
2. Frame level
3. Major assembly level (e.g. processor node).
4. Sub-Assembly level (e.g. cards, fan assembly).

The format structure is used to individually identify any connection location at any level in the assembly. The main use of this format is to describe connector, cabling, and schematic locations shown in tables and diagrams throughout this manual.

Example of format structure

Format: FRAME(WWW) - MAJOR ASSEMBLY(XXX) - SUBASSEMBLY(YY) - CONNECTOR NUMBER (ZZZZ)

Frame (WWW)

- 1st character is the frame type:
 - E for RS/6000 SP frame
 - L for logical RS/6000 SP frame (used for models 30X and 40X)
 - S for multi-switch frame
 - C for control workstation
 - Z for another frame such as a server
- 2nd and 3rd characters are the frame number:
 - 00 for any/all frames (designates location inside any/all frames)

- 01 - 99 for frames 1-99 (specific to that frame)

Notes:

1. E01 designates RS/6000 SP physical frame 1
2. L00 designates any/all RS/6000 SP logical frames
3. S00 designates any/all RS/6000 SP multi-switch frames
4. For locations inside a frame, the Frame (WWW) and/or Major Assembly (XXX) strings may be omitted, making the format YY-ZZZ

Major assembly (XXX)

- 1st character is the major assembly type (all three characters if the assembly occurs only once in a frame):
 - N for processor node assembly
 - S for switch assembly
 - PDU for frame power supply assembly
 - ADC for ac/dc Converter assembly
 - FRA for frame
- 2nd and 3rd characters are the major assembly number:
 - 00 for any/all major assemblies (designates location inside any/all major assemblies)
 - 01 - 99 for major assembly 1-99 (specific to that major assembly)

Sub-assembly (YY)

1st and 2nd characters are the assembly designation inside the major assembly. (This string may be omitted in some cases.)

Refer to the lists of two-character designations associated with each major assembly throughout this chapter.

Example: SC denotes a switch card.

Connection location (ZZZZ)

- 1st character is the connection type:
 - P for plug (cable side)
 - J for jack (card/component side)
 - G for chassis ground connection
- 2nd, 3rd, and 4th characters are number identifiers. Leading zeroes may be omitted.

Example: P102 is plug 102

Examples for using complete levels of nomenclature

To describe the jack 23 on the switch assembly bulkhead in the second RS/6000 SP frame in a four-frame configuration, designate as:

E02-S01-BH-J23

To describe plug 1 on the power card of the any switch assembly of any RS/6000 SP frame in any size system configuration, designate as:

E00-S00-PC-P1 or just PC-P1

Location diagrams of the RS/6000 SP components

See Figure 2-1 on page 2-3, Figure 2-2 on page 2-4, and Figure 2-3 on page 2-5, in the pages that follow, for views of the RS/6000 SP frame locations. Refer to the diagrams included in this section for specific views and cabling of the main component sections in the RS/6000 SP frame.

Front and rear views of RS/6000 SP frame

Figure 2-1 shows a front view of the RS/6000 SP frame locations. "Frame (FRA)" on page 2-5 describes the assembly designations for the RS/6000 SP frame.

SP Frame locations (2.01 m and 1.93 m frames) - front view





Figure 2-1. Front view of frame locations. See notes below.

Figure notes:

1. Frames equipped with the SP Redundant Power Supply must have four power modules (books) installed in the SEPBU.
2. Wide processor nodes take up an entire shelf position (two thin processor node slots). They are identified by the odd numbered position.
3. In a F/C 2032 frame, switch assemblies take up an entire shelf partition. (They are identified by the even-numbered position.)
4. Processor node slots are numbered up to N16.
5. An SMP High Node takes up 2 shelf positions (slots). It is identified by the least odd number position of the occupied slots.

Figure 2-2 shows a front view of the RS/6000 SP multi-switch frame.



(Front Cover and Skirt, and Air Filter Removed)

Figure 2-2. Front view of multi-switch frame locations

Figure 2-3 on page 2-5 shows a rear view of the RS/6000 SP frame locations.

SP Frame Locations - Rear View




Figure 2-3. Rear view of frame locations

Note: See notes under Figure 2-1 on page 2-3 for processor node/switch assembly numbering.

Frame locations

Figure 2-1 on page 2-3 shows a front view of the RS/6000 SP frame locations, with numbered processor nodes, and the three phase SEPBU.

Frame (FRA)

This list shows the designations specifically for the RS/6000 SP frame:

- G1:** Right-hand rear ground
- G2:** Left-hand rear ground
- G3:** PDU ac ground
- G4:** PDU dc ground
- G5:** Input cable ground

- G6:** Front door ground
- G7:** Rear door ground
- G8:** Ground
- SW:** Power-on switch
- LD:** LED card
- FC:** Front cover
- RC:** Rear cover

Example: E01-FRA-G1

Switch assembly locations




Figure 2-4. SP Switch2 high level planar view

Connector details

Figure 2-5 on page 2-8 shows RS/6000 SP component connector details.




Figure 2-5. RS/6000 SP connector details (as seen at receiving ends, not at cable ends)

Cable routing

Figure 2-6 on page 2-9 and Figure 2-7 on page 2-9 show back views of the RS/6000 SP frame, showing the horizontal and vertical paths of cable routing from connector-to-connector, with the depth amplified on the drawing.

Note: When attaching exterior and interior cables to a POWER3 SMP High Node allow for enough cable for a 2-foot service loop for node movement into service position.




Figure 2-6. Frame cabling routing path in rear of RS/6000 SP frame — 1.93 m frame




Figure 2-7. Frame cabling routing path in rear of RS/6000 SP frame — 2.01 m frame

Note: For a multi-switch frame (F/C 2032), refer to Figure 2-6.

Table 2-1 on page 2-10 shows external cable routing in a RS/6000 SP frame populated with 16 processor nodes. (Refer to “Cable routing” on page 2-8 to see the routing paths.)

Table 2-1. External cable routing

Slot Number (Node)	Cable Budget millimeters (inches)	Frame Entrance (New Style)	Frame Entrance (Old Style)	Vertical Routing (Old Style)	Horizontal Routing (Old Style)
1	1800 (71)	E3	E1	V4	H3
2	1500 (59)	E3	E1	V4	H3
3	1680 (66)	E3	E2	V5	H4
4	1980 (78)	E3	E2	V5	H4
5	2160 (85)	E3	E1	V3	H5
6	1850 (73)	E3	E1	V3	H5
7	2030 (80)	E3	E2	V6	H6
8	2340 (92)	E3	E2	V6	H6
9	2510 (99)	E3	E1	V2	H7
10	2210 (87)	E3	E1	V2	H7
11	2390 (94)	E3	E2	V7	H8
12	2690 (106)	E3	E2	V7	H8
13	2870 (113)	E3	E1	V1	H9
14	2570 (101)	E3	E1	V1	H9
15	2740 (108)	E3	E2	V8	H10
16	3050 (120)	E3	E2	V8	H10

Cable routing in a multi-switch frame (F/C 2032)

Figure 2-8 on page 2-11 shows the back view of the RS/6000 SP multi-switch frame with frame extension, showing the horizontal and vertical paths of cable routing from connector-to-connector. The depths has been amplified on the drawing.




Figure 2-8. Frame cable routing paths in rear of RS/6000 SP multi-switch frame (F/C 2032) — 1.93 m frame

Switch data cables

SP Switch2 data cables

Table 2-2 describes the attachment locations and routing for the internal SP Switch2 data cables.

Table 2-2. SP Switch2 data cable chart

Cable Part Number	Plug from Location	Plug to Location
05N6351	E00-S00-BH-J7	E00-N01-BH-PA
05N6351	E00-S00-BH-J8	E00-N02-BH-PA
05N6351	E00-S00-BH-J26	E00-N03-BH-PA
05N6351	E00-S00-BH-J25	E00-N04-BH-PA
05N6351	E00-S00-BH-J9	E00-N05-BH-PA
05N6351	E00-S00-BH-J10	E00-N06-BH-PA
05N6351	E00-S00-BH-J24	E00-N07-BH-PA
05N6351	E00-S00-BH-J23	E00-N08-BH-PA
05N6351	E00-S00-BH-J31	E00-N09-BH-PA
05N6351	E00-S00-BH-J32	E00-N10-BH-PA
05N6351	E00-S00-BH-J18	E00-N11-BH-PA
05N6351	E00-S00-BH-J17	E00-N12-BH-PA
05N6351	E00-S00-BH-J33	E00-N13-BH-PA
05N6351	E00-S00-BH-J34	E00-N14-BH-PA
05N6351	E00-S00-BH-J16	E00-N15-BH-PA

Table 2-2. SP Switch2 data cable chart (continued)

Cable Part Number	Plug from Location	Plug to Location
05N6351	E00-S00-BH-J15	E00-N16-BH-PA

Notes:

1. "PA" refers to connector on SP Switch2 adapter.
2. Only one cable type is used for all switch locations.

Note: For external frame-to-frame cable locations, see *RS/6000 SP: Installation and Relocation*.

Chapter 3. Service procedures

Personal ESD requirements	3-1
Tools and files overview	3-1
Using the css.snap script	3-3
css.snap file structure	3-4
Files collected by css.snap.	3-4
css.snap file package names	3-6
Disk space handling	3-6
SP Switch2 supervisor self-test	3-6
Self-test Conditions	3-7
Switch supervisor status verification using Perspectives	3-7
Opening a switch pane	3-7
Checking switch status	3-7
Base code verification	3-8
Updating the SP Switch2 supervisor code	3-8
Removing and restoring switch resources	3-9
Removing an SP Switch2 from the active configuration	3-9
Restoring an SP Switch2 to the active configuration	3-9
Using Perspectives to fence and unfence nodes attached to the switch	3-10
Fencing nodes.	3-10
Unfencing nodes	3-10
Service position procedures	3-10
Placing an SP Switch2 into service position	3-10
Replacing an SP Switch2 from service position	3-11
Resetting the clock and bootlist after servicing a node	3-11
Running diagnostics on a switch port	3-12

Attention: Components in the frame are susceptible to damage from static discharge. Always use an ESD wristband when working inside frame covers. (See “Personal ESD requirements” for more details.) Do not touch the pins or circuitry on these components.

Personal ESD requirements

The processor uses FRUs that are known to be sensitive to electrostatic discharge (ESD). To prevent ESD damage to FRUs or to prevent system failures, observe the following procedures:

- Keep the FRU in its original static-dissipative shipping container until the FRU is ready to be installed in the system. Move the static-dissipative container near the location where the FRU is to be installed (within ESD wrist strap distance). If the FRU must be put down for any reason, first place it in its static-dissipative container or place it on the static-dissipative mat.
- Open only the covers that are necessary to complete the task. Any time a cover is open the service representative and all people in the area must be ESD-safe. If power is switched on, or if removing or exchanging any FRU, always use the ESD kit (part 93F2649).
 1. Put on the ESD wrist strap.
 2. Attach the ESD cable to the wrist strap.
 3. Attach the ESD mat to the wrist strap, if required.
 4. Attach the insulated clip to the ESD cable.
 5. Attach the insulated clip to the frame holes labeled **ESD**. If the frame holes are not available, use a grounding point on the frame.

Tools and files overview

The following three tables provide an overview of the tools, setup files, and tuning files used in the service procedures.

Table 3-1. Service procedure tools

Utility	Runs on	Description	Directory
fault_service_Worm_RTG_CS	All nodes	Monitors the switch for faults. It restarts the switch if a fault is detected.	/usr/lpp/ssp/css
css.snap	All nodes, CWS	Collects log, trace, and dump information created by SP Switch2 support code (device driver, worm, fault-service daemon, diagnostics)	/usr/lpp/ssp/css
rc.switch	All nodes	Starts the daemons and IP configuration tools.	/usr/lpp/ssp/css Note: When working with a two-plane SP Switch2 system, add the adapter name to the command, as follows: /usr/lpp/ssp/css/rc.switch -a <adapter_name>
Estart	Primary or Control Node	Tunes the switch and puts in into run phase. Also, kicks off the route table generator and distributes the routes to the nodes, by placing them in the etc/SP directory on the control node.	/usr/lpp/ssp/bin
Eprimary	All nodes	Sets a node as the primary node.	/usr/lpp/ssp/bin
Etopology	All nodes	Stores switch topology information in the System Data Repository for a node or a series of nodes. Also retrieves a topology files out of the SDR.	/usr/lpp/ssp/bin
ifconfig	All nodes	This sets up the IP interface to the switch.	NA (AIX command)

Table 3-2. Setup output files

File	Location	Description	Directory
rc.switch.log	All nodes	Logs all information on the last run of rc.switch . It will indicate if this is a primary or secondary node, the associated switch chip information, and IP address information.	/var/adm/SPIlogs/css
rc.switch.log.previous	All nodes	A copy the previous run of rc.switch .	/var/adm/SPIlogs/css
expected.top.xnsb.yisb.0	All nodes	Used by rc.switch to more easily parse out chip connection information. Where: x = the number of the node switch board y = the number of the intermediate switch board	/etc/SP/
fs_daemon_print.file	All nodes	A log of the daemon	/var/adm/SPIlogs/css0/p0

Table 3-2. Setup output files (continued)

File	Location	Description	Directory
css.snap.log	All nodes	Log files created by the switch support code	/var/adm/SPIlogs/css

Table 3-3. Tuning output files

File	Location	Description	Directory
daemon.stdout	All nodes	Keeps a detailed account of the tuning process initiated by the Estart command. It includes data from every tuning operation since the current daemon on the primary node was initiated.	/var/adm/SPIlogs/css
topology.data	Primary	A record of the primary node, how many nodes were initialized, and the links between them.	/var/adm/SPIlogs/css
daemon.stderr	All nodes	A record of which nodes were not initialized.	/var/adm/SPIlogs/css
out.top	Primary	Reports errors from the last tuning procedure. It begins as a copy of the topology file and errors are indicated to the right of each entry.	/var/adm/SPIlogs/css0/p0
out.top.old	Primary	A copy of out.top from the previous run.	/var/adm/SPIlogs/css0/p0
router.log	Primary	The router log file generated by the route table generator after initialization.	/var/adm/SPIlogs/css0/p0
router.log.old	Primary	A copy of router.log from a previous run.	/var/adm/SPIlogs/css0/p0

Using the **css.snap** script

The **css.snap** script is located in the **/usr/lpp/ssp/css** directory. When the script runs, it collects log, trace, and dump files created by SP Switch2 support code (device driver, worm, fault-service daemon, and diagnostics) into a single compressed package.

Attention: **css.snap** uses a number of undocumented utilities to collect information. Some of these can be destructive when used on a running system. After using **css.snap** to collect diagnostic information, it's best to run **/usr/lpp/ssp/css/rc.switch** in order to reset and reload the switch adapter and eliminate residual effects of these utilities. This procedure should be used only under the direction of the IBM Support Center.

When working with a two-plane SP Switch2 system, add the adapter name to the command, as follows:

```
dsh -a /usr/lpp/ssp/css/rc.switch -a <adapter_name>
```

The **css.snap** script is called whenever a serious error is detected by the switch support code. You can direct the system to create a snapshot by logging into the desired node and manually issuing the command: **/usr/lpp/ssp/css/css.snap** with any of the optional flags: [-c | -n] [-s] [-a cssX (where X=0 or 1)] [-p p0] where:

- **-c** Flushes the adapter cache and prints the result. This is the default.

- **-n** Assumes that the device driver or daemon has flushed the cache.
- **-s** Takes a soft snap, which does not dump the adapter state. This excludes the col_dump.out. This flag is used for temporary errors (TYPE=TEMP) where the integrity of the adapter is in doubt, or when it is not desirable to corrupt the adapter state by the use of diagnostic routines.
- **-a** Specifies a single adapter. When this flag is not used, all the node's configured adapters will be selected. This is the default.
- **-p** Specifies a single port on a specified adapter, hence a specific plane. This option must be used together with the -a option. When this flag is not specified, all the adapter's ports are selected. This is the default.

Collect the **css.snap** information from both the primary node and all nodes that are experiencing SP Switch2 problems. Do not reboot the nodes before running **css.snap**, because rebooting causes the loss of valuable diagnostic information.

css.snap file structure

The files collected by running the **css.snap** script are organized into the following hierarchy of directories:

/var/adm/SPIlogs/css

- Node (global) level log file
- Contains information relevant to all the ports and adapters in the node

/var/adm/SPIlogs/cssX (where X=0 or 1)

- Adapter level log file (the 0 in css0 refers to the adapter id)
- Contains information relevant to all the ports on a specific adapter

/var/adm/SPIlogs/cssX/p0 (where X=0 or 1)

- Port level log file (the 0 in p0 is the port number on the adapter)
- Contains information relevant to a specific port

Files collected by css.snap

The **css.snap** script collects all the files which reside in the **/var/adm/SPIlogs/css** (node level), **/var/adm/SPIlogs/css0** (adapter level), and **/var/adm/SPIlogs/css0/p0** (port level) directories, and some additional files from the **/tmp** directory. Some of the files reside on each node, while others reside only on the primary node or on the control workstation.

Under normal circumstances, the **css.snap** script will collect the following files:

Table 3-4. SP Switch2 log files

Log File	Information Level	File Location	File Contents
adapter.log	adapter	nodes	Adapter status information from the fault service daemon
cable_miswire	port	primary node	Node-to-switch or switch-to-switch plane miswired connection information.
cadd_dump.out	node	nodes	Most recent css.snap 's cadd_dump command dump file. SP Switch2 adapter device driver trace buffer dump file.
chgcss.log	node	nodes	Log file of chgcss , which changes the adapter device driver's attributes.
col_dump.gsd	adapter	nodes	The most recent css.snap 's col_dump command dump file. Microcode dump information.
colad.trace	adapter	nodes	SP Switch2 adapter diagnostics messages.

Table 3-4. SP Switch2 log files (continued)

Log File	Information Level	File Location	File Contents
core	node	nodes	Fault service daemon core dump file.
css.snap.log	node	nodes	css.snap snapshot command log information. Contains a list of all files gathered in the last snapshot.
CSS_test.log	node	nodes	Present if the CSS_test command was run on the node.
daemon.log	node	nodes	Fault service daemon output file.
DeviceDB.dump	port	nodes	Latest dump of the device data base from the fault service daemon.
Ecommands.log	node	control workstation	Log entries of all Ecommands .
emasterd.log	node	control workstation	TOD Management emasterd daemon collected errors and notifications.
emasterd.stdout	node	control workstation	More detailed trace file from TOD Management emasterd daemon.
errpt.out	node	nodes	Most recent errpt -a and errpt results.
flt	port	nodes	Hardware error conditions found on the SP Switch2, recovery action taken by the fault-service daemon, and general operations that alter the SP Switch2 configuration.
fs_daemon_print.file	port	nodes	Fault service daemon port status information.
ifcl_dump.out	adapter	nodes	Most recent css.snap's ifcl_dump command dump file. IP dump information.
logevnt.out	node	nodes	Log error log events monitored by ha .
netstat.out	adapter	nodes	Most recent css.snap's netstat command dump file. Network status information.
odm.out	adapter	nodes	The node's adapter_status configuration as saved in the ODM.
out.top	port	nodes	SP Switch2 plane link information.
rc.switch.log	node	nodes	Fault service daemon initialization information.
rc.switch.log.previous	node	nodes	Node's previous fault service daemon initialization information.
regs.out	adapter	nodes	Most recent css.snap's read_regs command dump file. SP Switch2 adapter's registers dump file.
router.log	port	nodes	SP Switch2 routing information.
scan_out.log	adapter	nodes	TBIC scan ring binary information.
scan_save.log	adapter	nodes	Previous TBIC scan ring binary information.
spd.trace	port	control workstation	Tracing of advanced switch diagnostics.
spdata.out	port	primary node	Most recent css.snap's splstdata command dump file. SP Switch2 data requests.

Table 3-4. SP Switch2 log files (continued)

Log File	Information Level	File Location	File Contents
topology.data	port	primary node	System error messages from the distribution of the topology file to the secondary nodes.
<p>Note: The files ending in .out are produced by running the appropriate command to dump internal (in memory) trace information or dump data to a file. The complete package of output files will be found in /var/adm/SPIlogs/css/.</p>			

css.snap file package names

Once the **css.snap** script creates the package of compressed files, the package file is given a name that varies according to the flags used with the **css.snap** command.

If the -a and -p flags are not used:

The file name is *hostname.yymmddhhmmss.css.snap.tar.Z*

If -a cssX (where X=0 or 1) is used but -p is not specified:

The file name is *hostname.yymmddhhmmss.adapter0.css.snap.tar.Z*

If -a cssX (where X=0 or 1) and -p p0 are both used:

The file name is *hostname.yymmddhhmmss.adapter0.port0.css.snap.tar.Z*

Hostname is the name of the node where the **css.snap** command was issued and *yymmddhhmmss* is the date and time that the information was collected.

Disk space handling

css.snap avoids flooding */var* by following these rules:

- If less than 10% of */var* is free, **css.snap** exits.
- If the CSS portion of */var* is more than 30% of the total space in */var*, **css.snap** erases old snap files until the CSS share sinks below 30%. If successful, **css.snap** proceeds. If not, it exits.

SP Switch2 supervisor self-test

The following procedures will help you perform self-test on the switch supervisor card. Upon completion of this test, return to the procedure that sent you here.

1. Detach supervisor harness from connector at back of the unit. Detaching the supervisor harness removes the 12 volt power from the supervisor card.
2. Reinsert the supervisor harness to perform the supervisor card self-test.
3. Check green and yellow LEDs on the switch supervisor card for the self-test conditions listed below.

Self-test Conditions

??

Pass sequence

1. Both LEDs light for about 10 seconds
2. Both LEDs go off
3. Green LED stays off, while the yellow LED flashes the switch address
4. Yellow LED goes off for about two seconds (green LED stays off)
5. Both LEDs light for about one second
6. Upon self-test completion:
 - Green LED should be on if the self-test was performed with switch power on
 - Green LED should be off if the self-test was performed with switch power off

Fail conditions

- Green and Yellow LEDs never light
- Yellow LED flashes wrong address
- Yellow LED is on steady

Switch supervisor status verification using Perspectives

To verify the switch supervisor status you must click the switch icon located on a Perspectives switch pane.

- If a switch icon **is not** visible, go to "Opening a switch pane"
- If a switch icon **is** visible, go to "Checking switch status"

Opening a switch pane

Unless you have saved display settings, the Hardware Perspective does not open with a switch pane displayed. To open a switch pane from the Hardware Perspectives window:

1. Click the "Add Pane" icon on the tool bar
 - The Add Pane dialog box opens
2. From the "Pane Type" pulldown, select "Frames and Switches"
3. Select your choice of adding the pane to the current window or to a new window
4. If desired, enter a new pane title
5. Click "OK" to open the pane and close the dialog box
6. You may repeat these steps to add additional switch panes

Checking switch status

1. In the Frame and Switch pane, click the icon of the switch you want to verify
 - A switch icon is displayed next to the frame icon **only if** a switch is installed in the frame
2. Click the "Notebook" icon on the tool bar
 - When the Notebook window opens, make certain that the "Switch Status" tab is selected
3. The "Node failure:" attribute displays the status of the **switch** supervisor.
 - "No" displayed in **green** highlight indicates that the switch supervisor **has not failed** and the supervisor is responding to communication from the frame supervisor.
 - "Yes" displayed in **red** highlight indicates that the switch supervisor has failed and it **is not responding** to the frame supervisor.

Note: Clicking "Help" in the Notebook window's lower right corner displays attribute descriptions.

Base code verification

Note: This is **not** a Perspectives function.

Perform the following procedure to check for supervisor conditions that require action.

1. From the control workstation window, enter:

smitty supervisor

2. The following menu is displayed:

- Check For Supervisors That Require Action (Single Message Issued)
- > List Status of Supervisors (Report Form)
- List Status of Supervisors (Matrix Form)
- List Supervisors That Require Action (Report Form)
- List Supervisors That Require Action (Matrix Form)
- Update *ALL* Supervisors That Require Action (Use Most Current Level)
- Update Selectable Supervisors That Require Action (Use Most Current Level)

Select the **second** option, "List Status of Supervisors (Report Form)"

3. A frame, similar to the following example, is displayed:

spsvrmgr:	Frame	Slot	Supervisor State	Media Versions	Installed Version	Required Action
	1	0	Active	u_10.3c.0721 u_10.3c.0723	u_10.3c.0721	Upgrade
		1	Active	u_10.2e.0702 u_10.2e.0704	u_10.2e.0704	None
		5	Active	u_10.2e.0702 u_10.2e.0704	u_10.2e.0704	None
		13	Active	u_90.10.071b u_90.10.071c	u_90.10.071c	None
		14	Active	u_90.10.071b u_90.10.071c	u_90.10.071c	None
		17	Active	u_90.00.070a u_90.00.070c u_90.00.070e	u_90.00.071e	None

Updating the SP Switch2 supervisor code

Note: Neither the SP Switch2 circuit breaker nor the inline switch need to be in the On ('1') position to load new supervisor code.

1. From the control workstation enter:

smitty supervisor

2. Select "List Supervisors That Require Action"
3. Note the frame number and slot number
4. Press PF3 (Cancel).
5. Select "Update Selectable Supervisors That Require Action"
6. Enter the frame number and slot numbers to be updated.

Note: This will take at least 12 minutes to complete.

7. Return to the procedure that directed you here.

Removing and restoring switch resources

This procedure can be performed to allow customer to use a switch feature while extended service actions are performed on an individual frame of a multi-frame system with the switch feature.

DO NOT PERFORM this procedure unless the required service operation will take the switch out of the switch configuration for a minimum of two hours (for example, a part must be ordered or a switch or frame must be repeatedly powered on/off) and/or the customer specifically requests it.

Care should be taken to understand the consequences on any partitions that might be sharing switch resources. See "Using Perspectives to fence and unfence nodes attached to the switch" on page 3-10.

Attention: This procedure is intended to allow the customer to use the switch feature during extended repair action. The customer must stop all parallel jobs prior to starting the repair. Once the repair is complete, the customer must stop all parallel jobs again to reconfigure the switch to include the resource again. If the service action is expected to be complete in a short period of time (for example, two hours or less), this additional interruption of all parallel jobs will probably cost the customer more time than was saved by use of the switch feature during that short period.

Removing an SP Switch2 from the active configuration

1. Identify the switch which is to be removed from the active configuration (see *RS/6000 SP: System Service Guide*).
2. **If the primary processor node (usually in Frame 1) is connected to the switch identified in step 1**, the customer must select an **available** processor node to be the new primary processor node. The primary node is set by the **Eprimary** command. Refer to *Parallel System Support Programs for AIX: Administration Guide (SA22-7348)* for more information.
3. Have customer stop all current parallel jobs and suspend all parallel jobs on the job queue.
4. Put circuit breaker at the rear of switch assembly in the Off ('0') position.
5. The customer can re-initialize the switch using the **Estart** command. The frame and processor nodes which were removed in this procedure will appear in the **out.top** file with error messages; however, the remainder of the switch resources are now available for customer use.
6. If switch re-initialization was successful, the customer can start running parallel jobs again.
7. Return to MAPs to continue service action(s).

Restoring an SP Switch2 to the active configuration

1. Identify the switch to be restored to the active configuration.
2. Have customer stop all current parallel jobs and suspend all parallel jobs on the job queue.
3. Make sure that the circuit breaker at the rear of the switch is in the Off ('0') position.
4. Connect all cables to the switch. Pay attention to the labels on the cables.
5. Put the circuit breaker at the rear of the switch in the On ('1') position.
6. If the primary processor node was changed during the isolation procedure, the customer can change the primary processor node back to the original selection; however, this is NOT required. The primary node is set by the **Eprimary** command. Refer to *Parallel System Support Programs for AIX: Administration Guide (SA22-7348)* for more information.
7. The customer can re-initialize the switch using the **Estart** command. Cables connected to the switch assembly and processor nodes which were restored in this procedure should appear in the **out.top** file without any error messages.
8. If switch re-initialization was successful, the customer can start running parallel jobs again.
9. Return to MAPs to continue service actions.

Using Perspectives to fence and unfence nodes attached to the switch

Fencing nodes

1. Bring up Hardware Perspectives for the system
2. Select the node to be fenced by either:
 - Double clicking the node
 - Opening the node's notebook
3. Select either:
 - Fence
 - Fence with autojoin

Note: Selecting the autojoin option will automatically place the node back into the operations of the partition on successful power on of the Node. It is suggested that "Autojoin" *not* be selected at any time when performing a service action.

4. Click "Apply"

Unfencing nodes

1. Bring up Hardware Perspectives for the system
2. Select the node to be unfenced by either:
 - Double clicking the node
 - Opening the node's notebook
3. Select "Unfence"
4. Click "Apply"

Efence of primary and primary backup nodes

System design does not allow **Efence** of primary and backup nodes by default. However, with the -f option, the primary and primary backup node may be fenced. In this case, a new oncoming primary node or oncoming primary backup node will be selected for you and an **Estart** will be issued. You will need to use the **Eprimary** command after the **Efence** command has completed to see what the new primary and primary backup nodes are.

Service position procedures

Note: When placing a switch into the service position, ensure that the customer has removed the switch from the active configuration.

Placing an SP Switch2 into service position

Note: Make certain the switch has been removed from the active configuration **before** placing the switch into the service position.

1. Place the switch circuit breaker in the Off ('0') position.
2. Set the inline switch on the power cable to the Off ('0') position.
3. At the rear of the switch, remove the power cable from slot J1 and the supervisor cable from slot J2.
4. Record the positions of all switch cables connected to the interposers in slots J3 through J34.
5. Remove the switch cables.
6. Remove the switch mounting screws from the front of the frame.
7. Remove the switch by sliding it out of the front of the frame.

Replacing an SP Switch2 from service position

Note: Make certain the switch has been returned to the active configuration **after** replacing the switch from the service position.

1. Install the switch by sliding it into the front of the frame.
2. Reinstall the screws holding the switch to the front of the frame.
3. Reconnect all switch cables to their recorded interposer positions.
4. Reattach the power cable to slot J1 and the supervisor cable to slot J2.
5. Set the inline switch to the On ('1') position.
6. Place the switch circuit breaker in the On ('1') position.

Resetting the clock and bootlist after servicing a node

When servicing a node, the node becomes disconnected from its power source for a period of time. Since nodes normally do not have a real battery, the NVRAM will lose its memory when disconnected from power for about 10 minutes (sometimes less). This will cause the date to be reset to January 1, 1970, and the bootlist to be cleared. This can cause some problems with booting.

It is **highly recommended** to reset the clock and bootlist before booting the node. This is done as follows:

1. Before powering down the node to be serviced, display the current bootlist:
 - a. Run diagnostics (**diag**)
 - b. Choose the "Service Aids" panel
 - c. Choose the "Display/Alter Bootlist" panel
 - d. Choose "Normal Mode"
 - e. Choose "Display Current Bootlist"

This will display the current bootlist.

2. Power down the node, service it, and hook it back into the frame.
3. On the control workstation, run **spbootins** to set the node to boot in maintenance mode. For example, if it is node 12 of frame 2, enter:

```
spbootins -r maintenance 2 12 1
```
4. On the control workstation, netboot the node:
 - a. From the SP Perspectives Launch Pad, select "Hardware Perspectives"
 - b. Click on the processor node (or nodes) you are going to boot from a network
 - c. Click on "Actions" button on the tool bar
 - d. Verify the nodes selected, then click on the "Apply" button
 - e. IPL from network device begins

Note: If Packets Received always shows "00000", there is a network or configuration problem.

5. When this boots, a console window will pop up on your display. Follow the prompts:
 - a. "Start Maintenance Mode for System Recovery"
 - b. "Access a Root Volume Group"
 - c. "Continue"
 - d. Choose correct disk from the list
 - e. Access this volume group and start a shell
6. In the maintenance shell, set the date command. For example, to set the date to August 3, 1995, do "date 0803123095"
7. In the maintenance shell, set the boot list.
 - a. Run diagnostics (**diag**)
 - b. Choose the "Service Aids" panel
 - c. Choose the "Display/Alter Bootlist" panel
 - d. Choose "Normal Mode"
 - e. Choose "Alter Current Bootlist"
 - f. Set the bootlist the way it was before the node was serviced
8. Close the console window

9. On the control workstation, set the node to boot from disk. For example:
`spbootins -r disk 2 12 1`
10. On the control workstation, use Perspectives to power off the node and then power it back on.
The node will now boot from the device that you specified in step 7 with the correct time.

Running diagnostics on a switch port

Attention: Servicing a processor node or switch assembly may interrupt customer usage of the processor node and the remainder of the switch network. If the switch feature must be replaced in a multi-frame system, refer to “Removing and restoring switch resources” on page 3-9, for information on isolating the switch assembly.

Before running diagnostic tests on a switch to diagnose node to switch problems, you must identify the port number. For example:

Bulkhead jack 6 on switch 17 frame 1 is identified as **E01-S17-BH-J6**

To run the test from the control workstation for this example the syntax of the command is:

```
/usr/lpp/ssp/bin/spd/wrap_test -j E01-S17-BH-J6
```

The wrap test will indicate when to use the following items that are supplied as part of the ship group:

- Wrap cable
- Wrap plug
- Interposer wrap card

Chapter 4. FRU removals and replacements

Handling static-sensitive devices	4-1
SP Switch2 service procedures	4-2
Removing a fan assembly	4-2
Replacing a fan assembly	4-2
Removing a power supply	4-3
Replacing a power supply	4-3
Removing the LED bracket assembly	4-4
Replacing the LED bracket assembly	4-4
Removing the switch supervisor card	4-5
Replacing the switch supervisor card	4-6
Removing an interposer card	4-6
Replacing an interposer card	4-7
Removing the switch planar	4-7
Replacing the switch planar	4-8
Removing the 48 V dc circuit breaker assembly	4-8
Replacing the 48 V dc circuit breaker assembly	4-9
Removing the LED power extension cable	4-9
Replacing the LED power extension cable	4-10

This chapter describes the removal and replacement of RS/6000 SP product-specific Field Replaceable Unit (FRU) components.

Attention: Components in the frame are susceptible to damage from static discharge. Always use an ESD wristband when working inside frame covers. (See “Personal ESD requirements” on page 3-1 for more details.) Do not touch the pins or circuitry on these components.

Handling static-sensitive devices

Attention: Adapters, planars, disk drives, supervisor cards and memory cards are sensitive to static electricity discharge. These devices are wrapped in antistatic bags or containers to prevent this damage.

Perform the following procedures to prevent damage to these devices:

1. Do not remove the device from the antistatic bag or container until you are ready to install the device in the system unit.
2. You must wear an ESD wristband while installing or removing any static-sensitive devices.
3. With the device still in its antistatic bag, touch it to a metal frame of the system.
4. Grasp cards and boards by the edges. Hold drives by the frame. Avoid touching the solder joints and pins.
5. Handle the devices carefully in order to prevent permanent damage.

SP Switch2 service procedures




Figure 4-1. Handling an anti-static device

SP Switch2 service procedures

CAUTION:

The unit weight exceeds 18 Kg (40 lbs) and requires two service personnel to lift. (SPSFC002)

Note

This chapter describes removal and replacement procedures for the following SP Switch2 FRUs:

- Circuit breaker assembly
- LED bracket assembly
- LED power extension cable
- Switch supervisor card
- Power supplies
- Fan assemblies
- Switch planar assembly
- Interposer cards

Removing a fan assembly

Note: The fan assembly is hot-pluggable.

Note: Refer to “Handling static-sensitive devices” on page 4-1.

1. Unscrew the fan assembly mounting screws located on the front of the switch chassis.
2. Grasp the fan assembly’s grill-work flange and remove the assembly by pulling it out of the chassis.

Note: If the fan assembly contains the LED bracket assembly, remove the assembly and save it for use with the new fan assembly.

- Refer to “Removing the LED bracket assembly” on page 4-4.

Replacing a fan assembly

Note: If the failed fan assembly contained the LED bracket assembly, reinstall the saved assembly into the new fan assembly.

- Refer to “Replacing the LED bracket assembly” on page 4-4.

1. Insert and seat the fan assembly into the switch chassis.
2. Tighten the assembly’s mounting screws.

- Return to the procedure that directed you here.

Removing a power supply

Note: The power supply is a card-mounted assembly and is hot-pluggable.

Note: Refer to “Handling static-sensitive devices” on page 4-1.

- Remove the fan assembly blocking access to the power supply assembly.
 - Refer to “Removing a fan assembly” on page 4-2.
- Swing the hinged air dam (covering the entrance to the fan bay) back and upward to expose the locking levers on each side of the power supply card.
- Unlatch the card by rotating the locking levers outward.
- Slide the power supply forward and remove it.




Figure 4-2. Removing SP Switch2 fan assemblies and power supplies

Replacing a power supply

- Swing the hinged air dam (covering the entrance to the fan bay) back and upward to expose the card-guide tracks on the chassis framework.
- Align the power supply card with the guide tracks and insert the card.
- Seat the assembly and engage the two locking levers by rotating them inward.
- Replace the fan.
 - Refer to “Replacing a fan assembly” on page 4-2.
- Return to the procedure that directed you here.

SP Switch2 service procedures

Removing the LED bracket assembly

Note: The LED bracket assembly is hot-pluggable.

Note: Refer to “Handling static-sensitive devices” on page 4-1.

1. Remove the fan assembly housing the LED bracket assembly.
 - Refer to “Removing a fan assembly” on page 4-2.
2. Remove the LED bracket mounting screw from the side of the fan assembly.
3. Remove the LED bracket assembly.

Note: If you are replacing a failed fan, save the LED bracket assembly for use with the new fan.




Figure 4-3. Removing SP Switch2 power and environmental LED assembly

Replacing the LED bracket assembly

1. Mount the LED bracket assembly in the fan assembly.
2. Secure the LED bracket assembly to the fan assembly side wall with the mounting screw.
3. Replace the fan assembly.
 - Refer to “Replacing a fan assembly” on page 4-2.
4. Return to the procedure that directed you here.

Removing the switch supervisor card

Note: The switch supervisor card is hot-pluggable.

Note: Refer to “Handling static-sensitive devices” on page 4-1.

1. Remove the switch supervisor cable from the supervisor card located in slot J2.
2. Loosen the captive screw holding the card retention bracket to the switch chassis.
3. Swing the bracket out and remove it from the switch chassis.
4. Remove the supervisor card from switch by pulling outward on the card's hot-plug actuator.




Figure 4-4. Removing and replacing SP Switch2 supervisor and interposer cards

SP Switch2 service procedures




Figure 4-5. Installing an SP Switch2 supervisor and interposer cards

Replacing the switch supervisor card

1. Position and hold the switch supervisor card at the far end of the hot-plug actuator.
2. Insert the far end of the actuator into the actuator guides of switch slot J2.
3. Push the actuator to the end of the guide track.
4. Push the actuator handle inward and seat the supervisor card into switch planar jack J2.
5. Hook the card retention bracket to the chassis side-wall mount and swing the bracket closed.
 - Make certain all actuator handles are inside the bracket.
6. Secure the card retention bracket to the switch chassis by tightening the captive screw.
7. Reconnect the switch supervisor cable to the switch supervisor card.
8. Perform "Updating the SP Switch2 supervisor code" on page 3-8.
9. Return to the procedure that directed you here.

Removing an interposer card

Note: An interposer card may be either a:

- Switch interposer
- Blank interposer

Note: Interposer card assemblies are hot-pluggable.

Note: Refer to “Handling static-sensitive devices” on page 4-1.

Note: If multiple cards are to be removed, label and record the position of each card and its associated I/O cable.

1. If the interposer card is a switch interposer, remove the I/O cable.
 - Only switch interposer cards have an attached I/O cable
2. Loosen the captive screw holding the card retention bracket to the switch chassis.
3. Swing the bracket out and remove it from the switch chassis.
4. Remove the interposer card from its slot by pulling outward on the hot-plug actuator handle.

Replacing an interposer card

Note: An interposer card may be either a:

- Switch interposer
 - Blank interposer
1. Position and hold the interposer card at the far end of the hot-plug actuator.
 2. Insert the far end of the actuator into the actuator guides of the interposer slot.
 3. Push the actuator to the end of the guide track.
 4. Seat the interposer card into its switch planar jack by pushing the actuator handle inward.
 5. Hook the card retention bracket to the chassis and swing the bracket closed.
 - Make certain all actuator handles are inside the bracket.
 6. Secure the card retention bracket by tightening the captive screw.
 7. If this was a switch interposer card, reconnect the I/O cable.
 8. Return to the procedure that directed you here.

Removing the switch planar

Attention: Removal of the switch planar involves the removal of the switch’s externally accessible plug-in assemblies. **Do not** attempt to remove the planar from the chassis.

Note: Refer to “Handling static-sensitive devices” on page 4-1.

1. Place the switch in service position.
 - Refer to “Placing an SP Switch2 into service position” on page 3-10.
2. Remove **all** fan assemblies.
 - Refer to “Removing a fan assembly” on page 4-2.
3. Remove **all** power supplies.
 - Refer to “Removing a power supply” on page 4-3.
4. Remove **all** installed interposer cards.
 - Refer to “Removing an interposer card” on page 4-6.
5. Remove the switch supervisor card.
 - Refer to “Removing the switch supervisor card” on page 4-5.
6. The switch planar is now considered to be removed.

Note: The new planar assembly is supplied as a chassis mounted unit.

SP Switch2 service procedures

Replacing the switch planar

Attention: Replacement of the switch planar involves the replacement of the removed switch's externally accessible plug-ins into a new, partially populated switch planar-in-chassis assembly.

1. Remove **all** fan assemblies from the new switch planar assembly.
 - Refer to "Removing a fan assembly" on page 4-2.
2. Install the components from the old switch into the new chassis assembly in the following order:
 - a. Replace the switch supervisor card.
 - Refer to "Replacing the switch supervisor card" on page 4-6.
 - b. **All** interposer cards.
 - Refer to "Replacing an interposer card" on page 4-7.
 - c. **All** power supplies.
 - Refer to "Replacing a power supply" on page 4-3.
 - d. **All** fan assemblies.
 - Refer to "Replacing a fan assembly" on page 4-2.
3. Replace the switch from service position.
 - Refer to "Replacing an SP Switch2 from service position" on page 3-11.
4. Return to the procedure that directed you here.

Removing the 48 V dc circuit breaker assembly

Note: Refer to "Handling static-sensitive devices" on page 4-1.

1. Place the switch in service position.
 - Refer to "Placing an SP Switch2 into service position" on page 3-10.
2. Remove the switch supervisor card from slot J2.
 - Refer to "Removing the switch supervisor card" on page 4-5.
3. Remove the circuit breaker assembly mounting screws.
4. Loosen the captive screws on the chassis center top-cover and remove the cover.
5. Unplug the circuit breaker assembly power cable from J48V on the switch planar.
6. Grasp the circuit breaker bracket with one hand, apply finger pressure at its base from the empty J2 slot with the other hand, and remove the assembly by pulling it out of the chassis.




Figure 4-6. Removing SP Switch2 circuit breaker assembly

Replacing the 48 V dc circuit breaker assembly

1. Insert the 48 V dc circuit breaker assembly into the switch chassis.
2. Secure the assembly to the chassis with the mounting screws.
3. Plug the circuit breaker assembly power cable into J48V on the switch planar.
4. Install the center top-cover and secure it by tightening the captive screws.
5. Replace the switch supervisor card and the card retention bracket.
 - Refer to “Replacing the switch supervisor card” on page 4-6.
6. Replace the switch from service position.
 - Refer to “Replacing an SP Switch2 from service position” on page 3-11.
7. Return to the procedure that directed you here.

Removing the LED power extension cable

Note: Refer to “Handling static-sensitive devices” on page 4-1.

1. Place the switch in service position.
 - Refer to “Placing an SP Switch2 into service position” on page 3-10.
2. Remove the fan assembly containing the LED display.
 - Refer to “Removing a fan assembly” on page 4-2.
3. Loosen the captive screws on the chassis center top-cover and remove the cover.
4. Unhook and remove both planar air baffles.
5. Unplug the LED extension cable power connector from switch planar jack JLED.
 - At this time, do not remove the extension cable from the cover slot.
6. At the rear of the front top-cover and at the top of power bays 2 and 3, loosen the captive screws securing the removable trays.
7. Remove the tray from bay 3 and then remove the tray from bay 2.

SP Switch2 service procedures

8. Remove the front top-cover from the chassis as follows:
 - a. Remove the cover mounting screws.
 - b. Slide the front top-cover toward the center of the chassis.
 - c. Remove the cover when it disengages from the chassis framework.
9. Cut the tie-wrap securing the LED power extension cable to the cover mounted power tray.
10. Slide the LED extension cable out of the holding slot.
11. Remove the LED extension cable by squeezing the retention "wings" on the power connector and pushing the connector out of the tray bracket.

Replacing the LED power extension cable

1. Insert the fan-end connector of the LED power extension cable into its mounting hole on the front top-cover mounted tray bracket.
2. Lock the connector to the bracket by pushing the connector into the mounting hole until its retention wings extend.
3. Slide the cable into the slot at the rear of the tray.
4. Using the tie-wrap cutouts provided in the tray sheet metal, tie-wrap the cable to the tray.
5. Install the front top-cover to the chassis as follows:
 - a. Place the front top-cover (beveled edge rearward) over the center of the switch and align the cover's outboard trays to the power bay guides on the chassis framework.
 - b. Push the top-cover forward until it is seated and install the cover mounting screws.
6. Insert a removable tray into the framework guides near the top of power bay 2, seat the tray and tighten the tray's captive screw.
7. Insert the remaining removable tray into the framework guides near the top of power bay 3, seat the tray and tighten the tray's captive screw.
8. Plug the connector on the planar-end of the LED extension cable into switch planar jack JLED.
9. Install both planar air baffles by hooking the ends of each baffle to the switch chassis.
 - Make certain that the LED extension cable is captured by the slot in the baffle.
10. Install the center top-cover and tighten the captive mounting screws.
11. Install the fan assembly containing the LED display into the switch chassis.
 - Refer to "Replacing a fan assembly" on page 4-2.
12. Replace the switch from the service position.
 - Refer to "Replacing an SP Switch2 from service position" on page 3-11.
13. Return to the procedure that directed you here.

Chapter 5. Parts catalog

SP Switch2 assembly (view 1)	5-2
SP Switch2 assembly (view 2)	5-4
Switch cables	5-6
SP Switch2 Frame (F/C 2032)	5-8
F/C 2032 frame extender	5-10
SP Switch2 Frame Model 556 and F/C 2034.	5-12
Model 556 and F/C 2034 frame extender	5-14

SP Switch2 assembly (view 1)




Table 5-1. SP Switch2 assembly (view 1)

Assembly index	Part number	Units	Description
			SP Switch2 Assembly (reference only)
1	31L7106	4	Fan assembly
2	11P1636	4	Power Supply, 3.4 V
3	31L7137	2	Baffle, Air Flow
4	21L3969	1	Cover, Center Top
5	05N6603	1	Replacement Assembly, Switch Planar
6	31L7112	1	Cable, LED Power Extension
	77G0818	1	Wrap Plug, Diagnostic, Male (not shown)
	46H9688	1	Wrap Plug, Diagnostic, Female (not shown)
	05N6647	1	Cable, 8.75 m (for wrap testing)
7	31L7109	1	Assembly, LED Bracket

SP Switch2 assembly (view 2)




Table 5-2. SP Switch2 assembly (view 2)

Assembly index	Part number	Units	Description
			SP Switch2 Assembly (reference only)
1	05N6603	1	Replacement Assembly, Switch Planar
2	31L7112	1	Cable, LED Power Extension
3	21L3966	2	Baffle, Power Supply Bay (Tray)
4	31L7113	1	Bracket, Card Retention
5	12K0606	AR	Card, Switch Interposer
	12K0486	1	Card, Switch Interposer Wrap
	12K0487	AR	Blank (not shown)
6	31L8752	1	Card, Switch Supervisor
7	21L3967	1	Assembly, Circuit Breaker

Switch cables

This page intentionally left blank.

Table 5-3. Switch cables

Assembly index	Part number	Units	Description
	11P0006	AR	SP Switch2 Data Cable Cable, Switch Data - (2615 mm) -----
	31L7152	1	SP Switch2 External Cables Cable, SP Switch 2 Power
	46G9698	AR	Cable, S - S External 5 m
	46G9699	AR	Cable, S - S External 10 m
	46G9700	AR	Cable, S - S External 15 m
	46G9701	AR	Cable, S - S External 20 m

SP Switch2 Frame (F/C 2032)




Table 5-4. SP Switch2 Frame (F/C 2032)

Assembly index	Part number	Units	Description
1	31L8515	AR	Rail, left
	77G0599	AR	Screw
	74F1823	AR	Nutclip
2	11P0097	AR	Bracket, mounting, SP Switch2
	77G0559	AR	Screw
	74F1823	AR	Nutclip
3	31L8514	AR	Rail, right
	77G0599	AR	Screw
	74F1823	AR	Nutclip
4		AR	SP Switch2 assembly
5	11J4774	AR	Plate, blank, 4 EIA
	54G2882	AR	Screw, M5
	0375867	AR	Nutclip
6	11J5155	8	Plate, blank, 2 EIA
	54G2882	AR	Screw, M5
	0375867	AR	Nutclip
	08J5557	4	Chocks, Rubber (not shown)
			Power cables, multi-switch frame
	11J5189	1	Cable, +48 V dc, Frame slots 2 and 4 (not shown)
	11J5191	1	Cable, +48 V dc, Frame slots 6 and 8 (not shown)
	11J5193	1	Cable, +48 V dc, Frame slots 10 and 12 (not shown)
	11J5195	1	Cable, +48 V dc, Frame slots 14 and 16 (not shown)

F/C 2032 frame extender




Table 5-5. F/C 2032 frame extender

Assembly index	Part number	Units	Description
1	44P1029	1	Top cover, frame extender
2	4491031	1	Right side, frame extender
3			Bracket, lower frame
4	54G2943	2	Leveling pad
5	44P1032	16	Cable bracket, frame extender
6	44P1030	1	Left side, frame extender
	54G2882	36	Screw, hex head, M5

SP Switch2 Frame Model 556 and F/C 2034




Table 5-6. SP Switch2 Frame Model 556 and F/C 2034

Assembly index	Part number	Units	Description
1	31L8515	AR	Rail, left
	77G0599	AR	Screw
	74F1823	AR	Nutclip
2	11P0097	AR	Bracket, mounting, SP Switch2
	77G0599	AR	Screw
	74F1823	AR	Nutclip
3	31L8514	AR	Rail, right
	77G0599	AR	Screw
	74F1823	AR	Nutclip
4	44P0769	1	Frame asm, single line cord
	44P0771	1	Frame asm, dual line cord
5	11J5155	AR	Plate, blank, 2 EIA
	54G2882	AR	Screw, M5
	0375867	AR	Nutclip
6	11P0492	AR	SP Switch2

Model 556 and F/C 2034 frame extender




Table 5-7. Model 556 and F/C 2034 frame extender

Assembly index	Part number	Units	Description
1	21L3091	1	Top cover, frame extender
2	21L3088	1	Right side, frame extender
3			Bracket, lower frame
4	54G2943	2	Leveling pad
5	21L3090	16	Cable bracket, frame extender
6	21L3089	1	Left side, frame extender
	54G2882	36	Screw, hex head, M5

Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785
U.S.A

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law:

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Trademarks

The following terms are trademarks of the International Business Machines Corporation in the United States, or other countries, or both:

AIX
IBM
IBMLink™
POWERstation®
RS/6000
SP

Other company, product, and service names may be the trademarks or service marks of others.

Electronic emissions notices

Federal Communications Commission (FCC) statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

European Union (EU) statement

This product is in conformity with the protection requirements of EU Council Directive 89/336/EEC on the approximation of the laws of the Member States relating to electromagnetic compatibility. The manufacturer cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the fitting of option cards supplied by third parties. Consult with your dealer or sales representative for details on your specific hardware.

This product has been tested and found to comply with the limits for Class A Information Technology Equipment according to CISPR 22 / European Standard EN 55022. The limits for Class A equipment were derived for commercial and industrial environments to provide reasonable protection against interference with licensed communication equipment.

Attention: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

United Kingdom telecommunications safety requirements

Notice to customers

This apparatus is approved under approval number NS/G/1234/J/100003 for indirect connection to public telecommunications systems in the United Kingdom.

Industry Canada compliance statement

This Class A digital apparatus meets the requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

For installations in Japan:

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

The following is a summary of the VCCI Japanese statement in the box above. This is a Class A product based on the standard of the Voluntary Control Council for Interference by Information Technology Equipment (VCCI). If this equipment is used in a domestic environment, radio disturbance may arise. When such trouble occurs, the user may be required to take corrective actions.

Electromagnetic interference (EMI) statement - Taiwan

警告使用者:

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

The following is a summary of the EMI Taiwan statement above.

Warning: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user will be required to take adequate measures.

Radio protection for Germany

Dieses Gerät ist berechtigt in Übereinstimmung mit Dem deutschen EMVG vom 9.Nov.92 das EG-Konformitätszeichen zu führen.

Der Aussteller der Konformitätserklärung ist die IBM Germany.

Dieses Gerät erfüllt die Bedingungen der EN 55022 Klasse A. Für diese von Geräten gilt folgende Bestimmung nach dem EMVG:

Geräte dürfen an Orten, für die sie nicht ausreichend entstört sind, nur mit besonderer Genehmigung des Bundesministers für Post und Telekommunikation oder des Bundesamtes für Post und Telekommunikation betrieben werden. Die Genehmigung wird erteilt, wenn keine elektromagnetischen Störungen zu erwarten sind.

(Auszug aus dem EMVG vom 9.Nov.92, Para.3, Abs.4)

Hinweis

Dieses Genehmigungsverfahren ist von der Deutschen Bundespost noch nicht veröffentlicht worden.

Index

Numerics

0375867 5-9, 5-13
05N6603 5-3, 5-5
05N6647 5-3
08J5557 5-9
11J4774 5-9
11J5155 5-9, 5-13
11J5189 5-9
11J5191 5-9
11J5193 5-9
11J5195 5-9
11P0006 5-7
11P0097 5-9, 5-13
11P0492 5-13
11P1636 5-3
12K0486 5-5
12K0487 5-5
12K0606 5-5
21L3088 5-15
21L3089 5-15
21L3090 5-15
21L3091 5-15
21L3966 5-5
21L3967 5-5
21L3969 5-3
31L7106 5-3
31L7109 5-3
31L7112 5-3, 5-5
31L7113 5-5
31L7137 5-3
31L7152 5-7
31L8514 5-9, 5-13
31L8515 5-9, 5-13
31L8752 5-5
44P0769 5-13
44P0771 5-13
44P1029 5-11
44P1030 5-11
44P1031 5-11
44P1032 5-11
46G9698 5-7
46G9699 5-7
46G9700 5-7
46G9701 5-7
46H9688 5-3
48 V dc circuit breaker assembly
 removing 4-8
 replacing 4-9
54G2882 5-9, 5-11, 5-13, 5-15
54G2943 5-11, 5-15
74F1823 5-9, 5-13
77G0599 5-9, 5-13
77G0818 5-3

A

active configuration
 removing from 3-9
 restoring 3-9
assembly naming standard 2-2
audience of this book xv

B

base code verification 3-8
blank interposer
 removing 4-6
 replacing 4-7
bootlist, resetting 3-11

C

cable plug locations 2-1
cables, switch 5-6
circuit breaker assembly, 48 V dc
 removing 4-8
 replacing 4-9
clock, resetting 3-11
component connector details 2-7
connector location naming standard 2-2
css.snap
 disk space 3-6
 file package names 3-6
 file structure 3-4
 files 3-4
 script, using 3-3

D

data cables, Switch2 2-11
diagnostics
 switch port 3-12
disk space
 css.snap 3-6

E

ESD
 procedures 3-1
 requirements 3-1
external cable routing 2-9

F

F/C 2032 5-8, 5-10
F/C 2034 5-12, 5-14
fan assembly
 removing 4-2
 replacing 4-2
female wrap plug 1-5
fencing nodes 3-10

- files
 - created by css.snap 3-4
 - package names, css.snap 3-6
 - structure, css.snap 3-4
- files overview, service 3-1
- format structure 2-1
- frame
 - multi-switch 5-8, 5-12
 - rear view 2-4
- frame cable routing path in rear of frame 2-8, 2-10
- frame extender
 - F/C 2032 5-10
 - F/C 2034 5-14
 - Model 556 5-14
- frame locations 2-3, 2-5
- frame naming standard 2-1
- front view of frame locations 2-3
- front view of multi-switch frame locations 2-4

H

- handling static-sensitive devices 4-1

I

- interposer card
 - removing 4-6
 - replacing 4-7
- isolation, service procedures 3-1

L

- LED bracket
 - removing 4-4
 - replacing 4-4
- LED cable 1-11
- LED power extension cable
 - removing 4-9
 - replacing 4-10
- location diagrams of the RS/6000 SP components
 - component connector details 2-7
 - external cable routing 2-9
 - frame 2-5
 - frame cable routing path in rear of frame 2-8, 2-10
 - front view of frame locations 2-3
 - front view of multi-switch frame locations 2-4
- locations
 - cable plug 2-1
 - cable plug locations 2-1
 - connector details 2-1
 - frame rear view 2-4
 - location diagrams of RS/6000 SP components 2-1

M

- major assembly naming standard 2-2
- male wrap plug 1-5
- Model 556 5-12, 5-14
- multi-switch frame 5-8, 5-10, 5-12, 5-14
- multi-switch frame locations 2-4

N

- names, css.snap files 3-6
- naming standard
 - assembly 2-2
 - connector location 2-2
 - for RS/6000 SP components 2-1
 - format structure 2-1
 - frame 2-1
 - major assembly 2-2
- nodes
 - fencing 3-10
 - unfencing 3-10
- notices, safety ix
- numbers, service request 1-24

O

- opening
 - switch pane 3-7

P

- package names, css.snap 3-6
- parts catalog
 - F/C 2034 5-12
 - frame 5-8
 - frame extender 5-10, 5-14
 - Model 556 frame 5-12
 - switch cables 5-6
 - view 1 5-2
 - view 2 5-4
- Perspectives
 - checking switch status 3-7
 - fencing nodes 3-10
 - opening a switch pane 3-7
 - switch supervisor verification 3-7
 - unfencing nodes 3-10
- placing into service position 3-10
- plug locations, cable 2-1
- plugs, wrap 1-5
- port, switch
 - diagnostics 3-12
- power assembly 1-11
- power supply
 - removing 4-3
 - replacing 4-3
- prerequisite knowledge for this book xv
- Procedures
 - ESD 3-1
- purpose of book xv
 - task procedures overview xv

R

- rear view of frame locations 2-4
- removing
 - 48 V dc circuit breaker assembly 4-8
 - blank interposer 4-6
 - fan assembly 4-2
 - interposer card 4-6

- removing (*continued*)
 - LED bracket 4-4
 - LED power extension cable 4-9
 - power supply 4-3
 - RS/6000 components 4-1
 - switch interposer 4-6
 - switch planar 4-7
 - switch supervisor card 4-5
 - wrap interposer 4-6
- removing switch from active configuration 3-9
- removing switch resources 3-9
- replacing
 - 48 V dc circuit breaker assembly 4-9
 - blank interposer 4-7
 - fan assembly 4-2
 - interposer card 4-7
 - LED bracket 4-4
 - LED power extension cable 4-10
 - power supply 4-3
 - RS/6000 components 4-1
 - switch interposer 4-7
 - switch planar 4-8
 - switch supervisor card 4-6
 - wrap interposer 4-7
- replacing from service position 3-11
- request numbers, service 1-24
- Requirements
 - ESD 3-1
- resetting, clock and bootlist 3-11
- restoring switch resources 3-9
- restoring switch to active configuration 3-9
- RS/6000 components
 - removing and replacing 4-1

S

- safety notices ix
- script, using `css.snap` 3-3
- self-test, switch supervisor 3-6
- service position
 - placing into 3-10
 - replacing from 3-11
- service position procedures 3-10
- service procedures
 - placing switch assembly into service position 3-10
 - removing switch resources 3-9
 - replacing a switch assembly from service position 3-11
 - restoring switch resources 3-9
 - service position 3-10
 - verification and isolation 3-1
- service request numbers 1-24
- SP Switch2
 - LED cable 1-11
 - power assembly 1-11
- SP Switch2 assembly high-level diagram 1-2
- SP Switch2 data cables 2-11
- SPS resources
 - removing 3-9
 - restoring 3-9
- SRNs 1-24

- static-sensitive devices 4-1
- structure, `css.snap` file 3-4
- supervisor code
 - updating 3-8
- supervisor self-test, switch 3-6
- supervisor verification
 - switch 3-7
- switch
 - removing from active configuration 3-9
 - restoring to active configuration 3-9
 - switch assembly environment MAP
 - flowcharted 1-9
 - switch cables 5-6
 - switch function MAP
 - flowcharted 1-17
 - switch interposer
 - removing 4-6
 - replacing 4-7
 - switch pane
 - opening 3-7
 - switch status 3-7
 - switch planar
 - removing 4-7
 - replacing 4-8
 - switch port
 - diagnostics 3-12
 - switch power MAP
 - flowcharted 1-13
 - switch resources
 - removing 3-9
 - restoring 3-9
 - switch status 3-7
 - switch supervisor card
 - removing 4-5
 - replacing 4-6
 - switch supervisor code
 - updating 3-8
 - switch supervisor self-test 3-6
 - switch supervisor verification 3-7
 - Switch2 data cables 2-11

T

- tools overview, service 3-1
- trademarks A-1

U

- unfencing nodes 3-10
- updating
 - switch supervisor code 3-8
- user's responsibilities xvi
- using `css.snap` script 3-3

V

- verification
 - base code 3-8
 - switch supervisor 3-7
- verification and isolation procedures
 - switch supervisor self-test 3-6

verification, service procedures 3-1

W

who should use book xv

wrap interposer

removing 4-6

replacing 4-7

wrap plugs 1-5

Reader's comments – We'd like to hear from you

RS/6000 SP
SP Switch2 Service Guide

Publication No. GA22-7444-03

Overall, how satisfied are you with the information in this book?

	Very Satisfied	Satisfied	Neutral	Dissatisfied	Very Dissatisfied
Overall satisfaction	<input type="checkbox"/>				

How satisfied are you that the information in this book is:

	Very Satisfied	Satisfied	Neutral	Dissatisfied	Very Dissatisfied
Accurate	<input type="checkbox"/>				
Complete	<input type="checkbox"/>				
Easy to find	<input type="checkbox"/>				
Easy to understand	<input type="checkbox"/>				
Well organized	<input type="checkbox"/>				
Applicable to your tasks	<input type="checkbox"/>				

Please tell us how we can improve this book:

Thank you for your responses. May we contact you? Yes No

When you send comments to IBM, you grant IBM a nonexclusive right to use or distribute your comments in any way it believes appropriate without incurring any obligation to you.

Name

Address

Company or Organization

Phone No.



Fold and Tape

Please do not staple

Fold and Tape




NO POSTAGE
NECESSARY
IF MAILED IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 40 ARMONK, NEW YORK

POSTAGE WILL BE PAID BY ADDRESSEE

IBM Corporation
Department 55JA, Mail Station P384
2455 South Road
Poughkeepsie NY 12601-5400



Fold and Tape

Please do not staple

Fold and Tape



Printed in the United States of America
on recycled paper containing 10%
recovered post-consumer fiber.

GA22-7444-03



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>