

Portable DVD Player

User Guide



Playable Disk Format:
DVD/CD/CD-R/CD-RW/MMC/SD card

English

Svenska

82-184-00170



Table of Contents

FCC and Safety Information.....	4
Important Safety Instructions.....	5
Precautions.....	6
Selecting the type of disc for the type of TV connected.....	7

Chapter 1. DVD

1-1 DVD Playback.....	8
Basic Playback.....	8
Stopping Playback and Returning to The Menu Screen (If a Menu Is Available on The Disc).....	8
Stopping Playback.....	9
Rapid Advance and Rapid Reverse.....	9
Skipping Ahead or Back to Chapters.....	9
Still Picture (PAUSE).....	9
Repeat Viewing.....	10
1-2 Convenient functions.....	11
Displaying Scene Information.....	11
Changing Audio Soundtrack Language.....	11
Clearing/Displaying Subtitles (A).....	11
Changing Subtitle Language (B).....	12
Viewing From Another Angle.....	12
Mute the DVD Player.....	12
Using a DVD Menu.....	13
Using the Menu Function.....	13

Chapter 2. Audio CD

2-1 Audio CD Playback.....	14
Basic Playback.....	14
Stopping Playback.....	14
Rapid Advance and Rapid Reverse.....	14
Skipping Ahead or Back to Tracks.....	15
Pause.....	15
Displaying Track Information.....	15

Chapter 3. Special Functions

3-1 Playing Kodak Picture CDs.....	16
Basic Playback.....	16
Slide Show.....	16
Thumbnail Mode.....	17
3-2 Playing JPEG picture CDs.....	18
Basic Playback.....	18
File Manager.....	18
Playing Mode.....	19
Thumbnail Mode.....	19



Chapter 4. Setup

4-1 Language Setup..... 20
 On Screen Display (OSD) Language Setting..... 20
 DVD MENU Language Setting..... 21
 AUDIO Soundtrack Language Selection [DVD]..... 22
 SUBTITLE Language Selection [DVD]..... 23

4-2 Screen TV Tuner..... 24
 TV Type Setting.....24
 Screen Saver Setting..... 25
 TV System Setting.....26
 Video Out Setting.....27

4-3 AUDIO Setup..... 29
 Digital Out Setting..... 29
 Analog Out Setting.....30

4-4 Custom Setup..... 31
 MMC/SD Setting..... 31
 Parental Control Setting [DVD]..... 32
 Password Setting [DVD]..... 33
 Angle Mark Setting [DVD]..... 34
 Default Setting..... 35

4-5 LCD Setup..... 36
 Panel Setting..... 36
 Color Setting.....36
 Bright Setting.....37

Chapter 5. For Your Reference

5-1 Troubleshooting..... 38
5-2 Disc Handling and Maintenance..... 39
5-3 Defintion of Terms..... 40



FCC and Safety Information

CAUTION:

This unit employs a laser. Due to possible eye injury, only qualified service personnel should remove the cover or attempt to service this device. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Since it is usual for DVD movies to be released at different times in different regions of the world, all players have region codes and disc can have an optional region code. If you load a disc of a different region code to your player, you will see the region code notice on the screen. The disc will not play, and should be unloaded.

(Possible region codes:)



There are 6 regions (also called "locals"). Each DVD player and disc will be played in one region ONLY.

- 1: Canada, U.S., U.S. Territories
- 2: Japan, Europe, South Africa, Middle East (including Egypt)
- 3: Southeast Asia, East Asia (including Hong Kong)
- 4: Australia, New Zealand, Pacific Islands, Central America, Mexico, South America, Caribbean
- 5: Former Soviet Union, Indian Subcontinent, Africa (also North Korea, Mongolia)
- 6: China

Never make or change connections with the power switched on.

CAUTION VISIBLE AND INVISIBLE LASER RADIATION WHEN OPEN. AVOID EXPOSURE TO BEAM
(WARNING LOCATION: INSIDE ON LASER COVERSIELD)

For DVD Players with 525p, but not 625p, progressive scan output:

'CONSUMERS SHOULD NOTE THAT NOT ALL HIGH DEFINITION TELEVISION SETS ARE FULLY COMPATIBLE WITH THIS PRODUCT AND MAY CAUSE ARTIFACTS TO BE DISPLAYED IN THE PICTURE. IN CASE OF 525 PROGRESSIVE SCAN PICTURE PROBLEMS, IT IS RECOMMENDED THAT THE USER SWITCH THE CONNECTION TO THE 'STANDARD DEFINITION' OUTPUT. IF THERE ARE QUESTIONS REGARDING YOUR TV SET COMPATIBILITY WITH THIS MODEL 525p DVD PLAYER, PLEASE CONTACT OUR CUSTOMER SERVICE CENTER.'



Manufactured under license from Dolby Laboratories. "Dolby" and the double-D symbol are trademarks of Dolby Laboratories. Confidential Unpublished Works. ©1992-1997 Dolby Laboratories, Inc. All rights reserved.

Important Safety Instructions



1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a damp cloth.
7. Do not block any of the ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized-type plug. A polarized plug has two blades with one wider than the other. The wide blade is provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plug, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Unplug this apparatus during lightning storms or when unused for long periods of time.
13. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way; such as when the power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
14. Ambient Temperature 0~40°C.



Outdoor use or wet location applications:

An apparatus that does not comply with the requirements in Appendix A# (Outdoor Use and Wet Location Apparatus) shall be marked or the instruction manual packed with the word "WARNING" and the following or equivalent: "To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture."

A Class II APPARATUS shall be permanently marked with the words "DOUBLE INSULATION" or "Double insulated" and "When servicing use only identical replacement parts."

WARNING: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.



Precautions

Please read these precautions before operating this unit.

■ Power cord protection

To avoid any malfunctions of the unit and to protect against electric shock, fire or personal injury, please observe the following.

- Hold the plug firmly when connecting or disconnecting the AC power cord.
- Keep the AC power cord away from heating appliances.
- Never put any heavy object on the AC power cord.
- Do not attempt to repair or reconstruct the AC power cord in any way.

■ Placement

Avoid placing the unit in areas of:

- Direct sunlight or heating radiators, or closed automobiles.
- High temperature (over 35°C) or high humidity (over 90%).
- Much dust as the internal parts may be seriously damaged.

■ Non-use periods

Turn the unit off when not in use. When left unused for a long period of time, the unit should be unplugged from the household AC outlet.

■ No fingers or other objects inside

- Touching internal parts of this unit is dangerous and may cause serious damage to the unit. Do not attempt to disassemble the unit.
- Do not put any foreign object on the disc tray.

■ Keep away from water/magnet

- Keep the unit away from flower vases, tubs, sinks, etc. If liquids are spilled into the unit, serious damage could occur.
- Never bring a magnet or magnetized object near the unit.

■ Stacking

- Place the unit in a horizontal position, and do not place anything heavy on it.

■ Condensation

Moisture may form on the lens in the following conditions:

- immediately after a heater has been turned on
- in a steamy or very humid room
- when the unit is suddenly moved from a cold environment to a warm one

If moisture forms inside this unit, it may not operate properly. In this case, turn on the power and wait about one hour for the moisture to evaporate.

■ If there is noise interference on the TV while a broadcast is being received





Depending on the reception condition of the TV, interference may appear on the TV monitor while you watch a TV broadcast and the unit is left on. This is not a malfunction of the unit or the TV. To watch a TV broadcast, turn off the unit.

Selecting the type of disc for the type of TV connected







DVDs are recorded in PAL or NTSC formats. Please refer to the table below to find the appropriate format for your region.





■ Connecting to a multi-system TV

DISC	TV MONITOR
 PAL	 Played in the PAL system.
 NTSC	 Played in the NTSC system.

■ Connecting to a NTSC TV

DISC	TV MONITOR
 PAL	 No clear images are shown on the screen.
 NTSC	 Played in the NTSC system.

■ Connecting to a PAL TV

DISC	TV MONITOR
 PAL	 Played in the PAL system.
 NTSC	 No clear images are shown on the screen.



Preparation

Attach the battery or connect the portable DVD player to a wall outlet. If connecting to external equipment, please perform the following:

- Press on the power button of the TV set, and select "Video" as the TV input.
- Press on the power button of the stereo system if the player has been connected to one.
- Push the AV OUT/IN slide switch to AV OUT.

Basic Playback

1 Press POWER on.

2 Press <OPEN> to open the disc cover.

3 Hold the edge of the disc to put it in the center with the printed side up.

Hold the disc without touching its surfaces, position it with the printed title side facing up, align it with the guides, and place it in its proper position.

4 Close the disc cover.

- Close the disc cover and the portable DVD player starts playback if the disc does not have any menus recorded on it.
- If the disc has one or more titles recorded on it, a menu screen will appear on the screen.


5 Press  or the number button(s) to select the preferred title.

<< NOTE: To select a title, input the number, i.e. 1 for chapter 1, 10 for chapter 10, and etc. >>

6 Press  <PLAY/SEL.> .

The player now starts playing the selected item.

Stopping Playback and Returning to The Menu Screen (If a Menu Screen Is Available on The Disc)


Press  <MENU>.

The portable DVD player stops playback, and then displays the menu screen.


After operation

When the portable DVD player is not in use, remove the disc and press **POWER** to turn off the player. Then close the display panel.

<< NOTE >>

- The disc continues to rotate while the menu is displayed even after the player has finished playing a particular disc. When no further selections are to be played, be sure to press the  <STOP> button to clear the menu screen.
- If the disc is placed in upside down (and it is a single sided disc), the player will display "NO DISC".

For your reference:

- When "" appears while a button is being operated, it means that the corresponding operation is prohibited by the player.







Stopping Playback

Press  <STOP> once to prestop. Press  <STOP> twice to stop.

Rapid Advance and Rapid Reverse

Press  <F.BWD> or  <F.FWD> during playback.

- Normal playback is resumed when you press  <PLAY/SEL.>.
- The speed of advance ( x2,  x4,  x8,  x16,  x32) or reverse ( x2,  x4,  x8,  x16,  x32) changes with each press of the  <F.FWD> or  <F.BWD> button.

Skipping Ahead or Back to Chapters

You can skip a specific chapter or track.

Skipping Ahead

Press  <NEXT> during playback.

Skips a chapter each time you press the button.

Skipping Back

Press  <PREVIOUS> during playback.

When you press the button once midway through a chapter, the portable DVD player returns to the beginning of the chapter being played back. The player skips a chapter each time you press the button.

Still Picture (PAUSE)

Press  <PAUSE> during playback.

The screen is paused.


*To return to normal playback

---Press  <PLAY/SEL.>.

**Repeat Viewing**


Press  **<1/ALL REPEAT>** during playback.

Each time you press the button, the disc will repeat a chapter or title.



Press once:  Chapter (Repeat chapter)

Press twice:  Title (Repeat title)

Press three times:  Disc (Repeat disc)

Press four times:  Off (Repeat cancelled)

***To return to normal playback**


---Press  **<1/ALL REPEAT>** several times until “ Off” appears on the screen.


<< NOTE >>

- Repeat playback works only with discs for which the elapsed playing time appears on the player's display during playback.
- Repeat playback may not work correctly with some DVDs.




Displaying Scene Information

Press  **<INFO.>** during playback.

Press  **<INFO.>** a number of times, the title number, chapter number, and other information will show on the screen.

*To stop displaying scene information

---Press  **<INFO.>** a number of times until the information disappears.

Changing Audio Soundtrack Language

You can change the audio language from the one selected at the initial settings to a different language. (This operation functions only with discs on which multiple audio soundtrack languages are recorded.)

1 Press  **<AUDIO>** during playback.

2 Press  **<AUDIO>** a number of times until the preferred language is selected.


For your reference:

- When the preferred language is not selected even after pressing the button several times, it may indicate that language is not available on the disc.
- When you turn on or remove the disc, the portable DVD player will playback the language which is selected at the initial setting. If you select a language which is not recorded on the disc, the portable DVD player will playback a prior language programmed on the disc.

Clearing/Displaying Subtitles (A)

If a disc provides subtitles, you can choose to hide or display them. (This operation works only with discs that provide subtitles.)

Press  **<SUBTITLE>** during playback to display subtitles or hide them.

When you press  **<SUBTITLE>** once, the first subtitle recorded on the disc will display. The rest of the subtitles recorded will display in sequence as you press the button.


- You may change to another language with this function, or you can clear the subtitle by pressing this button until "SUBTITLE OFF" appears on the screen.



Changing Subtitle Language (B)

You can change the subtitle language with the initial settings. (This operation works only with discs on which multiple subtitle languages are included.)

1 Press  <SUBTITLE> during playback.

When no subtitles are recorded, "” will display instead of the language number.

2 Press  <SUBTITLE> a number of times until the preferred language is selected.


<< NOTE >>

- In some cases, the subtitle language may not change immediately to the selected one.

For your reference:


- When the preferred subtitle language is not selected even after pressing the button several times, it may indicate that the language is not available on the disc.
- When you turn on or remove the disc, the portable DVD player will playback the subtitle language which is selected at the initial setting. If you select a subtitle language which is not recorded on the disc, the portable DVD player will playback a prior subtitle language programmed on the disc.

Viewing From Another Angle

Some DVD discs may contain scenes which have been shot simultaneously from a number of different angles. For these discs, the same scenes can be viewed from each of these different angles using the  <ANGLE> button. (The recorded angles vary depending on the disc programmed.)

1 Press  <ANGLE> during playback.

2 Press  <ANGLE> a number of times until the preferred viewing angle is selected.

Press  <ANGLE> button a number of times to change the viewing angle.

<< NOTE >>

- The viewing angles are shown on the player's display and you can select one from them for viewing.

Mute the DVD Player

Press  <MUTE> button during playback.

- When "MUTE" appears on the screen, the portable DVD player is mute. To resume the sound, press the button until "MUTE OFF" appears on the screen.




Using a DVD Menu

Some DVD discs have unique menu structures. For example, DVDs programmed with complex contents provide guide menus, and those recorded with various languages provide menus for audio and subtitle language. Although the DVD menu's contents and operation vary from disc to disc, the following explains basic operation when this feature is used.

- 1 **Press**  **<TITLE> in stop mode.**

The DVD menu available on the disc now appears.

- 2 **Press**  **<◀/▶/▲/▼> to select the preferred item.**

- 3 **Press**  **<PLAY/SEL.>.**

You now enter to the selected item.

*To enter other menu screen

---Repeat steps 2 and 3.

*To return to the previous menu screen

---Press  **<TITLE>.**

Using the MENU Function

- 1 **Press**  **<PLAY/SEL.>.**

- 2 **Press**  **<MENU>.**

A DVD chapter menu with brief broadcast of each paragraph now appears. You may see the introduction of each chapter and then decide with which chapter to start first.

- 3 **Press**  **<◀/▶/▲/▼> or number button(s) to select the preferred item.**

<< NOTE >>

- The menu details vary.



Preparation

Attach the battery or connect the portable DVD player to a wall outlet. If connecting to external equipment, please perform the following:

- Press on the power button of the TV set, and select "Video" as the TV input.
- Press on the power button of the stereo system if the player has been connected to one.
- Push the AV OUT/IN SWITCH button to AV OUT.

Basic Playback














- 1 Press POWER on.**
- 2 Press <OPEN> to open the disc cover.**
- 3 Hold the edge of the disc to put it in the center with the printed side up.**
Hold the disc without touching its surfaces, position it with the printed title side facing up, align it with the guides, and place it in its proper position.
- 4 Close the disc cover.**
For audio CDs without playback control:
The portable DVD player starts to playback.
For audio CDs provided with playback control:
A menu appears after a few seconds.

Stopping Playback

Press  <STOP> once to prestop. Press  <STOP> twice to stop.

Rapid Advance and Rapid Reverse

Press  <F.BWD> or  <F.FWD> during playback.

- Normal playback is resumed when you press  <PLAY/SEL.>.
- The speed of advance  x2,  x4,  x8,  x16,  x32) or reverse ( x2,  x4,  x8,  x16,  x32) changes with each press of the  <F.FWD> or  <F.BWD> button.



Skipping Ahead or Back to Tracks

Skipping Ahead

Press  **<NEXT>** during playback.

A track is skipped each time you press the button.

Skipping Back

Press  **<PREVIOUS>** during playback.

When you press the button once midway through a track, the portable DVD player returns to the beginning of the track being played back. The player skips a track each time the button is pressed.

Pause

Press  **<PAUSE>** once during playback.

The player will pause playback.


To return to normal playback

Press  **<PLAY/SEL.>**.


Displaying Track Information

Displaying Track Information

Press  **<INFO.>** during playback.

Press  **<INFO.>** a number of times, the elapsed time, track number and other information will show on the screen.

***To stop displaying track information**

---Press  **<INFO.>** a number of times until the information disappears.

**Basic Playback**

You can play Kodak picture CDs for viewing on the screen.



Load a kodak picture CD.

After few seconds, the portable DVD player starts to play back the pictures in a slide show automatically.

OR

You can press the number buttons corresponding to the order of the picture, then press

 **<PLAY/SEL.>**.

Press  **<INFO.>**, the current picture number and total picture numbers will show on the screen. And press the number buttons corresponding to the order of the picture, then press  **<PLAY/SEL.>**. The portable DVD player will begin the slide show.

*To pause slide show

--Press  **<PAUSE>**, the slide show will pause.

*To stop slide show

--Press  **<STOP>**, then enter Thumbnail mode.

<<Note: Press  **<TITLE>** to enter Thumbnail mode.>>


*To resume slide show


--Press  **<PLAY/SEL.>** again.

Slide Show

1 Press  **<NEXT>** to view the next picture or  **<PREVIOUS>** to view the previous picture.

2 Press  **<RIGHT>** button or  **<LEFT>** button to rotate the picture.

Press  **<RIGHT>** button to rotate right by 90 degrees.

Press  **<LEFT>** button to rotate left by 90 degrees.

*To pause slide show

--Press  **<PAUSE>**, the slide show will pause.

*To stop slide show


--Press  **<STOP>**, then enter Thumbnail mode.

<<Note: Press  **<TITLE>** to enter Thumbnail mode.>>

*To resume slide show


--Press  **<PLAY/SEL.>** again.

**Thumbnail Mode**

- 1** Press  **<TITLE>** to enter **Thumbnail mode.**

While in Thumbnail mode, there are 20 pictures per page for viewing.

- 2** Press  **<◀/▶/▲/▼>** to select the picture in thumbnail. If you want to view the selected picture in its original size, press  **<PLAY/SEL.>**

When you view the picture in its original size, you can press  **<STOP>** to view the pictures in thumbnail.

- 3** Press  **<NEXT>** or  **<PREVIOUS>** to view the next or previous thumbnail page.

**Basic Playback**

You can play JPEG pictures CDs for viewing on the screen.

Load a JPEG picture CD.


After few seconds, the portable DVD player starts to play back the pictures in a slide show automatically.

OR

You can press the number buttons corresponding to the order of the picture, then press

 **<PLAY/SEL.>**

Press  **<INFO.>**, the current picture number, total picture numbers and other information will show on the screen.

Press the number button corresponding to the order of the picture, then press  **<PLAY/SEL.>**. The portable DVD player will begin the slide show.

*To pause slide show

--Press  **<PAUSE>**, the slide show will pause.





*To stop slide show

--Press  **<STOP>**, then enter the File Manager.

*To resume slide show

--Press  **<PLAY/SEL.>** again.

File Manager

- 1 Under File Manager Menu, press  <◀/▶/▲/▼> to choose the preferred picture, then press  <PLAY/SEL.> to playback the picture.**
- 2 Press  <NEXT> to skip for the next six pictures or  <PREVIOUS> to skip to the previous six pictures.**



Playing Mode

1 Press <NEXT> to view the next picture or <PREVIOUS> to view the previous picture.

2 Press <RIGHT> button or <LEFT> button to rotate the picture.

Press <RIGHT> button to rotate right by 90 degrees.

Press <LEFT> button to rotate left by 90 degrees.

*To pause playback

--Press <PAUSE>.

*To stop playback

--Press <STOP>, then enter to the File Manager.

<<Note: Press <TITLE> to enter Thumbnail mode.>>

*To resume playback

--Press <PLAY/SEL.> again.

Thumbnail Mode

1 Press <TITLE> to enter Thumbnail mode.

While in Thumbnail mode, there are 20 pictures per page for viewing.











2 Press << / > / > / >> to select the picture in the thumbnail. If you want to view the selected picture in its original size, press <PLAY/SEL.>.


When you view the picture in its original size, you can press <STOP> to view the pictures in the thumbnail.

3 Press <NEXT> or <PREVIOUS> to view the next or previous thumbnail page.

**On Screen Display (OSD) Language Setting**

Allows you to set various languages for the on screen display (OSD).


- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select "Language Setup", and then press  **<PLAY/SEL.>**
- 3 Press  **<UP>** button /  **<DOWN>** button to select "OSD", and then press  **<PLAY/SEL.>**
- 4 Press  **<UP>** button /  **<DOWN>** button to select the preferred language.
- 5 Press  **<PLAY/SEL.>**



*To return to the SETUP MENU screen

---Press  **<LEFT>** button.











*To finish the setup operation


---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.



DVD Menu Language Setting

You can select a language that has been recorded on the disc menu.


- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select "Language Setup", and then press  **<PLAY/SEL.>**
- 3 Press  **<UP>** button /  **<DOWN>** button to select "Menu", and then press  **<PLAY/SEL.>**
- 4 Press  **<UP>** button /  **<DOWN>** button to select the preferred language.
- 5 Press  **<PLAY/SEL.>**



*To return to the SETUP MENU screen











---Press  **<LEFT>** button.

*To finish the setup operation


---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.

**AUDIO Soundtrack Language Selection [DVD]**

You can select a preferred soundtrack language that has been recorded on the DVD discs.

- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select "Language Setup", and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to select "Audio", and then press  **<PLAY/SEL.>**.
- 4 Press  **<UP>** button /  **<DOWN>** button to select the preferred language.
- 5 Press  **<PLAY/SEL.>**.


ORIGINAL: The top-priority language of each disc will always playback first.



*To return to the SETUP MENU screen

---Press  **<LEFT>** button.

*To finish the setup operation

---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.











For your reference:


- If the language selected is not recorded on the disc, the portable DVD player will playback the top-priority language of the disc.



SUBTITLE Language Selection [DVD]

You can select a preferred language that has been recorded on the DVD.


- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select "Language Setup", and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to select "Subtitle", and then press  **<PLAY/SEL.>**.
- 4 Press  **<UP>** button /  **<DOWN>** button to select the preferred language.
- 5 Press  **<PLAY/SEL.>**.



*To return to the SETUP MENU screen

---Press  **<LEFT>** button.

*To finish the setup operation

---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.


For your reference:

- If the language selected is not recorded on the disc, the portable DVD player will playback the top-priority language of the disc.

**TV Type Setting**

The kind of TV set (4:3 or 16:9) connected to the player and a wide-screen picture type for a 4:3 TV can be selected.

- 1 Press **<SETUP>** in the stop mode.
- 2 Press **<UP>** button / **<DOWN>** button to select "Screen Setup", and then press **<PLAY/SEL.>**.
- 3 Press **<UP>** button / **<DOWN>** button to select "TV Type", and then press **<PLAY/SEL.>**.
- 4 Press **<UP>** button / **<DOWN>** button to select a preferred TV display.
- 5 Press **<PLAY/SEL.>**.



*To return to the SETUP MENU screen

---Press **<LEFT>** button.

*To finish the setup operation

---Press **<SETUP>** to exit or select EXIT from SETUP MENU screen.

4:3 Pan Scan

Select 4:3 PS for a conventional size TV set. Video material formatted in the pan & scan style has the left and right edges trimmed.

4:3 Letter Box

Select 4:3 LB for a conventional size TV set. Black bands appear at top and bottom of screen (letter-box style).

16:9 Wide

Select 16:9 for a wide-screen TV set. Played in "FULL" size.











- Setting the wide-screen TV to "FULL" mode is also necessary.
- Each screen shows an example when the video material for a wide-screen is played.






Screen Saver Setting

This function will only work when the player is stopped.

- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select "Screen Setup", and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to select "Screen Saver", and then press  **<PLAY/SEL.>**.
- 4 Press  **<UP>** button /  **<DOWN>** button to select "On" or "Off".
- 5 Press  **<PLAY/SEL.>**.


The waiting time of the screen saver is set to 10 minutes.



*To return to the SETUP MENU screen











---Press  **<LEFT>** button.


*To finish the setup operation

---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.

**TV System Setting**

The player provides "PAL", "NTSC" and "AUTO" settings for your selection. When connecting the portable DVD player to your TV, set the "TV SYSTEM" from the on-screen display to the format that is compatible with your TV's system. Set to "AUTO" if your system is a multi-TV system that supports both PAL and NTSC.


- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select "Screen Setup", and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to select "TV System", and then press  **<PLAY/SEL.>**.
- 4 Press  **<UP>** button /  **<DOWN>** button to select the appropriate TV system for your clearest view.
- 5 Press  **<PLAY/SEL.>**.



*To return to the SETUP MENU screen

---Press  **<LEFT>** button.











*To finish the setup operation


---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.



Video Output Setting

Please choose the preferred video output supported by your equipment.


- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select "Screen Setup", and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to select "Video Output", and then press  **<PLAY/SEL.>**.
- 4 Press  **<UP>** button /  **<DOWN>** button to select the preferred video output setting.
- 5 Press  **<PLAY/SEL.>**.



*To return to the SETUP MENU screen

---Press  **<LEFT>** button.


*To finish the setup operation

---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.



Video Output Setting-continued

If you choose "P-Scan", the following will show on the screen as a reminder.



<< NOTE >>

- If you choose "P-Scan" as the video output setting, make sure your TV set supports P-Scan input feature and the YUV cable be properly connected to your TV and the portable DVD player.

If your TV doesn't support P-Scan feature, press  <STOP>.

<<Troubleshooting>>











What if the screen turns black while operating...


Solution: Press  <Mode> to switch to "S-Video" mode.



Digital Out Setting

The portable DVD player provides three options, “SPDIF/PCM”, “SPDIF/RAW” and “Off” for the digital out setting.


- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select “Audio Setup”, and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to select “Digital Out”, and then press  **<PLAY/SEL.>**.
- 4 Press  **<UP>** button /  **<DOWN>** button to select the preferred digital out setting.
- 5 Press  **<PLAY/SEL.>**.



*To return to the SETUP MENU screen

---Press  **<LEFT>** button.

*To finish the setup operation











---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.


For your reference:

- If you have a Dolby Digital 5.1 or DTS capable amplifier, you must set the audio output to SPDIF/RAW. If you have a 2-channel Dolby Digital amplifier, you must set the audio output to SPDIF/PCM.



Analog Out Setting


- 1 Press  <SETUP> in the stop mode.
- 2 Press  <UP> button /  <DOWN> button to select "Audio Setup", and then press  <PLAY/SEL.>.
- 3 Press  <UP> button /  <DOWN> button to select "Analog Out", and then press  <PLAY/SEL.>.
- 4 Press  <UP> button /  <DOWN> button to select the preferred analog out setting.
- 5 Press  <PLAY/SEL.>.



*To return to the SETUP MENU screen

---Press  <LEFT> button.











*To finish the setup operation

---Press  <SETUP> to exit or select EXIT from SETUP MENU screen.





MMC/SD Setting

Note: You can only change the MMC/SD setting to “On” or “Off” while there is no disc inside the DVD player.

- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select “Custom Setup”, and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to select “MMC/SD”, and then press  **<PLAY/SEL.>**.
- 4 Press  **<UP>** button /  **<DOWN>** button to select “On” or “Off”, and then press  **<PLAY/SEL.>**.

<< Important >>


- If you set the MMC/SD setting to “On”, the portable DVD player can only read MMC/SD card. The portable DVD player can't playback any discs.
- While the disc is played back, you can only press the  **<Mode>** button to switch to MMC/SD mode.



*To return to the SETUP MENU screen

---Press  **<LEFT>** button.


*To finish the setup operation

---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.

**Parental Control Setting [DVD]**

A built-in viewer rating setting enables you to lock the videos that you do not want children to view. For example, setting the rating limit to PG-13 will prevent the unit from playing video rated R, NC-17 or X unless the correct password is entered.

- 1 Press <SETUP> in the stop mode.
- 2 Press <UP> button / <DOWN> button to select "Custom Setup", and then press <PLAY/SEL.>.
- 3 Press <UP> button / <DOWN> button to select "Parental Ctrl", and then press <PLAY/SEL.>.
- 4 Enter a 4-digit password before selecting ratings and press <PLAY/SEL.>.
Factory pre-set password: 0000
You need to enter "0000" to set the rating for the first time when purchasing your DVD from the store.
- 5 Press <UP> button / <DOWN> button to select the preferred ratings.
- 6 Press <PLAY/SEL.>.



<< Rating Explanations >>

3.PG: Parental Guidance suggested.

4.PG13: Material is unsuitable for children under the age of 13.

6.R: Restricted, children under 17 would not be admitted without an accompanying parent or adult guardian.

7.NC17: No children under the age of 17, not recommended viewing for children under age 17.

***To return to the SETUP MENU screen**

---Press <LEFT> button.

***To finish the setup operation**

---Press <SETUP> to exit or select EXIT from SETUP MENU screen.











For your reference:


- You can use the parental control lock ONLY with DVD discs featured with the parental lock function.
- Please keep in mind that discs not encoded with rating lock protection will play regardless of rating and content.



Password Setting [DVD]

You can change the password to the portable DVD player.


- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select "Custom Setup", and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to select "Password", and then press  **<PLAY/SEL.>**.
- 4 Enter your old password and then press  **<PLAY/SEL.>**.
Factory pre-set password: 0000
- 5 Enter your new password and then press  **<PLAY/SEL.>**.
- 6 Re-enter your password to verify it and then press  **<PLAY/SEL.>**.




*To return to the SETUP MENU screen











---Press  **<LEFT>** button.

*To finish the setup operation


---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.


**Angle Mark Setting [DVD]**

You can choose to display or hide the angle mark “” on the screen.

- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select “Custom Setup”, and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to select “Angle Mark”, and then press  **<PLAY/SEL.>**.
- 4 Press  **<UP>** button /  **<DOWN>** button to select “On” or “Off”, and then press  **<PLAY/SEL.>**.

<< NOTE >>


- Pressing the  **<ANGLE>** button will change camera angles for movies that support this feature regardless of whether the ANGLE MARK feature is “On” or “Off”.



*To return to the SETUP MENU screen

---Press  **<LEFT>** button.










*To finish the setup operation

---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.




Default Setting

You may re-set the previous settings in CUSTOM SETUP to the default setting.

- 1 Press  **<SETUP>** in the stop mode.
- 2 Press  **<UP>** button /  **<DOWN>** button to select "Custom Setup", and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to select "Default", and then press  **<PLAY/SEL.>**.
- 4 Press  **<RIGHT>** button to select "Read", and then press  **<PLAY/SEL.>**.

<< EXCEPTION >>


- The viewer rating and the password setting will NOT be changed even though you re-set to the default setting.



*To return to the SETUP MENU screen







---Press  **<LEFT>** button.

*To finish the setup operation

---Press  **<SETUP>** to exit or select EXIT from SETUP MENU screen.

**Panel Setting**

The portable DVD player provides five panel adjustment options: “Normal”, “16:9”, “4:3”, “Zoom” or “Close”.


- 1 Press  **<LCD>**, the LCD setting box show on the screen.
- 2 Press  **<UP>** button /  **<DOWN>** button to select “Panel”, and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to choose the preferred panel setting. The panel will change to the selected setting.

Panel	▶▶ Normal
Color	16:9
Bright	4:3
	Zoom
	Close







<< NOTE >>

- When you choose “Zoom” in the panel setting, the up and down edges are cut off.
- When you choose “Close” in the panel setting, the LCD turns off and the power indicator will blink in yellow light.

*To finish setup operation


---Press  **<LCD>** again until the LCD setting box disappears.

Color Setting







- 1 Press  **<LCD>**, the LCD setting box show on the screen.
- 2 Press  **<UP>** button /  **<DOWN>** button to select “Color”, and then press  **<PLAY/SEL.>**.
- 3 Press  **<UP>** button /  **<DOWN>** button to choose the preferred color setting. The panel will change to the selected setting.

	+3
	+2
Panel	+1
Color	▶▶ 0
Bright	-1
	-2
	-3

*To finish setup operation


---Press  **<LCD>** again until the LCD setting box disappears.

**Bright Setting**

- 1 Press  <LCD>, the LCD setting box show on the screen.
- 2 Press  <UP> button /  <DOWN> button to select "Bright", and then press  <PLAY/SEL.>.
- 3 Press  <UP> button /  <DOWN> button to choose the preferred bright setting. The panel will change to the selected setting.

	+3
Panel	+2
Color	+1
Bright >>	0
	-1
	-2
	-3

*To finish setup operation

---Press  <LCD> again until the LCD setting box disappears.



Before requesting service for your portable DVD player, check the chart below for a possible cause of the problem you are experiencing. Some simple checkups or a minor adjustment on your part may eliminate the problem and restore proper operation.

SYMPTOM (COMMON)	REMEDY
No power.	<ul style="list-style-type: none">· Insert the power plug securely into the power outlet.· Check if the ON/OFF button on the right of the player is set to on.· Check if no power at the AC outlet may be the fault by plugging in another appliance for a test.
The player does not start playback when PLAY is pressed.	<ul style="list-style-type: none">· Condensation may have formed. Try again in 1 to 2 hours to ensure that the condensation has evaporated.· Ensure that the disc format is supported by your DVD player.· Check if the disc is defective by trying another disc.· Check the region (local) code.
The player starts playback but stops immediately. No picture.	<ul style="list-style-type: none">· The disc may be dirty and may require cleaning.· Ensure that the disc is installed with the label side up.· Ensure that the equipment is connected properly.· Ensure that the input setting for the TV is "Video".· Check if external equipment is on.· Select the same channel and source on the TV as on the player.· Check if the LCD is on.
No sound.	<ul style="list-style-type: none">· Ensure that the equipment is connected properly.· If using a HiFi amplifier, try another sound source.· Check the Audio Output Setting menu to make sure that Analog Output is selected.· Check the Volume Adjustment.
Distorted sound.	<ul style="list-style-type: none">· Ensure that the input settings for the TV and stereo system are proper.· No sound is heard during still picture (pause).
No audio at Digital Output.	<ul style="list-style-type: none">· Check the digital connections.· Check the settings menu to make sure that the digital output is set to on.· Check if the audio format of the selected audio language matches your receiver capabilities.
Distorted picture.	<ul style="list-style-type: none">· Check the disc for fingerprints and clean it with a soft cloth, wiping it from center to edge.· Sometimes a small amount of picture distortion may appear. This is not a malfunction.· The disc format is not compatible to the TV-set used (PAL/NTSC).
Completely distorted picture or no color in picture.	<ul style="list-style-type: none">· The picture will be somewhat distorted at times: this is normal.
Picture is distorted during rapid advance or rapid reverse.	<ul style="list-style-type: none">· Some discs may have sections which prohibit rapid advance (or rapid reverse) playback.
No 4:3 (16:9) picture.	<ul style="list-style-type: none">· Choose the correct setup "TV DISPLAY" item which matches the TV set used.
Picture is distorted during rapid advance or rapid reverse.	<ul style="list-style-type: none">· The picture will be somewhat distorted at times: this is normal.
No operations perform with the remote control.	<ul style="list-style-type: none">· Check the batteries are installed with the correct polarity (+ and -).· The batteries are depleted: replace them with new ones.· Point the remote control unit at the remote control signal sensor and operate.· Operate the remote control unit at a distance but no more than 6 meters from the remote control signal sensor.· Remove obstacles between the remote control unit and remote control signal sensor.
No key operation (by the DVD player power and/or the remote control) is effective.	<ul style="list-style-type: none">· Turn the unit off and then back on. Alternatively, turn off the unit, disconnect the AC cord and then re-connect it. (The player may not be operating properly due to lightning, static electricity or some other external factor.)
PLAY does not start playback even when title is selected.	<ul style="list-style-type: none">· This may be a result of the parental lock function that has been set. Confirm the "PARENTAL" setup.
Audio soundtrack and/or subtitle language is not the one selected at the initial settings.	<ul style="list-style-type: none">· If the audio soundtrack and/or subtitle language does not exist on the disc, the language selected at the initial settings will not be seen/heard.
No subtitles.	<ul style="list-style-type: none">· Subtitles appear only with discs that contain them.· Subtitles are hidden from the TV screen. Press SUBTITLE to display the subtitles.
Alternative audio soundtrack (or subtitle) languages cannot be selected. Angle cannot change.	<ul style="list-style-type: none">· An alternative language can not be selected may result of no more than one language available.· This function depends on software availability. Even if a disc has a number of angles recorded, these angles may be recorded for specific scenes only.



Handling Precautions


- Hold the disc by the edges so the surface will not be soiled with fingerprints. (A) Fingerprints, dirt and scratches can cause skipping and distortion.
- Do not write on the label side with a ball-point pen or other writing utensils that can leave indentations or scratch the surface of the disc.
- Do not use record cleaning sprays, benzene, thinner, static electricity prevention liquids or any other solvent.
- Be careful not to drop or bend the disc.
- Do not install more than 1 disc on the disc tray.
- Do not try to close the disc cover when the disc is not installed properly.
- Be sure to store the disc in its exclusive case when not in use.

If the surface is soiled (B)

Wipe gently with a soft, damp (water only) cloth.

When wiping discs, always move the cloth from the center hole toward the outer edge.

(If you wipe the discs using a circular motion, circular scratches are likely to occur and may cause noise or skipping.)



If the disc is brought from a cold to a warm environment, moisture may form on the disc

Wipe this moisture off with a soft, dry, lint-free cloth before using the disc.

Improper disc storage

You can damage discs if you store them in the following places:

- Areas exposed to direct sunlight
- Humid or dusty areas
- Areas directly exposed to a heat outlet or heating appliance

Disc which cannot be played with this player

- CD-ROM (Application Program)
- CVD
- CD-G
- DVD with a Locale No. other than that shown on the DVD unit's Region Code Label on the rear panel

Maintenance

- Be sure to turn the unit off and disconnect the AC power cord before performing maintenance on the unit.
- Wipe this unit with a dry soft cloth. If the surfaces are extremely dirty, wipe clean with a cloth which has been dipped in a weak soap-and-water solution and wrung out thoroughly, and then wipe again with a dry cloth.
- Never use alcohol, benzene, thinner, cleaning fluid or other chemicals. Do not use compressed air to remove dust.

**Angle**

Recorded onto some DVD discs are scenes which have been simultaneously shot from a number of different angles (the same scene is shot from the front, from the left side, from the right side, etc.). With such discs, the ANGLE button can be used to view the scene from different angles.

Chapter Number

These numbers are recorded on DVD discs. A title is subdivided into many sections, each of which is numbered, and specific parts of video presentations can be searched quickly using these numbers.

DVD

These refer to a high-density optical disc on which high-quality pictures and sound have been recorded by means of digital signals. Incorporating a new video compression technology (MPEG II) and high-density recording technology, DVD enables aesthetically pleasing full-motion video to be recorded over long periods of time (for instance, a whole movie can be recorded).

DVD has a structure consisting of two 0.6 mm thin discs which are adhered to each other. Since the thinner the disc, the higher the density at which the information can be recorded, a DVD disc has a greater capacity than a single 1.2 mm thick disc. Since the two thin discs are adhered to each other, there is the potential to achieve double-sided play sometime in the future for even longer duration play.

Subtitles

These are the printed lines appearing at the bottom of the screen which translate or transcribe the dialogue. They are recorded on DVD discs.

Time Digit

This indicates the play time which has elapsed from the start of a disc or a title. It can be used to find a specific scene quickly. (It may not work with some discs.)

Title Number


These numbers are recorded on DVD discs. When a disc contains two or more movies, these movies are numbered as title 1, title 2, etc.

Track Number

These numbers are assigned to the tracks which are recorded on audio CDs. They enable specific tracks to be located quickly.

Bärbar DVD-spelare

Bruksanvisning



Spelbara skivformat:
DVD/CD/CD-R/CD-RW/MMC/SD-kort



Innehåll

El- och säkerhetsinformation.....	4
Viktiga säkerhetsanvisningar.....	5
Försiktighetsåtgärder.....	6
Välja typ av skiva för den anslutna TV-apparaten	7

Kapitel 1. DVD

1-1 DVD-avspelning.....	8
Normal avspelning.....	8
Stoppa avspelning och återgå till menyskärmen (om skivan har en meny).....	8
Stoppa avspelning	9
Snabbavspelning framåt och bakåt	9
Hoppa framåt eller bakåt till kapitel.....	9
Stilbild (PAUS).....	9
Repetering.....	10
1-2 Användbara funktioner	11
Visa information om scenen.....	11
Byta ljudspråk.....	11
Dölja/Visa textning (A).....	11
Byta textningspråk (B).....	12
Byta kameravinkel.....	12
Stänga av ljudet för DVD-spelaren.....	12
Använda DVD-menyer.....	13
Använda menyfunktionen	13

Kapitel 2. Audio-CD

2-1 Audio-CD avspelning.....	14
Normal avspelning.....	14
Stoppa avspelning.....	14
Snabbavspelning framåt och bakåt.....	14
Hoppa framåt eller bakåt till spår.....	15
Paus.....	15
Visa spårinformation.....	15

Kapitel 3. Specialfunktioner

3-1 Spela Kodak Picture-CD.....	16
Normal avspelning.....	16
Bildspel.....	16
Miniatyrläge.....	17
3-2 Spela JPEG Picture-CD.....	18
Normal avspelning.....	18
Filhanteraren.....	18
Avspelningsläge.....	19
Miniatyrläge.....	19



Kapitel 4. Inställningar

4-1 Språkinställningar	20
Ställa in språk för skärmtexter (OSD, On Screen Display).....	20
Ställa in språk för DVD MENY	21
Välja språk för ljudspår [DVD]	22
Välja TEXTNINGSPRÅK [DVD]	23
4-2 Skärm-inställningar	24
Ställa in typ av TV.....	24
Ställa in skärmläckare	25
Ställa in TV-system.....	26
Ställa in Video Out	27
4-3 AUDIO-inställningar	29
Ställa in Digital Out.....	29
Ställa in Analog Out.....	30
4-4 Egna inställningar	31
MMC/SD-inställningar.....	31
Ställa in barnlås [DVD]	32
Ställa in lösenord [DVD].....	33
Ställa in kameravinkelsymbol [DVD].....	34
Förinställningar.....	35
4-5 LCD-inställningar	36
Ställa in skärmen	36
Färginställningar	36
Ljusstyrka	37

Kapitel 5. Övrigt

5-1 Felsökning	38
5-2 Skivhantering och underhåll	39
5-3 Ordlista	40



El- och säkerhetsinformation

VARNING:

Enheten använder laser. Endast behörig servicepersonal får avlägsna höljiet eller försöka reparera enheten på grund av risk för ögonskador. All annan justering eller användning av funktioner än de som behandlas här, kan resultera i exponering för farlig laserstrålning.

MÄRK:

Den här utrustningen har testats och godkänts som en Klass B digital enhet, i enlighet med Del 15 i FCC-reglerna. Dessa gränsvärden är utformade för att ge skydd mot skadliga störningar i en heminstallation. Den här utrustningen genererar, använder och utstrålar radiofrekvenser som kan orsaka radiostörningar om den installeras och används felaktigt och i strid mot instruktionerna. Men det finns inga garantier för att störningar inte kan uppstå i vissa fall. Om utrustningen orsakar störningar på radio eller tv-mottagning, vilket du avgör genom att slå på och av utrustningen, kan du försöka åtgärda problemet genom något av följande:

- Rikta om eller placera om mottagarantennen.
- Öka avståndet mellan utrustningen och mottagaren.
- Anslut inte utrustningen i samma vägguttag som mottagaren.
- Kontakta återförsäljaren eller en radio/TV-tekniker.

Denna produkt innehåller teknologi för upphovsrättsskydd som bygger på vissa US patent och andra intellektuella rättigheter ägda av Macrovision Corporation och andra rättighetsinnehavare. Användning av denna teknologi måste auktoriseras av Macrovision Corporation och gäller endast för hemmabruk och övriga begränsade visningar, såvida inte ytterligare rättigheter erhålles från Macrovision Corporation. Det är förbjudet att plocka isär produkten eller att använda "reverse engineering"

Eftersom DVD-filmer ofta släpps vid olika tidpunkter i olika delar av världen, är alla DVD-spelare och en del skivor utrustade med regionskoder. Om du matar in en skiva med en annan regionskod än DVD-spelaren visas ett felmeddelande på skärmen. Skivan går inte att spela och måste matas ut.

(Möjliga regionskoder:)



Det finns 6 olika regioner. DVD-spelare och skivor kan bara spelas i EN region.

- 1: Kanada, USA, Amerikanskt territorium
- 2: Japan, Europa, Sydafrika, Mellanöstern (inklusive Egypten)
- 3: Sydostasien, Ostasien (inklusive Hongkong)
- 4: Australien, Nya Zeeland, Stillehavsöarna, Centralamerika, Mexiko, Sydamerika, Västindien
- 5: Före detta Sovietunionen, Indien, Afrika (samt Nordkorea, Mongoliet)
- 6: Kina

Enheten ska aldrig vara påslagen när du gör anslutningar eller kopplar loss anslutningar.

VARNING SYNLIG OCH OSYNLIG LASERSTRÅLNING OM ENHETEN ÖPPNAS. UNDVIK ATT UTSÄTTAS FÖR LASERSTRÅLNING (PLACERING FÖR VARNINGEN: PÅ INSIDAN AV LASERSKYDDSHÖLJET)

För DVD-spelare med 525p, men inte 625p, progressive scan output:

KONSUMENTER BÖR BEAKTA ATT INTE ALLA HÖGUPPLÖSTA TV-APPARATER ÄR HELT KOMPATIBLA MED DENNA PRODUKT OCH KAN FÖRORSAKA BILDSTÖRNINGAR. VID BILDSTÖRNINGAR I 525 PROGRESSIVE SCAN-LÅGE, REKOMMENDERAR VI ATT DU VÄXLAR TILL "STANDARDUPPLÖSNING" ISTÄLLET. VID FRÅGOR GÅLLANDE DIN TV-APPARATS KOMPATIBILITET MED 525p DVD-SPELARE, KONTAKTA VÅR KUNDTJÄNST.



Tillverkad på licens från Dolby Laboratories. Dolby och dubbel D-symbolen är varumärken tillhörande Dolby Laboratories. Konfidentiella opublicerade arbeten. ©1992-1997 Dolby Laboratories, Inc. Alla rättigheter förbehålles.

Viktiga säkerhetsanvisningar



1. Läs dessa instruktioner.
2. Behåll dessa instruktioner.
3. Beakta alla varningar.
4. Följ alla instruktioner.
5. Använd inte denna utrustning nära vatten.
6. Rengör endast med fuktig trasa.
7. Blockera inga ventilationsöppningar. Installera enligt tillverkarens instruktioner.
8. Enheten bör placeras bort från värmekällor som element, värmealstrande utrustning, spisar eller andra apparater (inklusive förstärkare) som genererar värme.
9. Försök inte åsidosätta säkerhetsfunktionen i den polariserade stickkontakten. En polariserad stickkontakt har ett stift som är större än det andra. Det större stiftet är en säkerhetsfunktion. Om stickkontakten inte går att föra in i ditt vägguttag, kontakta en elektriker för att byta ut det felaktiga vägguttaget.
10. Se till att ingen riskerar att trampa på nätsladden eller att den inte kläms, särskilt vid stickkontakten och i sladdupsamlare, samt där sladden är ansluten till enheten.
11. Använd endast extra utrustning/tillbehör rekommenderad av tillverkaren.
12. Koppla loss apparaten från vägguttaget under åskoväder eller om enheten inte ska användas under lång tid.
13. Alla reparationer skall utföras av behörig servicepersonal. Service krävs om apparaten har skadats; till exempel om nätsladden eller stickkontakten blivit skadad, vätska har spillts på apparaten eller föremål har hamnat i apparaten, apparaten har utsatts för regn eller fukt, den inte fungerar normalt eller har tappats i golvet.
14. Omgivande temperatur 0-40° C.



Användning utomhus eller på fuktiga platser:

En apparat som inte uppfyller kraven i Appendix A# (Apparater för användning utomhus och på fuktiga platser) ska vara märkt eller utrustad med en bruksanvisning med ordet "WARNING" samt följande eller motsvarande: "För att minska risken för brand eller elektriska stötar, utsätt inte apparaten för regn eller fukt".

En Klass II APPARAT skall vara permanent markerad med orden "DUBBEL ISOLERING" eller "Dubbelt isolerad" och "Vid service, använd endast identiska reservdelar."

WARNING: För att minska risken för brand eller elektriska stötar, utsätt inte apparaten för regn eller fukt. Apparaten ska inte utsättas för dropp eller stänk och inga föremål med vätska, som vaser, får ställas på apparaten.



Försiktighetsåtgärder

Läs alla dessa instruktioner noga innan du börjar använda enheten.

■Skydd av nätsladden

För att undvika funktionsfel och för att skydda mot elstötar, brand och personskada, vänligen beakta följande.

- Håll i stickkontakten när du ansluter och kopplar loss nätsladden.
- Håll nätsladden borta från värmealstrande utrustning.
- Placera aldrig tunga föremål på nätsladden.
- Försök inte reparera eller göra om nätsladden på något sätt.

■Placering

Undvik att placera enheten på platser med:

- direkt solljus eller värmeelement, eller i stängda fordon.
- hög temperatur (över 35 grader C) eller hög fuktighet (över 90%).
- mycket damm eftersom interna delar kan skadas allvarligt.

■Perioder när enheten inte används

Stäng av enheten när den inte används. Apparats nätsladd ska kopplas bort från vägguttaget om apparaten inte ska användas under lång tid.

■Inga fingrar eller främmande föremål i apparaten

- Det är fartigt att vidröra interna delar i apparaten; detta kan förorsaka att enheten skadas allvarligt. Försök inte plocka isär enheten.
- Placera inga främmande föremål på skivfacket.

■Undvik kontakt med vatten/magneter

- Placera enheten bort från blomvaser, badkar, diskhoar, etc. Om vätska hamnar i enheten kan allvarliga skador uppstå.
- Undvik att föra en magnet eller något magnetiskt föremål nära enheten.

■Placering

- Placera enheten på ett plant underlag, och ställ inget tungt ovanpå den.

■Kondensbildning

Fukt kan uppstå på linsen under följande omständigheter:

- omedelbart efter att en värmare har satts på
- i ett mycket fuktigt rum
- Om enheten flyttas direkt från en kall till en varm plats.

Om fukt bildas i enheten kan funktionsfel uppstå. Om detta inträffar, sätt på enheten och vänta i ca 1 timme så att fukten försvinner.

■Om störningar uppstår på TV:n under sändning





Beroende på TV-apparats mottagningsförhållanden kan störningar uppstå på TV-skärmen när du tittar på en TV-sändning och enheten är påslagen. Detta är inget funktionsfel på enheten eller TV:n. Stäng av enheten om du ska titta på en TV-sändning.

Välja typ av skiva för den anslutna TV-apparaten







DVD-skivor är inspelade i PAL- eller NTSC-format. I tabellen nedan hittar du rätt format för din region.





■ Anslutning till en TV med flera system

DISC	TV MONITOR
 PAL	 Played in the PAL system.
 NTSC	 Played in the NTSC system.

■ Anslutning till en NTSC TV

DISC	TV MONITOR
 PAL	 No clear images are shown on the screen.
 NTSC	 Played in the NTSC system.

■ Anslutning till en PAL TV

DISC	TV MONITOR
 PAL	 Played in the PAL system.
 NTSC	 No clear images are shown on the screen.



Förberedelser

Sätt in batteriet eller anslut den bärbara DVD-spelaren till ett vägguttag. För att ansluta till extern utrustning, utför följande:

- Tryck på TV-apparatens strömbrytare och välj "Video" som TV-inmatning.
- Tryck på stereons strömbrytare om DVD-spelaren är ansluten till en stereoanläggning.
- Ställ AV OUT/IN-reglaget på AV OUT.

Normal avspelning

1 Tryck på strömbrytaren POWER.

2 Tryck på <OPEN> för att öppna skivluckan.

3 Håll i kanten på skivan och placera den i mitten på skivluckan med den tryckta sidan uppåt.

Håll i skivan så att du inte vidrör skivytan, placera den med den tryckta sidan uppåt i markeringarna på skivluckan och se till att den är korrekt placerad.

4 Stäng skivluckan.

- Stäng skivluckan så startar avspelningen om skivan inte har några menyer.
- Om det finns en eller flera titlar på skivan visas en menyskärm på skärmen.

5 Tryck på  <</> / <▲/▼> eller sifferknapparna för att välja önskad titel.

<< MÄRK: För att välja en titel, mata in motsvarande nummer, dvs. 1 för kapitel 1, 10 för kapitel 10, och så vidare. >>

6 Tryck på  <PLAY/SEL.> .

Nu spelas den valda titeln.

Stoppa avspelning och återgå till menyskärmen (om skivan har en meny)


Tryck på  <MENU>.

Avspelningen avbryts och menyskärmen visas.


Efter användning

När den bärbara DVD-spelaren inte används, ta ut skivan och tryck på **POWER** för att stänga av enheten. Då släcks displayen.

<< MÄRK >>



- Skivan fortsätter snurra så länge som meny visas, dvs. även efter avslutad avspelning. För att stänga av spelaren efter avslutad avspelning, tryck på  <STOPP> för att rensa menyskärmen.
- Om skivan är placerad upp och ner (och det är en enkelsidig skiva), visas felmeddelandet "NO DISC".

Tänk på:

- Om "" visas när en knapp trycks ner är den åtgärden inte möjlig eller tillgänglig.



Stoppa avspelning

Tryck på  <STOPP> en gång för att ställa enheten i stoppläge. Tryck på  <STOPP> två gånger för att stoppa avspelningen.

Snabbavspelning framåt och bakåt

Tryck på  <F.BWD> eller  <F.FWD> under avspelning.

- Återgå till normal avspelning genom att trycka på  <PLAY/SEL.>.
- För varje knapptryckning på  <F.BWD> eller  <F.FWD> ändras hastigheten på snabbavspelning bakåt respektive framåt (x2, x4, x8, x16, x32).

Hoppa framåt eller bakåt till kapitel

Du kan hoppa över ett kapitel eller spår.

Hoppa framåt

Tryck på  <NÄSTA> under avspelning.

För varje knapptryckning hoppas nästa kapitel över.

Hoppa bakåt

Tryck på  <FÖREGÅENDE> under avspelning.

Om du trycker på knappen en gång under avspelning av ett kapitel, hoppar DVD-spelaren till början på det aktuella kapitlet. För varje knapptryckning hoppas nästa kapitel över.

Stillbild (PAUS)

Tryck på  <PAUS> under avspelning.


Skärmbilden ställs i pausläge.

*För att återgå till normal avspelning

---Tryck på  <PLAY/SEL.>.


**Repetering****Tryck på  <1/ALL REPEAT> under avspelning.**

Varje gång du trycker på knappen repeteras kapitlet eller titeln.



Tryck en gång för:  Kapitel (Repetera kapitel)

Tryck två gånger för:  Titel (Repetera titel)

Tryck tre gånger för:  Skiva (Repetera skiva)

Tryck fyra gånger för:  Off (Repetering avstängd)

***För att återgå till normal avspelning**

---Tryck på  <1/ALL REPEAT> flera gånger tills " Off" visas på skärmen


<< MÄRK >>

- Repetering fungerar endast på skivor som visar spelad tid på displayen under avspelning.
- Repeterad avspelning kanske inte fungerar korrekt på vissa DVD-skivor.




Visa information om scenen

Tryck på  <INFO.> under avspelning.

Tryck på  <INFO.> flera gånger för att visa titel- och kapitelnummer samt annan information på skärmen.

***Stänga av funktionen**

---Tryck på  <INFO.> flera gånger tills informationen försvinner från displayen.

Byta ljudspråk

Du kan byta det inställda ljudspråket. (Detta fungerar bara på skivor med flera inspelade ljudspråk.)

1 Tryck på  <AUDIO> under avspelning.

2 Tryck på  <AUDIO> flera gånger tills önskat språk blir valt.


Tänk på:

- Om det önskade språket inte blir valt trots att du trycker flera gånger på knappen, kan det innebära att språket inte finns på skivan.
- När du sätter på spelaren eller tar ut en skiva, spelas det språk som valts som förinställning. Om du försöker välja ett språk som inte finns på skivan används det närmast föregående tillgängliga språket på skivan.

Dölja/Visa textning (A)

Om skivan spelats in med textning, kan du ställa in att gömma eller visa denna. (Detta fungerar bara på skivor som innehåller textning.)

Tryck på  <SUBTITLE> under avspelning för att visa eller dölja textningen.

Om du trycker på  <SUBTITLE> en gång, visas den första tillgängliga textningen på skivan. Tryck flera gånger på knappen för att visa övriga tillgängliga textningar.

- Du byter till önskat textningspråk med den här funktionen, eller du kan dölja textningen helt genom att trycka på knappen tills "SUBTITLE OFF" visas på skärmen.

**Byta textningsspråk (B)**

Du kan byta det förinställda textningsspråket. (Detta fungerar bara på skivor med flera inspelade textningsspråk.)

1 Tryck på  <SUBTITLE> under avspelning.

Om textning saknas på skivan visas "" istället för siffran för textningsspråket.

2 Tryck på  <SUBTITLE> flera gånger tills önskat språk blir valt.


<< MÄRK >>

- I vissa fall ändras inte textningsspråket direkt.


Tänk på:

- Om det önskade språket inte blir valt trots att du trycker flera gånger på knappen, kan det innebära att språket inte finns på skivan.
- När du sätter på spelaren eller tar ut en skiva, spelas det språk som valts som förinställning. Om du försöker välja ett språk som inte finns på skivan används det närmast föregående tillgängliga språket på skivan.

Byta kameravinkel

Vissa DVD-skivor innehåller scener som har tagits från flera olika kameravinklar. På en sådan skiva kan du titta på en och samma scen från olika kameravinklar med hjälp av  <ANGLE>-knappen. (Kameravinklarna varierar beroende på vad som spelats in på den aktuella skivan.)

1 Tryck på  <ANGLE> under avspelning.**2 Tryck på  <ANGLE> flera gånger tills önskad kameravinkel visas.**

Tryck på  <ANGLE> flera gånger för att byta kameravinkel.

<< MÄRK >>

- Tillgängliga kameravinklar visas på spelarens display så att du kan välja vilken vinkel du vill visa.

Stänga av ljudet för DVD-spelaren**Tryck på  <MUTE> under avspelning.**

- När "MUTE" visas på skärmen är ljudet från DVD-spelaren avstängt. För att sätta på ljudet igen, tryck på knappen tills "MUTE OFF" visas.



Använda DVD-menyer

Vissa DVD-skivor har egna menystrukturer. Till exempel, DVD-skivor med mycket innehåll kan ha hjälpmenyer, medan skivor med många olika inspelade språk har menyer för ljud- och textningspråk. DVD-menyer kan ha olika innehåll och fungera lite olika beroende på skivan, men nedan förklaras de grundläggande funktionerna för de flesta skivor.

1 Tryck på <TITLE> i stoppläge.

Nu visas skivmenyn.

2 Tryck på << / >> / ▲ / ▼> för att välja önskat menyalternativ.

3 Tryck på <PLAY/SEL.>.

Det markerade menyalternativet aktiveras.

*För att gå till en annan menyskärm

---upprepa steg 2 och 3.

*För att återgå till föregående menyskärm

---Tryck på  <TITLE>.

Använda MENY-funktionen

1 Tryck på <PLAY/SEL.>.

2 Tryck på <MENU>.

En kapitelmeny visas med korta klipp av varje kapitel. Början av varje kapitel visas så att du kan bestämma vilket kapitel du vill titta på.

3 Tryck på << / >> / ▲ / ▼> eller sifferknapparna för att välja önskat alternativ.

<< MÄRK >>

- Menyalternativen varierar beroende på skivan.



Förberedelse


Stoppa in ett batteri eller anslut DVD-spelaren till ett vägguttag. För att ansluta till extern utrustning, utför följande:

- Tryck på TV-apparatens strömbrytare och välj "Video" som TV-inmatning.
- Tryck på stereons strömbrytare om DVD-spelaren är ansluten till en stereoanläggning.
- Ställ AV OUT/IN-reglaget på AV OUT.

Normal avspelning

- 1 Tryck på strömbrytaren POWER.**
- 2 Tryck på <OPEN> för att öppna skivluckan.**
- 3 Håll i kanten på skivan och placera den i mitten på skivluckan med den tryckta sidan uppåt.**
Håll i skivan så att du inte vidrör skivytan, placera den med den tryckta sidan uppåt i markeringarna på skivluckan och se till att den är korrekt placerad.
- 4 Stäng skivluckan.**
För audio CD utan "playback control":
DVD-spelaren börjar avspelningen.
För audio CD med "playback control":
En meny visas efter några få sekunder.

Stoppa avspelning

Tryck på  <STOPP> en gång för att ställa enheten i stoppläge. Tryck på  <STOPP> två gånger för att stoppa avspelningen.

Snabbavspelning framåt och bakåt

Tryck på  <F.BWD> eller  <F.FWD> under avspelning.

- Återgå till normal avspelning genom att trycka på  <PLAY/SEL.>.
- För varje knapptryckning på  <F.BWD> eller  <F.FWD> ändras hastigheten på snabbavspelning bakåt respektive framåt (x2, x4, x8, x16, x32).



Hoppa framåt eller bakåt till spår

Hoppa framåt

Tryck på  **<NÄSTA>** under avspelning.

För varje knapptryckning hoppas ett spår över.

Hoppa bakåt

Tryck på  **<FÖREGÅENDE>** under avspelning.

Om du trycker på knappen en gång under avspelning av ett spår, hoppar DVD-spelaren till början på det aktuella spåret. För varje knapptryckning hoppas nästa spår över.

Paus

Tryck på  **<PAUS>** en gång under avspelning.

Avspelningen ställs nu i pausläge.


För att återgå till normal avspelning

Tryck på  **<PLAY/SEL.>**


Visa spårinformation

Visa spårinformation

Tryck på  **<INFO.>** under avspelning.

Tryck på  **<INFO.>** flera gånger för att visa spelad tid, spårnummer samt annan information på skärmen.

*Stänga av funktionen

---Tryck på  **<INFO.>** flera gånger tills informationen försvinner från displayen.

**Normal avspelning**


DVD-spelaren kan spela Kodak Picture CD-skivor för visning på skärmen.


Mata in en KODAK Picture CD-skiva

Efter några sekunder visas automatiskt bilderna i ett bildspel.

ELLER

Du kan trycka på motsvarande sifferknappar för bilderna och sedan på  <PLAY/SEL.>

Tryck på  <INFO.> för att visa aktuell bildsiffra samt totalt antal bilder på skärmen. Och tryck sedan på

motsvarande sifferknappar för bilderna och sedan på  <PLAY/SEL.>. Bildspelet visas.

*För att pausa ett bildspel

--Tryck på  <PAUS> för att ställa ett bildspel i pausläge.

*För att stänga av ett bildspel

--Tryck på  <STOPP> och ställ bildspelet i miniatyrläge.



<<Märk: Tryck på  <TITLE> för att aktivera miniatyrläget>>


*För att starta bildspelet igen


--Tryck på  <PLAY/SEL.> igen.

Bildspel

1 Tryck på  <NÄSTA> för att visa nästa bild eller  <FÖREGÅENDE> för att visa föregående bild.

2 Tryck på  <HÖGER> eller  <VÄNSTER> för att rotera bilden.

Tryck på  <HÖGER> för att rotera bilden medsols 90 grader.

Tryck på  <VÄNSTER> för att rotera bilden motsols 90 grader

*För att pausa ett bildspel

--Tryck på  <PAUS> för att ställa ett bildspel i pausläge.

*För att stänga av ett bildspel

--Tryck på  <STOPP> och ställ bildspelet i miniatyrläge.

<<Märk: Tryck på  <TITLE> för att aktivera miniatyrläget.>>

*För att starta bildspelet igen

--Tryck på  <PLAY/SEL.> igen.

**Miniatyrläge**

- 1 Tryck på  <TITLE> för att aktivera miniatyrläget.**
I miniatyrläge visas 20 bilder per sida.
- 2 Tryck på  <</> / <>/> / ▲ / ▼> för att välja önskad bild. Om du vill titta på den markerade bilden i originalstorlek, tryck på  <PLAY/SEL.>**
När en bild visas i originalstorlek kan du trycka på  <STOPP> för att visa den i miniatyrläge.
- 3 Tryck på  <NÄSTA> för att visa nästa bild eller på  <FÖREGÅENDE> för att visa föregående bild.**

**Normal avspelning**


DVD-spelaren kan spela JPEG-bildskivor för visning på skärmen.


Mata in en JPEG-bildskiva.

Efter några sekunder visas automatiskt bilderna i ett bildspel.

ELLER

Du kan trycka på motsvarande sifferknappar för bilderna och sedan på  <PLAY/SEL.>.

Tryck på  <INFO.> för att visa nummer för den aktuella bilden, totalt antal bilder samt annan information på skärmen.

Tryck sedan på motsvarande sifferknappar för bilderna och sedan på  <PLAY/SEL.>. Bildspelet visas.

*För att pausa ett bildspel

--Tryck på  <PAUS> för att ställa ett bildspel i pausläge.

*För att stänga av ett bildspel

--Tryck på  <STOPP> och ställ spelaren i filhanteringsläge.

*För att starta bildspelet igen

--Tryck på  <PLAY/SEL.> igen.

Filhanteraren


- 1 I Filhanterarmenyn, tryck på  <</> / </> / </> / </> för att välja önskad bild och tryck sedan på  <PLAY/SEL.> för att visa bilden.**
- 2 Tryck på  <NÄSTA> för att hoppa till nästa grupp med sex bilder, eller på  <FÖREGÅENDE> för de föregående sex bilderna.**




Avspelningsläge

1 Tryck på  <NÄSTA> för att visa nästa bild eller på  <FÖREGÅENDE> för att visa föregående bild.

2 Tryck på  <HÖGER> eller  <VÄNSTER> för att rotera bilden.

Tryck på  <HÖGER> för att rotera bilden medsols 90 grader.

Tryck på  <VÄNSTER> för att rotera bilden motsols 90 grader.

*Ställa avspelning i pausläge

--Tryck på  <PAUS>.

*Stoppa avspelning

--Tryck på  <STOPP> och ställ spelaren i filhanteringsläge.

<<Märk: Tryck på  <TITLE> för att aktivera miniatyrläget.>>

*För att starta bildspelet igen

--Tryck på  <PLAY/SEL.> igen.


Miniatyrläge



1 Tryck på  <TITLE> för att aktivera miniatyrläget.

I miniatyrläge visas 20 bilder per sida.

2 Tryck på  <◀/▶/▲/▼> för att välja önskad bild. Om du vill titta på den











markerade bilden i originalstorlek, tryck på  <PLAY/SEL.>


När en bild visas i originalstorlek kan du trycka på  <STOPP> för att visa den i miniatyrläge.

3 Tryck på  <NÄSTA> för att visa nästa bild eller på  <FÖREGÅENDE> för att visa föregående bild.


**Ställa in språk för skärmtexter (OSD, On Screen Display)**

Du kan ställa in önskat språk för skärmtexterna (On Screen Display, OSD).


- 1 Tryck på  **<SETUP>** i stoppläge.
- 2 Tryck på  **<UPP>** /  **<NER>** för att välja "Language Setup", och tryck sedan på  **<PLAY/SEL.>**.
- 3 Tryck på  **<UPP>** /  **<NER>** för att välja "OSD", och tryck sedan på  **<PLAY/SEL.>**.
- 4 Tryck på  **<UPP>** /  **<NER>** för att välja önskat språk.
- 5 Tryck på  **<PLAY/SEL.>**.



*För att återgå till SETUP-skärmen

---Tryck på  **<VÄNSTER>**.











*För att avsluta


---Tryck på  **<SETUP>** för att avsluta eller välj EXIT från SETUP-skärmen.



Ställa in språk för DVD-menyer

Du kan välja språk för skivmenyer.


- 1 Tryck på  **<SETUP>** i stoppläge.
- 2 Tryck på  **<UPP>** /  **<NER>** för att välja "Language Setup", och tryck sedan på  **<PLAY/SEL.>**.
- 3 Tryck på  **<UPP>** /  **<NER>** för att välja "Menu", och tryck sedan på  **<PLAY/SEL.>**.
- 4 Tryck på  **<UPP>** /  **<NER>** för att välja önskat språk.
- 5 Tryck på  **<PLAY/SEL.>**.



*För att återgå till SETUP-skärmen







---Tryck på  **<VÄNSTER>**.

*För att avsluta


---Tryck på  **<SETUP>** för att avsluta eller välj EXIT från SETUP-skärmen.

**Välja språk för ljudspår [DVD]**

Du kan välja önskat språk för ljudspåret.

- 1 Tryck på  **<SETUP>** i stoppläge.
- 2 Tryck på  **<UPP>** /  **<NER>** för att välja "Language Setup", och tryck sedan på  **<PLAY/SEL.>**.
- 3 Tryck på  **<UPP>** /  **<NER>** för att välja "Audio", och tryck sedan på  **<PLAY/SEL.>**.
- 4 Tryck på  **<UPP>** /  **<NER>** för att välja önskat språk.
- 5 Tryck på  **<PLAY/SEL.>**.


ORIGINAL: Detta alternativ innebär att det första inspelade språket på skivan alltid spelas först.



*För att återgå till SETUP-skärmen

---Tryck på  **<VÄNSTER>**.

*För att avsluta

---Tryck på  **<SETUP>** för att avsluta eller välj EXIT från SETUP-skärmen.











Tänk på:


- Om du försöker välja ett språk som inte finns på skivan används det först inspelade språket på skivan.



Välja TEXTNINGSSPRÅK [DVD]

Du kan välja önskat textningsspråk.


- 1 Tryck på  <SETUP> i stoppläge.
- 2 Tryck på  <UPP> /  <NER> för att välja "Language Setup", och tryck sedan på  <PLAY/SEL.>.
- 3 Tryck på  <UPP> /  <NER> för att välja "Subtitle", och tryck sedan på  <PLAY/SEL.>.
- 4 Tryck på  <UPP> /  <NER> för att välja önskat språk.
- 5 Tryck på  <PLAY/SEL.>.



*För att återgå till SETUP-skärmen

---Tryck på  <VÄNSTER>.

*För att avsluta











---Tryck på  <SETUP> för att avsluta eller välj EXIT från SETUP-skärmen.


Tänk på:

- Om du försöker välja ett språk som inte finns på skivan används det först inspelade språket på skivan.


**Ställa in typ av TV**

Du kan välja vilken typ av TV (4:3 eller 16:9) som är ansluten till DVD-spelaren.


- 1 Tryck på  <SETUP> i stoppläge.
- 2 Tryck på  <UPP> /  <NER> för att välja "Screen Setup", och tryck sedan på  <PLAY/SEL.>.
- 3 Tryck på  <UPP> /  <NER> för att välja "TV Type", och tryck sedan på  <PLAY/SEL.>.
- 4 Tryck på  <UPP> /  <NER> för att välja önskad bildskärmsstorlek.
- 5 Tryck på  <PLAY/SEL.>.



*För att återgå till SETUP-skärmen

---Tryck på  <VÄNSTER>.

*För att avsluta

---Tryck på  <SETUP> för att avsluta eller välj EXIT från SETUP-skärmen.

4:3 Pan Scan

Välj 4:3 PS för en vanlig TV-apparat. Skärmbilden i "pan & scan"-storlek beskärs i vänster och höger kant.

4:3 Letter Box

Välj 4:3 LB för en vanlig TV-apparat. Svarta fält visas upptill och nertill på TV-skärmen ("letter-box"-format).

16:9 Wide

Välj 16:9 för en bredbilds-TV. Ställ in storleksalternativet "FULL".











- Du måste också ställa in alternativet "FULL" för TV-skärmen.
- Illustrationerna till höger visar exempel på hur skärmbilden ser ut när bredbild spelas.






Ställa in skärmläckare

Funktionen är bara tillgänglig när spelaren har stoppats.

- 1 Tryck på  **<SETUP>** i stoppläge.
- 2 Tryck på  **<UPP>** /  **<NER>** för att välja "Screen Setup", och tryck sedan på  **<PLAY/SEL.>**.
- 3 Tryck på  **<UPP>** /  **<NER>** för att välja "Screen Saver", och tryck sedan på  **<PLAY/SEL.>**.
- 4 Tryck på  **<UPP>** /  **<NER>** för att välja "On" eller "Off".
- 5 Tryck på  **<PLAY/SEL.>**.


Skärmläckaren är inställd till att aktiveras efter 10 minuter.



*För att återgå till SETUP-skärmen











---Tryck på  **<VÄNSTER>**.


*För att avsluta

---Tryck på  **<SETUP>** för att avsluta eller välj EXIT från SETUP-skärmen.

**Ställa in TV-system**

Du kan välja mellan alternativen "PAL", "NTSC" och "AUTO" för TV-systemet. När du ansluter den bärbara DVD-spelaren till din TV, ställer du in "TV SYSTEM" från skärmen till det format som är kompatibelt med din TV. Ställ in "AUTO" om din TV stöder både PAL och NTSC.


- 1 Tryck på  **<SETUP>** i stoppläge.
- 2 Tryck på  **<UPP>** /  **<NER>** för att välja "Screen Setup", och tryck sedan på  **<PLAY/SEL.>**.
- 3 Tryck på  **<UPP>** /  **<NER>** för att välja "TV System", och tryck sedan på  **<PLAY/SEL.>**.
- 4 Tryck på  **<UPP>** /  **<NER>** för att välja önskat TV-system.
- 5 Tryck på  **<PLAY/SEL.>**.



*För att återgå till SETUP-skärmen

---Tryck på  **<VÄNSTER>**.

*För att avsluta


---Tryck på  **<SETUP>** för att avsluta eller välj EXIT från SETUP-skärmen.




Inställning av videosignaler (Video Output)

Välj de videosignaler som din utrustning stöder.


- 1 Tryck på  **<SETUP>** i stoppläge.
- 2 Tryck på  **<UPP>** /  **<NER>** för att välja "Screen Setup", och tryck sedan på  **<PLAY/SEL.>**.
- 3 Tryck på  **<UPP>** /  **<NER>** för att välja "Video Output", och tryck sedan på  **<PLAY/SEL.>**.
- 4 Tryck på  **<UPP>** /  **<NER>** för att välja önskad videosignal.
- 5 Tryck på  **<PLAY/SEL.>**.



*För att återgå till SETUP-skärmen

---Tryck på  **<VÄNSTER>**.


*För att avsluta

---Tryck på  **<SETUP>** för att avsluta eller välj EXIT från SETUP-skärmen.



Inställning av videosignaler (Video Output), fortsättning

Om du väljer "P-Scan", visas följande på skärmen som påminnelse:



<<MÄRK>>

- Om du väljer "P-Scan" som videosignal, se till att din TV stöder P-Scan-funktionen och att YUV-kabeln är korrekt ansluten till din TV och den bärbara DVD-spelaren.

Om din TV inte stöder P-Scan, tryck på  <STOPP>.

<<Felsökning>>


Om skärmen blir svart...


Åtgärd: Tryck på  <Mode> för att växla till "S-Video"-läge.




Ställa in Digital Out

DVD-spelaren har tre olika inställningsalternativ: "SPDIF/PCM", "SPDIF/RAW" och "Off" för digitala signaler.


- 1 Tryck på  **<SETUP>** i stoppläge.
- 2 Tryck på  **<UPP>** /  **<NER>** för att välja "Audio Setup", och tryck sedan på  **<PLAY/SEL.>**.
- 3 Tryck på  **<UPP>** /  **<NER>** för att välja "Digital Out", och tryck sedan på  **<PLAY/SEL.>**.
- 4 Tryck på  **<UPP>** /  **<NER>** för att välja önskad inställning.
- 5 Tryck på  **<PLAY/SEL.>**.



*För att återgå till SETUP-skärmen

---Tryck på  **<VÄNSTER>**.

*För att avsluta






---Tryck på  **<SETUP>** för att avsluta eller välj EXIT från SETUP-skärmen.


Tänk på:

- Om du har en Dolby Digital 5.1- eller DTS-förstärkare, måste audiosignalerna ställas in till "SPDIF/RAW". Om du har en 2-kanals Dolby Digital-förstärkare, måste audiosignalerna ställas in till "SPDIF/PCM".




Ställa in Analog Out


- 1 Tryck på  <SETUP> i stoppläge.
- 2 Tryck på  <UPP> /  <NER> för att välja "Audio Setup", och tryck sedan på  <PLAY/SEL.>.
- 3 Tryck på  <UPP> /  <NER> för att välja "Analog Out", och tryck sedan på  <PLAY/SEL.>.
- 4 Tryck på  <UPP> /  <NER> för att välja önskad inställning.
- 5 Tryck på  <PLAY/SEL.>.



*För att återgå till SETUP-skärmen

---Tryck på  <VÄNSTER>.











*För att avsluta

---Tryck på  <SETUP> för att avsluta eller välj EXIT från SETUP-skärmen.





MMC/SD-inställningar

Märk: Det går bara att ändra inställningen för MMC/SD till "On" eller "Off" när det inte finns någon skiva i DVD-spelaren.

- 1 Tryck på  **<SETUP>** i stoppläge.
- 2 Tryck på  **<UPP>** /  **<NER>** för att välja "Custom Setup", och tryck sedan på  **<PLAY/SEL.>**.
- 3 Tryck på  **<UPP>** /  **<NER>** för att välja "MMC/SD", och tryck sedan på  **<PLAY/SEL.>**.
- 4 Tryck på  **<UPP>** /  **<NER>** för att välja "On" eller "Off", och tryck sedan på  **<PLAY/SEL.>**.

<< Viktigt >>


- Om du ställer in MMC/SD-inställningen till "On", kan DVD-spelaren bara läsa MMC/SD-kort. Inga skivor kan spelas.
- Under avspelning av en skiva kan du trycka på knappen  **<Mode>** för att växla till MMC/SD-läge.



*För att återgå till SETUP-skärmen

---Tryck på  **<VÄNSTER>**.


*För att avsluta

---Tryck på  **<SETUP>** för att avsluta eller välj EXIT från SETUP-skärmen.

**Ställa in barnlås [DVD]**

Genom att ställa in en nivå för visning kan du låsa vissa videofilmer så att barn inte kan titta på dem. Till exempel, om du ställer in nivån PG-13 för DVD-spelaren, måste ett korrekt lösenord anges för att filmer med nivåerna R, NC-17 eller X ska spelas.

- 1 Tryck på <SETUP> i stoppläge.
- 2 Tryck på <UPP> / <NER> för att välja "Custom Setup", och tryck sedan på <PLAY/SEL.>.
- 3 Tryck på <UPP> / <NER> för att välja "Parental Ctrl", och tryck sedan på <PLAY/SEL.>.
- 4 Mata in ett 4-siffrigt lösenord innan du väljer nivå och tryck sedan på <PLAY/SEL.>. Det fabriksinställda lösenordet: 0000
Du måste ange "0000" för att ställa in visningsnivån första gången.
- 5 Tryck på <UPP> / <NER> för att välja önskad nivå.
- 6 Tryck på <PLAY/SEL.>.



<< Förklaringar av nivåerna >>

- 3.PG: I sällskap av förälder (Parental Guidance suggested).
 4.PG13: Olämpligt för barn under 13 år.
 6.R: Restriktion, ej för barn under 17 utan sällskap av vuxen.
 7.NC17: Olämpligt för barn under 17.

*För att återgå till SETUP-skärmen

---Tryck på <VÄNSTER>.

*För att avsluta

---Tryck på <SETUP> för att avsluta eller välj EXIT från SETUP-skärmen.

Tänk på:


- Det går bara att använda barnlåset på DVD-skivor utrustade med barnlåsfunktion.
- Tänk på att skivor utan barnlåsfunktion kan spelas oavsett vilken nivå du ställer in i DVD-spelaren.




Ställa in lösenord [DVD]

Du kan ändra lösenordet för DVD-spelaren.


- 1 Tryck på  <SETUP> i stoppläge.
- 2 Tryck på  <UPP> /  <NER> för att välja "Custom Setup", och tryck sedan på  <PLAY/SEL.>.
- 3 Tryck på  <UPP> /  <NER> för att välja "Password", och tryck sedan på  <PLAY/SEL.>.
- 4 Mata in det aktuella lösenordet och tryck på  <PLAY/SEL.>
Det fabriksinställda lösenordet: 0000
- 5 Mata in det nya lösenordet och tryck på  <PLAY/SEL.>.
- 6 Mata in det nya lösenordet igen för att bekräfta och tryck på  <PLAY/SEL.>.



*För att återgå till SETUP-skärmen











---Tryck på  <VÄNSTER>.

*För att avsluta


---Tryck på  <SETUP> för att avsluta eller välj EXIT från SETUP-skärmen.

**Ställa in kameravinkelsymbol [DVD]**

Du kan välja att visa eller dölja kameravinkelsymbolen "◻" på skärmen.

- 1 Tryck på  **<SETUP>** i stoppläge.
- 2 Tryck på  **<UPP>** /  **<NER>** för att välja "Custom Setup", och tryck sedan på  **<PLAY/SEL.>**
- 3 Tryck på  **<UPP>** /  **<NER>** för att välja "Angle Mark", och tryck sedan på  **<PLAY/SEL.>**
- 4 Tryck på  **<UPP>** /  **<NER>** för att välja "On" eller "Off", och tryck sedan på  **<PLAY/SEL.>**
<<MÄRK>>


- Om du trycker på knappen  **<ANGLE>** ändras kameravinkeln för filmer med flera kameravinklar oavsett om funktionen "ANGLE MARK" är på eller av ("On" eller "Off").



*För att återgå till SETUP-skärmen

---Tryck på  **<VÄNSTER>**.










*För att avsluta


---Tryck på  **<SETUP>** för att avsluta eller välj EXIT från SETUP-skärmen.



Förinställningar

Du kan återställa alla egna inställningar i "Custom Setup" till fabriksinställningarna.


- 1 Tryck på  **<SETUP>** i stoppläge.
- 2 Tryck på  **<UPP>** /  **<NER>** för att välja "Custom Setup", och tryck sedan på  **<PLAY/SEL.>**.
- 3 Tryck på  **<UPP>** /  **<NER>** för att välja "Default", och tryck sedan på  **<PLAY/SEL.>**.
- 4 Tryck på  **<HÖGER>** för att välja "Read", och tryck sedan på  **<PLAY/SEL.>**.
<<UNDANTAG>>
 - Nivåinställningen för visning och lösenordet återställs INTE även om du återgår till fabriksinställningarna.



*För att återgå till SETUP-skärmen







---Tryck på  **<VÄNSTER>**.

*För att avsluta

---Tryck på  **<SETUP>** för att avsluta eller välj EXIT från SETUP-skärmen.

**Ställa in skärmen**

Din bärbara DVD-spelare har fem olika alternativ för skärminställningen: "Normal", "16:9", "4:3", "Zoom" och "Close".


- 1 Tryck på  <LCD> för att visa LCD-inställningsrutan på skärmen.
- 2 Tryck på  <UPP> /  <NER> för att välja "Panel", och tryck sedan på  <PLAY/SEL.>.
- 3 Tryck på  <UPP> /  <NER> för att välja önskad inställning. Den önskade skärmbildsstorleken ställs nu in.

Panel	▶▶	Normal
Color		16:9
Bright		4:3
		Zoom
		Close






<<MÄRK>>

- Alternativet "Zoom" innebär att skärmbilden beskärs i över- och underkant.
- Alternativet "Close" innebär att skärmen stängs av och strömindikatorn blinkar med gult ljus.

*För att avsluta


---Tryck på  <LCD> igen tills LCD-inställningsrutan försvinner.

Färginställningar

- 1 Tryck på  <LCD> för att visa LCD-inställningsrutan på skärmen.
- 2 Tryck på  <UPP> /  <NER> för att välja "Color", och tryck sedan på  <PLAY/SEL.>.
- 3 Tryck på  <UPP> /  <NER> för att välja önskad inställning. Den önskade färgnivån ställs nu in.







		+3
		+2
		+1
Panel		
Color	▶▶	0
Bright		-1
		-2
		-3

*För att avsluta

---Tryck på  <LCD> igen tills LCD-inställningsrutan försvinner.




Ljusstyrka

- 1 Tryck på  <LCD> för att visa LCD-inställningsrutan på skärmen.
- 2 Tryck på  <UPP> /  <NER> för att välja "Bright", och tryck sedan på  <PLAY/SEL.>.
- 3 The panel will change to the selected setting. Tryck på  <UPP> /  <NER> för att välja önskad inställning. Den önskade ljusstyrkan ställs nu in.

	+3
Panel	+2
Color	+1
Bright >>	0
	-1
	-2
	-3

*För att avsluta

---Tryck på  <LCD> igen tills LCD-inställningsrutan försvinner.



Innan du lämnar din DVD-spelare till service, kontrollera diagrammet nedan efter en möjlig lösning om du får problem med din DVD-spelare. En enkel åtgärd eller mindre justering kan kanske lösa problemet så att DVD-spelaren fungerar optimalt igen.

SYMPTOM (VANLIGA)**ÅTGÄRD**

Ingen ström.

- Anslut nätsladdens stickkontakt ordentligt i vägguttaget.
- Kontrollera att On/Off-knappen till höger på spelaren är på.
- Kontrollera att det finns ström i vägguttaget genom att koppla in en annan apparat
- Kondensbildning kan vara orsaken. Försök igen efter 1 till 2 timmar för att se till att eventuell kondens har försvunnit.
- Kontrollera att skivformatet stöds av DVD-spelaren.
- Kontrollera om skivan är defekt genom att prova med en annan skiva.
- Kontrollera regionskoden.

Avspelnigen startar inte när du trycker på PLAY-knappen.

DVD-spelaren börjar avspelnigen men stannar direkt.

- Skivan kan vara smutsig och i behov av rengöring.
- Kontrollera att skivan är inmatad med etikettsidan uppåt.
- Kontrollera att ansluten utrustning är korrekt ansluten.
- Kontrollera att TV-apparaten är inställd till "Video".
- Kontrollera att extern utrustning är påslagen.
- Välj samma kanal och källa för TV-apparaten och spelaren.
- Kontrollera att LCD-skärmen är på.

Ingen bild.

Inget ljud

- Kontrollera att ansluten utrustning är korrekt ansluten.
- Om du använder en HiFi-förstärkare, försök med en annan ljudkälla.
- Kontrollera att alternativet "Analog Output" är valt i menyn för ljudutmatning (Audio Output Setting).
- Justera volymen.

Ljudstörningar.

- Kontrollera inställningarna (input) för TV-apparaten och stereosystemet.
- Inget ljud vid stillbild (pause).

Inget ljud vid digital utmatning.

- C- Kontrollera digitalanslutningarna.
- Kontrollera att alternativet "Digital Output" är valt i menyn.
- Kontrollera att det valda audiospråkets format matchar din mottagares.

Bildstörningar.

- Torka bort fingeravtryck från skivan med en mjuk trasa; torka från mitten och utåt mot kanten.
- Ibland kan små bildstörningar uppstå. Detta är normalt.
- Skivformatet är inte kompatibelt med TV-apparaten (PAL/NTSC).
- Ibland uppstår smärre bildstörningar. Detta är normalt.

Kraftiga bildstörningar eller ingen färgbild.

Bildstörningar uppstår vid snabbavspelnin framåt eller bakåt.

Snabbavspelnin framåt (eller bakåt) fungerar inte.

Ingen 4:3 (16:9) bild.

- Vissa avsnitt på en del skivor stöder inte snabbavspelnin framåt (eller bakåt).

Bildstörningar uppstår vid snabbavspelnin framåt eller bakåt.

Fjärrkontrollen fungerar inte.

- Ibland uppstår smärre bildstörningar. Detta är normalt.

Inga knapptryckningar (på DVD-spelaren och/eller fjärrkontrollen) fungerar.

- Kontrollera att batterierna är rättvända (+ och -).
- Batterierna är tomma; Byt batterier.
- Rikta fjärrkontrollen mot fjärsensorn och tryck på knapparna.
- Avståndet mellan fjärrkontrollen och spelaren får vara högst 6 meter.
- Avlägsna eventuella hinder mellan fjärrkontrollen och spelaren.
- Stäng av och slå på enheten igen. Eller, stäng av enheten, dra ut nätsladden och anslut den igen. (Funktionsstörningar kan uppstå på spelaren på grund av åska, statisk elektricitet eller andra yttre faktorer.)

AVSPELNINGEN startar inte trots att en titel är markerad.

Ljud- och/eller textningsspråket är inte det som är förinställt.

Textning visas inte.

- Detta kan bero på inställningen för barnläsnivån (Parental Control).
- Kontrollera inställningen för "PARENTAL".
- Om ljud- och/eller textningsspråket inte finns på skivan, visas/hörs inte det förinställda språket.
- Textning visas bara för skivor som spelats in med textning.
- Tryck på SUBTITLE för att visa textningen.

Ljudspråk (eller textningsspråk) går inte att välja. Det går inte att ändra kameravinkel.

- Detta kan bero på att det bara finns ett språk tillgängligt på skivan.
- Funktionen beror på vad som är tillgängligt på skivan. Även om skivan har flera inspelade kameravinklar, kan dessa vara inspelade endast för vissa scener.



Handskas med skivor


- Håll i kanten på skivan så att du undviker att lämna fingeravtryck på ytan. (A) Fingeravtryck, smuts och repor kan orsaka ljudstörningar.
- Skriv inte på avspelningsidan (den med etiketten på) med en kulspetspenna eller liknande som kan lämna repor eller skada ytan.
- Använd inte vinylskivrenöjningsprejer, tvättbensin, thinner, vätskor avsedda att förhindra statisk elektricitet eller andra lösningsmedel.
- Var försiktig så att du inte tappar eller böjer skivor.
- Placera aldrig flera skivor på skivtallriken.
- Försök inte stänga skivluckan om skivan inte är rätt placerad på skivtallriken.
- Se till att förvara skivor i sina fodral när de inte spelas.

Om ytan är smutsig (B)

Torka av ytan försiktigt med en mjuk, lätt fuktad (endast vatten) trasa.

När du torkar av skivor, torka alltid från mitten och utåt mot kanten.

(Om du torkar med en cirketrörelse kan det uppstå repor som kan förorsaka missljud eller att ljudet hoppar.)



Om skivor flyttas direkt från en kall till en varm plats kan det bildas fukt på skivan.

Torka av fukten med en mjuk, torr och luddfri trasa innan skivan spelas.

Felaktig skivförvaring

Skivorna kan skadas om de förvaras på följande platser:

- Områden utsatta för direkt solljus
- På fuktiga eller dammiga platser
- Områden direkt utsatta för värmeutsläpp eller värmealstrande utrustning

Skivor som inte kan spelas på den här enheten.

- CD-ROM (Program)
- CVD
- CD-G
- DVD med annan regionskod än den som finns på etiketten på baksidan av DVD-spelaren.

Underhåll

- Det är viktigt att stänga av enheten och dra ut nätsladden före rengöring och underhåll.
- Torka av enheten med en mjuk och torr trasa. Om ytan är mycket smutsig, torka rent med en trasa doppad i vatten och en svag tvällösning och sedan urvriden. Eftertorka med torr trasa.
- Använd aldrig alkohol, tvättbensin, thinner, rengöringsmedel eller andra kemikalier. Använd inte komprimerad luft för att avlägsna damm.

**Kameravinkel (Angle)**

På en del skivor är vissa scener filmade och inspelade ur flera olika kameravinklar (en och samma scen kan vara filmad framifrån, från vänster och höger sida, etc.). När du spelar en sådan skiva kan du trycka på knappen ANGLE för att titta på scenen från olika kameravinklar.

Kapitelnummer

Dessa nummer spelas in på DVD-skivan. En titel delas in i olika avsnitt som numreras så att det är enkelt att snabbt söka efter vissa avsnitt genom att söka på dessa nummer.

DVD

DVD är en högdensitets optisk skiva som spelats in med högkvalitets digitalt bild och ljud. Med hjälp av ny bildkompressionsteknologi (MPEG II) och högdensitets inspelningsteknologi, kan stora mängder rörliga bilder spelas in på DVD (en hel spelfilm till exempel kan spelas in).

DVD-skivans struktur består av två 0,6 mm tunna skivor som sitter ihop. Ju tunnare skiva, desto högre densitet som information kan spelas in med; därför har en DVD-skiva högre kapacitet än en 1,2 mm tjock skiva. Eftersom de två tunna skivorna sitter ihop, finns även möjlighet att i framtiden kunna spela in på båda sidor av skivan och på så sätt uppnå ännu längre avspelnings tid.

Textning

Detta är texten som visas längst ner på skärmen med en översättning eller avskrift av dialogen. Textningen spelas in på DVD-skivan.

Tidsmarkering

Tidsmarkeringen visar spelad tid från början av skivan eller en titel. Denna kan användas för att snabbt hitta en viss scen. (Funktionen kanske inte fungerar på vissa DVD-skivor.)

Titelnummer

Dessa nummer spelas in på DVD-skivan. På skivor som innehåller två eller flera filmer, numreras dessa som titel 1, titel 2, etc.

Spårnummer

Dessa nummer tilldelas de inspelade spåren på audio-CD-skivor. Med hjälp av spårnummer är det enkelt att snabbt hitta ett visst spår.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>