

# KENWOOD

## **SK-EXCL1**

---

MOBILE VIDEO CONSOLE

### **INSTRUCTION MANUAL**

**FOR USE WITH KENWOOD MOBILE VIDEO  
PRODUCTS**

**2000-up Ford Excursion  
1999-up Ford Super Duty Trucks\***

**\*(Extended Cab & Crew Cab with Center Console)**

KENWOOD CORPORATION

**Take the time to read through this instruction manual.  
Familiarity with installation and operation procedures  
will help you obtain the best performance from your  
new mobile video system.**

# Installation

## Accessories

6 - #8 x 1/2" Black SMS  
(KSMSB8.5)



2 - 1/4-20 Star Nut  
(KSN1420)



1 - Monitor Bracket  
(KMB701)



2 - Mounting Bracket  
(KMBEXCL1)



## Remove Factory Console:

Raise console lid and remove the (4) 8mm bolts holding the console to the floor. Slide the console toward the rear seats and remove the 4 factory screws, two on each side, toward the rear of the console. Remove the rear portion of the factory console enough to allow access to the rear radio control wiring, if so equipped. Disconnect the radio control wiring and remove the rear portion of the console.



Factory Console(Excursion)

### **Removal of factory radio controls: (if equipped)**

Remove the factory radio controls from the factory console by carefully unsnapping and sliding out. It may be helpful to unsnap and remove the cupholders from the console. Save radio controls for reinstallation into video console.



Factory Console (Super Duty Truck)

## Prepare Video Console

Prepare the monitor for installation by sliding the small studded bracket into the back panel of the monitor. Run the monitor data cable through the rectangular-shaped hole in the video console and connect to the monitor. Slide the monitor into the console and secure using the (2) supplied star nuts. (*Do not overtighten*)



Back of Factory Console

Reinstall the rear radio controls into the video console by pushing in until it snaps into place. Install the mounting brackets onto the side of the video console. The brackets mount with the "V" shaped notch down, and the smaller holes behind the video console. Line up the predrilled holes in the video console with the holes in the bracket. Secure the bracket with the supplied #8 x 1/2" sheet metal screws. Repeat procedure on opposite side.

## Filler plate

The filler plate is used in the event the vehicle is not equipped with rear radio controls. Install by centering the plate over radio control opening and marking the housing through the holes.

Remove the plate and drill a 3/32" hole at each mark and install using (2) of the supplied #8 x 1/2" sheet metal screws.



Installing Filler Plate

## Wiring and Connections

Route all wires and cable at this time.

Install wiring and cables according to the instructions provided with electronic equipment.

## Installation of Video Console

Make all electrical connections, including the rear radio controls.

Slide the video console onto the back of the factory console by sliding the top into place and swinging the bottom down. The brackets and the video housing should fit behind the rear edge of the factory console by about 1/2".

Line up the factory screw holes in the side of the console with the large holes in the bracket and secure with the factory screws removed earlier.

## Final Steps

Reinstall all previously removed factory components and panels.

Turn on and test everything.

(If the system doesn't work properly, recheck all connections and fuses.)

The install of the video system is now complete.



SK-EXCL1 Installed

Rev 10-01-01

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>