



Installation Instructions

This kit includes a water splash shield and clips. These can be installed together or separately to eliminate the possibility of water tracking on the bottom of the left or right evaporator brackets to the back wall where it could flow into the ice bin instead of back into the water trough.

INSTALLATION OF LEFT AND RIGHT CLIPS

1. Remove bin switch from its mounting position (depress locking tab and slide bin switch out).
2. Slide right side clip onto right evaporator bracket, as shown. Clip must be positioned towards front of evaporator bracket (bottom flange of clip must be located inside water trough).
3. Reassemble bin switch onto evaporator bracket.
4. Install left side clip onto left side evaporator bracket.

IMPORTANT: B-0320/B-0420 models only – clips cannot be installed on B-0320 and B-0420 models. Splash shield must be installed to prevent water tracking.

INSTALLATION OF WATER SPLASH SHIELD

1. Loosen bottom evaporator mounting screws.
2. Peel off backside of tape and slide splash shield between backside of evaporator and wall. Position splash shield into water trough so that all the water is deflected back into the trough.
3. Tighten evaporator mounting screws.

Manitowoc Ice, Inc.

2110 South 26 Street, P.O. Box 1720, Manitowoc, WI 54221-1720 USA
Telephone 920-682-0161, Fax – Sales: 920-683-7589, Service/Parts: 920-683-7585, Other: 920-683-7879

8009883
Rev. 08/25/97

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>