



USER MANUAL

About ICE Pal Plus

ICE Pal Plus is a smart mobile watch with a GPS/AGPS/LBS tracker. It's a wrist watch mobile phone equipped with a GPS tracker and SOS function. With ICE Pal Plus, parents can always keep track of their children's location on Google Maps and have the ability to contact them. Children can also make calls to the pre-set numbers. ICE Pal Plus is easily controlled via the free App. ICE Pal Plus availble both on the App Store and GooglePlay.


Features

- Micro-SIM card with GSM (2G) network
- Frequency: GSM 850/900/1800/1900MHz
- GPS/AGPS/LBS precise tracking
- Dual-way phone calls
- Read and send voice messages
- Remote voice monitor
- Instant location/route playback
- SOS function with dedicated button
- Notification when the watch leaves pre-set geo-fence
- Built-in speaker and microphone
- ELLP[™] ultra-low power consumption
- Environmentally friendly safety material

Watch Appearance and Display Information Watch Appearance Display Information — Steps 🛂 🙏 16888 🔳

Watch Charging

To protect the battery, please charge the watch for at least 12h for first time usage and for over 8 hours for second and third time usage.




Insert SIM Card

This watch relies on GPS technology and modern mobile devices. In order for these to work, they require a Micro SIM card with 2G data.











How to Use the Watch

Without a SIM card, it works as a watch

1) Long press the Power button to turn ON watch.

2) Long press the Power button for about 3 seconds to turn OFF the watch.

With a SIM card, it acts as a mobile phone after being powered on

1) Power OFF the watch and insert the Micro SIM card. Then, close the rubberplug. : Please make sure the SIM card has the function of Caller ID Display, SMS and GPRS mobile data flow.

2) Light up the watch display screen to check the time.data.weeks and steps.

Long press phone call button for 3 seconds, the watch will automatically send a current location to the "family contact list", and continually dial the 1st number and alternate between the 2nd and 3rd numbers for 3 times until the phone gets

• Make a phone call Standby statement

Double press the "Phone Call" button to enter the phonebook page. Press the "Phone Call" button again to choose a phone number; then long press this button to dial; press voice message button to exit the phonebook page. Press the "Voice Message" button to hang up the phone call during dialing and answering a phone call.

• Answer a phone call

Press the "Phone Call" button to answer the phone call from family members

Press the "Voice Message" button to hang up the phone call.

About App App Download

iPhone users can search and download the app "ICE PAL plus" on the App Store. Andriod users can search and download the app "ICE PAL plus" on GooglePlay.



Registration

1) Install and open the App after download.
2) Click the "Registration" button to enter the registration page. Choose your country and fill in your phone number to complete the registration



Add Devices

1) Connect your mobile phone using WIFI or switch on mobile data to get an

2) Choose your country and fill in your account number and password to log on to

3) Click the icon on the left head to enter the watch addition page.

How to Add a Device


Way 1: Scan the QR-code on the back of watch or the below QR-code to add the

Please keep this QR-code for future device addition

Way 2: Fill in the CID number on the gift box or warranty card to add the device and

3. Watch Location

Press the location area on the main page to check the precise position of the watch. You can also change the map model: satellite map, 2D map or 3D map by pressing the icon on the right hand side.



through successfully. Press the "Voice Message" button to hang up the phone call.

App Operation

After logging in, you will see the main screen as shown below. It shows your added

device information such as your device name / time / address / watch battery capacity and the main functions of the watch.



0000

1. Edit User Information

Press the person icon on the left top of the main screen. Then, you can edit the user information of the watch. You can also change the watch image by clicking the person icon in the user info page.





Press the setting icon on the top right corner to enter the watch settings page as shown below. You can change the App's languages, manage your account information or logout from the App.



* You can add contacts as many as you want.

4. Route Playback

Press the icon on to track the history of the watch device by setting the date. It will then show the route on the map.


* The first account connected with the watch will default as its administrator.






5. Geo-fence List

A "fence" is a virtual boundary for a zone which the GPS watch is not supposed to leave. For example, if you use the GPS watch device on your child ,you could set up a geo-fence around your house or school to get an alert if your child leaves the area. Press the fence list icon [iii] in "Manage Page" to set a geo-fence. Press the icon 🕟 and click the fence listicon.



6. Contact List

This watch allows 30 contact numbers including the administrator preset in the contact list. Press the icon 🃋 in "Manage Page" to enter the contact list. Click the "Add" button to add numbers as shown below.



7. Phone Call


Press the icon 🔼 to make a phone call to the watch device as shown below.





8. Guarding

Click icon in main page to enter the guarding function. Press the icon and it will automatically place a phone call to the watch without ringing. Then, you can hear the environment around the watch to ensure the safety of your child.



9. Voice Message

Press voice message button 💽

(1) Long press "Hold to Talk" to record a voice message and send it to the watch

*Voice message recorded cannot be longer than 15 seconds.


(2) When receiving a voice message from the watch, the icon will look like this and you can click the icon to check message details.

* The mobile phone will receive reminder messages even if it is switched off as the App still runs offline



10. Mute Mode

To make sure kids are not disturbed during class, you can set the watch on mute mode using the App. Click the icon in "Manage Page" to enter mute mode settings. You can set 5 different mute periods and repeat days at the same time. During the mute period, the watch will receive the phone call without ringing or vibrating as shown below:



11. Manage the Watch

Press the manage icon is on the main screen to enter the watch's "Advanced Settings" page as shown below. You can remotely turn off the watch, watch alarm, watch volume or press the icon it or estore factory settings.



cifications

- Dimension: 50*38*10mm
- Screen size: 1.0"
- Weight: about 40g
- Chipset: MTK6260D
- GPS/AGPS: u-BLOX 7020
- G-sensor: BOSCH BMA250E
- Operating System: NUCLEUS
- Support: GPS/AGPS/LBS,Access to backend server
- Frequency: GSM/GPRS850+1900+1800MHz
- GPRS/WAP/MMS/: GPRS CLASS12
- Flash: 32M bit
- RAM: 32M bit
- Antenna: built-in GSM,GPS,LBS antenna
- Battery: Li-Po 450mAh
- Working time: 75-90 hours
- GSM talking time: >2 hours
- Waterproof: daily waterproof

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com