

PARTS LIST

for

KitchenAid®

SUPERBA 27" BUILT-IN ELECTRIC THERMAL CONVECTION OVEN

**MODEL
KEBS177YBL1**



▲ BL-Black Glass
AL-Almond Glass
WH-White Glass




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



OVEN PARTS

For Model: KEBS177YBL1, KEBS177YWH1, KEBS177YAL1
(Black) (White) (Almond)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Model: KEBS177YBL1, KEBS177YWH1, KEBS177YAL1
(Black) (White) (Almond)

| Illus. Part No. No. DESCRIPTION | Illus. Part No. No. DESCRIPTION | Illus. Part No. No. DESCRIPTION |
|---|------------------------------------|--|
| NOTE: The screws and nuts required to attach a part are listed immediately following that part. | | |
| 1 3185085 Button, Plug | 20 3179220 Rail, Support (2) | 34 3177787 Vent, Lower Trim |
| 3 3177738 Cabinet, Back | 300890 Screw (4) | 3177789 White or Almond Model |
| 300890 Screw (10) | 22 3177434 Support, Oven | 3180022 Screw (4) |
| 6 3178138 Cabinet, Top | 300890 Screw (2) | 4168863 Screw (2) |
| 300890 Screw (5) | 23 3178612 Shield, Radiation | 35 3183791 Vent, Tube |
| 7 3183748 Top, Module | 3179795 Screw (6) | 39 4168203 Cover, Cap Tube |
| 300890 Screw (8) | 300890 Screw (2) | 4159445 Screw |
| 8 Side, Cabinet | 24 3177433 Bracket, Hinge | 40 4167518 Plate, Cover |
| 3177441 Left Hand | 300890 Screw (2) | 3177991 Screw |
| 3177442 Right Hand | 25 3177572 Side, Module | 43 3177551 Bottom, Oven |
| 300890 Screw (14) | (R.H. & L.H.) | 44 4163883 Cover, Probe |
| 9 3181699 Tube, Vent | 300890 Screw (4) | 3177991 Screw (4) |
| 3179117 Screw (3) | 26 3177561 Back, Module | 45 3177545 Bracket, Conduit |
| 11 3150505 Oven Light Assy. | 300890 Screw (8) | 46 3183752 Bracket, Mounting |
| 12 311255 Bulb, Oven Light | 27 3177473 Liner, Oven | Control Panel |
| 14 3177682 Frame, Front | 28 3178298 Hinge, Door (2) | 300890 Screw |
| 15 3179813 Seal, Door | 3178000 Screw (4) | |
| 16 3179848 Clip, Oven Seal | 31 4173553 Switch, Door | FOLLOWING PARTS NOT ILLUSTRATED |
| 17 3177681 Bracket, Switch | 4159117 Nut (2) | INSULATION |
| 18 3177923 Insulator, Switch | 313489 Screw (2) | 3177862 Insulation, Wrap |
| 19 3177621 Bottom, Module | 3177991 Screw (2) | 3177872 Insulation, Back |
| | 33 3179587 Retainer, Seal | |
| | 4159450 Screw (2) | |
| | 3179776 Screw (4) | |
| | 4168863 Screw | |

OPTIONAL PARTS (NOT INCLUDED)


| Illus. Part No. No. DESCRIPTION | Illus. Part No. No. DESCRIPTION | Illus. Part No. No. DESCRIPTION |
|--|---|--------------------------------------|
| <u>SPLICING WIRES--25FT. LENGTH</u> | | |
| 350806 18 Ga. 80°c Rating Yellow | <u>PAINT, TOUCH-UP (1/2oz.)</u> | |
| 242829 16 Ga. 80°c Rating Blue | 72017 White | <u>PAINT, BULK (1 qt.)</u> |
| 242820 14 Ga. 150°c Rating Black | 72107 Almond | 799344 White |
| 242821 Blue | 72110 Harvest Gold | 978883 Almond |
| 242822 14 Ga. 150°c Rating Brown | 72112 Toast | 261891 Harvest Gold |
| 242823 Green | 72113 Platinum | 285367 Toast |
| 242824 Orange | 72032 Black | 285368 Platinum |
| 242825 Red | 261869 Citrine White | <u>ADHESIVE</u> |
| 242826 White | <u>PAINT, PRESSURIZED SPRAY (13 oz.)</u> | 482338 Sealer, Silastic (3 Oz.) |
| 242827 Yellow | 350930 White | 591014 Adhesive, Loctite (1/3 Oz.) |
| 242830 14 Ga. 200°c Rating Brown | 350956 Almond | <u>ACCESSORY PARTS</u> |
| 242831 Red | 261890 Harvest Gold | 799832 Kit, Porcelain Repair (White) |
| 242832 Yellow | 285365 Toast | 832985 Rack, Cooking (Bi-Level) |
| 12 Ga. 150°c Rating | 285366 Platinum | |
| 242828 Black | 830864 Black | <u>MISCELLANEOUS</u> |
| 242829 Red | 350942 Primer | 3171507 Mounting Hardware |
| | 350941 Leveler (Primer) | |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LATCH AND VENT PARTS

For Model: KEBS177YBL1, KEBS177YWH1, KEBS177YAL1

(Black) (White) (Almond)




| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|---|----------|-------------------|------------|----------|----------------------|------------|----------|-----------------------|
| NOTE: The screws and nuts required to attach a part are listed immediately following that part. | | | 8 | 3184039 | Knob, Latch Handle | 17 | 3183533 | Bracket, Mounting Fan |
| 1 | 3183748 | Module, Top | | 3183294 | Screw | | 3177991 | Screw |
| 2 | 258076 | Block, Terminal | 9 | 3184040 | Spacer, Latch Handle | 18 | 3183720 | Blower, Fan |
| | 308043 | Screw | | 3184037 | Screw (2) | 19 | 3183791 | Tube, Vent |
| 4 | 3183784 | Switch, Latch | 10 | 3178410 | Latch Mechanism | | 4173231 | Screw |
| 5 | 3178185 | Insulator, Switch | 11 | 3177496 | Plate Mounting | 20 | 3149650 | SPST Thermostat |
| 6 | 3177662 | Guard, Switch | | 3177991 | Screw | | 300890 | Screw |
| 7 | 3177969 | Handle, Latch | 13 | 3183954 | Nozzle, Vent Bottom | 22 | 3183953 | Box, Vent |
| | | | 14 | 3183955 | Nozzle, Vent Top | 23 | 3183785 | Shield, Heat |
| | | | 15 | 3183999 | Box, Vent | 24 | 313755 | Seal, Foam |
| | | | 16 | 3183964 | End, Vent Box | | | |
| | | | | 300890 | Screw | | | |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: KEBS177YBL1, KEBS177YWH1, KEBS177YAL1
(Black) (White) (Almond)



| Illus. No. | Part No. | DESCRIPTION |
|---|----------|-----------------------------------|
| NOTE: The screws and nuts required to attach a part are listed immediately following that part. | | |
| 1 | 3181780 | Membrane, Switch Black |
| | 3181781 | White |
| | 3181782 | Almond |
| 2 | 3183794 | Bracket, Mounting Switch Membrane |
| 3 | 3181703 | Microcomputer |
| | 3179117 | Screw |
| 4 | 3183705 | Retainer, Bracket |
| | 3182939 | Screw |


| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|--------------------------|
| 5 | 3182985 | Clip, Retainer (3) |
| 6 | 3182162 | Trim, Door (2) |
| 7 | 3182151 | Door, Latch Handle Black |
| | 3182154 | White |
| | 3182157 | Almond |
| | 3179847 | Screw |
| 8 | 3183702 | Trim, Panel |
| | 300890 | Screw |
| 9 | 3184321 | Bracket |
| | 3182939 | Screw |
| 10 | 3182148 | Frame, Control Panel |
| 11 | 3184567 | Clip, Control Frame |

| Illus. No. | Part No. | DESCRIPTION |
|--|------------|---------------------------|
| FOLLOWING PARTS NOT ILLUSTRATED | | |
| LITERATURE PARTS | | |
| | LIT4174237 | Repair Parts List |
| | LIT3182131 | Tech Sheet |
| | LIT3183659 | Installation Instructions |
| | LIT3182135 | Use & Care Guide |
| | LIT3150693 | Cookbook |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Model: KEBS177YBL1, KEBS177YWH1, KEBS177YAL1
 (Black) (White) (Almond)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

| | | |
|---|---------|----------------|
| 1 | 3177599 | Liner, Door |
| 2 | 3178584 | Gasket, Window |
| 3 | 3179693 | Spacer, Window |
| 4 | 3177831 | Latch, Strike |
| | 300890 | Screw (2) |

| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

| | | |
|---|---------|-----------------------------|
| 5 | 3177718 | Insulation Retainer |
| | 300890 | Screw (4) |
| 6 | 4163855 | Bracket, Glass Mounting (2) |
| | 300890 | Screw (4) |
| 7 | | Glass, Door |
| | 3181548 | Black |
| | 3181550 | White |
| | 3181552 | Almond |
| 8 | 4164243 | Glass, Reflective |
| 9 | 3181402 | Frame, Door |



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|

| | | |
|----|---------|--------------------|
| 10 | | Handle, Door |
| | 3182165 | Black |
| | 3182168 | White |
| | 3182171 | Almond |
| | 3181637 | Screw (2) |
| 11 | 3182138 | Spacer (2) |
| 13 | 4164235 | Window Pack |
| 14 | 3180094 | Insulation, Door |
| | 4168863 | Screw (6) |
| | 3178001 | Screw, Black (2) |
| 15 | 3181651 | Bushing |
| 16 | 3181701 | Bumper, Door Glass |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN LINER PARTS

For Model: KEBS177YBL1, KEBS177YWH1, KEBS177YAL1
(BLACK) (WHITE) (ALMOND)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

| | | |
|----|---------|---------------------------|
| 1 | 3177473 | Liner, Oven |
| 2 | 661415 | Element, Broil |
| 3 | 3147563 | Grill, Broiler |
| 4 | 3147845 | Pan, Broiler |
| 5 | 3185307 | Rack, Offset |
| 6 | 3185308 | Rack, Oven |
| 7 | 661416 | Element, Bake |
| | 3179117 | Screw (2) |
| 8 | 4167277 | Nut, Meat Probe |
| 9 | 4163975 | Gasket, Meat Probe |
| 10 | 4167266 | Probe Cover |
| 11 | 4159557 | Washer |
| 13 | 4173575 | Receptacle, Lighted Probe |
| 14 | 3150144 | Meat Probe |
| 16 | 3180694 | Bracket, Element |
| | 3179117 | Screw (4) |
| 19 | 3179672 | Spacer, Tubing |
| 20 | 3178517 | Element, Convection |
| | 3179117 | Screw (2) |
| 21 | 3180815 | Cover, Fan |
| | 3179117 | Screw (4) |
| 22 | 3181534 | Rack, Roasting |
| 23 | 3148440 | Sensor, Heat |
| | 3179117 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONVECTION FAN PARTS

For Model: KEBS177YBL1, KEBS177YWH1, KEBS177YAL1
 (Black) (White) (Almond)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------|
|------------|----------|-------------|


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

| | | |
|----|---------|---------------------|
| 1 | 3178512 | Plate, Mounting |
| 2 | 4173193 | Screw, Fan Mounting |
| 3 | 4173194 | Lockwasher (3) |
| 5 | 4173237 | Nut, Left Hand |
| 6 | 4173236 | Fan |
| 7 | 3182088 | Motor |
| 8 | 4173238 | E-Ring |
| 9 | 4173185 | Bracket Guard |
| 11 | 3179790 | Gasket, Foam |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS

For Model: KEBS177YBL1, KEBS177YWH1, KEBS177YAL1
 (Black) (White) (Almond)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|--------------------------------|
| 1 | 3183655 | Harness Wire Door Light Switch |
| 2 | 3183976 | Harness, Wire Latch Assy. |
| 4 | 3184221 | Harness Wire Main |
| 5 | 3183657 | Harness, Wire Blower Fan |
| 6 | 3179668 | Standoff, Wire |
| | 300890 | Screw (4) |
| 8 | 4159037 | Clamp, Wire |
| | 112432 | Nut (3) |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>