

quickpress = next song press & hold = volume up 2. [►II MODE] button **Bluetooth**® quickpress = Play/Pause/Answer Call/End Call

> 3. [**◄ VOL-**] button quickpress = previous song press & hold = volume down

Charging the Bluetooth Speaker

DC5V port on the side of the speaker.

3. The **RED LED** indicator light turns on.

fully charged (approximately 4 hours).

0

light starts to flash.

1. Connect the small end of the Micro USB charging cord into the

2. Connect the other end of the Micro USB cable to your

4. The **RED LED** indicator light shuts off when the speaker is

NOTE: When the battery is running low, the RED indicator

ALIX DC5V OFF ON

NOTE: Make sure you charge your speaker for 8 hours

before using it for the first time.

4. LED light

5. [POWER OFF/ON] switch

6. 3.5 mm auxillary cord jack

7. DC5V charging jack

computer's USB port.

Micro USB Cable

1. [**►► VOL**+] button

3. Microphone


In the box

Bluetooth Headset

Wireless Stereo

Speaker

EBT1000



Owner's

3.5 mm Charging Cable Auxillary Cord

Drive Safe

Driving while talking on your mobile phone is dangerous, and

Although this device enables drivers to conduct handsfree conversations, it is still dangerous to drive and use a mobile phone at the same time.

We recommend pulling over before making or answering calls, especially during adverse driving conditions. Please use your mobile phone, and our product responsibly while driving!



mode

_0-

5. Set your mobile phone to search for Bluetooth devices.

light flashes 6 times quickly.

Pairing the speaker with a Bluetooth enabled phone

2. Keep your **Bluetooth Speaker** and mobile phone within **3**

3. Slide the [POWER OFF/ON] switch to the ON position,


4. Quickpress the [►II MODE] button, the LED will flash

BLUE and RED alternately. The speaker is now in pairing


1. Make sure the Bluetooth Speaker is turned off.

feet of each other during the pairing process.


the LED light will flash BLUE 6 times quickly.



6. When the phone finds the headset, confirm by selecting EBT1000 from the list.




7. Enter passcode "0000" when prompted by the phone.




OR depending on which model mobile phone you are trying to connect the speaker to, it may not be necessary to enter a passcode.

8. Your mobile phone will confirm that the pairing was completed, and prompt you to accept the connection. Please respond **YES** to connect the headset to your mobile phone. If the pairing was successful, the headset's indicator light flashes BLUE every few seconds.



9. When attempting to reconnect the headset to your mobile phone, you may see the message below, and your mobile phone will prompt you to accept the connection request to the EBT1000 headset, and an option not to ask this again. Please accept the connection, and if you select "Don't ask this again", your phone will automatically accept future connection requests from your Bluetooth Speaker.



NOTE: The screenshots above are typical of many Bluetooth enabled phones in the market today, and are used to assist in the explanation of the pairing process. Your mobile phone's interface and interaction with the Bluetooth Speaker may slightly differ from the illustrations above

Using your Bluetooth Speaker

Powering ON/OFF

LED light

• To turn ON, slide the [POWER ON/OFF] switch to the ON position, the LED flashes BLUE 6 times quickly then once every few seconds.

• To turn OFF, slide the [POWER ON/OFF] switch to the OFF position. The LED will turn RED and the speaker will power

Answering/Ending a call

• To answer a call, quickpress the [►11 MODE] button. • To end a call, quickpress the [► | MODE] button.

Adjusting the volume

Press & hold the [➤ VOL +] or [VOL -] button to adjust the volume to the desired level

NOTE: You may also adjust the volume from your mobile phone's volume control.

To make a call

Dial the number and press the send button on your mobile phone, the call is automatically transferred to the headset.





Redialing the last number called (Dependent on your phone supporting this feature)

Quickpress the [►II MODE] button twice. The last number called will be redialed.

Rejecting calls

To reject an incoming call, longpress the [►II MODE] button

Stereo Bluetooth

This speaker allows you to listen to (in full stereo) and control* the music on your Bluetooth enabled mobile phone, computer or mp3 player and supports the following Bluetooth profiles:

- A2DP Advanced Audio Distribution Profile
- AVRCP Audio/Video Remote Control Profile
- HSP Headset Profile

To use the speaker to listen/control music, your Bluetooth enabled device must support the A2DP and AVRCP profiles. Please

refer to the user guide of your Bluetooth enabled device for more information.

Bluetooth ((stereo)

Music or Chat





laying music

To enjoy wireless music on your Bluetooth Speaker, make sure you are connected to a Bluetooth enabled media device. Once connected, you can press PLAY on your Bluetooth device or you can press the [►II MODE] button on the EBT1000 Bluetooth Speaker. Once playback has begun, you can control the music or answer phone calls from the control buttons of the Bluetooth Speaker (Not all mobile phones support the control of music using Bluetooth).

NOTE: Most media enabled smart phones will display "connected to phone audio and media" when connecting to the Bluetooth Speaker. This means you can make phone calls and enjoy your music.

Adjusting the volume

Press and hold the [► VOL+] or [K VOL-] button to adjust the volume to the desired level.

NOTE: You may also adjust the volume from your mobile phone's volume control

Play/Pause*

Press the [►II MODE] button to pause the music. To resume music playback, press the [►II MODE] button again.

Skipping or searching songs* (Dependent on your phone supporting this feature) Press the [► VOL +] button to go to the next song.



1. [► VOL+] button quickpress = next song press & hold = volume up

2. [►II **MODE**] button quickpress = Play/Pause/Answer Call/End Call

3. [**◄◄ VOL-**] button quickpress = previous song press & hold = volume down

4. LED light

Using as a wired speaker

The EBT1000 can be used as a wired speaker by using the included 3.5mm Auxiliary Cord.

- 1. Plug one end of the Auxiliary cord into the AUX jack on the side of the speaker.
- 2. Plug the other end of the Auxiliary Cord into the headphone jack of any media device which has a 3.5mm headphone jack (This is standard headphone-out jack).
- 3. Use your media device's music controls to control the music. Only volume can be controlled when connecting to a device using the Auxiliary Cord

*The Emerson Bluetooth stereo wireless headphones are compatible with any brand of Bluetooth-enabled phone or music device that supports Advanced Audio Distribution Profile (A2DP) and Audio Video Remote Control Profile (AVRCP).

In order for Bluetooth devices to communicate with one another properly, they must utilize the same Bluetooth profile. To determine the profiles supported by your device (mobile phone, computer or mp3 player), please refer to the device's user quide.

Certain Bluetooth features including those listed may not be supported by all compatible Bluetooth-enabled devices, and/or the functionality of such features may be limited in certain devices.

Troubleshooting tips

(?) I Can pair the Bluetooth Speaker with my Bluetooth device, but I cannot hear any music?


Make sure your Bluetooth device supports A2DP profile.

(?) My iPhone is paired correctly and I hear music but I cannot control (play, pause, next song, previous song) the music using the controls on the Bluetooth Speaker.

• At the time of this User's Guide publication, the iPhone only supports the playback of music using Bluetooth, and does not support the control of the music using Bluetooth.

(?) I cannot get the **Bluetooth** Speaker into **Pairing Mode**.

- Make sure the **Bluetooth** Speaker is turned off before beginning the pairing process.
- Slide the [Power ON/OFF] switch to the ON position, wait for the LED to flash BLUE 6 times quickly, then quick press the [►II MODE] button. The RED and BLUE lights will flash alternately, this will signal that the headphones are in



Pairing Mode, and ready to connect to your mobile phone.

- · Make sure that you fully charged the speaker before pairing. • Keep your Bluetooth Speaker and mobile phone within 3 feet of each other during the pairing process.
- Check that your phone's Bluetooth feature is turned ON. • Try repeating the pairing process, see "Pairing the speaker with a Bluetooth enabled device."

Safety information

Check local laws regarding use of a mobile handset and wireless headset while driving. If you use the **Bluetooth Headset** while driving, ensure your attention and focus remains on your driving. Observe all signs in the designated areas where some electronic devices or RF radio products are required to be switched off. These could include airplanes, hospitals, blasting areas, and potentially explosive atmospheres.



CAUTION: Although this device enables drivers to conduct handsfree conversations, it is still dangerous to drive and use a mobile phone at the same time. Always keep your full attention on your driving

Product maintenance

Power off this product when not in use.

DO NOT expose this product to water or other liquids. DO NOT use abrasive cleaning solvents to clean the Bluetooth Speaker. If you will not use the **Bluetooth Speaker** for long periods, be sure store it in a dry place, free from extreme temperature, humidity and dust.

FCC and telephone company information

This equipment has been tested and found to comply with the

requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules. These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Re-orient or relocate the receiving antenna.

Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

Industry Canada

Do not attempt to repair or modify this equipment.

Warning: Changes or modifications to this equipment not

could void the user's authority to operate the equipment.

Operation is subject to the following two conditions: (1) This

device may not cause interference and (2) This device must

accept any interference, including interference that may

The term "IC:" before the certification/registration number

only signifies that registration was performed based on a

Declaration of Conformity indicating that Industry Canada

technical specifications were met. It does not imply that

cause undesired operation of the device.

Industry Canada approved the equipment.

APPLICABLE TO THIS PRODUCT. ALL OTHER WARRANTIES EXPRESS OR IMPLIED (INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTARII ITY OR FITNESS FOR A PARTICUI AR PURPOSE) ARE HERERY DISCLAIMED, NO VERBAL OR WRITTEN INFORMATION expressly approved by the party responsible for compliance GIVEN BY SOUTHERN TELECOM INC. IT'S AGENTS, OR EMPLOYEES SHALL CREATE A GUARANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY.

> IS THE EXCLUSIVE REMEDY OF THE CONSUMER, SOUTHERN TELECOM INC. SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT OR ARISING OUT OF ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THIS PRODUCT. THIS DISCLAIMER OF WARRANTIES AND LIMITED WARRANTY ARE GOVERNED BY THE LAWS OF THE STATE OF NEW YORK, EXCEPT TO THE EXTENT PROHIBITED BYAPPLICABLE LAW, ANY IMPLIED WARRANT OF MERCHANTARII ITY OR FITNESS FOR A PARTICUL AR PURPOSE ON THIS PRODUCT IS LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion nor limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts so the above limitations or exclusions may not apply



Manufactured by Southern Telecom Inc. Brooklyn, NY 11232 © 2012 Southern Telecom Inc. All rights reserved. Emerson and the G-Clef logo are registered trademarks of Emerson Radio Corp. Parsippany, New Jersey USA.

Warranty information

Limited Warranty

In the unlikely event that this product is defective, or does not perform properly, you may within ninety (90) days from

service center for repair or exchange.

TO OBTAIN WARRANTY SERVICE:

 Provide proof of the date of purchase within the package (Dated bill of sale). Prepay all shipping costs to the authorized service center,

your original date of purchase return it to the authorized

- and remember to insure your return. Include a return shipping address (no P.O. Boxes),
- a telephone contact number, and the defective unit within the package.
- Describe the defect or reason you are returning the product.

Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged

The shipping address of the authorized service center is:

as a result of shipping will require you to file a claim with the carrier.

Southern Telecom Inc. ATTN: Returns Department 14-C 53rd Street Brooklyn, NY 11232

Should you have any questions or problems concerning this product, please contact our customer service department at

(1-877-768-8483 (Toll Free) Monday - Thursday: 9AM - 5PM (EST) Friday: 9AM - 3PM (EST)

via e-mail at

cs@southerntelecom.com

Warranty service not provided

This warranty does not cover damage resulting from accident, misuse, abusé, improper installation or operation, lack of reasonable care, and unauthorized modification. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.

Limitation of Warranty:

• THE WARRANTY STATED ABOVE IS THE ONLY WARRANTY

REPAIR OR REPLACEMENT AS PROVIDED UNDER THIS WARRANTY

to you. This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.



www.emersonphones.com

The Bluetooth® word mark and logos are owned by the Bluetooth

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com