


# 69 - HINGE PIN DOOR STOP




FOR USE ON REMOVABLE PIN-HINGED TYPE DOORS TO STOP DOOR AND PREVENT DAMAGE TO DOOR, WALL AND DOOR KNOB. FEATURES REMOVABLE BUSHING TO ACCOMMODATE LARGE HINGE PINS.

## INSTALLATION INSTRUCTIONS


**TOOLS REQUIRED:** Regular screwdriver and hammer.

1. Using screwdriver and hammer, carefully remove pin (A) from hinge.
2. Position door stop on top of hinge and tap hinge pin (A) into hinge using hammer. If hinge pin (A) is too large, remove bushing (B) by loosening bolt (C); retighten.
3. To adjust for desired degree of opening, loosen adjustment bolt (C) and slide stop arm (D). Retighten bolt.



**NOTE:** Two hinge pin door stops are recommended per door.

ASK FOR OTHER FINE HARDWARE BY H.B. IVES



HINGE PIN DOR STOP C69F3 BRASS

MADE IN U.S.A.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>