

## Record in Hi-Definition! Video Recording Guide

**1 Turn off the camera and attach the battery pack**

Battery

Set the power/mode switch to **OFF (CHARGE)**

**2 Charge the battery pack**  
Required charging time (approx.): 2 hr. 40 min.

To AC Outlet (110V to 240V)

Blinks while charging. When the lamp goes out, charging is finished.

**3 Open the lens cover**

Lens cover switch

LENS COVER

**4 Open the LCD monitor**

LCD monitor

**5 Set the power/mode switch to ON**

Slide while pressing down the lock button

**6 Select auto recording mode**

AUTO

The mode changes when you press the button

<b>Auto recording mode</b>	<b>Manual recording mode</b>
<b>A</b>	<b>M</b>

**7 Start recording**

REC

Press **REC** button to start recording, and press it again to stop

Picture Quality	Remaining space on the hard disk
<b>XP [4h 59m]</b>	<b>XP [4h 59m]</b>
<b>REC</b>	<b>  </b>
Recording	Record-standby

**When the recording is failed...**  
Check the LCD monitor one more time.

**1 Did you select video mode?**

<b>Video mode</b>	<b>Still image mode</b>

MODE

The mode changes when you slide the switch

**2 Did you select video recording mode?**

<b>While recording</b>	<b>While playing back</b>

**SELECT PLAY/REC**

The mode changes when you press the button

**Let's Playback Videos!**

**1 Follow the procedures 1 to 6 shown in the left side of this sheet**

**2 Select playback mode**

**SELECT PLAY/REC**

The mode changes when you press the button

Selected video file

**3 Move the set lever to ^/~/</> to select the desired file**

**4 Press down the set lever to start playback**

Press down the set lever

**Basic Operations during Playback**

- Return to the first scene of the file
- Play/Pause
- Reverse search
- Forward search
- Go to the first scene of the next file

For customers using DVD Burner  
(sold separately)

# Back-Up Hi-Definition Images (Easy and correct way of copying to a DVD)

## 1. Get ready a recommended disc

Please use the recommended discs stated below.  
Using discs other than those recommended may cause problem when copying to the DVD and when playing back the DVD.


### Recommended discs

	DVD-R	DVD-RW	DVD-R DL (single-sided double layer)
Brand	JVC TDK Verbatim SONY	JVC	JVC Verbatim

### Caution

- Only DVD-R and DVD-RW discs can be used.
- Recording and playback may not function properly if the recording side is scratched or dirty.

## 2. Set up each device before copying



**1** Connect the USB cable provided with DVD Burner (CU-VD40/CU-VD20)

**2** Turn on the DVD Burner

After turning on the power, wait for approximately 20 seconds before proceeding to step 3.  
The burner may not function properly within this 20 seconds.

**3** Turn on the camera (GZ-HD3)

**4** Insert a new recommended disc into the DVD Burner


Next, operate the camera (GZ-HD3). Proceed to step 3. ➔

## 3. Copy all images to the DVD


Perform operations on the camera.

**1** Confirm that the display on the right appears on the LCD screen of the camera (GZ-HD3)


**2** Select “NORMAL BACK-UP”



**3** Select “ALL”




**4** Select “EXECUTE AND FINALIZE”






**IMPORTANT**

- Playback is not possible if the disc is not finalized.
- Wait for the “copy in progress” screen on the right and the “hourglass” mark to disappear, then turn off the power and disconnect the USB cable.


**5** Exit



(Camera's LCD screen display)



“Copy in progress” screen



**Copying completed!**

### Note

- There are other ways of copying which includes copying only the desired files. For details, refer to the instruction manual of the camera (GZ-HD3).

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>