

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KEBS277SBL04, KEBS277SWH04, KEBS277SSS04
(Black) (White) (Stainless)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	12	W10169757	Bulb, Light	29	W10131825	Sensor
	8304336	Installation Instructions	13	3400832	Screw (2)	30	8303724	Vent, Center
	W10162180	Use & Care Guide	14	8304629	Frame, Front	31	8303772	Base, Chassis
		Tech Sheet	15		Gasket, Door	32	8304478	Retainer, Gasket
	W10220954	English		8304494	Lower	33	8303517	Cover, Back
	W10220955	French		4455381	Upper	34		Trim, Bottom Vent
	8304335	Easy Set Guide	16	3196176	Screw		8303706BL	Black
		Safer Cooking Tips	17	4449040	Screw		8303706WH	White
	9762761	English	18	4449154	Screw		W10165444	Stainless
	W10065852	French	19	4451477	Support, Insulation	35	4448444	Grommet, Mounting Rail
2	W10153090	Bracket, Base	20	4450038	Screw (2)	36	3400893	Screw (12)
3		Hinge Receiver	21		Mounting Rail, Side Right	37	W10169348	Bracket, Thermostat
	4455606	Right		8303677BL	Black			
	4455605	Left		8303677WH	White			
4	W10105790	Bumper, Door (2)		8303678BL	Black			
5	8303829	Exhaust, Vent Slope		8303678WH	White			
6	W10181198	Divider, Center Vent	22	W10195935	Latch, Mortorized			
7	W10204469	Top Chassis	23	4449743	Screw			
8	4449809	Screw	24	4449748	Screw			
9	4452158	Tube, Vent	25	4455641	Side, Chassis			
10	W10169756	Lens, Light	26	8304304	Back, Chassis			
11	W10009940	Oven Light Assembly	27		Liner, Oven (Not serviceable)			
			28	8304452	Thermal Fuse 105C			

FOLLOWING PARTS NOT ILLUSTRATED


INSULATION

- 8303966 Insulation, Wrap
- 8303968 Insulation, Back

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Models: KEBS277SBL04, KEBS277SWH04, KEBS277SSS04
 (Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
1	8303717BL 8303717WH W10165446	Panel, Control Black White Stainless
2	8303687	Support, Appliance Manager
4	8304332	Keyboard, Glass Touch
5	W10172472	User Interface
6	8303720	Backer, Control
7	8303887	Bracket, Enclosure (2)
8	4449154	Screw
9	3400832	Screw
10	W10119142	Appliance Manager
11	8304441	Resistor, Drop

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: KEBS277SBL04, KEBS277SWH04, KEBS277SSS04
(Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	8304522	Bumper, Door
2	W10174288	Hinge, Door (2)
3	3196183	Screw
4	8304580BL	Vent, Door Top
5		Bracket, Door
	8304377	Right
	8304378	Left
6	8303738BL	Door Liner
7	8303732	Glass, Inner
8	4449743	Screw
9		Cover, Hinge
	W10137044	Right
	W10137043	Left



Illus. No.	Part No.	DESCRIPTION
10	8304523	Seal
11	8304361BL	Bracket, Handle
12		Door Glass, Assembly
		Lower Includes #17
	8304001	Black
	8304003	White
	W10237352	Stainless
		Door Glass, Assembly
		Upper No Badge
	8304002	Black
	8304004	White
	W10237353	Stainless

Illus. No.	Part No.	DESCRIPTION
13		Door Handle
	8303775BL	Black
	8303775WH	White
	8303775SS	Stainless
15	8303745BL	Frame, Door Side(2)
16	8303754	Door, Top Bracket
17		Badge
	8304603BL	Black
	8304603WH	White
	8304603SS	Stainless

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KEBS277SBL04, KEBS277SWH04, KEBS277SSS04
 (Black) (White) (Stainless)




Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

1	8304602	Element, Broil Shield
2	9760774	Element, Broil
3	4449154	Screw
4	8303842	Rack, Oven
6	9760768	Element, Bake
7	4455036	Tray, Bake
8	4450039	Cover, Bake Tray
9	4449809	Screw
10	8304422BU	Cover, Fan
11	9760769	Element Convection
12	W10116351	Blade, Fan
13	W10116349	Nut
14	W10116228	Fan, Convection
15	9755543	Jack, Meat Probe
16	9755542	Probe, Meat
17	9755547	Washer, Lock
18	9755546	Nut, Hidden

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KEBS277SBL04, KEBS277SWH04, KEBS277SSS04
 (Black) (White) (Stainless)



Illus. No.	Part No.	DESCRIPTION
1	9752759	Relay (2)
2	8304643	Duct, Air Outlet
3	4449809	Screw
4	8303972	Blower, 60mm
6	8285593	Connector, Cover
7	W10111628	Control, Transformer
8	4450118	Nut
9	4449868	Block, Terminal
10	3400080	Screw
11	8303722	Vent, Control Panel
12	8303518	Side, Control Top Right
	8304255	Left
13	8303520	Back, Control Panel
14	8304220	Cover, Top
15	112432	Nut (3)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: KEBS277SBL04, KEBS277SWH04, KEBS277SSS04
(Black) (White) (Stainless)

Illus.	Part
No.	No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White
261869 Cord Brown
72032 Black

PAINT, SPRAY

350930 White
261900 Citrine White
830864 Black

ADHESIVE

591014 Adhesive
Loctite (1/3 oz.)
482338 Sealer, Silastic
(3 oz.)

WIRING HARNESS PARTS

W10143473 Harness, Latch
W10155291 Connector, Flex
W10171563 Harness, Main
8304051 Harness,
Communication
8304439 Conduit, Double
4450800 Screw, Ground
7103P027-60 Nut
4452260 Spacer, Foam

Miscellaneous

4448950 Screw, Install (4)
98997 Clip

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>