


LifeFitness

Classic Cross-trainer CLSXH-0XXX-02
(international only)



Customer Support Services PARTS MANUAL rev 25 Nov 2009

Console Support and Deadshaft Covers	4
Handlebars and Bullhorns	5
Console and Related Components	6
Upper Frame Hardware	7
Rocker Arms and Pedal Levers	8
Crank Cover and Lower Caps	9
Lower Frame Shrouds and Hardware	10
Pedal Lever Components	11
PCB, Battery, Reed Switch, and Bracket	12
Bearing Insert Assembly	13
Crank Arm Pulley Assembly	14
Drive Module	15
Drive Module Hardware	16
Cables	17

Description	Part No.
OPERATION MANUAL (CD)	OKCD-02003-0001
SERVICE MANUAL	M051-00K62-A149
TOUCH UP PAINT: SPRAY CAN .5 OZ BOTTLE W/APPLICATOR .33 OZ PEN	0017-00008-0204 0017-00008-0205 0017-00008-0206
HARDWARE BAG	AK62-00152-0001
ACCESS PANEL ASSEMBLY CONSISTS OF: 120" COAX CABLE 120" POWER EXTENSION CABLE BRACKET F-TYPE PANEL CONNECTOR #8 PLASTIC GROMMET	AK62-00210-0000 AK32-00020-0002 AK32-00078-0001 OK62-01179-0001 0017-00021-2846 0017-00042-0754
PLUG IN OPTION 120/60	GK62-00002-0018
PLUG IN OPTION 240/50 UK	GK62-00002-0019
PLUG IN OPTION 240v AUS	GK62-00002-0020
PLUG IN OPTION 230/50 CONT	GK62-00002-0021


This treadmill has both Lifepulse sensors and telemetry for reading heart rate.


Console Support
AK62-00123-0000
Console Support Cap
0K62-01030-0001
(Stealth Gray)
Console Support
Shroud
0K62-01023-0001
Console Support
Grommet
0017-00042-0754


Right
Bullhorn Cover
0K62-01007-0001
Left
Bullhorn Cover
0K62-01008-0001

Right Inside
Deadshaft Cover
0K62-01010-0000
Left Inside
Deadshaft Cover
0K62-01011-0000
2-Front Inside
Deadshaft Cover
0K62-01009-0000


2-Outside Front
Deadshaft Cover
0K62-01012-0000
2-Outside Rear
Deadshaft Cover
0K62-01013-0000









Language	Part Nos.	
	Console	Overlay/Bezel/Switch
Eng + Met	AK62-00329-0001	AK62-00191-0001
Ger/Met	AK62-00329-0003	AK62-00191-0003
Spn/Met	AK62-00329-0004	AK62-00191-0004
Jap/Met	AK62-00329-0006	AK62-00191-0006
Frn/Met	AK62-00329-0007	AK62-00191-0007
Ital/Met	AK62-00329-0008	AK62-00191-0008
Dut/Met	AK62-00329-0009	AK62-00191-0009
Port/Met	AK62-00329-0010	AK62-00191-0010
Turk/Met	AK62-00329-0014	AK62-00191-0014





Items Not Shown:


Accessory Tray	0K62-01022-0001 (Stealth Gray)
Mounting Screws (2)	0017-00101-1846














Bearing Insert Assembly
AK62-00299-0000


Service Kit
GK62-00002-0044
kit contents:
Crankshaft (1)
Bearings (2)
Bearing Flanges (2 sets)
Nuts (4)
Washers (4)


Service Kit
GK62-00002-0045
kit contents:
Intermediate Shaft (1)
Bearings (2)
Bearing Flanges (2 sets)
Nuts (4)
Washers (4)











Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>