

Caution RCX400 Telescopes

Caution: When using AC power, use only the RCX400 AC Wall Adapter (optional accessory). The RCX400 telescopes require a 5-amp, 12-volt power supply. A power supply, rated less than 5-amps, may cause the telescope to fail in operation. Using a non-conforming power supply may void your Meade warranty.



MEADE[®]

6001 Oak Canyon, Irvine, California 92618
(800) 626-3233 ■ www.meade.com

Ver. 11-05 14-7584-00

Caution RCX400 Telescopes

Caution: When using AC power, use only the RCX400 AC Wall Adapter (optional accessory). The RCX400 telescopes require a 5-amp, 12-volt power supply. A power supply, rated less than 5-amps, may cause the telescope to fail in operation. Using a non-conforming power supply may void your Meade warranty.



MEADE[®]

6001 Oak Canyon, Irvine, California 92618
(800) 626-3233 ■ www.meade.com

Ver. 11-05 14-7584-00

Caution RCX400 Telescopes

Caution: When using AC power, use only the RCX400 AC Wall Adapter (optional accessory). The RCX400 telescopes require a 5-amp, 12-volt power supply. A power supply, rated less than 5-amps, may cause the telescope to fail in operation. Using a non-conforming power supply may void your Meade warranty.



MEADE[®]

6001 Oak Canyon, Irvine, California 92618
(800) 626-3233 ■ www.meade.com

Ver. 11-05 14-7584-00

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>