

SPEAKER STAND

AS-140

Instruction Manual



Thank you for purchasing the Onkyo speaker stand.
Please read this manual thoroughly before using it.
Keep this manual for future reference.

Cautions

1. Be sure to tighten the screws when you assemble the speaker stands and attach the speaker stands to the speakers.
2. The speaker stands are tall. Install the stands in a manner that will not allow the speakers to tip over. You may want to use commercially available chains to prevent the stands from falling in the event of an earthquake.
3. Do not place the stands on an unstable table, slope, or thick carpet. Otherwise, the stands may fall, causing injury.
4. Place the stands in a location in which they would not cause injury if they accidentally fell.
5. Do not place the stands in an area at risk of fire or damage, such as near a fireplace, heater, glass window, etc.

Supplied Accessories

- Screws (large) [2]
- Screws (small) [4]
- Pipe stands [2]
- Base panels [2]

**Note:**


Speaker cables are not included in this package.

Speaker Stand Assembly

Onkyo recommends that you wire the speaker cables through the pipe stands.


1 Insert one end of the speaker cable into the pipe stand from the pipe stand cover side.

Be sure to insert the cable from the pipe stand cover side. Pull the cable out from the other side so that about 3" (8 cm) of the cable will remain extended from the pipe stand cover, then attach that portion of the cable to the pipe stand cover with adhesive tape.



Note:


You can also wire the speaker cables without passing them through the pipe stands.



Pass the speaker cable through one of the two notches located on the bottom of the pipe stand cover.


Be careful not to pinch the speaker cable between the pipe stand cover and the speaker's rear panel.

2 Insert the cable into the hole of the base panel from the top, then pull the cable out and downward.




Do not pull the speaker cable too hard, as it may break.


3 Attach the pipe stand to the base panel in the correct orientation so that the screw holes on the pipe stand and the holes in the base panel will align. Tighten the screws firmly.



4 Guide the speaker cable along the arrow on the base panel bottom, and snap the cable into the notch on the perimeter of the base panel bottom.




5 While pressing in the lever on the speaker terminal on the rear panel of the speaker, connect the speaker cable to the terminal.



- 6** Remove the adhesive tape that you attached in Step 1.
(1) Insert the hook on the pipe stand into the key hole on the speaker's rear panel, then (2) press and slide the speaker downward.


(2) Press and slide the speaker downward.



Note:

Be careful not to pinch the speaker cable between the pipe stand cover and the speaker's rear panel.

- 7** Attach the pipe stand to the speaker securely using the included screw (large).



- 8** Completed.



Caution:

To remove the speaker from the stand, remove the screw, slide the speaker upward to release the hook, and reverse the steps for installing the speaker to the stand.

Specifications

Dimensions (W × H × D): 10-5/8" × 35-3/16" × 10-5/8"
(270 × 894 × 270 mm)

Assembly height
(with optional speaker SKF-750XF): 41-5/16" (1050 mm)

Weight: 6.0 lbs. (2.7 kg)

Specifications and appearance are subject to change without prior notice.

ONKYO CORPORATION

Sales & Product Planning Div. : 2-1, Nisshin-cho, Neyagawa-shi, OSAKA 572-8540, JAPAN
Tel: 072-831-8023 Fax: 072-831-8124

ONKYO U.S.A. CORPORATION

18 Park Way, Upper Saddle River, N.J. 07458, U.S.A.
Tel: 201-785-2600 Fax: 201-785-2650 <http://www.us.onkyo.com/>

ONKYO EUROPE ELECTRONICS GmbH

Liegnitzerstrasse 6, 82194 Groebenzell, GERMANY
Tel: +49-8142-4401-0 Fax: +49-8142-4401-555 <http://www.eu.onkyo.com/>

ONKYO EUROPE UK Office

Suite 1, Gregories Court, Gregories Road, Beaconsfield, Buckinghamshire, HP9 1HQ
UNITED KINGDOM Tel: +44-(0)1494-681515 Fax: +44(0)-1494-680452

ONKYO CHINA LIMITED

Unit 1&12, 9/F, Ever Gain Plaza Tower 1, 88, Container Port Road, Kwai Chung,
N.T., HONG KONG Tel: 852-2429-3118 Fax: 852-2428-9039
<http://www.ch.onkyo.com/>



I0807-1

SN 29344872

(C) Copyright 2008 ONKYO CORPORATION Japan. All rights reserved.

Download from www.Somanuals.com. All Manuals Search And Download.



* 2 9 3 4 4 8 7 2 *

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>