



Simple ON/OFF
switch operation



Wedge shape
design prevents
door from opening



Standard 9 volt
battery power

Warranty Information

Oreck Corporation warrants the Wedge Guard (Model S063) free from defects in material and workmanship under normal, non-commercial use and service. Oreck will remedy any such defects if they appear within one (1) year from date of purchase.


This warranty gives you specific legal rights, and you may have other rights, which vary, from state to state.

CAUTION

THE WEDGE GUARD ALARM IS EXTREMELY LOUD. FOR YOUR SAFETY, NEVER PLACE THE UNIT CLOSE TO YOUR EARS. TO TEST THE ALARM, DIRECT THE UNIT AWAY FROM YOU AT ARMS LENGTH AND ACTIVATE.

ORECK WEDGE GUARD

Door Break-In Protection and Alarm



Model S063

Instruction Manual

Register your product on the web at:

WWW.ORECK.COM

Congratulations on your purchase of the LOCK'N ALARM Wedge Guard model SO63 door stop and alarm. The Wedge Guard can be used to provide protection from forced or unauthorized entry. Its high output alarm can be a powerful deterrent to would-be burglars or robbers.

FEATURES

- Provides both contact and vibration alarm activation
- Wedge stop design prevents entry
- 9 volt battery power
- High output 120 dB alarm siren
- Simple ON/OFF switch operation

IMPORTANT SAFETY TIPS

- The alarm siren is very loud, never place the unit close to your ear, or allow children to play with this unit.
- Keep this manual for future reference.

OPERATION

1. Make sure the ON/OFF switch is in the "OFF" position. Remove the bottom plate of the unit and install a new 9 volt alkaline battery. Replace the bottom plate.
2. Place the unit on the floor close to the door without touching the door. (When the unit is turned on, do not place the

unit against the door with the metal contact plate depressed or the alarm will sound.)

3. When the unit is switched to the "ON" position, it will wait approximately 10 seconds then become active. The unit will now sound the alarm instantly when vibration is detected or if the metal contact plate is depressed.
4. When properly set, the unit will sound its alarm the moment the door is opened. In cases where there is an attempt to tamper with the unit from the outside, or push it out from under the door, the vibration sensor will sound the alarm immediately.
5. To disarm the unit, simply slide the switch to the "OFF" position.
6. When the alarm volume becomes low, or the unit does not produce a normal strong alarm sound, replace the battery.

NOTICE TO CONSUMERS: DISCLAIMER OF LIABILITY

When utilized correctly, the "Wedge Guard" can effectively increase your personal safety in your home or business. However, Oreck Corp. makes no warranties, representations or guarantees regarding: fitness for intended purpose; or its ability to act as a deterrent to robbery, burglary or other crime against your person or property. Oreck Corp. expressly denies responsibility for any losses, damages, or injuries which may result from use.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>