


Feature & Functions


1. With attached audio cable, it can be connected with any audio player such as Ipod and Ipod Video .
2. FM stereo transmitter provides real-time transmission of music. High separation and crystal clear sound.
3. Powered by car cigarette lighter socket. Plug and play.
4. The angle between plug and main unit can be adjusted at will.
5. 200 selectable frequencies with LCD indicator.
6. PLL circuit for steady frequency, never skip frequently.

Pi.PYLE


PiFMDK6 **CAR FM TRANSMITTER**




SKETCH-MAP




OPERATION



OPERATION



OPERATION



- ④ Adjust the frequency of car FM radio to the same frequency as transmitter for receiving signals.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>