




Owner's Manual



PPG450A Guitar Amplifier



- | | |
|---|---|
| <ul style="list-style-type: none"> 1) Power Switch: Switches amplifier on/off. 2) Power LED: Illuminates when power is switched on. 3) Input Jack: Connect your instrument to this jack. 4) Master: Adjusts overall volume. 5) Volume: This sets the volume gain level. 6) Bass: This control adjusts the low frequency level. 7) Mid: This control adjusts the middle frequency level. | <ul style="list-style-type: none"> 8) Treble: This control adjusts the high frequency level. 9) Bass Expander: Toggles an extra bass effect. 10) Output Jack: Lets you output the signal. 11) Phones: This is your headphone connection. Inserting the headphones disables the internal speaker (great for practicing). |
|---|---|



- 1) **Voltage Selector:** 110/220 Volt Selectable Switch.
- 2) **Power Cord:** Connect to power outlet.

Troubleshooting

Distorted Sound:

- ✓ Check if the amplifier is overdriven. If it is, you will have to turn the level down.
- ✓ Check signal source.

Signal sounds "discolored":

- ✓ Check and adjust the EQ settings.
- ✓ Ensure you are using quality cables.
- ✓ Check signal source.

No Sound:

- ✓ Check connections.
- ✓ Try a different cable.
- ✓ Check level on amplifier.
- ✓ Confirm amplifier is getting a signal.
- ✓ Make sure nothing is plugged into the Phones jack.

Intermittent Output:

- ✓ Check connections.
- ✓ Try a different cable.

Specifications

Model	Driver	RMS	Peak	Dimensions	Weight
PPG450	8" High Definition Speaker	30W	150W	W = 16" D = 9" H = 17"	22 lb.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>