



LCD SCREEN PROTECTOR

Protect Your Creative Vision

INSTRUCTIONS FOR APPLICATION

1. Use Cleaning Wipe to clean the camera's LCD screen, then use the microfiber cloth to dry it
 2. If there is still residue, repeat step one, then try to remove it with the cleaning tape
 3. Peel off the wrapper marked "A"
 4. Carefully align the cover over your LCD screen, then press it down gently, starting from one end and moving across
 5. If there is an air bubble, use the plastic pick to slide it out
 6. Peel off the wrapper marked "B"
- Clean the screen thoroughly before application
 - Do not attempt to remove and re-apply the protector
 - Try not to peel the edges of the protector



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>