

Philips
Complete cleaning system

CD and DVD

SAC2550



All you need to clean CD/DVD

Keep equipment at peak performance

Regular cleaning of your CDs, DVDs and players prolongs the life of your discs and protects your players. Regular cleaning of your discs and player's lens also ensures top performance from your equipment. Now get everything in one package.

Clean and protect your disc and device

- Microfiber cleaning pad

Maintain original sound and video quality

- Safe dry brush cleaning system
- Safe and easy radial cleaning action

Easy to use

- Voice instructions in 14 languages

PHILIPS
sense and simplicity

Complete cleaning system
CD and DVD

Specifications

Technical specifications

- **Contents:** Cleaning Fluid, 30ml

Storage Media

- **Supported formats:** 8cm discs, CD-Audio, CD-Rewritable, CD-ROM, DVD-ROM, DVD/R, Photo CD, Laser disc

Accessories

- **User Manual:** 3 languages

Packaging Data

- **Quantity:** 1
- **EAN/UPC/GTIN:** 6 09585 12772 2
- **Gross weight:** .36 kg
- **Tare weight:** .06 kg
- **Net weight:** .3 kg
- **Width:** 220 mm
- **Height:** 38 mm
- **Length:** 313 mm

Outer Carton

- **EAN/UPC/GTIN:** 2 06 09585 12772 6
- **Quantity:** 36
- **Gross weight:** 10.78 kg
- **Tare weight:** 1.08 kg
- **Net weight:** 9.7 kg
- **Width:** 340 mm
- **Height:** 510 mm
- **Length:** 405 mm

Inner Carton

- **EAN/UPC/GTIN:** 1 06 09585 12772 9
- **Quantity:** 4
- **Gross weight:** 2.42 kg
- **Tare weight:** .48 kg
- **Net weight:** 1.94 kg
- **Width:** 190 mm
- **Height:** 235 mm
- **Length:** 320 mm

SAC2550/27

Product highlights

Dry brush system

The dry brush cleaning system safely removes dust, debris and other contaminants from the CD/DVD players laser lens, leaving it clean and performing optimally.

Microfiber cleaning pad

This cleaning pad is made of special microfiber material. It works in concert with anti-static cleaning fluid to ensure that your discs are cleaned safely and remain free from dust and dirt.

Radial cleaning action

Clean and protect your discs with this safe and easy radial cleaning action that clears discs free of dirt, dust and debris.

Voice instructions

The voice instructions on this easy to use CD lens cleaner guide you through the cleaning process in one of the 14 languages provided.



Issue date 2008-09-02

Version: 3.0.6

12 NC: 8670 000 27726
UPC: 6 09585 12772 2

© 2008 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>