

Philips
CD lens cleaner

US2-PH62022



Clean and protect your CD player

Regular cleaning of your CD player's lens ensures optimum performance of your equipment. It is important to keep a CD player optical laser lens clean and dust free. This dry-brush system safely removes dust, debris and other contaminants.

Maintain original sound quality

- Safe dry brush cleaning system

Easy to use

- Voice instructions in 14 languages

PHILIPS
sense and simplicity

Specifications

Packaging dimensions

- **Packaging dimensions (W x H x D):**
6.3 x .3 x 9.7 inch
- **Nett weight:** .232 lb
- **Gross weight:** .27784 lb
- **Tare weight:** .04584 lb

Outer Carton

- **Gross weight:** 1.7 lb
- **Outer carton (L x W x H):** 6.8 x 3.5 x 10.3 inch
- **Nett weight:** 1.392 lb
- **Tare weight:** .308 lb

Product highlights

Dry brush system

The dry brush cleaning system safely removes dust, debris and other contaminants from the CD/DVD players laser lens, leaving it clean and performing optimally.

Voice instructions

The voice instructions on this easy to use CD lens cleaner guide you through the cleaning process in one of the 14 languages provided.



Issue date 2008-08-17

Version: 1.0.5

12 NC: 8670 000 45672
UPC: 0 26616 00077 7

© 2008 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips
Electronics N.V. or their respective owners.

www.philips.com

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>