















Dock and play your GoGear or iPod

Dock your GoGear or iPod player. Listen to your music from one simple control. Great sound and sophisicated design. Sit back and relax, enjoy your music all day, your way.

Enrich your sound experience

- Play MP3/WMA-CD, CD and CD-RW
- · Dynamic Bass Boost for deep and dramatic sound
- Digital Sound Control for optimized music style settings
- 2x15W RMS/30W Total power

Wake up to CD or radio tunes

- · Wake-Up and Sleep Timer
- · Stereo tuning with digital readout

Fits any space, any lifestyle

- · Compact design
- Dock and play your GoGear or iPod players



Specifications

Sound

- Output Power: 2x15watts rms
- Sound Enhancement: Dynamic Bass Boost, Digital Sound Control
- Volume Control: Volume Control up/down

Loudspeakers

 Main Speaker: 3.5" woofer, Bass Reflex Speaker System

Audio Playback

- Loader Type: Top
- Playback Media: CD, CD-R, CD-RW, MP3-CD, WMA-CD
- Disc Playback Modes: 20-Track Programmable, Repeat/one/all/program, Shuffle Play
- Cradle playback mode: Fast forward and backward, Next and Previous track, Play and Pause, Program play, Repeat, Shuffle play, Charging iPod

Tuner/Reception/Transmission

• Tuner Bands: FM Stereo, AM

Connectivity

- Headphone: 3.5 mm
- · Other connections: Cradle connection, FM fixed

pigtail antenna, AM Antenna

Convenience

- Alarms: CD Alarm, Radio Alarm, Sleep timer
- · Clock: On main display
- · Display Type: LCD
- Backlight color: White
- Eco Power Standby: I watt

Accessories

- · Included Accessories: AM antenna
- Remote control: 20-key with battery
- User Manual: English and Spanish
- Cradle: Cradle and adaptors for GoGear and iPod
- · Cables: Docking cable

Dimensions

- Set dimensions (W x H x D): 150 x 153 x 244 mm
- Main speaker dimensions (W x H x D): 150 x 153 x 204 mm
- Packaging dimensions (W x H x D): 535 x 200 x 302 mm
- Weight incl. Packaging: 5.5 kg

Power

• Power supply: I20V, 60Hz

Product highlights

1CM118D/37

Dynamic Bass Boost

Dynamic Bass Boost maximizes your music enjoyment by emphasizing the bass content of the music throughout the range of volume settings - from low to high — at the touch of a button! Bottom-end bass frequencies usually get lost when the volume is set at a low level. To counteract this, Dynamic Bass Boost can be switched on to boost bass levels, so you can enjoy consistent sound even when you turn down the volume.

Digital Sound Control

Digital Sound Control offers you a choice of pre-set Jazz, Rock, Pop and Classic controls you can use to optimise the frequency ranges for different musical styles. Each mode uses graphic equalizing technology to automatically adjust the sound balance and enhance the most important sound frequencies in your chosen music style. Ultimately, Digital Sound Control makes it easy for you get the most out of your music by precisely adjusting the sound balance to match the type of music you are playing.



Issue date 2008-04-12

© 2008 Koninklijke Philips Electronics N.V. All Rights reserved.

Version: 3.0.9

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

12 NC: 9073 100 13576 UPC: 6 09585 11740 2

www.philips.com

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com