

KVM102/104/104E USERS MANUAL

Introduction

Thank you for purchasing TOP-VIEW KVM switch. TOP-VIEW KVM switch can save your MONEY, TIME, SPACE, EQUIPMENT and POWER.

Controlling multiple PCs from One Keyboard, Mouse and VGA Monitor. TOP-VIEW KVM switch is loaded with features such as hot-key, front panel push button and auto scan control. It has complete keyboard and mouse emulation for simultaneous PCs boot-up process.

Features

- 2/4 port KVM switch is compact size design, easy portable.
- Support Microsoft Intellimouse, Logitech Net Mouse, etc...
- Support DOS, Win3.X, Win95/98/98SE/2000/ME, WinNT, Netware, Unix, Linux
- Hot Plug Add or Remove Connected PCs for Maintenance Without Powering Down the KVM switch or PCs.
- Very High Video Quality Up To 1920X1440, Bandwidth: 200MHz
- No Software Required easy PC selection via Push Buttons, Hot Keys
- Auto Scan Mode for monitoring PCs
- Keyboard status restored when switching PCs
- . LED Display for easy status monitoring
- Buzzer sound for switching port confirmation.

Package Contents

KVM-102	KVM-104	KVM-104E
Top-View 2 port KVM Switch (Plastic)	Top-View 4 port KVM Switch (Metal)	Top-View 4 port KVM Switch (Plastic)
User's manual	User's manual	User's manual

Technical Specifications

Functions	KVM-102	KVM-104	KVM-104E	
PC Port	2	4	4	
Console Port	1	1	1 ,	
MAX PC Connections	2	4	4	
LED	2	4	4	
PC Port Connector (All Female Type)	PS/2 Keyboard mini-Din 6 pin PS/2 Mouse Mini-Din 6 pin VGA HDDB 15pin			
Console port connector (All Female Type)	PS/2 Keyboard mini-Din 6 pin PS/2 Mouse Mini-Din 6 pin VGA HDDB 15pin	a series con s		
PC selection	Hot Key / Button			
On Screen Display Control	No			
Scan Intervals	8sec.			
Keyboard Emulation	PS2			
Mouse Emulation	PS2			
VGA Resolution	1920X1440			
Bandwidth	200MHz			
Daisy Chain and Levels	NO			
Housing	Plastic	Metal	Plastic	
Size	Mini Desktop	Desktop	Desktop	
Weight (g)	140g	720g	300g	
Dimension (mm)	110(L) X 74(W) X 29(H)	200(L) X98 (W) X 44(H)	(L)X(W)X(H)	

System Requirements Specifications

Functions	KVM-102	KVM-104/KVM-104E
Console side	One VGA Monitor One PS/2 Keyboard One PS/2 Mouse	One VGA Monitor One PS/2 Keyboard One PS/2 Mouse
Computer Side Two HDB 15 pin male to male VGA cables Two PS/2 cable male to male for Keyboard Two PS/2 cable male to male for Mouse		Four HDB 15 pin male to male VGA cables Four PS/2 cable male to male for Keyboard Four PS/2 cable male to male for

Product Details


KVM-102 <Diagram>





KVM-104 front and rear views :

<Diagram>



Hardware Installation

Before installation, please make sure all of peripherals and computers have been turned off.

- Connect the Keyboard, VGA, Mouse cables to the computer ports of KVM switch
- Connect the Keyboard, VGA monitor, and Mouse to console port of KVM switch
- 3. After Powering on computers and finishing the boot-up process, you can start to go KVM switch.

Please don't switch the PC port (i.e. Don't press the push button of KVM switch or run hot key) during the computers are under boot-up process.

Usage The push Button:

Pressing the button cyclically through all the ports.

KVM-102 (2 Ports)



Normally, there is one LED is always lit (i.e. the console is connected to this PC port) for one PC port and the other PC port's LED is off, when you power on KVM switch.

When you select one of two PCs and it is shut down, the selected port LED flashed.

KVM-104 /KVM-104E(4 Ports)

$$1 \longrightarrow 2 \longrightarrow 3 \longrightarrow 4 \longrightarrow$$

KVM-104 has separate push button on the panel

You can press the buttons in order like mentioned-above diagram or also press the destination button you want directly. When you select one of four PCs and it is powered on, the selected port LED is lit.

When you select one of four PCs and it is shut down or disconnected a PC, the selected port LED flashed.

Keyboard Hot Key Commands:

You can also conveniently command Top-View KVM to switch ports through simple key sequences. To send commands to Top-View KVM, The SCROLL LOCK key must be pressed twice within 2 seconds. You will hear a beep for confirmation.

Below are the different commands:

SCROLL SCROLL SCROLL SCROLL LOCK LOCK Previous Channel LOCK LOCK (or 2 or 3 or 4) select PC port directly SCROLL SCROLL SCROLL SCROLL Beeper On LOCK LOCK Next Channel LOCK LOCK (Factory default Off) SCROLL SCROLL LOCK LOCK Auto Scan

To get out of Auto Scan Mode, Press any key or SPACE bar.

Troubleshooting

Ensure that all cables are well seated. Label all of cables with the number for each respective computer to avoid confusion.

- KVM switch draws the power from keyboard port of computers. If the computer like laptop computer, notebook computer or the other computer cannot support enough power to KVM switch, please add a DC 5V~9V, 100mA~1A to the power jack. The power jack polarity is center positive
- Don't press any keys on the keyboard while the selected computer is booting up. Otherwise, it might cause the keyboard error or keyboard is not detected at PC side.
- 3. The computer boot up fine, but keyboard doesn't work
- Make sure the keyboard works when directly plugged into the computer.
- Try a different keyboard, but use only 101, 102 or 104-key keyboard.
- The Mouse is not detected during PC boot up.
- Make sure the mouse works when directly plugged into the computer.
- Make sure the mouse is a true PS/2 mouse. A combo mouse will work just as long as it is set for PS/2 mode with the correct adapter.
- Try a different mouse.
- Avoiding moving the mouse or pressing the mouse buttons when switching the port.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com