


Install two "AAA" batteries in the remote control prior to use.
NOTE: Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.

- 1. ON-OFF
Turns on/off the unit.
2. SLEEP
Selects sleep time.
3. NIGHT
Selects among night mode options (DRC ON/DRC OFF/DRC SOFT) which compresses the volume difference between normal voices and sounds such as explosions.
4. TEST TONE
The setting is also available in SETUP MENU.
5. SURROUND
Selects among digital surround sound effects.
6. DISTANCE
Adjusts the speakers' listening distance.
7. Navigation buttons
8. LEVEL
Speaker level setting.
9. SUBWOOFER
Selects among subwoofer sound levels.

Advanced Sound Control

Sound Enhancement Systems
This receiver is equipped with several built-in sound enhancement systems.
Dolby Digital
The Dolby Digital mode lets you enjoy full digital surround from software processed in the Dolby Digital format.

Dolby Pro Logic II
The Pro Logic II mode uses the built-in circuit to steer the Left, Center, Right and Surround left and right channel audio signals and uses all five speakers to play both stereo and Dolby Pro Logic program source, such as TV and VCR.




Care and Maintenance

Disconnect the audio system from the power source before performing any maintenance.
Cleaning the exterior
Disconnect the system from AC power before cleaning the exterior of the system with a soft dust cloth, or with a slightly damp leather chamois.

Important Battery Information
Remove the batteries to avoid leakage if you do not use your remote control for more than one month.
Discard leaky batteries immediately as leaking batteries may cause skin burns or other personal injuries.

Safety Precautions
Never open the cabinet under any circumstances. Any repairs or internal adjustments should be made only by a trained technician.
Never operate this product with the cabinet removed.

Need more help? Please visit online help at http://www.RCAav.com



10. MEM + / MEM -
Selects programmed stations in AM/FM mode.
11. TUNER +
Tap to increase the radio frequency in AM/FM mode. Press and hold to search next available station in ascending frequencies.

Advanced Sound Control

Fine Setting of the Components
You can select the surround mode by pressing SURROUND follow by ^ / v key to select among different options.
The default surround modes for different components are listed in the table below. The unit will keep the last selection in memory.

Table with columns: Source Input, If digital input (HDMI, optical or coaxial) is selected, and selected mode (Dolby Digital, Pro Logic II Movie, etc.).

HDMI and Digital Inputs
The Home Theater has two digital audio inputs and three HDMI AV inputs for BD, SAT-CABLE, DVD, TV, or GAME sources.
The default input is HDMI IN 1 for BD, HDMI IN 2 for SAT-CABLE, and HDMI IN 3 for DVD.

Table with columns: Source, Default input, and selected mode (HDMI IN 1, SAT-CABLE, etc.).

Technical Specifications


Amplifier Section:
RMS Output Power: Dolby Digital Mode with 10% Total Harmonic Distortion
Front, Rear and Center Channel: 167 Watts per channel (1kHz, 8Ω)
Subwoofer Channel: 167 Watts (100Hz, 8Ω)
Total RMS Output Power, Dolby Digital mode: 1000 W

AM Tuner Section:
Frequency Response: 2kHz +/-6dB, 1kHz ref.
Usable Sensitivity: 800uV/m @ 5/N 20dB
Signal to Noise: 38dB
IF Rejection: 35dB

FM Tuner Section:
Frequency Response: 12kHz +/-3dB, 1kHz ref.
Quieting: 24dBu
Signal to Noise: 60dB(stereo) / 65dB(mono)
IF Rejection: 50dB

Dimensions (H x W x D mm) :
Unit: 69 x 430 x 325
Front and Surround Speakers: 120 x 110 x 96
Center Speaker: 120 x 180 x 96
Subwoofer: 370 x 180 x 330

Need more help? Please visit online help at http://www.RCAav.com



12. EQ buttons
Selects among preset equalizer mode (POP, FLAT, JAZZ, CLASSIC, ROCK, BASS and TREBLE). Press the corresponding button to select the desired sound mode. This function is only available in Stereo mode.
13. Number buttons
Directly accesses a preset station in AM/FM mode.
14. MEMORY
Stores stations as preset stations in AM/FM mode.
15. MONO/ST
Selects between Stereo and Mono sound in FM mode.
16. SETUP
Enters Setup mode. Use </> to select among setup options.

Advanced Sound Control

Analog Inputs
The Home Theater has four analog audio inputs: TV, VCR, GAME and LINE-IN.
Note:
To play Dolby Prologic II Movie sound when listening to an analog audio source, press the SURROUND buttons until "Dolby PL II MOVIE" appears on the Display.

Fine Setting of the Speakers
All the basic settings have already been preset for the speakers included in the box.
Also, to make the surround sound more effective and suit the acoustic conditions in your listening room, you may need to delay the signal coming from some of the speakers.

Testing and Adjusting Speaker Loudness
The TEST TONE button on the remote control allows you to adjust each speaker volume level individually to suit your particular listening environment.

Adjusting Speaker Loudness Without Using Test Tones
1. To adjust individual speaker volume level, press LEVEL on the remote control.
2. Continue to press LEVEL on the remote control to select the speaker to be adjusted, then press the ^ / v buttons to adjust the level.
3. Press Exit button to exit this mode.

Limited Warranty


AVC MULTIMEDIA ("AVC") makes the following limited warranty. This limited warranty extend to the original consumer purchaser and is limited to non-commercial use of the product.
One Year Parts & Labor Warranty
AVC products purchased in the United States or Canada are warranted to be free from defects in materials or workmanship for a period of one year from the date of their original retail purchase.

Packaging and Shipping Instruction
When you send the product to the AVC service facility you must use the original carton box and packing material or an equivalent as designated by AVC.

LIMITED WARRANTY

Your Responsibility
(1) You must retain the original sale receipt to provide proof of purchase.
(2) These warranties are effective only if the product is purchased and operated in the United States or Canada.
(3) Warranties extend only to defects in material or workmanship, and do not extend to any product or parts which have been lost or discarded, or damage to product or parts caused by misuse, accident, improper operation or maintenance, or use in violation of instructions provided with the product, or to product which has been altered or modified without authorization of AVC, or to products or parts thereof which have had the serial number removed or changed.

Out of Warranty
In the event your product requires repair after the limited warranty period has expired, please contact our Customer Support Center at 1-877-252-6873, 1-800-506-5746 or www.RCAav.com
Hours: Monday-Thursdays: 9am-7pm, Friday: 9am-5pm, Saturday: 9am-NOON Eastern time.
Important: You are responsible for any transportation, shipping or insurance relative to the return of product to our Product Returns Center.



Selecting Source
When one of the SOURCE buttons on the front panel or on the remote control is pressed, the corresponding input will be activated.
The unit acts as a switching device between all the sources that are plugged into it.
Example 1:
If you have connected a DVD player to HDMI IN 3 (DVD) jack on the unit, press DVD on the front panel or on the remote control to receive the sounds transmitted by the DVD.
Example 2:
If a VCR is connected to the VCR jack of the unit, press VCR on the front panel or on the remote control, the sound from the VCR will be selected.

Limited Warranty


AVC MULTIMEDIA ("AVC") makes the following limited warranty. This limited warranty extend to the original consumer purchaser and is limited to non-commercial use of the product.
One Year Parts & Labor Warranty
AVC products purchased in the United States or Canada are warranted to be free from defects in materials or workmanship for a period of one year from the date of their original retail purchase.

Packaging and Shipping Instruction
When you send the product to the AVC service facility you must use the original carton box and packing material or an equivalent as designated by AVC.

LIMITED WARRANTY

Your Responsibility
(1) You must retain the original sale receipt to provide proof of purchase.
(2) These warranties are effective only if the product is purchased and operated in the United States or Canada.
(3) Warranties extend only to defects in material or workmanship, and do not extend to any product or parts which have been lost or discarded, or damage to product or parts caused by misuse, accident, improper operation or maintenance, or use in violation of instructions provided with the product, or to product which has been altered or modified without authorization of AVC, or to products or parts thereof which have had the serial number removed or changed.

Out of Warranty
In the event your product requires repair after the limited warranty period has expired, please contact our Customer Support Center at 1-877-252-6873, 1-800-506-5746 or www.RCAav.com
Hours: Monday-Thursdays: 9am-7pm, Friday: 9am-5pm, Saturday: 9am-NOON Eastern time.
Important: You are responsible for any transportation, shipping or insurance relative to the return of product to our Product Returns Center.



Operating Your Unit
3. Repeat step 2 to tune to another radio station.
4. To prematurely stop the searching function, press TUNER+ or TUNER- button on the remote control.
5. Adjust the volume by pressing VOL +/VOL -.

Limited Warranty


AVC MULTIMEDIA ("AVC") makes the following limited warranty. This limited warranty extend to the original consumer purchaser and is limited to non-commercial use of the product.
One Year Parts & Labor Warranty
AVC products purchased in the United States or Canada are warranted to be free from defects in materials or workmanship for a period of one year from the date of their original retail purchase.

Packaging and Shipping Instruction
When you send the product to the AVC service facility you must use the original carton box and packing material or an equivalent as designated by AVC.

LIMITED WARRANTY

Your Responsibility
(1) You must retain the original sale receipt to provide proof of purchase.
(2) These warranties are effective only if the product is purchased and operated in the United States or Canada.
(3) Warranties extend only to defects in material or workmanship, and do not extend to any product or parts which have been lost or discarded, or damage to product or parts caused by misuse, accident, improper operation or maintenance, or use in violation of instructions provided with the product, or to product which has been altered or modified without authorization of AVC, or to products or parts thereof which have had the serial number removed or changed.

Out of Warranty
In the event your product requires repair after the limited warranty period has expired, please contact our Customer Support Center at 1-877-252-6873, 1-800-506-5746 or www.RCAav.com
Hours: Monday-Thursdays: 9am-7pm, Friday: 9am-5pm, Saturday: 9am-NOON Eastern time.
Important: You are responsible for any transportation, shipping or insurance relative to the return of product to our Product Returns Center.



Operating Your Unit
Manual Tuning
Press TUNER+ or TUNER- button on the remote control or << or >> button on the front panel of the unit repeatedly to tune a desired frequency.
Automatic Preset Programming
The unit can preset 30 FM stations and 30 AM stations. Before tuning, make sure to turn down the volume.

Limited Warranty

AVC MULTIMEDIA ("AVC") makes the following limited warranty. This limited warranty extend to the original consumer purchaser and is limited to non-commercial use of the product.
One Year Parts & Labor Warranty
AVC products purchased in the United States or Canada are warranted to be free from defects in materials or workmanship for a period of one year from the date of their original retail purchase.

Packaging and Shipping Instruction
When you send the product to the AVC service facility you must use the original carton box and packing material or an equivalent as designated by AVC.

LIMITED WARRANTY

Your Responsibility
(1) You must retain the original sale receipt to provide proof of purchase.
(2) These warranties are effective only if the product is purchased and operated in the United States or Canada.
(3) Warranties extend only to defects in material or workmanship, and do not extend to any product or parts which have been lost or discarded, or damage to product or parts caused by misuse, accident, improper operation or maintenance, or use in violation of instructions provided with the product, or to product which has been altered or modified without authorization of AVC, or to products or parts thereof which have had the serial number removed or changed.

Out of Warranty
In the event your product requires repair after the limited warranty period has expired, please contact our Customer Support Center at 1-877-252-6873, 1-800-506-5746 or www.RCAav.com
Hours: Monday-Thursdays: 9am-7pm, Friday: 9am-5pm, Saturday: 9am-NOON Eastern time.
Important: You are responsible for any transportation, shipping or insurance relative to the return of product to our Product Returns Center.

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>