

**Odyssey Wireless Guitar  
For PS2™  
RTPS2696o**

Website: [www.reactgamer.com](http://www.reactgamer.com)

**Table of Contents**

Precautions ..... 2  
 Features ..... 4  
 Directions ..... 5  
 Diagrams ..... 7  
 Registration ..... 9  
 Warranty ..... 10

**Precautions**

Some medical studies have suggested that long periods of repetitive motion, coupled with poor habits may be linked to certain types of physical discomfort or injuries. It is important to take frequent breaks during game play, and if you feel aching, numbness, or tingling in your arms, wrists, or hands, consult a qualified health professional.

If you have heart, respiratory, or other physical impairments that limit your physical activity, Do not use the Wireless Guitar. if you have any doubts, consult with a physician before using the Wireless Guitar.

- The Wireless Guitar must be used with care to avoid injury. React will not be liable from injuries resulting from improper use of the Wireless Guitar.
- The Wireless Guitar is for indoor use only and should be kept away from open flames or other heat sources.
- Do not leave the Wireless Guitar in a dusty or humid place.
- Small children should be monitored at all times when using the Wireless Guitar.
- Do not modify or disassemble the Wireless Guitar under any circumstances.

- When not in use, make sure the Wireless Guitar is removed from playing area and properly stored.
- Excessive use of the whammy bar can cause it to break.
- Never get the Wireless Guitar wet.
- Never stand on the Wireless Guitar.
- Use a dry cloth to clean the Wireless Guitar, never use chemicals to clean the product.
- Do not mix old and new batteries.
- Always make sure the batteries are inserted correctly.(+ / -)
- Remove batteries from guitar when it is stored or not used for long periods of time.
- Remove the Whammy Bar Safety Tab Before Playing.

## Features

- Advanced 2.4GHz wireless technology.
- Auto scan mode and manual scan mode.
- Power switch.
- Uses 4 "AA" batteries(not included).
- Working distance up-to 50 feet.
- Looks and feels like a real guitar for the ultimate rock 'n' roll experience.
- Five multicolored Fret Buttons and a responsive and durable Strum Bar let you play along to the notes on the screen.
- Working Whammy Bar adds an extra touch of realism.
- Adjustable strap makes playing comfortable.

4

## Directions

Start Button: Start/Pause  
Select Button: Select/Activates star power  
Green Fret Button: Activates the green note/confirm  
Red Fret Button: Activates the red note/cancel  
Yellow Fret Button: Activates the yellow note  
Blue Fret Button: Activates the blue note  
Orange Fret Button: Activates the orange note  
Strum Bar: Press the Strum Bar UP or DOWN to activate the Fret Button(s) you have pressed. To navigate in menus press the Strum Bar UP or DOWN.  
Whammy Bar: Press in towards the guitar on long notes to alter the sound of the song.  
TILT Sensor: Tilt Wireless Guitar up to activate star power.  
Power Switch: Turn off after you finish playing.

### **How to use the Wireless Guitar**

#### **1-Auto scan mode:**

1. Remove the Whammy Bar Safety Tab by slowly pulling the small square tab off of the Whammy Bar.
2. Place 4 AA batteries into the Wireless Guitar.
3. Plug the wireless receiver into the desired gameport.
4. Power on your console and the Wireless Guitar via the power switch.
5. The Wireless Guitar will search for a signal and the receiver's yellow LED will illuminate when the connection has been made.

5

**Note:** If Wireless Guitar does not find a connection, please repeat steps 1 - 4 again to ensure that your operation is right. If this does not work, please check your video game console for other issues.

#### **2-Manual scan mode:**

If you are unable to get a connection with the wireless Guitar, you may make the connection using the manual scan mode.

1. Press the CONNECT button on the receiver;
2. Immediately press CONNECT button on the Guitar backside.

The yellow LED will illuminate to indicate that the connection is a success. This may take as long as 20 seconds.


**Note:** If the Wireless Guitar does not find a connection, please repeat 1 & 2 all over again to ensure that your operation is right. If this does not work, please check your video game console for other issues.

**Two Player Note:** If using two wireless Guitars please connect the 1<sup>st</sup> Wireless Guitar and 1<sup>st</sup> wireless receiver before connecting the 2<sup>nd</sup> Guitar and receiver. Do not connect both units at the same time, they must be connected and scanned separately.

6


## Diagrams

### **Front View**



7

## Back View



8

## Registration

For the following Warranty to be valid, you must register this product at [www.reactgamer.com](http://www.reactgamer.com)

You will need to provide:

Full Name

Phone Number

Model Number

Date of Purchase

Validation Number (Found on Receipt)

If you are unable to access the Internet, please mail the same information to:

Warranty Info

c/o React Gaming

100 N 6th St 300C

Minneapolis, MN 55403

React takes your privacy seriously. You have our explicit guarantee we will not sell or distribute your personal information to any third party.

9

## Warranty

React™ warrants to the original purchaser of this product that it will be free from defects in materials and/or workmanship for a period of 7 (seven) years from the date of purchase from an authorized retailer.

This warranty is limited to the internal works of this product and the external housing. It will not apply if your React product has been damaged by abuse, misuse, negligence, accident, modification, tampering, or by any other causes unrelated to defective materials and/or workmanship. Compensation or restoration of data loss and software are not covered. React is not liable for loss of revenue or loss of use of equipment.

Repair, replacement, or commensurate value as provided under this warranty is React's exclusive prerogative. Any applicable implied warranties, including warranties of merchantability and fitness for a particular purpose, are hereby limited to 7 years from the date of purchase and are subject to the conditions set forth in this limited warranty. In no event shall React or its affiliates be liable for consequential or incidental damages resulting from the breach of any express or implied warranties.

Some states do not allow limitations on how long an implied warranty lasts or exclusion or limitation of incidental/consequential damages, so the above limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other legal rights, which vary from state to state. To obtain service while under warranty contact us at [customerservice@reactgamer.com](mailto:customerservice@reactgamer.com) and request a Return Merchandise Authorization. Upon receipt of the returned product, verification of defective materials and/or workmanship will be performed in a timely manner.

### Equipment Protection Guarantee

React's equipment protection guarantee delivers on the promise that our products will work with your video game console. This guarantee warrants the connection inputs and outputs. Should the use of our products damage these inputs and outputs during proper use and as a result of our products failing, we will replace your video game console with a like system free of charge. This equipment protection guarantee does not include the video game console's optical drives, hard drives, operating system, cabinet, or power supply. This protection guarantee is void if not purchased from an authorized retailer.

10

© 2007 React Gaming

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>