

REMINGTON®

All That!™

**Use and  
Care Guide**



- 1 Even heating**  
Black ceramic
- 2 Less frizz**  
Ionic conditioning
- 3 Less hair breakage**  
Teflon® coating

S-1009at

## IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

### READ ALL INSTRUCTIONS BEFORE USING.

### KEEP AWAY FROM WATER.

### DANGER

*As with most electrical appliances, electrical parts are electrically live even when switch is off.*

**To reduce the risk of death by electric shock:**

- Always unplug this appliance from the electrical outlet immediately after using.
- Do not use while bathing or in the shower.
- Do not place or store this appliance where it can fall or be pulled into a tub or sink.
- Do not place or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug it immediately.
- Unplug this appliance before cleaning it.

2

### WARNING

**To reduce the risk of burns, fire, electric shock or injury to persons:**

- An appliance should never be left unattended when it is plugged in.
- Close supervision is necessary when this appliance is used by, on, or near children or invalids.
- Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by Remington.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or if it has been dropped into water.
- Keep the cord away from the heated surfaces. **Do not wrap the cord around the appliance.**
- Never use while sleeping.
- Never drop or insert any object into any of the appliance's openings.
- Do not use outdoors or operate where aerosol (spray) products are being used, or where oxygen is being administered.
- Do not use an extension cord.
- This appliance is hot when in use. Do not let eyes or bare skin touch heated surfaces.

- Do not place the heated unit directly on any surface while it is hot or plugged in.
- The plug on this appliance has one blade wider than the other, it is a polarized plug. As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit contact a qualified electrician.

Do not attempt to defeat this safety feature.

- Always store this appliance and cord in a moisture-free area. Do not store it in temperatures exceeding 140°F (60°C).
- This appliance is for household use only.
- Do not plug or unplug this appliance when your hands are wet.



**KEEP AWAY FROM CHILDREN**

**SAVE THESE INSTRUCTIONS**

3

## Product Features

Thank you for purchasing the Remington® All That!™ triple protection straightener. This unique flat iron combines optimum styling features with the convenience of compact storage. Please carefully read the instructions contained in this booklet, and keep it in a safe place for future reference.

### Key Features


#### Triple Protection:

- 1 Even heating**  
Black ceramic
- 2 Less frizz**  
Ionic conditioning
- 3 Less hair breakage**  
Teflon® coating

#### Automatic shutoff:

This styler is equipped with automatic shutoff. This safety feature turns the unit off after 60 minutes, in case you accidentally leave it on after styling your hair.

- (A) Teflon® plus black ceramic coating
- (B) Ionic conditioning
- (C) ON/OFF switch
- (D) Swivel cord
- (E) Closing lock
- (F) Swivel hinge buttons
- (G) Hair guides
- (H) Ready Light



## Usage Tips

### Straightening Your Hair

1. Hair should be dry and free of tangles before using the straightening iron.
2. Plug the straightener into an electrical outlet. Slide the ON/OFF switch to the ON position. The ready light will glow.
3. Divide hair into manageable sections and clip the upper layers on top of your head and out of the way. Work with underneath layers first.
4. Take a small section of hair and pull hair down and away from your scalp, and hold it taut.
5. Starting at the roots, clamp hair firmly between the plates and run the styler down the entire hair strand, from root to tip, in one smooth stroke. Do not hold it in one area for a long period of time.
6. Repeat with all sections of your hair, working with the underneath layers first, then the top and sides.
7. When you are finished styling, slide the ON/OFF button to turn the unit off, unplug it, and allow it to cool before storing.


## How to Use

### Folding for Storage

1. Allow the iron to cool before folding.
2. Flip the closing lock and press until it clicks to lock the iron closed.
3. Press the two swivel hinge buttons with one hand while rotating the handle to fold the styler in half.
5. Insert the folded styler hinge end first into the storage pouch, leaving the cord outside the pouch. Press the pouch opening closed.
5. Loop the cord loosely and secure to the outside of the pouch with the attached Velcro strap.

### Closing Lock

This professional flat iron has a closing lock to make the unit easier to store. To lock the iron, simply squeeze the plates together and flip the switch down to the locked position. To unlock, flip the switch up in to the unlocked position. **NOTE: Do not heat the unit in the locked position.**



## ***Maintenance***


### **Cleaning**

Make sure the unit is unplugged and cool. Use a damp cloth to clean the plates and the outside of the power handle. No other maintenance of the unit is required.

### **Storage**

Unplug the unit whenever it is not in use.

Never wrap the cord around the appliance, since this will cause the cord to wear prematurely and break, thus voiding warranty. Handle the cord carefully and avoid jerking, twisting, or straining it, especially at plug connections.



## Performance Guarantee

### Full Two-Year Warranty

Spectrum Brands, Inc. warrants this product against any defects that are due to faulty material or workmanship for a two-year period from the original date of consumer purchase. This warranty does not include damage to the product resulting from accident or misuse.

If the product should become defective within the warranty period, we will repair it or elect to replace it free of charge. Return your product and sales receipt with your name, address and day time phone number to: Spectrum Brands, Inc., Attention: Consumer Services, 601 Rayovac Drive, Madison, WI 53711. For more information call 800-736-4648.

**KEEP ORIGINAL SALES RECEIPT AS PROOF OF PURCHASE FOR WARRANTY PURPOSES.**

This warranty does not cover products damaged by the following:

- Accident, misuse, abuse or alteration of the product
- Servicing by unauthorized persons
- Use with unauthorized accessories
- Connecting it to incorrect current and voltage
- Wrapping cord around appliance causing premature wear & breakage
- Any other conditions beyond our control

No responsibility, obligation, or liability is assumed for the installation or maintenance of this product.

**SPETRUM BRANDS, INC. SHALL NOT BE RESPONSIBLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT. ALL IMPLIED WARRANTIES INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO TWO YEARS FROM DATE OF ORIGINAL PURCHASE.**

This warranty gives you specific legal rights and you may also have other rights which vary from state to state or province to province. Some states do not allow the exclusion or limitation of incidental, special or consequential damages.

### Spectrum Brands, Inc. Money-back Offer

If within 30 days after you have purchased your Remington® branded product, you are not satisfied and would like a refund, return it with the sales slip indicating purchase price and date of purchase to the retailer from whom it was purchased. Spectrum Brands, Inc. will reimburse all retailers who accept the product within 30 days from the date of purchase. If you have any questions concerning the money-back guarantee, please call 800-736-4648.

120/240 VAC 50/60 Hz

**Questions or comments:**  
Call 800-736-4648 in U.S.

Or visit [www.remington-products.com](http://www.remington-products.com)

REMINGTON and ALL THAT! are trademarks of ROVCAL, INC.

TEFLON® is a registered trademark of E.I. du Pont de Nemours and Company and is used under license by ROVCAL, INC.

©2005 ROVCAL, INC.  
8/05 Job# 29084

**T22-20462**

Dist. by: Spectrum Brands, Inc.,  
Madison, WI 53711

MADE IN CHINA



**REMINGTON®**

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>