



ATMOS™ NOISE CANCELLING HEADPHONES

RF-NCHP01



QUICK SETUP GUIDE

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution:

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

IC Statement

This Class "B" digital apparatus complies with Canadian ICES-003. Cet appareil numérique de la classe "B" est conforme à la norme

WARNING

- Excessive sound pressure from earphones and headphones can cause hearing loss.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

One-year limited warranty

Visit www.rocketfishproducts.com for details.

We're here for you

www.rocketfishproducts.com

For customer service, call:

800-620-2790 (U.S./Canada markets)

© 2011 BBY Solutions, Inc., All Rights Reserved.

Distributed by Best Buy Purchasing, LLC 7601 Penn Avenue South, Richfield, MN USA 55423-3645


ROCKETFISH is a trademark of BBY Solutions, Inc. All other products and brand names are trademarks of their respective owners.

Thank you for purchasing the Rocketfish Atmos Noise Cancelling Headphones. Your headphones have a built-in active noise cancellation (ANC) feature that diminishes ambient noise (such as surrounding conversations, an aircraft engine or construction noise).

Package contents

- Rocketfish™ Atmos™ headphones
- Carrying case
- Detachable audio cable
- USB charging cable
- Airline headphone jack adapter
- ¼ in. headphone jack adapter
- *User Guide*
- *Quick Setup Guide*

Features



Charging the battery

Before using your headphones for the first time, you should charge the battery for two hours. When the battery is fully charged, it provides up to 20 hours of ANC.

- Plug the charging cable into the power adapter jack on your headphones, and the other end into a laptop USB port or other USB charger.

Note: When the battery is charging, the charging LED lights red. When the battery is fully charged the charging LED lights green.

Note: Your Rocketfish Atmos headphones also function as a passive headset when used without the ANC function turned on, or if the battery is expired. Audio will always be available.

Connecting your headphones to an audio device

- Plug one end of the audio cable into the audio cable jack on the headphones, then plug the other end of the audio cable into the audio jack on your device, using the ¼ in. headphone jack adapter if necessary.

Using the ANC (automatic noise cancelling) feature

- The Mute button function can only be activated when the ANC switch is set to “on”.
- Slide the ANC off/on switch to the on position. When the ANC feature is turned on, your headphones block ambient noise. The audio sent though the audio cable is not affected. When the ANC feature is turned on the power LED lights blue.

Note: You can use your headphones to block ambient noise even when your headphones are not connected to an audio device.

Muting your headphones

You can temporarily turn off your headphones so you can communicate with others without removing them.

- Press and hold the Mute button. The ANC feature and audio will turn off.
- Release the Mute button to turn the ANC feature and audio back on.

Connecting your headphones to an airplane’s AV system

- Plug the audio cable into the twin-plug adapter, then plug the twin-plug adapter into the audio jacks on the airplane (usually on the armrests).

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>