

# ECO-i™ Submittal Data



Building Life.

## APR-RZP 1350BAB Kit Heat Recovery: Distribution Kits, Indoor Units

Job Name: \_\_\_\_\_  
 Location: \_\_\_\_\_  
 Engineer: \_\_\_\_\_  
 Submitted to: \_\_\_\_\_  
 Submitted by: \_\_\_\_\_  
 Reference: \_\_\_\_\_


Approval: \_\_\_\_\_  
 Date: \_\_\_\_\_  
 Construction: \_\_\_\_\_  
 Unit #: \_\_\_\_\_  
 Drawing #: \_\_\_\_\_



### APR-RZP1350BAB

Use: For indoor unit (Capacity after distribution joint is greater than 232.000 BTU/h and no more than 460.700 BTU/h.)

Example: (B below indicates inner diameter. Ⓟ below indicates outer diameter.)



Size	Part A	Part B	Part C	Part D	Part E	Part F	Part G	Part H	Part I
Inch	1 5/8"	1 3/8"	1 1/8"	1 1/8"	7/8"	3/4"	5/8"	1/2"	3/8"



## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>