

warranty

Soundolier wireless products purchased in the United States from authorized dealers are guaranteed against defects in material and workmanship for a period of 90 days. The warranty period begins the day the product is purchased by the end user. This warranty is limited to the original retail purchaser of the product. Product found to be defective during that period will be repaired or replaced by Soundolier at no charge. This warranty is void if it is determined that unauthorized parties have attempted repairs or alterations of any nature. Warranty does not extend to cosmetics or finish. Before presuming a defect is present in the product, be certain that all related equipment and wiring is functioning properly. Soundolier disclaims any liability for other incurred damages resulting from product defects. Any expenses incurred in the removal and reinstallation of product is not covered by this warranty. Soundolier's total liability will not exceed the purchase price of the product. Shipping charges incurred to send the product in for warranty service shall be paid by the customer. Return shipping from service center to the customer will be paid by Soundolier. Proof of purchase is required when requesting service, so please retain your sales receipt. Also, a Return Authorization number (RA) is required before shipping product back to Soundolier, call 800-837-7879. Retain original packaging for all warranty returns.

contact information

Thank you for purchasing the Soundolier wireless audio receiver. For technical assistance, or if you have any questions/comments, please contact us by phone at 1-800-837-7879 or by e-mail: soundolier@mitekcorp.com.

specifications

dimensions

- height: 5¾" (14.6cm)
- width: 2¼" (5.7cm)
- depth: 1⅜" (3.4cm)
- weight: 2.2oz (62g)

audio

- selectable left, right, or mix output

wireless

- 2.4GHz stereo receiver
- 4 selectable signal channels
- 20Hz-20kHz full range audio
- 300ft (100m) maximum reception range




SOUNDOLIER®

Integrated Wireless Technologies

Soundolier, 1 Mitek Plaza, Winslow, IL 61089


© 2007 Soundolier. Soundolier, duo, maestro & maestroSWR are trademarks of Mitek Corp. All rights reserved. Due to continual product development, all specifications are subject to change without notice.



maestroSWR™

setup guide


wireless mode



wireless transmitter may be sold separately

*walls and other obstructions may limit range

step 1: unplug speaker/sub & insert maestroSWR





icon indicates orientation



the maestroSWR can only be used on Soundolier Wireless Ready audio devices

step 2: mount with provided screw




do not over tighten screw



plug back into power after mounting process is complete

interface guide


feature 1: wireless transmission channel select



* if wireless signal interferes with other devices, change both the receiver and the transmitter to different corresponding channels


* possible devices of interference include cordless phones, satellite radio, & wireless computer networks

feature 2: wireless signal detection



green light = wireless signal
red light = no signal

feature 3: right/mix/left



left/right - use for surround applications

mix - receive 2 channel signal (ideal for subwoofers)

Soundolier Wireless Ready audio devices auto switch to wireless mode when maestroSWR is connected

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>