

VXI LIMITED WARRANTY

1. VXI warrants that your TP150 headset will be free from defects in material and workmanship for two years from the date of purchase. If, during the first two years from the date of purchase, your TP150 headset fails to work due to a defect in material or workmanship, VXI will repair or replace the product, at its election, free of charge. Without proof of purchase, the warranty period begins on the date of manufacture.

2. The foregoing limited warranty does not cover equipment failure attributable to accident, improper operation, misuse, abuse, or any cause other than defects in the materials or workmanship of VXI's products.

3. VXI's obligations under this warranty are limited to repair or replacement (at our option) of any defective part returned to VXI, freight prepaid. Returned products require a Return Authorization that may be obtained by calling customer service at 1-800-742-8588.

4. THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not permit the exclusion of implied warranties and the foregoing exclusions may not apply to you.

5. In no event shall VXI be responsible for any other damages whatsoever, including direct, indirect, special, incidental, consequential, or other damages for breach of this or any other warranty, express or implied.

6. Products returned to VXI for in-warranty, freight prepaid and with proper Return Authorization, will be return shipped to the customer at VXI's expense.

For customer service, please call:

VXI Corporation

1-800-742-8588 or 603-742-2888

Technical support is available on our web site at: www.vxiparrott.com

© 2004 VXI Corporation

PN 201711A

vxiparrott TP150

Computer Headset for Voice Applications



VXI CORPORATION

One Front Street, Rollinsford, NH 03869

603-742-2888 Toll free 1-800-742-8588

e-mail: info@vxiparrott.com website: www.vxiparrott.com



COMPONENTS

1. Adjustable headband
2. T-Bar
3. Receiver / ear cushion
4. Flexible microphone boom
5. Noise canceling microphone
6. 3.5mm sound card connectors
7. Microphone boom swivels for left or right side wear




OPERATION

1. CONNECTING YOUR HEADSET TO YOUR PC.

Insert the plugs into your computer as shown in Figure 1. The pink plug is inserted in the microphone port  and the green plug is inserted in the line output  speaker port.


2. CHOOSE A SIDE FOR THE MICROPHONE.

Determine which side of your head you would prefer to locate the microphone. Swivel the microphone boom as shown.




3. MICROPHONE ADJUSTMENT.

Position the microphone so it is located one finger-width from the corner of your mouth just below your bottom lip. The microphone has the word TALK embossed on it or a painted dot printed on it (look under the cushion). Be sure that this mark is facing your mouth.



For customer assistance, please call VXI at 1-800-742-8588 or visit our website at www.vxi-parrott.com.

Figure 1



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>